

EXPLODED VIEWS AND PARTS LIST

PACKING SECTION (Page 21)

(1) PACKING SECTION PARTS LIST

*:Non spare part

Mark	No.	Description	MVH-S512BS/XINUC	MVH-S522BS/XINUC
*	1	Unit Box	QHG4406	QHG4549
	2	Contain Box	QHL4406	QHL4549
	6-1	Quick Start Guide	QRD3629	QRD3780
	6-2	Web IM	QRI3108	See Contents of Web IM (2)

Quick Start Guide

Part No.	Language
QRD3780	English, French, Spanish(Espanol)

(2) CONTENTS OF WEB IM

Part No.	Language
*OPM_MVHS522BSUC_3L_A	English, French, Spanish(Espanol)

All operation manuals are supplied in PDF files by the WEB. No printed papers are available.

EXTERIOR SECTION (Page 23)

EXTERIOR SECTION PARTS LIST

Mark	No.	Description	MVH-S512BS/XINUC	MVH-S522BS/XINUC
	1	Detach Grille Assy	QXA5623	QXA6178
	7	Grille Unit	QXA5533	QXA6318
	17	Plate	QNM3229	QNM3283
	18	Knob Unit	QXA5429	QXA6324
	29	Tuner Amp Unit	QWM4933	QWM5310

1234

ELECTRICAL PARTS LIST (Page 40)

Tuner Amp Unit

Circuit Symbol and No.	Part Name	MVH-S512BS/XINUC	MVH-S522BS/XINUC
IC711	RAM IC	M12L128168A-5TG2N	W9812G6KH-5
IC741	Flash ROM Unit	QVQ1053	QVQ1102
Q251	Bipolar Transistor	LSAR523UB	2SAR502UB
D851	Zener Diode	Not used	RSB6R8SM
D852	Zener Diode	Not used	RSB6R8SM
P1276	Poly Switch	FSMD075-24R	Not used
R113		XRS1/16SS682J	XRS1/16SS822J
R251		XRS1/16SS471J	XRS1/16SS472J
R252		XRS1/16SS103J	XRS1/16SS473J
R519		XRS1/16SS271J	XRS1/16SS151J
R538		XRS1/16SS472J	XRS1/16SS223J
R539		Not used	XRS1/16SS473J
R591		XRS1/16SS361J	XRS1/16SS221J
R610		Not used	XRS1/16SS222J
R702		XRS1/16SS472J	XRS1/16SS152J

Keyboard Unit

Circuit Symbol and No.	Part Name	MVH-S512BS/XINUC	MVH-S522BS/XINUC
IC1851	IR RC REC Module	PNJ4833M	SIR8440B5
D1951	LED	NSSM124F-A21107	NSSM124F-A27847
D1952	LED	NSSM124F-A21107	NSSM124F-A27847
D1953	LED	NSSM124F-A21107	NSSM124F-A27847
D1954	LED	NSSM124F-A21107	NSSM124F-A27847
D1955	LED	NSSM124F-A21107	NSSM124F-A27847

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.

1234

ELECTRICAL PARTS LIST (Page 40)

Tuner Amp Unit

Circuit Symbol and No.	Part Name	MVH-S512BS/XINUC	MVH-S522BS/XINUC
IC711	RAM IC	M12L128168A-5TG2N	W9812G6KH-5
IC741	Flash ROM Unit	QVQ1053	QVQ1102
Q251	Bipolar Transistor	LSAR523UB	2SAR502UB
D851	Zener Diode	Not used	RSB6R8SM
D852	Zener Diode	Not used	RSB6R8SM
P1276	Poly Switch	FSMD075-24R	Not used
R113		XRS1/16SS682J	XRS1/16SS822J
R251		XRS1/16SS471J	XRS1/16SS472J
R252		XRS1/16SS103J	XRS1/16SS473J
R519		XRS1/16SS271J	XRS1/16SS151J
R538		XRS1/16SS472J	XRS1/16SS223J
R539		Not used	XRS1/16SS473J
R591		XRS1/16SS361J	XRS1/16SS221J
R610		Not used	XRS1/16SS222J
R702		XRS1/16SS472J	XRS1/16SS152J

Keyboard Unit

Circuit Symbol and No.	Part Name	MVH-S512BS/XINUC	MVH-S522BS/XINUC
IC1851	IR RC REC Module	PNJ4833M	SIR8440B5
D1951	LED	NSSM124F-A21107	NSSM124F-A27847
D1952	LED	NSSM124F-A21107	NSSM124F-A27847
D1953	LED	NSSM124F-A21107	NSSM124F-A27847
D1954	LED	NSSM124F-A21107	NSSM124F-A27847
D1955	LED	NSSM124F-A21107	NSSM124F-A27847

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.