


EXPLODED VIEW (UNIT)



PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation	Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
KDC-7024/Y,722,8023						242	2D		E30-6212-05	CORD WITH PINPLUG (2PR+1AUX)	M2
201	1C	*	A02-2731-03	PLASTIC CABINET ASSY		242	2D	*	E30-6213-05	CORD WITH PINPLUG (2PR)	K6E4E5
204	3C	*	A22-2988-03	SUB PANEL ASSY		243	2D	*	E30-6216-05	CORD WITH DIN CONNECTOR (CH)	K6M2
206	1D	*	A52-0831-02	TOP PLATE		243	2D		E30-6217-05	CORD WITH DIN CONNECTOR (CH+DIS)	E4E5
PA1	1D	*	A64-2981-01	PANEL ASSY	K6	245	3D	*	E41-0351-05	FLAT CABLE CONNECTOR	
PA1	1D	*	A64-2983-01	PANEL ASSY	M2	△ DC1	1C		E30-4942-05	DC CORD (ISO)	E4E5
PA1	1D	*	A64-2987-01	PANEL ASSY	E4E5	△ DC2	1C		E30-6062-05	DC CORD	M2
PA2	1C		A64-2995-02	PANEL ASSY	K6M2	△ DC2	1C		E30-6106-05	DC CORD	K6
PA2	1C		A64-3003-02	PANEL ASSY	E4E5	FC1	2D	*	E39-0565-05	FLAT CABLE	
PME1	2C	*	A10-5029-11	CHASSIS ASSY		249	2C	*	F07-1121-03	COVER	
RM1	1C		A70-2026-05	REMOTE CONTROLLER ASSY (RC-420)	M2	250	3C	*	F07-1122-03	COVER	
RM2	1C		A70-2040-05	REMOTE CONTROLLER ASSY (RC-505)	K6	251	3C	*	F07-1123-03	COVER	
-			B46-0100-50	WARRANTY CARD	K6M2E4	252	2C	*	F09-1794-04	SHEET	
-			B46-0606-04	ID CARD	K6	253	3C	*	F09-1798-04	SHEET	
-			B46-0612-14	ID CARD	M2E4E5	256	2D	*	F09-1842-04	SHEET	
-		*	B46-0653-03	USER CARD	K6	262	2D		F29-0049-05	INSULATING COVER	
-			B64-2460-00	INSTRUCTION MANUAL (ENGLISH)	K6	△ F1	2D		F52-0006-05	FUSE (MINI BLADE TYPE)	
-		*	B64-2461-10	INSTRUCTION MANUAL (FRE.SPA.)	K6	264	2C	*	G01-3162-04	EXTENSION SPRING	
-		*	B64-2463-00	INSTRUCTION MANUAL (ENG.T-CHI.)	M2	265	3C	*	G01-3188-04	EXTENSION SPRING	
-			B64-2468-00	INSTRUCTION MANUAL (ENGLISH)	E4E5	266	3C	*	G01-3189-04	TORSION COIL SPRING	
-			B64-2469-00	INSTRUCTI.MANUAL (FRE.GER.DUT.)	E4	267	3D	*	G01-3199-04	TORSION COIL SPRING	
-			B64-2470-00	INSTRUCTI.MANUAL (ITA.SPA.POR.)	E4	270	2C	*	G11-3539-04	CUSHION (VOL)	
-		*	B64-2471-00	INSTRUCTION MANUAL (RUS.POL.)	E5	272	3D	*	G11-3559-04	CUSHION	
-		*	B64-2472-00	INSTRUCTI.MANUAL (CZE.HUN.CRO.)	E5	-		*	H10-4854-12	POLYSTYRENE FOAMED FIXTURE	
-		*	B64-2473-00	INSTRUCTION MANUAL (SWE.FIN.)	E5	-		*	H21-1151-04	PROTECTION SHEET	
208	3C		B03-5015-03	DRESSING PLATE ASSY		-			H25-0329-04	PROTECTION BAG (280X450X0.03)	K6M2
210	1C	*	B07-3078-01	ESCUTCHEON		-			H25-0337-04	PROTECTION BAG (180X300X0.03)	E4E5
212	3C	*	B07-3080-02	ESCUTCHEON		-			H25-1111-04	PROTECTION BAG (280X450X0.03)	
213	1D	*	B10-4388-01	FRONT GLASS	K6	-		*	H54-2721-03	ITEM CARTON CASE	K6
213	1D	*	B10-4390-01	FRONT GLASS	M2	-		*	H54-2723-03	ITEM CARTON CASE	M2
213	1D	*	B10-4394-01	FRONT GLASS	E4E5	-		*	H54-2727-03	ITEM CARTON CASE	E4
214	1C	*	B12-1221-04	INDICATOR		-		*	H54-2728-03	ITEM CARTON CASE	E5
215	1C	*	B12-1222-03	INDICATOR ASSY		277	3C	*	J19-5220-03	HOLDER	
216	1C	*	B19-2201-04	LIGHTING BOARD		278	1C		J21-9823-03	MOUNTING HARDWARE ASSY	
219	1C	*	B43-1505-04	KENWOOD BADGE		279	3D	*	J21-9951-03	MOUNTING HARDWARE ASSY	
220	1C		D10-4674-04	LEVER		280	3D	*	J21-9954-02	MOUNTING HARDWARE ASSY	
222	2C	*	D10-4716-04	ARM ASSY		281	2C	*	J21-9956-12	MOUNTING HARDWARE ASSY	
223	3C	*	D10-4718-04	ARM ASSY		283	3D	*	J21-9997-03	MOUNTING HARDWARE ASSY	
224	3D	*	D10-4721-11	SLIDER ASSY		284	2C	*	J21-9999-02	MOUNTING HARDWARE ASSY	
225	2C	*	D10-4749-03	LEVER		285	3C	*	J31-1055-04	COLLAR	
226	3D	*	D10-4750-04	LEVER		286	3C	*	J31-1056-04	COLLAR	
227	3D	*	D12-0637-03	CAM		287	3D	*	J74-1444-04	RIGID PRINTED WIRING BOARD	
228	2D	*	D13-2270-04	GEAR		FPC1	2D	*	J84-0153-05	FLEXIBLE PRINTED WIRING BOARD	
229	3D	*	D13-2272-04	GEAR		FPC2	3D	*	J84-0156-04	FLEXIBLE PRINTED WIRING BOARD	
230	3C	*	D13-2273-14	GEAR		292	1C	*	K24-4004-04	KNOB (PLAY)	
232	3C	*	D13-2274-14	GEAR		293	1C	*	K24-4005-04	KNOB (EJECT)	
233	3D	*	D13-2276-04	GEAR		294	1C	*	K24-4006-04	KNOB (ATT)	
234	3D	*	D13-2277-04	GEAR		295	2C	*	K24-4007-04	KNOB (OPEN)	
235	3D	*	D13-2278-04	GEAR		296	1C	*	K25-1527-03	KNOB (SRC,Q)	
236	3D	*	D13-2289-03	RACK (GEAR)		297	1C	*	K25-1529-03	KNOB (AM/FM)	
237	3C	*	D13-2290-04	GEAR ASSY		298	1C	*	K25-1530-04	KNOB (SCRL)	
238	3C	*	D16-0617-05	BELT		299	2C	*	K25-1528-03	KNOB (1-6)	
239	3C	*	D23-0958-04	RETAINER		300	1C	*	K29-7031-03	KNOB ASSY (VOL)	

E : Europe K : North America K6 : KDC-722 E4 : KDC-7024
M : Other Areas W : Without Europe M2 : KDC-8023 E5 : KDC-7024Y

△ Indicates safety critical components.

PARTS LIST

* New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

KDC-7024/Y,722,8023

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
302	1C		N99-1723-05	SCREW SET	K6M2
303	1C	*	N99-1734-05	SCREW SET	
A	3D		N09-4448-05	MACHINE SCREW	
B	3C	*	N09-6073-05	STEPPED SCREW	
C	3D	*	N09-6087-05	MACHINE SCREW	
D	3C	*	N09-6088-05	STEPPED SCREW	
E	3D	*	N09-6089-05	MACHINE SCREW	
F	2C	*	N09-6093-05	TAPTITE SCREW	
G	2C	*	N09-6094-05	MACHINE SCREW	
H	2C	*	N09-6095-05	MACHINE SCREW	
J	2C	*	N09-6096-05	MACHINE SCREW	E4E5
K	3C	*	N09-6097-05	MACHINE SCREW	
M	2C	*	N09-6105-05	STEPPED SCREW	
N	2C	*	N19-2175-04	FLAT WASHER	
P	3D	*	N19-2176-04	FLAT WASHER	
Q	2C		N24-3015-60	E TYPE RETAINING RING	
R	3C		N38-2025-46	PAN HEAD MACHIN SCREW	
S	3D	*	N38-2650-45	PAN HEAD MACHIN SCREW	
T	2D		N67-3005-46	PAN HEAD SEMS SCREW	
U	2D		N83-3005-46	PAN HEAD TAPTITE SCREW	
V	2D		N83-3008-46	PAN HEAD TAPTITE SCREW	
W	3C		N86-2004-45	BINDING HEAD TAPTITE SCREW	
RLED			RK73GB2A102J	CHIP R 1.0K J 1/10W	
RPH			RK73GB2A104J	CHIP R 100K J 1/10W	
SW1			S68-0871-05	PUSH SWITCH (PANEL MECHA)	
SW2-3			S68-0863-05	PUSH SWITCH (PANEL MECHA)	
SW4			S68-0864-05	PUSH SWITCH (PANEL MECHA)	
306	1C		T90-0552-05	ANTENNA ADAPTOR	
PH			T95-0212-05	OPTO ISOLATOR (PANEL MECHA)	
PM1	3D	*	T42-1076-14	MOTOR ASSY	
PM2	3D	*	T42-1077-04	MOTOR ASSY	
DME1	2D		X92-4450-01	CD MECHANISM ASSY	
SUB-CIRCUIT UNIT (X16-2080-10)					
J1			E59-0833-15	RECTANGULAR PLUG	
CP1			R90-1019-05	MULTI-COMP 100 X2	
IC1		*	BR24C01AFV-W	MEMORY IC	
SUB-CIRCUIT UNIT (X16-2140-10)					
310	2C	*	B11-1405-04	REFLECTION SHEET	
311	2C	*	B11-1406-04	OPTICAL DIFFUSER	
312	2C	*	B19-2204-02	LIGHTING BOARD	
D11			B30-1564-05	LED (1608, BLUE)	
D16-19			B30-1571-05	LED (WHITE)	
ED1		*	B38-1119-05	LIQUID CRYSTAL	
C1			CC73GCH1H681J	CHIP C 680PF J	
C2-5			CK73GB1C104K	CHIP C 0.10UF K	
C2-5			CK73GB1H104K	CHIP C 0.10UF K	
C6			CK73GB1H103K	CHIP C 0.010UF K	
C7			CK73FB1A225K	CHIP C 2.2UF K	
C11			CC73GCH1H681J	CHIP C 680PF J	
C12-14			CK73GB1C104K	CHIP C 0.10UF K	

Ref. No.	Add	New	Parts No.	Description	Destination			
C12-14 C15 C16 C16 C21	2C	*	CK73GB1H104K CK73GB1H103K CK73GB1C104K CK73GB1H104K CK73GB1H103K	CHIP C 0.10UF K CHIP C 0.010UF K CHIP C 0.10UF K CHIP C 0.10UF K CHIP C 0.010UF K				
C26-29			CK73GB1H103K	CHIP C 0.010UF K				
313 CN1 CN2			E29-1930-04 E40-9364-05 E41-0166-05	CONDUCTIVE RUBBER FLAT CABLE CONNECTOR FLAT CABLE CONNECTOR				
CP1 CP4,5 R1 R2-5 R6			R90-1016-05 R90-0724-05 RK73GB2A433J RK73GB2A222J RK73GB2A392J	MULTI-COMP 470 X4 MULTI-COMP 1K X4 CHIP R 43K J 1/10W CHIP R 2.2K J 1/10W CHIP R 3.9K J 1/10W				
R7,8 R9 R10 R11 R12			RK73GB2A331J RK73GB2A101J RK73GB2A102J RK73GB2A4R7J RK73GB2A751J	CHIP R 330 J 1/10W CHIP R 100 J 1/10W CHIP R 1.0K J 1/10W CHIP R 4.7 J 1/10W CHIP R 750 J 1/10W				
R13 R14 R15 R23 R24			RK73GB2A102J RK73GB2A4R7J RK73GB2A104J RK73GB2A102J RK73GB2A473J	CHIP R 1.0K J 1/10W CHIP R 4.7 J 1/10W CHIP R 100K J 1/10W CHIP R 1.0K J 1/10W CHIP R 47K J 1/10W				
R26 R31 R32-35 R36 R41,42			RK73GB2A102J RK73GB2A433J RK73GB2A222J RK73GB2A4R7J RK73GB2A122J	CHIP R 1.0K J 1/10W CHIP R 43K J 1/10W CHIP R 2.2K J 1/10W CHIP R 4.7 J 1/10W CHIP R 1.2K J 1/10W				
R51,52 R53,54 R67,68			RK73FB2B271J RK73GB2A472J RK73GB2A331J	CHIP R 270 J 1/8W CHIP R 4.7K J 1/10W CHIP R 330 J 1/10W				
D1 D2-5 D21,22 D26 IC1			MA3062-M DA204U FTZ6.8E MA3091-M LC75808W	ZENER DIODE DIODE ZENER DIODE ZENER DIODE MOS-IC				
IC2 IC3 Q1 Q1 Q5			LC75878W RS-171 DTA114EUA UN5111 2SC4081	MOS-IC ANALOGUE IC DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR				
Q6 Q6 Q11			DTA114EUA UN5111 2SC4081	DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR				
SWITCH UNIT (X16-2190-10)								
D1-11 D12 D13 D14 D15						B30-1605-05 B30-1566-05 B30-1605-05 B30-1566-05 B30-1605-05	LED (2COLOR PG/RED) LED (1608, RED) LED (2COLOR PG/RED) LED (1608, RED) LED (2COLOR PG/RED)	
D16 D17						B30-1566-05 B30-1605-05	LED (1608, RED) LED (2COLOR PG/RED)	

E : Europe K : North America K6 : KDC-722 E4 : KDC-7024
M : Other Areas W : Without Europe M2 : KDC-8023 E5 : KDC-7024Y

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

SWITCH UNIT (X16-2190-10)

Ref. No.	Added	New	Parts No.	Description	Destination	Ref. No.	Added	New	Parts No.	Description	Destination
D18,19 D21			B30-1566-05 B30-1566-05	LED (1608, RED) LED (1608, RED)		C101 C102 C103 C104 C105			CK73GB1H103K C90-2866-05 CK73GB1H103K CE04NW1C100M CE04NW0J101M	CHIP C 0.010UF K ELECTRO 220UF 16WV CHIP C 0.010UF K ELECTRO 10UF 16WV ELECTRO 100UF 6.3WV	
CN1		*	E41-0419-05	FLAT CABLE CONNECTOR		C106 C107 C108 C109 C126			CK73GB1A474K CK73FB1C105K CE04CW1A221M CE04CW1A101M CE04NW1V3R3M	CHIP C 0.47UF K CHIP C 1.0UF K ELECTRO 220UF 10WV ELECTRO 100UF 10WV ELECTRO 3.3UF 35WV	
R1,2 R3-5 R6-9 R10 R15			RK73FB2B511J RK73FB2B331J RK73FB2B511J RK73FB2B471J RK73GB2A241J	CHIP R 510 J 1/8W CHIP R 330 J 1/8W CHIP R 510 J 1/8W CHIP R 470 J 1/8W CHIP R 240 J 1/10W		C127 C127 C128 C129 C130			CK73GB1C683K CK73GB1H683K CE04NW1H0R1M CK73GB1H103K CK73GB1E223K	CHIP C 0.068UF K CHIP C 0.068UF K ELECTRO 0.1UF 50WV CHIP C 0.010UF K CHIP C 0.022UF K	E4E5
R16-19			RK73GB2A102J	CHIP R 1.0K J 1/10W		C130 C131 C132 C134,135 C200			CK73GB1H223K CE04NW1H010M CK73GB1H102K CK73GB1H103K CE04NW0J470M	CHIP C 0.022UF K ELECTRO 1.0UF 50WV CHIP C 1000PF K CHIP C 0.010UF K ELECTRO 47UF 6.3WV	
S1 S2,3 S4 S5-8 S9		*	S70-0901-05 S70-0864-05 S70-0856-05 S70-0864-05 S70-0856-05	TACT SWITCH TACT SWITCH TACT SWITCH TACT SWITCH TACT SWITCH		C201 C202 C203 C204 C206			CK73GB1H103K CC73GCH1H220J CC73GCH1H270J CK73GB0J105K CK73GB0J105K	CHIP C 0.010UF K CHIP C 22PF J CHIP C 27PF J CHIP C 1.0UF K CHIP C 1.0UF K	
S10-13 S14 S15-18 S19 S20			S70-0864-05 S70-0856-05 S70-0864-05 S70-0856-05 S70-0864-05	TACT SWITCH TACT SWITCH TACT SWITCH TACT SWITCH TACT SWITCH		C207,208 C211 C213 C250 C251			CK73GB1H103K CK73GB1H102K CK73GB1H103K CE04NW1C470M CK73GB1H103K	CHIP C 0.010UF K CHIP C 1000PF K CHIP C 0.010UF K ELECTRO 47UF 16WV CHIP C 0.010UF K	
S21		*	T99-0445-05	ROTARY ENCODER		C252 C252 C253,254 C253,254 C255			CE04MW1H2R2M CE04NW1H2R2M CK73GB1C104K CK73GB1H104K CE04NW1H010M	ELECTRO 2.2UF 50WV ELECTRO 2.2UF 50WV CHIP C 0.10UF K CHIP C 0.10UF K ELECTRO 1.0UF 50WV	E4E5 K6M2
D20 D20 Q1 Q1 Q2,3			DAP202U MA142WA DTA114YUA UN5114 2SC4081	DIODE DIODE DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR		C256 C257 C258 C259-262 C401			CE04NW1C330M C90-2935-05 CE04NW1H010M CK73GB1A224K CK73GB1H103K	ELECTRO 33UF 16WV ELECTRO 1.0UF 50WV ELECTRO 1.0UF 50WV CHIP C 0.22UF K CHIP C 0.010UF K	
SUB-CIRCUIT UNIT (X16-2210-10)						C403 C405 C407 C408 C409			CK73GB1H103K CK73GB1H103K CK73GB1H103K CK73FB1A225K CK73GB1H103K	CHIP C 0.010UF K CHIP C 0.010UF K CHIP C 0.010UF K CHIP C 2.2UF K CHIP C 0.010UF K	E4E5 E4E5
315	2C	*	E58-0968-05	RECTANGULAR RECEPTACLE		C410 C411 C412,413			CE04NW1C100M CC73GCH1H331J CC73GCH1H100D	ELECTRO 10UF 16WV CHIP C 330PF J CHIP C 10PF D	E4E5 E4E5 E4E5
FPC3	2C	*	J84-0154-05	FLEXIBLE PRINTED WIRING BOARD		CN1 CN2 CN3 CN4 CN4		*	E41-0224-05 E40-3237-05 E41-0384-05 E40-9527-05 E41-0213-05	PIN ASSY PIN ASSY PIN ASSY FLAT CABLE CONNECTOR FLAT CABLE CONNECTOR	
ELECTRIC UNIT (X25-966x-xx)						CN5			E40-9368-05	FLAT CABLE CONNECTOR	
C1,2 C3,4 C5 C5,6 C7,8			CE04NW1HR47M CK73FB1C474K CE04NW0J470M CE04NW0J470M CK73FB1C474K	ELECTRO 0.47UF 50WV CHIP C 0.47UF K ELECTRO 47UF 6.3WV ELECTRO 47UF 6.3WV CHIP C 0.47UF K	K6E4E5 M2 M2						
C9 C10 C11 C11 C12			CK73GB1A474K CC73GCH1H151J CK73GB1E223K CK73GB1H223K CK73GB1H103K	CHIP C 0.47UF K CHIP C 150PF J CHIP C 0.022UF K CHIP C 0.022UF K CHIP C 0.010UF K							
C13-16 C21-24 C21,22 C31-34 C41,42			CK73FB1H104K CK73FB1C105K CK73FB1C105K C90-5296-05 CE04NW1V3R3M	CHIP C 0.10UF K CHIP C 1.0UF K CHIP C 1.0UF K NP-ELECT 0.22UF 50WV ELECTRO 3.3UF 35WV	M2E4E5 K6						
C49,50 C67 C69 C70,71 C71			CE04NW1V3R3M CK73FB1H104K CK73FB1H104K CK73GB1H103K CK73GB1H103K	ELECTRO 3.3UF 35WV CHIP C 0.10UF K CHIP C 0.10UF K CHIP C 0.010UF K CHIP C 0.010UF K	M2 K6E4E5						
C100 C100			C90-5235-05 C90-5484-05	ELECTRO 2200UF 16WV ELECTRO 3900UF 16WV	K6M2 E4E5						

E : Europe K : North America K6 : KDC-722 E4 : KDC-7024
M : Other Areas W : Without Europe M2 : KDC-8023 E5 : KDC-7024Y

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X25-966x-xx)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
CN6		*	E41-0399-05	FLAT CABLE CONNECTOR	
CN7			E41-0009-05	PIN ASSY	
J1			E58-0863-15	RECTANGULAR RECEPTACLE	
W2		*	E30-6218-05	CORD WITH PLUG	
L1			L33-1170-05	CHOKE COIL ASSY	
L4			L40-4795-91	SMALL FIXED INDUCTOR (4.7UH,J)	
L5			L92-0075-05	CHIP FERRITE	
L6			L40-4795-91	SMALL FIXED INDUCTOR (4.7UH,J)	
L7			L33-1039-05	LINE FILTER COIL	
L11-13			L40-4795-34	SMALL FIXED INDUCTOR	E4E5
L11-13			L40-4795-68	SMALL FIXED INDUCTOR (4.7UH)	E4E5
L11,12			L40-4795-34	SMALL FIXED INDUCTOR	K6M2
L11,12			L40-4795-68	SMALL FIXED INDUCTOR (4.7UH)	K6M2
X1			L78-0821-05	RESONATOR	
X2			L77-2738-05	CRYSTAL RESONATOR	
X3			L77-2002-05	CRYSTAL RESONATOR	E4E5
U	2D		N83-3005-46	PAN HEAD TAPTITE SCREW	
X	2D		N80-3008-46	PAN HEAD TAPTITE SCREW	
Y	2D		N83-3010-46	PAN HEAD TAPTITE SCREW	
Z	2D		N84-2004-46	PAN HEAD TAPTITE SCREW	
R1,2			RK73EB2E100J	CHIP R 10 J 1/4W	
R3			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	K6E4E5
R3,4			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	M2
R5,6			RK73EB2E100J	CHIP R 10 J 1/4W	M2
R7			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R8			RK73GB2A103J	CHIP R 10K J 1/10W	
R9,10			RK73FB2B333J	CHIP R 33K J 1/8W	
R21,22			RK73GB2A361J	CHIP R 360 J 1/10W	
R23,24			RK73GB2A223J	CHIP R 22K J 1/10W	
R31,32			RK73EB2E181J	CHIP R 180 J 1/4W	
R45,46			RK73GB2A361J	CHIP R 360 J 1/10W	
R47,48			RK73GB2A223J	CHIP R 22K J 1/10W	
R55,56			RK73EB2E181J	CHIP R 180 J 1/4W	
R60,61			RK73GB2A102J	CHIP R 1.0K J 1/10W	M2
R61			RK73GB2A102J	CHIP R 1.0K J 1/10W	K6E4E5
R100			RK73FB2B223J	CHIP R 22K J 1/8W	
R101			RK73GB2A101J	CHIP R 100 J 1/10W	
R102			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R103			RK73GB2A223J	CHIP R 22K J 1/10W	
R104			RK73FB2B221J	CHIP R 220 J 1/8W	
R105			RK73GB2A153J	CHIP R 15K J 1/10W	
R106			R92-3047-05	CHIP R 24K D 1/10W	
R107			R92-3032-05	CHIP R 4.3K D 1/10W	
R108			RK73FB2B152J	CHIP R 1.5K J 1/8W	
R112			RK73FB2B152J	CHIP R 1.5K J 1/8W	
R124			RK73FB2B472J	CHIP R 4.7K J 1/8W	
R125,126			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	K6M2
R127			RK73GB2A223J	CHIP R 22K J 1/10W	K6M2
R128,129			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	
R130			RK73GB2A223J	CHIP R 22K J 1/10W	
R131			RK73FB2B472J	CHIP R 4.7K J 1/8W	
R132			RK73FB2B561J	CHIP R 560 J 1/8W	M2E4E5
R133			RK73GB2A104J	CHIP R 100K J 1/10W	
R134			RK73GB2A473J	CHIP R 47K J 1/10W	E4E5

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
R135			RK73GB2A104J	CHIP R 100K J 1/10W	K6M2
R135			RK73GB2A223J	CHIP R 22K J 1/10W	E4E5
R138			RK73GB2A223J	CHIP R 22K J 1/10W	
R139			RK73FB2B103J	CHIP R 10K J 1/8W	
R140			RK73GB2A103J	CHIP R 10K J 1/10W	
R141			RK73GB2A822J	CHIP R 8.2K J 1/10W	
R142			RK73GB2A183J	CHIP R 18K J 1/10W	
R143			RD14DB2H332J	SMALL-RD 3.3K J 1/2W	
R144			RK73EB2E473J	CHIP R 47K J 1/4W	
R145			RK73GB2A104J	CHIP R 100K J 1/10W	
R146			RK73EB2E102J	CHIP R 1.0K J 1/4W	M2E4E5
R147,148			RK73EB2E103J	CHIP R 10K J 1/4W	E4E5
R148			RK73EB2E103J	CHIP R 10K J 1/4W	K6M2
R200			RK73GB2A153J	CHIP R 15K J 1/10W	
R201			RK73GB2A103J	CHIP R 10K J 1/10W	
R202			RK73GB2A104J	CHIP R 100K J 1/10W	
R203,204			RK73GB2A103J	CHIP R 10K J 1/10W	E4E5
R204,205			RK73GB2A103J	CHIP R 10K J 1/10W	K6
R205,206			RK73GB2A103J	CHIP R 10K J 1/10W	M2
R207			RK73GB2A104J	CHIP R 100K J 1/10W	
R208,209			RK73GB2A103J	CHIP R 10K J 1/10W	
R212,213			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R214,215			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R216,217			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R218			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R219,220			RK73GB2A101J	CHIP R 100 J 1/10W	
R221-224			RK73GB2A102J	CHIP R 1.0K J 1/10W	E4E5
R225-227			RK73GB2A101J	CHIP R 100 J 1/10W	
R228			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R229			RK73GB2A104J	CHIP R 100K J 1/10W	
R230			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R231			RK73GB2A104J	CHIP R 100K J 1/10W	
R232			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R233			RK73GB2A104J	CHIP R 100K J 1/10W	
R234-240			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R241			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R245,246			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R247			RK73GB2A104J	CHIP R 100K J 1/10W	
R248			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R250-253			RK73GB2A104J	CHIP R 100K J 1/10W	K6M2
R250,251			RK73GB2A104J	CHIP R 100K J 1/10W	E4E5
R254,255			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R256			RK73GB2A104J	CHIP R 100K J 1/10W	E4E5
R256,257			RK73GB2A104J	CHIP R 100K J 1/10W	K6M2
R259			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R260,261			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R262			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R264			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R265			RK73GB2A104J	CHIP R 100K J 1/10W	
R266			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R267			RK73GB2A473J	CHIP R 47K J 1/10W	
R268			RK73GB2A333J	CHIP R 33K J 1/10W	
R269			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R270,271			RK73GB2A471J	CHIP R 470 J 1/10W	
R272			RK73GB2A472J	CHIP R 4.7K J 1/10W	

E : Europe K : North America
M : Other Areas W : Without EuropeK6 : KDC-722 E4 : KDC-7024
M2 : KDC-8023 E5 : KDC-7024Y

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X25-966x-xx)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation	Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
R273			RK73GB2A222J	CHIP R 2.2K J 1/10W		D52-55			MA3062WA	ZENER DIODE	E4E5
R274			RK73GB2A102J	CHIP R 1.0K J 1/10W		D52,53			MA3062WA	ZENER DIODE	K6M2
R275			RK73GB2A104J	CHIP R 100K J 1/10W		D60			MA3062WA	ZENER DIODE	
R277,278			RK73GB2A471J	CHIP R 470 J 1/10W		D62			MA3062WA	ZENER DIODE	
R279,280			RK73GB2A472J	CHIP R 4.7K J 1/10W		D63-65			DA204U	DIODE	
R282			RK73GB2A103J	CHIP R 10K J 1/10W	M2	D66			IMSA-6801	SURGE ABSORBER	
R283			RK73GB2A103J	CHIP R 10K J 1/10W	K6E4E5	IC1		*	UPD703030GC015	MI-COM IC	
R285			RK73GB2A102J	CHIP R 1.0K J 1/10W		IC2			TDA7411	ANALOGUE IC	
R300,301			RK73GB2A472J	CHIP R 4.7K J 1/10W		IC3			M5237ML	ANALOGUE IC	
R302			RK73GB2A221J	CHIP R 220 J 1/10W		IC4			TDA7560	ANALOGUE IC	
R303			RK73GB2A223J	CHIP R 22K J 1/10W		IC7			S-80837CNNB	MOS-IC	E4E5
R305			RK73GB2A432J	CHIP R 4.3K J 1/10W		IC8			TC74HC02AF	MOS-IC	
R306			RK73GB2A100J	CHIP R 10 J 1/10W		IC12			TDA7479D	ANALOGUE IC	
R307			RK73GB2A622J	CHIP R 6.2K J 1/10W		IC13,14			LB1930M	ANALOGUE IC	
R308			RK73EB2E102J	CHIP R 1.0K J 1/4W	E4E5	IC15			BR24C01AF-W	ROM IC	
R309-311			RK73EB2E471J	CHIP R 470 J 1/4W	E4E5	Q1			2SA2057	TRANSISTOR	
R312			RK73EB2E101J	CHIP R 100 J 1/4W		Q2			2SC4081	TRANSISTOR	
R313-317			RK73EB2E472J	CHIP R 4.7K J 1/4W		Q3			2SA1576A	TRANSISTOR	
R318,319			RK73EB2E101J	CHIP R 100 J 1/4W		Q4			DTA124EUA	DIGITAL TRANSISTOR	
R321-323			RK73GB2A222J	CHIP R 2.2K J 1/10W		Q4			UN5112	DIGITAL TRANSISTOR	
R324,325			RK73GB2A472J	CHIP R 4.7K J 1/10W		Q5			DTC124EUA	DIGITAL TRANSISTOR	
R326			RK73GB2A104J	CHIP R 100K J 1/10W		Q5			UN5212	DIGITAL TRANSISTOR	
R327,328			RK73GB2A472J	CHIP R 4.7K J 1/10W		Q6			DTC144EUA	DIGITAL TRANSISTOR	
R329			RK73EB2E472J	CHIP R 4.7K J 1/4W		Q6			UN5213	DIGITAL TRANSISTOR	
R330,331			RK73EB2E101J	CHIP R 100 J 1/4W		Q7			DTA124EUA	DIGITAL TRANSISTOR	
R332			RK73EB2E471J	CHIP R 470 J 1/4W		Q7			UN5112	DIGITAL TRANSISTOR	
R402			RK73FB2B102J	CHIP R 1.0K J 1/8W		Q8,9			2SA2057	TRANSISTOR	
R403			RK73GB2A223J	CHIP R 22K J 1/10W		Q11			DTC124EUA	DIGITAL TRANSISTOR	
R404			RK73GB2A472J	CHIP R 4.7K J 1/10W	E4E5	Q11			UN5212	DIGITAL TRANSISTOR	
R405-407			RK73GB2A222J	CHIP R 2.2K J 1/10W	E4E5	Q12			DTA124EUA	DIGITAL TRANSISTOR	
W1			R92-1252-05	CHIP R 0 OHM J 1/16W	E4E5	Q12			UN5112	DIGITAL TRANSISTOR	
D1			1N5393G-M5	DIODE		Q13			2SA2057	TRANSISTOR	
D2			RB160L-40	DIODE		Q14			2SC4081	TRANSISTOR	
D3			MA4056(N)-M	ZENER DIODE		Q23			DTC114YUA	DIGITAL TRANSISTOR	K6M2
D4			MA4082(N)-L	ZENER DIODE		Q23			UN5214	DIGITAL TRANSISTOR	K6M2
D6			MA4110-L	ZENER DIODE		Q24,25			2SB1240	TRANSISTOR	K6M2
D9-12			S1J	DIODE		Q25			2SB1240	TRANSISTOR	E4E5
D9-12			1SR154-400	DIODE		Q26			DTC114YUA	DIGITAL TRANSISTOR	
D13			1SS133	DIODE		Q26			UN5214	DIGITAL TRANSISTOR	
D14			MA4056-M	ZENER DIODE	M2E4E5	Q27			2SA1576A	TRANSISTOR	
D15			MA4047-M	ZENER DIODE	E4E5	Q28			DTA124EUA	DIGITAL TRANSISTOR	
D16			MA4068(N)-M	ZENER DIODE		Q28			UN5112	DIGITAL TRANSISTOR	
D17			MA4062(N)-M	ZENER DIODE		Q29			DTA123JK	DIGITAL TRANSISTOR	M2E4E5
D20			1SS133	DIODE		Q29			KRA105S	DIGITAL TRANSISTOR	M2E4E5
D23,24			DAP202U	DIODE		Q30			DTC144EUA	DIGITAL TRANSISTOR	
D23,24			MA142WA	DIODE		Q30			UN5213	DIGITAL TRANSISTOR	
D25-27			RD6.8M(B2)	ZENER DIODE	M2	Q32-34			2SC4081	TRANSISTOR	
D25,26			RD6.8M(B2)	ZENER DIODE	K6E4E5	Q51,52			DTA124EUA	DIGITAL TRANSISTOR	
D28			RD6.8MW	ZENER DIODE	M2	Q51,52			UN5112	DIGITAL TRANSISTOR	
D29-31			1SS133	DIODE		Q53			DTC143TUA	DIGITAL TRANSISTOR	
D33-40			S1J	DIODE		Q53			UN5216	DIGITAL TRANSISTOR	
D33-40			1SR154-400	DIODE		Q54			DTC124EUA	DIGITAL TRANSISTOR	
D50			RD6.8M(B2)	ZENER DIODE		Q54			UN5212	DIGITAL TRANSISTOR	
D51			RD6.8MW	ZENER DIODE		Q55,56			DTC143TUA	DIGITAL TRANSISTOR	
						Q55,56			UN5216	DIGITAL TRANSISTOR	

E : Europe K : North America K6 : KDC-722 E4 : KDC-7024
M : Other Areas W : Without Europe M2 : KDC-8023 E5 : KDC-7024Y

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X25-966x-xx)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
Q59,60 Q59,60 Q63 Q63 Q102			DTC143TUA UN5216 DTA124EUA UN5112 DTC124EUA	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	
Q102 Q103 Q104 Q104 Q104 TH1			UN5212 2SB1188(Q,R) DTC143TUA UN5216 PTH9C42BD471Q	DIGITAL TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR POSITIVE RESISTOR	E4E5 E4E5
A1 A1		*	X86-3730-11 X86-3732-70	FRONT-END UNIT FRONT-END UNIT	K6M2 E4E5
CD PLAYER UNIT (X32-5200-00)					
C1,2 C3 C4 C5 C6			CK73GB0J105K CK73FB1A225K C92-0566-05 CC73GCH1H220J CC73GCH1H030C	CHIP C 1.0UF K CHIP C 2.2UF K CHIP-TAN 10UF 6.3WV CHIP C 22PF J CHIP C 3.0PF C	
C7 C8 C10 C11 C12			CK73GB1C104K CK73GB0J105K CK73GB1H472K CK73GB1H682K CK73GB1H332K	CHIP C 0.10UF K CHIP C 1.0UF K CHIP C 4700PF K CHIP C 6800PF K CHIP C 3300PF K	
C13 C14 C15 C16 C17			CK73GB1C333K CK73GB1H472K CK73GB1E473K CC73GCH1H221J CK73GB1H472K	CHIP C 0.033UF K CHIP C 4700PF K CHIP C 0.047UF K CHIP C 220PF J CHIP C 4700PF K	
C18 C19,20 C21 C23 C24			CC73GCH1H331J CK73GB1C104K CK73FB1A225K CK73GB1H102K CK73GB1E223K	CHIP C 330PF J CHIP C 0.10UF K CHIP C 2.2UF K CHIP C 1000PF K CHIP C 0.022UF K	
C25 C26 C28 C29 C33			CK73GB1H153K CK73GB0J105K CK73GB0J105K CK73GB1C104K CK73GB1C104K	CHIP C 0.015UF K CHIP C 1.0UF K CHIP C 1.0UF K CHIP C 0.10UF K CHIP C 0.10UF K	
C35 C39 C40 C41 C42			CK73GB1C104K CK73GB1H152K CK73GB1H103K CK73EB1C225K CK73GB1H152K	CHIP C 0.10UF K CHIP C 1500PF K CHIP C 0.010UF K CHIP C 2.2UF K CHIP C 1500PF K	
C44 C46 C51 C55 C67,68			CK73GB1H103K CK73GB1E473K CK73GB1C104K CK73GB1C104K CK73GB1C104K	CHIP C 0.010UF K CHIP C 0.047UF K CHIP C 0.10UF K CHIP C 0.10UF K CHIP C 0.10UF K	
C71,72 C77,78 C79,80 C85 C89			CK73GB1H471K CC73GCH1H680J CK73GB1H222K CK73GB1C104K CK73GB1H222K	CHIP C 470PF K CHIP C 68PF J CHIP C 2200PF K CHIP C 0.10UF K CHIP C 2200PF K	
CN1			E40-9536-05	FLAT CABLE CONNECTOR	

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
CN1 CN2 CN2			E41-0193-05 E40-9527-05 E41-0213-05	FLAT CABLE CONNECTOR FLAT CABLE CONNECTOR FLAT CABLE CONNECTOR	
X1			L78-0851-05	RESONATOR (16.93MHZ)	
CP1 CP2 R3 R5 R6			R90-1019-05 R90-1014-05 RK73GB2A272J RK73GB2A361J RK73GB2A272J	MULTI-COMP 100 X2 MULTI-COMP 100 X4 CHIP R 2.7K J 1/10W CHIP R 360 J 1/10W CHIP R 2.7K J 1/10W	
R7 R8 R9 R10,11 R12			RK73GB2A104J RK73GB2A472J RK73FB2B100J RK73GB2A562J RK73GB2A682J	CHIP R 100K J 1/10W CHIP R 4.7K J 1/10W CHIP R 10 J 1/8W CHIP R 5.6K J 1/10W CHIP R 6.8K J 1/10W	
R13 R15 R16 R17 R18			RK73GB2A392J RK73GB2A824J RK73GB2A223J RK73GB2A393J RK73GB2A392J	CHIP R 3.9K J 1/10W CHIP R 820K J 1/10W CHIP R 22K J 1/10W CHIP R 39K J 1/10W CHIP R 3.9K J 1/10W	
R19 R20 R21 R22 R32			RK73GB2A473J RK73GB2A104J RK73GB2A244J RK73GB2A623J RK73GB2A683J	CHIP R 47K J 1/10W CHIP R 100K J 1/10W CHIP R 240K J 1/10W CHIP R 62K J 1/10W CHIP R 68K J 1/10W	
R34 R35 R36 R37 R38			RK73GB2A363J RK73GB2A104J RK73GB2A151J RK73GB2A471J RK73GB2A224J	CHIP R 36K J 1/10W CHIP R 100K J 1/10W CHIP R 150 J 1/10W CHIP R 470 J 1/10W CHIP R 220K J 1/10W	
R40 R46 R47 R49 R52			RK73GB2A133J RK73GB2A102J RK73GB2A103J RK73GB2A472J RK73GB2A104J	CHIP R 13K J 1/10W CHIP R 1.0K J 1/10W CHIP R 10K J 1/10W CHIP R 4.7K J 1/10W CHIP R 100K J 1/10W	
R53 R54 R70 R71 R73			RK73GB2A103J RK73GB2A104J RK73GB2A103J RK73GB2A183J RK73GB2A683J	CHIP R 10K J 1/10W CHIP R 100K J 1/10W CHIP R 10K J 1/10W CHIP R 18K J 1/10W CHIP R 68K J 1/10W	
R74 R75 R76 R79,80 R81			RK73GB2A123J RK73GB2A333J RK73GB2A103J RK73GB2A103J RK73GB2A333J	CHIP R 12K J 1/10W CHIP R 33K J 1/10W CHIP R 10K J 1/10W CHIP R 10K J 1/10W CHIP R 33K J 1/10W	
R82 R84 R101,102 R103,104 R107,108			RK73GB2A223J RK73GB2A103J RK73GB2A332J RK73GB2A562J RK73FB2B331J	CHIP R 22K J 1/10W CHIP R 10K J 1/10W CHIP R 3.3K J 1/10W CHIP R 5.6K J 1/10W CHIP R 330 J 1/8W	
R110 R117,118 R121,122 R125,126 R202			RK73FB2B201J RK73FB2B203J RK73FB2B203J RK73FB2B203J RK73GB2A104J	CHIP R 200 J 1/8W CHIP R 20K J 1/8W CHIP R 20K J 1/8W CHIP R 20K J 1/8W CHIP R 100K J 1/10W	

E : Europe K : North America K6 : KDC-722 E4 : KDC-7024
M : Other Areas W : Without Europe M2 : KDC-8023 E5 : KDC-7024Y

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

CD PLAYER UNIT (X32-5200-00)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation	Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
R213			RK73GB2A104J	CHIP R 100K J 1/10W		43	1B		G01-3077-04	EXTENSION SPRING	
R218			RK73GB2A473J	CHIP R 47K J 1/10W		44	2B		G02-1399-04	FLAT SPRING	
R233			RK73GB2A622J	CHIP R 6.2K J 1/10W		45	2B		G02-1408-04	FLAT SPRING	
R234			RK73GB2A103J	CHIP R 10K J 1/10W							
S1,2			S68-0863-05	PUSH SWITCH		51	1A		J21-9676-22	MOUNTING HARDWARE	
S3			S68-0862-05	PUSH SWITCH		52	3B		J21-9677-02	MOUNTING HARDWARE	
D1			DAN202U	DIODE		53	1B		J21-9678-03	MOUNTING HARDWARE	
D2			MA8051-L	ZENER DIODE		55	1A		J90-1001-11	GUIDE	
D3			DA204U	DIODE		56	1B		J90-1023-03	GUIDE	
D4			DAN202U	DIODE		A	2B		N09-4460-05	TAPTITE SCREW (OVAL P TAPTIT)	
IC1			AN22002AA	ANALOGUE IC		B	1B		N09-4472-05	MACHINE SCREW (M1.7X8.5)	
IC2			MN662773KH2	MOS-IC		C	2B		N09-6004-05	MACHINE SCREW (M1.7X2.5 IB-L)	
IC4			BA5824FP	ANALOGUE IC		E	2B		N09-6007-05	MACHINE SCREW (PAN M2X2)	
IC6			NJM4580M1	ANALOGUE IC		F	1A		N09-6051-05	TAPTITE SCREW (BIND P 2X5)	
Q1			MCH6101	TRANSISTOR		G	2A		N19-2163-04	FLAT WASHER	
Q2			DTC124EUA	DIGITAL TRANSISTOR		H	1B		N39-2020-46	PAN HEAD MACHIN SCREW	
Q3			DTA143XUA	DIGITAL TRANSISTOR		J	1B		N09-6108-05	MACHINE SCREW (M2*3.5TYPE3)	
Q4			2SA1362(Y)	TRANSISTOR		DM1	3B		T42-1066-04	DC MOTOR ASSY (SP)	
Q5			DTC124EUA	DIGITAL TRANSISTOR		DM2	2B		T42-1067-04	DC MOTOR ASSY (LO)	
CD MECHANISM ASSY (X92-4450-01)						DPU1	2D		X93-2000-00	OPTICAL PICKUP ASSY	
2	1B		A10-4827-12	CHASSIS							
5	1B		D10-4576-43	ARM ASSY							
8	2A		D10-4579-03	LEVER ASSY							
10	3A		D10-4581-13	ARM							
11	2A		D10-4582-13	ARM							
12	3A		D10-4583-03	ARM							
13	3A		D10-4584-03	ARM							
14	3B		D10-4585-03	ARM							
15	2A		D10-4586-13	SLIDER							
16	3B		D10-4587-22	SLIDER							
17	3B		D10-4588-13	SLIDER							
18	3B		D10-4595-04	ARM							
19	3B		D10-4596-14	ARM							
22	2A		D13-2151-04	GEAR							
23	2B		D13-2152-04	GEAR							
24	3B		D13-2153-04	GEAR							
25	3B		D13-2154-04	GEAR							
26	3B		D13-2155-04	WORM							
27	3B		D13-2156-14	GEAR							
28	3B		D13-2157-04	GEAR							
29	3B		D13-2158-04	GEAR							
30	3B		D13-2168-04	GEAR							
31	3B		D13-2171-04	GEAR							
32	2B		D13-2172-03	RACK (GEAR)							
33	2A		D14-0759-04	ROLLER							
35	2B		D21-2382-04	SHAFT							
36	1A		D23-0954-04	RETAINER							
37	1B		D39-0246-05	DAMPER							
38	2B		G01-3072-04	EXTENSION SPRING							
39	2A		G01-3073-04	TORSION COIL SPRING							
40	2A		G01-3074-04	EXTENSION SPRING							
41	1B		G01-3075-04	EXTENSION SPRING							
42	2A		G01-3076-04	EXTENSION SPRING							

E : Europe K : North America K6 : KDC-722 E4 : KDC-7024
M : Other Areas W : Without Europe M2 : KDC-8023 E5 : KDC-7024Y

△ Indicates safety critical components.