


5 6 7 8

4. EXPLODED VIEWS AND PARTS LIST

- NOTES:
- Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
 - The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)

4.1 PACKING SECTION



(1) PACKING SECTION PARTS LIST


Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	1.2 m Coiled Cable (extended length 3.0 m)	See Contrast table (2)	NSP 4	Carry Case	
2	1.6 m Straight Cable	See Contrast table (2)	NSP 5	Operating Instructions	
3	6.3 mm Stereo Plug Adapter (threaded type)	30030150400101D			

(2) CONTRAST TABLE

HDJ-S7-K/XEGWL and HDJ-S7-W/XEGWL are constructed the same except for the following:

Mark	No.	Symbol and Description	HDJ-S7-K	HDJ-S7-W
	1	1.2 m Coiled Cable (extended length 3.0 m)	20030235000021D00	20030235000023D00
	2	1.6 m Straight Cable	20030235000022D00	20030235000024D00

4.2 EXTERIOR SECTION



(1) EXTERIOR SECTION PARTS LIST

Mark No.	Description	Part No.
1	Headband Assy	See Contrast table (2)
2※	SP Base Assy	1003046265T0005
3	JACK PCB Assy	1003046265T0006
4	Ear pad	See Contrast table (2)
5	Screw (T2*L8)	See Contrast table (2)

※ The SP Base Assy is supplied in 2 pieces. Even if only one side fails, be sure to replace both.

(2) CONTRAST TABLE

HDJ-S7-K/XEGWL and HDJ-S7-W/XEGWL are constructed the same except for the following:

Mark	No.	Symbol and Description	HDJ-S7-K	HDJ-S7-W
	1	Headband Assy	1003046265T0003	1003046265T0004
	4	Ear pad	301001000513D00	301001000514D00
	5	Screw (T2*L8)	30030220080015D	30030220080016D