



## EXPLODED VIEW



# KDC-1020/S/119/S

## PARTS LIST

\* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

| Ref. No.                         | A<br>d<br>d | N<br>e<br>w | Parts No.   | Description                     | Desti-<br>nation |
|----------------------------------|-------------|-------------|-------------|---------------------------------|------------------|
| <b>KDC-1020/1020S/119/119S</b>   |             |             |             |                                 |                  |
| 206                              | 1B          | *           | A52-0804-02 | TOP PLATE                       |                  |
| PA1                              | 3A          | *           | A64-2556-02 | PANEL ASSY                      | K0               |
| PA1                              | 3A          | *           | A64-2557-02 | PANEL ASSY                      | M1               |
| PA1                              | 3A          | *           | A64-2559-02 | PANEL ASSY                      | K1               |
| PA1                              | 3A          | *           | A64-2679-02 | PANEL ASSY                      | M2               |
| 210                              | 3B          |             | B07-3054-02 | ESCUTCHEON                      | K0K1M1           |
| 210                              | 3B          |             | B07-3055-02 | ESCUTCHEON                      | M2               |
| 211                              | 3A          | *           | B10-4144-01 | FRONT GLASS                     | K0               |
| 211                              | 3A          | *           | B10-4145-01 | FRONT GLASS                     | M1               |
| 211                              | 3A          | *           | B10-4147-01 | FRONT GLASS                     | K1               |
| 211                              | 3A          | *           | B10-4233-01 | FRONT GLASS                     | M2               |
| -                                |             |             | B46-0100-50 | WARRANTY CARD                   |                  |
| -                                |             |             | B58-1344-04 | CAUTION CARD                    | K0K1             |
| -                                |             |             | B58-1365-04 | CAUTION CARD                    |                  |
| -                                |             | *           | B64-2114-00 | INST.MANUAL (ENG.FRE.SPA.POR.)  | K0K1             |
| -                                |             | *           | B64-2115-00 | INSTRUCTION MANUAL (ENG.T-CHI.) | M1M2             |
| -                                |             | *           | B64-2116-00 | INSTRUCTION MANUAL (ARABIC)     | M1M2             |
| -                                |             | *           | B64-2208-00 | INSTRUCTION MANUAL (S-CHINES)   | M1               |
| 215                              | 1A          |             | D10-4589-04 | LEVER                           |                  |
| 218                              | 2A          | *           | E29-1872-02 | CONDUCTIVE RUBBER               |                  |
| △ DC1                            | 1A          |             | E30-4783-05 | DC CORD                         | K0K1             |
| △ DC1                            | 1A          |             | E30-4784-05 | DC CORD                         | M1M2             |
| FC1                              | 2A          |             | E39-0343-05 | FLAT CABLE                      |                  |
| △ F1                             | 2B          |             | F52-0006-05 | FUSE (MINI BLADE TYPE)          |                  |
| -                                |             | *           | H10-4801-02 | POLYSTYRENE FOAMED FIXTURE      |                  |
| -                                |             |             | H25-0329-04 | PROTECTION BAG (280X450X0.03)   |                  |
| -                                |             |             | H25-0337-04 | PROTECTION BAG (180X300X0.03)   |                  |
| -                                |             | *           | H54-2289-03 | ITEM CARTON CASE                | K0               |
| -                                |             | *           | H54-2290-03 | ITEM CARTON CASE                | M1               |
| -                                |             | *           | H54-2315-03 | ITEM CARTON CASE                | K1               |
| -                                |             | *           | H54-2380-03 | ITEM CARTON CASE                | M2               |
| 229                              | 1A          |             | J21-9641-13 | MOUNTING HARDWARE ASSY          |                  |
| 233                              | 3A          | *           | K24-3823-04 | KNOB (SRC)                      |                  |
| 234                              | 3A          | *           | K24-3824-04 | KNOB (AUD)                      |                  |
| 235                              | 3A          | *           | K24-3825-03 | KNOB (VOL)                      |                  |
| 236                              | 3A          | *           | K24-3826-04 | KNOB (EJECT)                    |                  |
| 237                              | 3A          | *           | K25-1396-03 | KNOB (PRE1-6,ATT,RESET)         |                  |
| 238                              | 3A          | *           | K25-1397-03 | KNOB (AUTO,CLK,FM,AM)           |                  |
| 241                              | 1A          | *           | N99-1719-05 | SCREW SET                       |                  |
| A                                | 3B          |             | N30-3008-46 | PAN HEAD MACHINE SCREW          |                  |
| B                                | 3A          |             | N80-2006-46 | PAN HEAD TAPTITE SCREW          |                  |
| C                                | 2A          |             | N80-2008-45 | PAN HEAD TAPTITE SCREW          |                  |
| D                                | 1B          |             | N83-3005-46 | PAN HEAD TAPTITE SCREW          |                  |
| DME1                             | 1B          | *           | X92-4030-00 | MECHANISM ASSY                  |                  |
| <b>SWITCH UNIT (X16-1460-13)</b> |             |             |             |                                 |                  |
| 245                              | 2A          | *           | B11-1358-04 | OPTICAL DIFFUSER                |                  |
| 246                              | 2A          | *           | B11-1359-04 | REFLECTION SHEET                |                  |
| 248                              | 2A          | *           | B19-2130-03 | LIGHTING BOARD                  |                  |
| D1-13                            |             |             | B30-1533-05 | LED (1608,PG)                   |                  |

| Ref. No.                              | A<br>d<br>d | N<br>e<br>w | Parts No.     | Description        | Desti-<br>nation |
|---------------------------------------|-------------|-------------|---------------|--------------------|------------------|
| D17,18                                |             |             | B30-1533-05   | LED (1608,PG)      |                  |
| D19                                   |             |             | B30-1633-05   | LED (WHITE)        |                  |
| D20                                   |             |             | B30-1533-05   | LED (1608,PG)      |                  |
| ED1                                   |             | *           | B38-1079-05   | LIQUID CRYSTAL     |                  |
| C1                                    |             |             | CK73GB1H102K  | CHIP C 1000PF      | K                |
| C2,3                                  |             |             | CK73GB1E473K  | CHIP C 0.047UF     | K                |
| C2,3                                  |             |             | CK73GB1H473K  | CHIP C 0.047UF     | K                |
| C4                                    |             |             | CK73GB1H103K  | CHIP C 0.010UF     | K                |
| C9                                    |             |             | CK73GB1H103K  | CHIP C 0.010UF     | K                |
| 249                                   | 2A          |             | E29-1829-04   | CONDUCTIVE RUBBER  |                  |
| 250                                   | 2A          |             | E29-1834-04   | CONDUCTIVE RUBBER  |                  |
| J1                                    |             |             | E59-0828-05   | RECTANGULAR PLUG   |                  |
| -                                     |             | *           | J19-5130-04   | HOLDER             |                  |
| R2-4                                  |             |             | RK73GB2A471J  | CHIP R 470 J       | 1/10W            |
| R5                                    |             |             | RK73GB2A102J  | CHIP R 1.0K J      | 1/10W            |
| R7                                    |             |             | RK73GB2A472J  | CHIP R 4.7K J      | 1/10W            |
| R8                                    |             |             | RK73GB2A563J  | CHIP R 56K J       | 1/10W            |
| R10                                   |             |             | RK73GB2A4R7J  | CHIP R 4.7 J       | 1/10W            |
| R14,15                                |             |             | RK73FB2B331J  | CHIP R 330 J       | 1/8W             |
| R16-20                                |             |             | RK73FB2B511J  | CHIP R 510 J       | 1/8W             |
| R21,22                                |             |             | RK73FB2B221J  | CHIP R 220 J       | 1/8W             |
| IC1                                   |             |             | LC75853NE     | MOS-IC             |                  |
| Q1                                    |             |             | DTA114EUA     | DIGITAL TRANSISTOR |                  |
| Q1                                    |             |             | UN5111        | DIGITAL TRANSISTOR |                  |
| <b>ELECTRIC UNIT (X25-9120-14/22)</b> |             |             |               |                    |                  |
| C1                                    |             |             | C90-5242-05   | ELECTRO 3300UF     | 16WV             |
| C21                                   |             |             | CK73GB1H103K  | CHIP C 0.010UF     | K                |
| C40                                   |             |             | CK73GB1H103K  | CHIP C 0.010UF     | K                |
| C50                                   |             |             | CE04NW1E100M  | ELECTRO 10UF       | 25WV             |
| C50,51                                |             |             | CE04NW1E100M  | ELECTRO 10UF       | 25WV             |
| C52-54                                |             |             | CE04NW1C100M  | ELECTRO 10UF       | 16WV             |
| C55                                   |             |             | CE04NW1E100M  | ELECTRO 10UF       | 25WV             |
| C56                                   |             |             | CE04CW1H100M  | ELECTRO 10UF       | 50WV             |
| C57                                   |             |             | C90-2980-05   | ELECTRO 220UF      | 16WV             |
| C58                                   |             |             | C90-2962-05   | ELECTRO 100UF      | 16WV             |
| C63                                   |             |             | CE04NW1C220M  | ELECTRO 22UF       | 16WV             |
| C101                                  |             |             | CE04NW0J101M  | ELECTRO 100UF      | 6.3WV            |
| C102                                  |             |             | CK73GB1H103K  | CHIP C 0.010UF     | K                |
| C103                                  |             |             | CK73GB1C104K  | CHIP C 0.10UF      | K                |
| C103                                  |             |             | CK73GB1H104K  | CHIP C 0.10UF      | K                |
| C104,105                              |             |             | CC73GCH1H150J | CHIP C 15PF        | J                |
| C106                                  |             |             | CK73GB1H472K  | CHIP C 4700PF      | K                |
| C142                                  |             |             | CK73GB1C104K  | CHIP C 0.10UF      | K                |
| C142                                  |             |             | CK73GB1H104K  | CHIP C 0.10UF      | K                |
| C201                                  |             |             | CE04NW1A470M  | ELECTRO 47UF       | 10WV             |
| C202                                  |             |             | CK73GB1H103K  | CHIP C 0.010UF     | K                |
| C203-205                              |             |             | CE04NW1H2R2M  | ELECTRO 2.2UF      | 50WV             |
| C206                                  |             |             | CK73GB1H153K  | CHIP C 0.015UF     | K                |
| C207                                  |             |             | CK73GB1A474K  | CHIP C 0.47UF      | K                |
| C208,209                              |             |             | CK73GB1C104K  | CHIP C 0.10UF      | K                |
| C208,209                              |             |             | CK73GB1H104K  | CHIP C 0.10UF      | K                |
| C210                                  |             |             | CK73GB1E333K  | CHIP C 0.033UF     | K                |
| C210                                  |             |             | CK73GB1H333K  | CHIP C 0.033UF     | K                |

E : Europe K : North America M : Other Areas

W : Without Europe

K0 : KDC-119

K1 : KDC-119S

M1 : KDC-1020

M2 : KDC-1020S

△ Indicates safety critical components.

## PARTS LIST

\* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

## ELECTRIC UNIT (X25-9120-14/22)

| Ref. No. | Add | New | Parts No.     | Description                    | Destination | Ref. No. | Add | New | Parts No.    | Description          | Destination |
|----------|-----|-----|---------------|--------------------------------|-------------|----------|-----|-----|--------------|----------------------|-------------|
| C211     |     |     | CC73GCH1H151J | CHIP C 150PF J                 |             | R113,114 |     |     | RK73GB2A473J | CHIP R 47K J 1/10W   |             |
| C223,224 |     |     | C90-2597-05   | ELECTRO 10UF 16WV              |             | R115     |     |     | RK73GB2A102J | CHIP R 1.0K J 1/10W  |             |
| C225     |     |     | CK73GB1H103K  | CHIP C 0.010UF K               |             | R116     |     |     | RK73GB2A103J | CHIP R 10K J 1/10W   |             |
| C251-254 |     |     | C90-5296-05   | NP-ELECT 0.22UF 50WV           |             | R117     |     |     | RK73GB2A102J | CHIP R 1.0K J 1/10W  |             |
| C255     |     |     | CE04NW1H010M  | ELECTRO 1.0UF 50WV             |             | R118     |     |     | RK73GB2A103J | CHIP R 10K J 1/10W   |             |
| C256     |     |     | CE04NW1A101M  | ELECTRO 100UF 10WV             | K0K1        | R119     |     |     | RK73GB2A473J | CHIP R 47K J 1/10W   |             |
| C256     |     |     | CE04NW1A330M  | ELECTRO 33UF 10WV              | M1M2        | R121     |     |     | RK73GB2A222J | CHIP R 2.2K J 1/10W  |             |
| C257     |     |     | CE04NW1H010M  | ELECTRO 1.0UF 50WV             |             | R122     |     |     | RK73GB2A101J | CHIP R 100 J 1/10W   |             |
| C258     |     |     | C90-2935-05   | ELECTRO 1.0UF 50WV             |             | R123     |     |     | RK73GB2A102J | CHIP R 1.0K J 1/10W  |             |
| C301     |     |     | CE04NW1A101M  | ELECTRO 100UF 10WV             |             | R125     |     |     | RK73GB2A102J | CHIP R 1.0K J 1/10W  |             |
| C302,303 |     |     | CK73GB1H103K  | CHIP C 0.010UF K               |             | R126     |     |     | RK73GB2A104J | CHIP R 100K J 1/10W  |             |
| C304     |     |     | CE04CW1A101M  | ELECTRO 100UF 10WV             |             | R127     |     |     | RK73GB2A222J | CHIP R 2.2K J 1/10W  |             |
| C305     |     |     | CK73GB1H103K  | CHIP C 0.010UF K               |             | R128     |     |     | RK73GB2A225J | CHIP R 2.2M J 1/10W  |             |
| C306     |     |     | C90-2594-05   | ELECTRO 10UF 10WV              |             | R129,130 |     |     | RK73GB2A222J | CHIP R 2.2K J 1/10W  |             |
| C307     |     |     | CK73GB1H103K  | CHIP C 0.010UF K               |             | R131     |     |     | RK73GB2A682J | CHIP R 6.8K J 1/10W  |             |
| C309     |     |     | CK73GB1H103K  | CHIP C 0.010UF K               |             | R132     |     |     | RK73GB2A223J | CHIP R 22K J 1/10W   |             |
| CN1      |     |     | E40-9550-05   | FLAT CABLE CONNECTOR           |             | R133     |     |     | RK73GB2A164J | CHIP R 160K J 1/10W  |             |
| J1       |     |     | E04-0312-05   | RF COAXIAL CABLE RECEPTACLE    |             | R136     |     |     | RK73GB2A473J | CHIP R 47K J 1/10W   | K0K1        |
| J2       |     |     | E58-0863-15   | RECTANGULAR RECEPTACLE         |             | R136,137 |     |     | RK73GB2A473J | CHIP R 47K J 1/10W   | M1M2        |
| J3       |     |     | E58-0880-05   | RECTANGULAR RECEPTACLE         |             | R138,139 |     |     | RK73GB2A473J | CHIP R 47K J 1/10W   | K0K1        |
| J5       |     |     | E63-0852-05   | PIN JACK                       |             | R139     |     |     | RK73GB2A473J | CHIP R 47K J 1/10W   | M1M2        |
| L1       |     |     | L33-1170-05   | CHOKE COIL ASSY                |             | R143     |     |     | RK73GB2A472J | CHIP R 4.7K J 1/10W  |             |
| L2       |     |     | L33-1807-05   | CHOKE COIL                     |             | R144     |     |     | RK73GB2A104J | CHIP R 100K J 1/10W  |             |
| L4       |     |     | L33-1123-05   | LINE FILTER COIL               |             | R201     |     |     | RK73GB2A272J | CHIP R 2.7K J 1/10W  |             |
| L101     |     |     | L40-4795-91   | SMALL FIXED INDUCTOR (4.7UH,J) |             | R202,203 |     |     | RK73GB2A472J | CHIP R 4.7K J 1/10W  |             |
| L201     |     |     | L40-4795-91   | SMALL FIXED INDUCTOR (4.7UH,J) |             | R223,224 |     |     | RK73FB2B271J | CHIP R 270 J 1/8W    |             |
| L303-306 |     |     | L40-4795-91   | SMALL FIXED INDUCTOR (4.7UH,J) |             | R251     |     |     | RK73GB2A472J | CHIP R 4.7K J 1/10W  | K0K1        |
| X1       |     |     | L77-1167-05   | CRYSTAL RESONATOR (4.19M)      |             | R254     |     |     | RK73GB2A472J | CHIP R 4.7K J 1/10W  | K0K1        |
| D        | 2B  |     | N83-3005-46   | PAN HEAD TAPTITE SCREW         |             | R255     |     |     | RK73GB2A333J | CHIP R 33K J 1/10W   |             |
| E        | 2B  |     | N80-3010-46   | PAN HEAD TAPTITE SCREW         |             | R256     |     |     | RK73FB2B102J | CHIP R 1.0K J 1/8W   |             |
| F        | 2B  |     | N83-3020-46   | PAN HEAD TAPTITE SCREW         |             | R257     | *   |     | RK73GB2A362J | CHIP R 3.6K J 1/10W  |             |
| G        | 2B  |     | N86-2606-46   | BINDING HEAD TAPTITE SCREW     |             | R258     |     |     | RK73GB2A101J | CHIP R 100 J 1/10W   | K0K1        |
| CP1      |     |     | R90-1056-05   | MULTIPLE RESISTOR              |             | R258     |     |     | RK73GB2A221J | CHIP R 220 J 1/10W   | M1M2        |
| CP2      |     |     | R90-1047-05   | MULTIPLE RESISTOR              |             | R260     |     |     | RK73GB2A751J | CHIP R 750 J 1/10W   | K0K1        |
| CP3      |     |     | R90-1046-05   | MULTIPLE RESISTOR              |             | R261     | *   |     | RK73GB2A100J | CHIP R 10 J 1/10W    | M1M2        |
| R10      |     |     | RK73FB2B303J  | CHIP R 30K J 1/8W              |             | R261     |     |     | RK73GB2A431J | CHIP R 430 J 1/10W   | K0K1        |
| R11      |     |     | RK73GB2A103J  | CHIP R 10K J 1/10W             |             | R263     |     |     | RK73GB2A184J | CHIP R 180K J 1/10W  | K0K1        |
| R12      |     |     | RK73GB2A104J  | CHIP R 100K J 1/10W            |             | R263     |     |     | RK73GB2A432J | CHIP R 4.3K J 1/10W  | M1M2        |
| R20      |     |     | RD14DB2H332J  | SMALL-RD 3.3K J 1/2W           |             | R264     |     |     | RK73GB2A473J | CHIP R 47K J 1/10W   |             |
| R22      |     |     | RK73GB2A103J  | CHIP R 10K J 1/10W             |             | R415     |     |     | RK73GB2A104J | CHIP R 100K J 1/10W  |             |
| R23      |     |     | RK73GB2A104J  | CHIP R 100K J 1/10W            |             | W151     |     |     | R92-2053-05  | CHIP R 0 J 1/8W      |             |
| R51      |     |     | RK73GB2A473J  | CHIP R 47K J 1/10W             |             | W152     |     |     | R92-1252-05  | CHIP R 0 OHM J 1/16W |             |
| R57      | *   |     | RK73FB2B152J  | CHIP R 1.5K J 1/8W             |             | W155     |     |     | R92-1252-05  | CHIP R 0 OHM J 1/16W |             |
| R58      |     |     | RK73GB2A472J  | CHIP R 4.7K J 1/10W            |             | W156,157 |     |     | R92-2053-05  | CHIP R 0 J 1/8W      |             |
| R67      |     |     | RK73GB2A103J  | CHIP R 10K J 1/10W             |             | W158,159 |     |     | R92-1252-05  | CHIP R 0 OHM J 1/16W |             |
| R71      | *   |     | RK73GB2A823J  | CHIP R 82K J 1/10W             |             | W160-165 |     |     | R92-2053-05  | CHIP R 0 J 1/8W      |             |
| R72      | *   |     | RK73GB2A363J  | CHIP R 36K J 1/10W             |             | W167-169 |     |     | R92-1252-05  | CHIP R 0 OHM J 1/16W |             |
| R73      |     |     | RK73GB2A104J  | CHIP R 100K J 1/10W            |             | W171-174 |     |     | R92-1252-05  | CHIP R 0 OHM J 1/16W |             |
| R103,104 |     |     | RK73GB2A222J  | CHIP R 2.2K J 1/10W            |             | W176-178 |     |     | R92-1252-05  | CHIP R 0 OHM J 1/16W | M1M2        |
| R105     |     |     | RK73GB2A471J  | CHIP R 470 J 1/10W             |             | W179     |     |     | R92-2052-05  | CHIP R 0 OHM J 1/10W |             |
| R106     |     |     | RK73GB2A104J  | CHIP R 100K J 1/10W            |             | D1       |     |     | S2V20*A      | DIODE                |             |
| R107,108 |     |     | RK73GB2A222J  | CHIP R 2.2K J 1/10W            |             | D1       |     |     | 1N5393G-M6   | DIODE                |             |
| R110     |     |     | RK73GB2A472J  | CHIP R 4.7K J 1/10W            |             | D10      |     |     | MA4068(N)-M  | ZENER DIODE          |             |
|          |     |     |               |                                |             | D11      |     |     | D1F60        | DIODE                | M1M2        |
|          |     |     |               |                                |             | D12      |     |     | AM01Z        | DIODE                | M1M2        |

E : Europe K : North America M : Other Areas

W : Without Europe

K0 : KDC-119

K1 : KDC-119S

M1 : KDC-1020

M2 : KDC-1020S

△ Indicates safety critical components.

## PARTS LIST

\* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

## ELECTRIC UNIT (X25-9120-14/22)

| Ref. No. | A<br>d<br>d | N<br>e<br>w | Parts No.      | Description        | Desti-<br>nation |
|----------|-------------|-------------|----------------|--------------------|------------------|
| D12      |             |             | DSM1SD2        | DIODE              | M1M2             |
| D12      |             |             | ERA15-02       | DIODE              | M1M2             |
| D13      |             |             | D1F60          | DIODE              |                  |
| D14      |             |             | AM01Z          | DIODE              |                  |
| D14      |             |             | DSM1SD2        | DIODE              |                  |
| D14      |             |             | ERA15-02       | DIODE              |                  |
| D20      |             |             | MA4068(N)-M    | ZENER DIODE        |                  |
| D40      |             |             | 1SS133         | DIODE              |                  |
| D50      |             |             | 1SS133         | DIODE              |                  |
| D51      |             |             | HZS9A1L        | ZENER DIODE        |                  |
| D51      |             |             | MA4082(N)-L    | ZENER DIODE        |                  |
| D70      |             |             | MA4068(N)-M    | ZENER DIODE        |                  |
| D101     |             |             | 1SS133         | DIODE              |                  |
| D103,104 |             |             | 1SS133         | DIODE              |                  |
| D201,202 |             |             | MA4068(N)-M    | ZENER DIODE        |                  |
| D251-253 |             |             | 1SS133         | DIODE              |                  |
| D261-263 |             |             | AM01Z          | DIODE              | M1M2             |
| D261-263 |             |             | DSM1SD2        | DIODE              | M1M2             |
| D261-263 |             |             | ERA15-02       | DIODE              | M1M2             |
| D264     |             |             | D1F60          | DIODE              | M1M2             |
| D264     |             | *           | S1J            | DIODE              | M1M2             |
| D265,266 |             |             | AM01Z          | DIODE              | M1M2             |
| D265,266 |             |             | DSM1SD2        | DIODE              | M1M2             |
| D265,266 |             |             | ERA15-02       | DIODE              | M1M2             |
| D267,268 |             |             | D1F60          | DIODE              | M1M2             |
| D267,268 |             | *           | S1J            | DIODE              | M1M2             |
| IC1      |             | *           | UPD780058GC430 | MI-COM IC          |                  |
| IC2      |             |             | TDA7407D       | ANALOGUE IC        |                  |
| IC4      |             |             | TDA7386        | ANALOGUE IC        | K0K1             |
| IC4      |             |             | TDA7560        | ANALOGUE IC        | M1M2             |
| IC7      |             |             | BA4911-V4      | ANALOGUE IC        |                  |
| IC8      |             |             | HD74HC27FP     | MOS-IC             |                  |
| IC11     |             |             | S-80835ANNP    | MOS-IC             |                  |
| IC12     |             |             | BR24C01AF      | MEMORY IC          |                  |
| IC12     |             |             | BR24C01AF-W    | MEMORY IC          |                  |
| IC12     |             |             | M24C01-WMN6T   | MEMORY IC          |                  |
| IC12     |             |             | S-24C01B       | MEMORY IC          |                  |
| Q10      |             |             | 2SC4081        | TRANSISTOR         |                  |
| Q10      |             |             | 2SD1819A       | TRANSISTOR         |                  |
| Q20      |             |             | 2SC4081        | TRANSISTOR         |                  |
| Q20      |             |             | 2SD1819A       | TRANSISTOR         |                  |
| Q40      |             |             | DTA124EUA      | DIGITAL TRANSISTOR |                  |
| Q40      |             |             | UN5112         | DIGITAL TRANSISTOR |                  |
| Q50      |             |             | 2SA1036K       | TRANSISTOR         |                  |
| Q51      |             |             | UMC2N          | TRANSISTOR         |                  |
| Q53      |             |             | UMC2N          | TRANSISTOR         | M1M2             |
| Q55      |             |             | 2SD2375        | TRANSISTOR         |                  |
| Q55      |             |             | 2SD2396        | TRANSISTOR         |                  |
| Q70      |             |             | 2SC4081        | TRANSISTOR         |                  |
| Q70      |             |             | 2SD1819A       | TRANSISTOR         |                  |
| Q223,224 |             |             | DTC143TUA      | DIGITAL TRANSISTOR |                  |
| Q223,224 |             |             | UN5216         | DIGITAL TRANSISTOR |                  |
| Q251     |             |             | DTC114YUA      | DIGITAL TRANSISTOR |                  |
| Q251     |             |             | UN5214         | DIGITAL TRANSISTOR |                  |
| TH1      |             |             | PTH9C42BE471Q  | POSITIVE RESISTOR  |                  |

| Ref. No. | A<br>d<br>d | N<br>e<br>w | Parts No.   | Description    | Desti-<br>nation |
|----------|-------------|-------------|-------------|----------------|------------------|
| A1       |             | *           | X86-3510-11 | FRONT-END UNIT |                  |

E : Europe K : North America M : Other Areas

W : Without Europe

K0 : KDC-119

K1 : KDC-119S

M1 : KDC-1020

M2 : KDC-1020S

△ Indicates safety critical components.

X92-4030-0x  
X92-4440-0x

PARTS LIST

\*New Parts  
Parts without **Parts No.** are not supplied.  
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.  
Teile ohne **Parts No.** werden nicht geliefert.

| Ref. No.                                  | A<br>d<br>d | N<br>e<br>w | Parts No.                                                                     | Description                                                                                                    |                                                  |                                           | D<br>e<br>s<br>t<br>i<br>n<br>a<br>t<br>i<br>o<br>n |
|-------------------------------------------|-------------|-------------|-------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|--------------------------------------------------|-------------------------------------------|-----------------------------------------------------|
| CD PLAYER UNIT (X32-5170-0x, X32-5190-0x) |             |             |                                                                               |                                                                                                                |                                                  |                                           |                                                     |
| C1,2<br>C3<br>C4<br>C5<br>C6              |             |             | CK73GB0J105K<br>CK73FB1A225K<br>C92-0566-05<br>CC73GCH1H150J<br>CC73GCH1H020C | CHIP C<br>CHIP C<br>CHIP-TAN<br>CHIP C<br>CHIP C                                                               | 1.0UF<br>2.2UF<br>10UF<br>15PF<br>2.0PF          | K<br>K<br>6.3WV<br>J<br>C                 |                                                     |
| C7<br>C8<br>C10<br>C11<br>C12             |             |             | CK73GB1C104K<br>CK73GB0J105K<br>CK73GB1H472K<br>CK73GB1H682K<br>CK73GB1H332K  | CHIP C<br>CHIP C<br>CHIP C<br>CHIP C<br>CHIP C                                                                 | 0.10UF<br>1.0UF<br>4700PF<br>6800PF<br>3300PF    | K<br>K<br>K<br>K<br>K                     |                                                     |
| C13<br>C14<br>C15<br>C16<br>C17           |             |             | CK73GB1C333K<br>CK73GB1H472K<br>CK73GB1E473K<br>CC73GCH1H151J<br>CK73GB1H472K | CHIP C<br>CHIP C<br>CHIP C<br>CHIP C<br>CHIP C                                                                 | 0.033UF<br>4700PF<br>0.047UF<br>150PF<br>4700PF  | K<br>K<br>K<br>J<br>K                     |                                                     |
| C18<br>C19,20<br>C21<br>C23<br>C24        |             |             | CC73GCH1H221J<br>CK73GB1C104K<br>CK73FB1A225K<br>CK73GB1H102K<br>CK73GB1E223K | CHIP C<br>CHIP C<br>CHIP C<br>CHIP C<br>CHIP C                                                                 | 220PF<br>0.10UF<br>2.2UF<br>1000PF<br>0.022UF    | J<br>K<br>K<br>K<br>K                     |                                                     |
| C25<br>C26<br>C28<br>C29<br>C33           |             |             | CK73GB1H153K<br>CK73GB0J105K<br>CK73GB0J105K<br>CK73GB1C104K<br>CK73GB1C104K  | CHIP C<br>CHIP C<br>CHIP C<br>CHIP C<br>CHIP C                                                                 | 0.015UF<br>1.0UF<br>1.0UF<br>0.10UF<br>0.10UF    | K<br>K<br>K<br>K<br>K                     |                                                     |
| C35<br>C39<br>C40<br>C41<br>C42           |             |             | CK73GB1C104K<br>CK73GB1H152K<br>CK73GB1H103K<br>CK73EB1C225K<br>CK73GB1H152K  | CHIP C<br>CHIP C<br>CHIP C<br>CHIP C<br>CHIP C                                                                 | 0.10UF<br>1500PF<br>0.010UF<br>2.2UF<br>1500PF   | K<br>K<br>K<br>K<br>K                     |                                                     |
| C44<br>C46<br>C51<br>C55<br>C67,68        |             |             | CK73GB1H103K<br>CK73GB1E473K<br>CK73GB1C104K<br>CK73GB1C104K<br>CK73GB1C104K  | CHIP C<br>CHIP C<br>CHIP C<br>CHIP C<br>CHIP C                                                                 | 0.010UF<br>0.047UF<br>0.10UF<br>0.10UF<br>0.10UF | K<br>K<br>K<br>K<br>K                     |                                                     |
| C71,72<br>C77,78<br>C79,80<br>C85<br>C89  |             |             | CK73GB1H471K<br>CC73GCH1H680J<br>CK73GB1H222K<br>CK73GB1C104K<br>CK73GB1H222K | CHIP C<br>CHIP C<br>CHIP C<br>CHIP C<br>CHIP C                                                                 | 470PF<br>68PF<br>2200PF<br>0.10UF<br>2200PF      | K<br>J<br>K<br>K<br>K                     |                                                     |
| CN1<br>CN1<br>CN2<br>CN2                  |             | *           | E40-9536-05<br>E41-0193-05<br>E40-9339-05<br>E41-0129-05                      | FLAT CABLE CONNECTOR (16p)<br>FLAT CABLE CONNECTOR (16p)<br>FLAT CABLE CONNECTOR (22P)<br>FLAT CABLE CONNECTOR |                                                  |                                           |                                                     |
| X1                                        |             |             | L78-0572-05                                                                   | RESONATOR 16.93MHZ                                                                                             |                                                  |                                           |                                                     |
| CP1<br>CP2<br>R3<br>R5<br>R6              |             | *           | R90-1019-05<br>R90-1014-05<br>RK73GB2A272J<br>RK73GB2A361J<br>RK73GB2A272J    | MULTI-COMP 100<br>MULTI-COMP 100<br>CHIP R<br>CHIP R<br>CHIP R                                                 | 100<br>100<br>2.7K<br>360<br>2.7K                | X2<br>X4<br>J 1/10W<br>J 1/10W<br>J 1/10W |                                                     |
| R9<br>R10,11                              |             |             | RK73FB2B100J<br>RK73GB2A103J                                                  | CHIP R<br>CHIP R                                                                                               | 10<br>10K                                        | J 1/8W<br>J 1/10W                         |                                                     |

A0 : X92-4030-00 (DXM-6000W)    A3 : X92-4030-03 (DXM-6003W)  
A1 : X92-4030-01 (DXM-6001W)    A4 : X92-4030-04 (DXM-6004W)  
A2 : X92-4030-02 (DXM-6002W)    A5 : X92-4030-05 (DXM-6005W)

| Ref. No.                                             | A<br>d<br>d | N<br>e<br>w | Parts No.                                                                    | Description                                              |                                    |                                                     | D<br>e<br>s<br>t<br>i<br>n<br>a<br>t<br>i<br>o<br>n |
|------------------------------------------------------|-------------|-------------|------------------------------------------------------------------------------|----------------------------------------------------------|------------------------------------|-----------------------------------------------------|-----------------------------------------------------|
| R12<br>R15<br>R16<br>R17<br>R18                      |             | *           | RK73GB2A912J<br>RK73GB2A824J<br>RK73GB2A223J<br>RK73GB2A433J<br>RK73GB2A392J | CHIP R<br>CHIP R<br>CHIP R<br>CHIP R<br>CHIP R           | 9.1K<br>820K<br>22K<br>43K<br>3.9K | J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W |                                                     |
| R19<br>R20<br>R21<br>R32<br>R34                      |             | *           | RK73GB2A513J<br>RK73GB2A104J<br>RK73GB2A244J<br>RK73GB2A683J<br>RK73GB2A363J | CHIP R<br>CHIP R<br>CHIP R<br>CHIP R<br>CHIP R           | 51K<br>100K<br>240K<br>68K<br>36K  | J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W |                                                     |
| R36<br>R37<br>R38<br>R40<br>R46                      |             | *           | RK73GB2A151J<br>RK73GB2A471J<br>RK73GB2A224J<br>RK73GB2A133J<br>RK73GB2A102J | CHIP R<br>CHIP R<br>CHIP R<br>CHIP R<br>CHIP R           | 150<br>470<br>220K<br>13K<br>1.0K  | J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W |                                                     |
| R47<br>R49<br>R52<br>R54<br>R70                      |             |             | RK73GB2A103J<br>RK73GB2A472J<br>RK73GB2A104J<br>RK73GB2A104J<br>RK73GB2A103J | CHIP R<br>CHIP R<br>CHIP R<br>CHIP R<br>CHIP R           | 10K<br>4.7K<br>100K<br>100K<br>10K | J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W |                                                     |
| R71<br>R73<br>R74<br>R75<br>R76                      |             | *           | RK73GB2A113J<br>RK73GB2A473J<br>RK73GB2A123J<br>RK73GB2A333J<br>RK73GB2A103J | CHIP R<br>CHIP R<br>CHIP R<br>CHIP R<br>CHIP R           | 11K<br>47K<br>12K<br>33K<br>10K    | J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W |                                                     |
| R79,80<br>R81<br>R82<br>R84<br>R101,102              |             | *           | RK73GB2A103J<br>RK73GB2A333J<br>RK73GB2A133J<br>RK73GB2A103J<br>RK73GB2A332J | CHIP R<br>CHIP R<br>CHIP R<br>CHIP R<br>CHIP R           | 10K<br>33K<br>13K<br>10K<br>3.3K   | J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W |                                                     |
| R103,104<br>R107,108<br>R110<br>R117,118<br>R121,122 |             | *           | RK73GB2A562J<br>RK73FB2B331J<br>RK73FB2B201J<br>RK73FB2B203J<br>RK73FB2B203J | CHIP R<br>CHIP R<br>CHIP R<br>CHIP R<br>CHIP R           | 5.6K<br>330<br>200<br>20K<br>20K   | J 1/10W<br>J 1/8W<br>J 1/8W<br>J 1/8W<br>J 1/8W     |                                                     |
| R125,126<br>R202<br>R214<br>R218<br>R233             |             | *           | RK73FB2B203J<br>RK73GB2A104J<br>RK73GB2A104J<br>RK73GB2A473J<br>RK73GB2A622J | CHIP R<br>CHIP R<br>CHIP R<br>CHIP R<br>CHIP R           | 20K<br>100K<br>100K<br>47K<br>6.2K | J 1/8W<br>J 1/10W<br>J 1/10W<br>J 1/10W<br>J 1/10W  |                                                     |
| R234                                                 |             |             | RK73GB2A103J                                                                 | CHIP R                                                   | 10K                                | J 1/10W                                             |                                                     |
| S1,2<br>S3<br>S4<br>S4                               |             | *           | S68-0863-05<br>S68-0862-05<br>S68-0864-05<br>S68-0864-05                     | PUSH SWITCH<br>PUSH SWITCH<br>PUSH SWITCH<br>PUSH SWITCH |                                    |                                                     | A2A3<br>B2B3                                        |
| D1<br>D2<br>D3<br>D4<br>IC1                          |             |             | DAN202U<br>MA8051-L<br>DA204U<br>DAN202U<br>AN22000AA                        | DIODE<br>ZENER DIODE<br>DIODE<br>DIODE<br>ANALOGUE IC    |                                    |                                                     |                                                     |
| IC2<br>IC2<br>IC2<br>IC2                             |             | *           | MN662773KH2<br>MN662773KH2<br>MN662774KJ2<br>MN662774KJ2                     | MOS-IC<br>MOS-IC<br>MOS-IC<br>MOS-IC                     |                                    |                                                     | B0B1B2<br>B3B4B5<br>A0A1A2<br>A3A4A5                |

B0 : X92-4440-00 (DXM-6100W)    B3 : X92-4440-03 (DXM-6103W)  
B1 : X92-4440-01 (DXM-6101W)    B4 : X92-4440-04 (DXM-6104W)  
B2 : X92-4440-02 (DXM-6102W)    B5 : X92-4440-05 (DXM-6105W)

# PARTS LIST

\* New Parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

| Ref. No.                                            | A<br>d<br>d | N<br>e<br>w | Parts No.   | Description                  | D<br>e<br>s<br>t<br>i<br>n<br>a<br>t<br>i<br>o<br>n |
|-----------------------------------------------------|-------------|-------------|-------------|------------------------------|-----------------------------------------------------|
| IC4                                                 |             | *           | BA5824FP    | ANALOGUE IC                  |                                                     |
| IC6                                                 |             | *           | NJM4580M1   | ANALOGUE IC                  |                                                     |
| Q1                                                  |             |             | MCH6101     | TRANSISTOR                   |                                                     |
| Q2                                                  |             |             | DTC124EUA   | DIGITAL TRANSISTOR           |                                                     |
| Q3                                                  |             |             | DTA143XUA   | DIGITAL TRANSISTOR           |                                                     |
| Q4                                                  |             |             | 2SA1362(Y)  | TRANSISTOR                   |                                                     |
| Q5                                                  |             |             | DTC124EUA   | DIGITAL TRANSISTOR           |                                                     |
| <b>CD MECHANISM ASSY (X92-4030-0x, X92-4440-0x)</b> |             |             |             |                              |                                                     |
| 2                                                   | 1B          | *           | A10-4827-12 | CHASSIS OUTER                |                                                     |
| 5                                                   | 2B          | *           | D10-4576-23 | ARM ASSY CLAMP               |                                                     |
| 8                                                   | 2A          | *           | D10-4579-03 | LEVER ASSY ROLLER            |                                                     |
| 10                                                  | 3A          | *           | D10-4581-13 | ARM DISC-L                   |                                                     |
| 11                                                  | 2A          | *           | D10-4582-13 | ARM DISC-R                   |                                                     |
| 12                                                  | 3A          | *           | D10-4583-03 | ARM JOINT-L                  |                                                     |
| 13                                                  | 3A          | *           | D10-4584-03 | ARM JOINT-R                  |                                                     |
| 14                                                  | 3B          | *           | D10-4585-03 | ARM CARRIER                  |                                                     |
| 15                                                  | 2A          | *           | D10-4586-03 | SLIDER L                     |                                                     |
| 16                                                  | 3B          | *           | D10-4587-02 | SLIDER R                     |                                                     |
| 17                                                  | 3B          | *           | D10-4588-03 | SLIDER TRIG                  |                                                     |
| 18                                                  | 3B          | *           | D10-4595-04 | ARM LOCK                     |                                                     |
| 19                                                  | 3B          | *           | D10-4596-04 | ARM ROLLER                   |                                                     |
| 22                                                  | 2A          | *           | D13-2151-04 | GEAR ROLLER                  |                                                     |
| 23                                                  | 2B          | *           | D13-2152-04 | GEAR HELICAL-1               |                                                     |
| 24                                                  | 3B          | *           | D13-2153-04 | GEAR SUN                     |                                                     |
| 25                                                  | 3B          | *           | D13-2154-04 | GEAR PLANET                  |                                                     |
| 26                                                  | 3B          | *           | D13-2155-04 | WORM 2                       |                                                     |
| 27                                                  | 3B          | *           | D13-2156-04 | GEAR HELICAL-2               |                                                     |
| 28                                                  | 3B          | *           | D13-2157-04 | GEAR LOAD-1                  |                                                     |
| 29                                                  | 3B          | *           | D13-2158-04 | GEAR LOAD-2                  |                                                     |
| 30                                                  | 3B          | *           | D13-2168-04 | GEAR PICK-1                  |                                                     |
| 31                                                  | 3B          | *           | D13-2171-04 | GEAR PICK-2                  |                                                     |
| 32                                                  | 2B          | *           | D13-2172-03 | RACK (GEAR)                  |                                                     |
| 33                                                  | 2A          | *           | D14-0759-04 | ROLLER N100X3DIES            |                                                     |
| 35                                                  | 2B          | *           | D21-2382-04 | SHAFT PICK                   |                                                     |
| 36                                                  | 1A          | *           | D23-0954-04 | RETAINER                     |                                                     |
| 37                                                  | 1B          | *           | D39-0246-05 | DAMPER                       |                                                     |
| 38                                                  | 2B          | *           | G01-3072-04 | EXTENSION SPRING TRIGGER     |                                                     |
| 39                                                  | 2A          | *           | G01-3073-04 | TORSION COIL SPRING ROLLER-L |                                                     |
| 40                                                  | 2A          | *           | G01-3074-04 | EXTENSION SPRING ROLLER-R    |                                                     |
| 41                                                  | 2B          | *           | G01-3075-04 | EXTENSION SPRING PICKUP      |                                                     |
| 42                                                  | 2A          | *           | G01-3076-04 | EXTENSION SPRING JOINT-SP    |                                                     |
| 43                                                  | 1B          | *           | G01-3077-04 | EXTENSION SPRING FLOATING    |                                                     |
| 44                                                  | 2B          | *           | G02-1399-04 | FLAT SPRING CLAMP            |                                                     |
| 45                                                  | 2B          | *           | G02-1408-04 | FLAT SPRING WORM             |                                                     |
| 51                                                  | 1A          | *           | J21-9676-12 | MOUNTING HARDWARE GUIDE-BKT  |                                                     |
| 52                                                  | 3B          | *           | J21-9677-02 | MOUNTING HARDWARE GEAR-BKT   |                                                     |
| 53                                                  | 1B          | *           | J21-9678-03 | MOUNTING HARDWARE DAMPER-BKT |                                                     |
| 55                                                  | 1A          | *           | J90-1001-11 | GUIDE 1                      |                                                     |
| 56                                                  | 1B          | *           | J90-1023-03 | GUIDE 2                      |                                                     |
| DFPC1                                               | 3A          | *           | J84-0128-15 | FLEXIBLE P.W.B. PICK-FPC     |                                                     |
| A                                                   | 2B          | *           | N09-4460-05 | TAPTITE SCREW PT2X8-SARA     |                                                     |
| B                                                   | 1B          | *           | N09-4472-05 | MACHINE SCREW PICK-RACK      |                                                     |

| Ref. No. | A<br>d<br>d | N<br>e<br>w | Parts No.   | Description              | D<br>e<br>s<br>t<br>i<br>n<br>a<br>t<br>i<br>o<br>n |
|----------|-------------|-------------|-------------|--------------------------|-----------------------------------------------------|
| C        | 2B          | *           | N09-6004-05 | MACHINE SCREW M1.7X2.5   |                                                     |
| D        | 1B          | *           | N09-6006-05 | TAPTITE SCREW ST-2X3.5   |                                                     |
| E        | 2B          | *           | N09-6007-05 | MACHINE SCREW M2X2       |                                                     |
| F        | 1A          | *           | N09-6051-05 | TAPTITE SCREW PT2X6-BIND |                                                     |
| G        | 2A          | *           | N19-2163-04 | FLAT WASHER 1.6X0.25     |                                                     |
| H        | 1B          | *           | N39-2020-46 | MACHIN SCREW M2X2        |                                                     |
| DM1      | 3B          | *           | T42-1066-04 | DC MOTOR ASSY SP         |                                                     |
| DM2      | 2B          | *           | T42-1067-04 | DC MOTOR ASSY LO         |                                                     |
| DPU1     | 2B          | *           | T25-0223-05 | OPTICAL PICKUP HEAD      |                                                     |

A0 : X92-4030-00 (DXM-6000W) A3 : X92-4030-03 (DXM-6003W)  
A1 : X92-4030-01 (DXM-6001W) A4 : X92-4030-04 (DXM-6004W)  
A2 : X92-4030-02 (DXM-6002W) A5 : X92-4030-05 (DXM-6005W)

B0 : X92-4440-00 (DXM-6100W) B3 : X92-4440-03 (DXM-6103W)  
B1 : X92-4440-01 (DXM-6101W) B4 : X92-4440-04 (DXM-6104W)  
B2 : X92-4440-02 (DXM-6102W) B5 : X92-4440-05 (DXM-6105W)