


9. EXPLODED VIEWS AND PARTS LIST

NOTES :

- Parts marked by " * " are generally unavailable because they are not in our Master Spare Parts List.
- The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Screw adjacent to ▽ mark on the product are used for disassembly.
- For the applying amount of lubricants or glue, follow the instructions in this manual.
(In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING



(1) PACKING SECTION PARTS LIST

Mark	No.	Description	DMH-340EX/XNUC	DMH-341EX/XNUC	DMH-342EX/XNUC
	1	Cable POWER	1238400031200	1238400031200	1238400031200
	2	*****			
	3	*****			
	4	Screw (Binding Head)	CBA2384	CBA2384	CBA2384
	5	Screw (Flush Surface)	CBA2383	CBA2383	CBA2383
	6	Uninstall Key	Not used	Not used	Not used
*	7	Poly Bag	127060000283	127060000283	127060000283
	8	Unit Box	KB007XNUC-UNITBOX	KB007DXNUC-UNITBOX	KB007BBXNUC-UNITBOX
	9	Contain Box	KB007XNUC-CONTBOX	KB007DXNUC-CONTBOX	KB007BBXNUC-CONTBOX
*	10	Protector	1270150017300	1270150017300	1270150017300
	11	Card Type RC	Not used	CXE9605	CXE9605
	12	Cover	Not used	CNU3681	CNU3681
	13	Cable MIC	1238400031300	1238400031300	1238400031300
	14	USB Extended Cable	1238400031010	1238400031010	1238400031010
	15	*****			
	16-1	Owner's Manual	See Contents of Web IM	See Contents of Web IM	See Contents of Web IM
	16-2	Quick Start Guide	QSG_DMH240EXUC_B	QSG_DMH240EXUC_B	QSG_DMH240EXUC_B
	16-3	Installation Manual	INSTM_DMH240EXUC_A	INSTM_DMH240EXUC_A	INSTM_DMH240EXUC_A
*	16-4	Warranty Card	QRY3001	QRY3001	QRY3001
*	16-5	Caution Card DAB Ant	Not used	Not used	Not used
	17	*****			
	18	*****			
	19	*****			
	20	Cable AV	1238400031100	1238400031100	1238400031100
	21	Panel	Not used	Not used	Not used



Mark	No.	Description	DMH-130BT/XNUC	DMH-A345BT/XECS	DMH-A340DAB/XEEU
	1	Cable POWER	1238400031200	1238400031200	1238400031400
	2	*****			
	3	*****			
	4	Screw (Binding Head)	CBA2384	CBA2384	Not used
	5	Screw (Flush Surface)	CBA2383	Not used	CBA2383
	6	Uninstall Key	Not used	Not used	1210900004900
*	7	Poly Bag	127060000283	127060000283	127060000283
	8	Unit Box	KB007MLXNUC-UNITBOX	1270200029300	1270200029500
	9	Contain Box	KB007MLXNUC-CONTBOX	1270000094100	1270000094300
*	10	Protector	1270150017300	1270150017300	1270150017300
	11	Card Type RC	Not used	CXE9605	Not used
	12	Cover	Not used	CNU3681	Not used
	13	Cable MIC	1238400031300	1238400031300	1238400031300
	14	USB Extended Cable	1238400031010	1238400031010	1238400031010
	15	*****			
	16-1	Owner's Manual	See Contents of Web IM	See Contents of Web IM	See Contents of Web IM
	16-2	Quick Start Guide	QSG_DMH240EXUC_B	1270750040000	1270750039610
	16-3	Installation Manual	INSTM_DMH240EXUC_A	Not used	Not used
*	16-4	Warranty Card	QRY3001	Not used	CYR1241
*	16-5	Caution Card DAB Ant	Not used	Not used	CYR1300
	17	*****			
	18	*****			
	19	*****			
	20	Cable AV	1238400031100	1238400031100	1238400031100
	21	Panel	Not used	Not used	12127000186000

Mark	No.	Description	DMH-A345BT/XEGS	DMH-A345BT/XNGS	DMH-A345BT/XNID
	1	Cable POWER	1238400031200	1238400031200	1238400031200
	2	*****			
	3	*****			
	4	Screw (Binding Head)	CBA2384	CBA2384	CBA2384
	5	Screw (Flush Surface)	Not used	Not used	Not used
	6	Uninstall Key	Not used	Not used	Not used
*	7	Poly Bag	127060000283	127060000283	127060000283
	8	Unit Box	1270200029400	KB007XNGS-UNITBOX	KB007XNID-UNITBOX
	9	Contain Box	1270000094200	KB007XNGS-CONTBOX	KB007XNID-CONTBOX
*	10	Protector	1270150017300	1270150017300	1270150017300
	11	Card Type RC	CXE9605	CXE9605	CXE9605
	12	Cover	CNU3681	CNU3681	CNU3681
	13	Cable MIC	1238400031300	1238400031300	1238400031300
	14	USB Extended Cable	1238400031010	1238400031010	1238400031010
	15	*****			
	16-1	Owner's Manual	See Contents of Web IM	See Contents of Web IM	See Contents of Web IM
	16-2	Quick Start Guide	1270750040900	QSG_DMHA245BTGS_B	QSG_DMHA245BTID_EG_A
	16-3	Installation Manual	Not used	Not used	Not used
*	16-4	Warranty Card	Not used	Not used	CRY1304
*	16-5	Caution Card DAB Ant	Not used	Not used	Not used
	17	*****			
	18	*****			
	19	*****			
	20	Cable AV	1238400031100	1238400031100	1238400031100
	21	Panel	Not used	Not used	CNS9475

CONTENTS OF Web IM

Part No.	Language
OPM_DMH240EXUC_EM_A	(UC model) Spanish (Espanol)
OPM_DMH240EXUC_EN_A	(UC model) English
OPM_DMH240EXUC_FC_A	(UC model) French
OPM_DMHA245BTCSRDEG_A	(CS model) English
OPM_DMHA245BTCSRDEM_A	(CS model) Spanish (Espanol)
OPM_DMHA245BTCSRDPB_A	(CS model) Portuguese (B)
OPM_DMHA240DABEU_DA_B	(EU model) Danish
OPM_DMHA240DABEU_DE_B	(EU model) German
OPM_DMHA240DABEU_EG_B	(EU model) English
OPM_DMHA240DABEU_EL_B	(EU model) Greek
OPM_DMHA240DABEU_ES_B	(EU model) Spanish (Espanol)
OPM_DMHA240DABEU_FI_B	(EU model) Finnish
OPM_DMHA240DABEU_FR_B	(EU model) French
OPM_DMHA240DABEU_IT_B	(EU model) Italian
OPM_DMHA240DABEU_NL_B	(EU model) Dutch
OPM_DMHA240DABEU_NO_B	(EU model) Norwegian
OPM_DMHA240DABEU_PT_B	(EU model) Portuguese
OPM_DMHA240DABEU_SV_B	(EU model) Swedish
OPM_DMHA240DABEU_TR_B	(EU model) Turkish
OPM_DMHA245BTGS_AR_A	(GS model) Arabic
OPM_DMHA245BTGS_EG_A	(GS model) English
OPM_DMHA245BTGS_FA_A	(GS model) Persian
OPM_DMHA245BTGS_ID_A	(GS model) Indonesian
OPM_DMHA245BTGS_RU_A	(GS model) Russian
OPM_DMHA245BTGS_TH_A	(GS model) Thai
OPM_DMHA245BTGS_ZT_A	(GS model) Traditional Chinese
OPM_DMHA245BTID_EG_A	(ID model) English

9.2 EXTERIOR (1)




EXTERIOR (1) SECTION PARTS LIST

Mark	No.	Description	DMH-340EX/XNUC	DMH-341EX/XNUC	DMH-342EX/XNUC
	1	*****			
	2	Plastic Sheet	1214600009900	1214600009900	1214600009900
	3	*****			
	4	Grille	12121000470000	12121000470000	12121000470000
	5	Button (Reset)	12123000586000	12123000586000	12123000586000
	6	Cushion	121405000347	121405000347	121405000347
	7	Cushion	121405000420	121405000420	121405000420
	8	Touch Panel	1234100019900	1234100019900	1234100019900
	9	TFT LCD	1434200010610	1434200010610	1434200010610
	10	Keyboard Unit	FGE2009	FGE2008	FGE2012
*	11	Bracket	*****	*****	*****
*	12	IR IC	*****	*****	*****
	13	*****	*****	*****	*****
	14	*****	*****	*****	*****
	15	Bracket	1210000097400	1210000097400	1210000097400
	16	Screw S2.6-L5	121104070007	121104070007	121104070007
	28	Screw M2.6-L5	121040000222	121040000222	121040000222
	29	FFC Connector	1238200008300	1238200008300	1238200008300
	30	DIN Holder	Not used	Not used	Not used

Mark	No.	Description	DMH-130BT/XNUC	DMH-A345BT/XECS	DMH-A340DAB/XEEU
	1	*****			
	2	Plastic Sheet	1214600009900	1214600009900	1214600009900
	3	*****			
	4	Grille	12121000470000	12121000470000MS	12121000470000MS
	5	Button (Reset)	12123000586000	12123000586000MS	12123000586000MS
	6	Cushion	121405000347	121405000347	121405000347
	7	Cushion	121405000420	121405000420	121405000420
	8	Touch Panel	1234100019900	1234100019900	1234100019900
	9	TFT LCD	1434200010610	1434200010610	1434200010610
	10	Keyboard Unit	FGE2007	840HMS108BKB00S	840HMS108AKB00S
*	11	Bracket	*****	*****	*****
*	12	IR IC	*****	*****	*****
	13	*****	*****	*****	*****
	14	*****	*****	*****	*****
	15	Bracket	1210000097400	1210000097400MS	1210000097400MS
	16	Screw S2.6-L5	121104070007	121104070007	121104070007
	28	Screw M2.6-L5	121040000222	121040000222	121040000222
	29	FFC Connector	1238200008300	1238200008300	1238200008300
	30	DIN Holder	Not used	Not used	1210000097200

Mark	No.	Description	DMH-A345BT/XEGS	DMH-A345BT/XNGS	DMH-A345BT/XNID
	1	*****			
	2	Plastic Sheet	1214600009900	1214600009900	1214600009900
	3	*****			
	4	Grille	12121000470000MS	12121000470000	12121000470000
	5	Button (Reset)	12123000586000MS	12123000586000	12123000586000
	6	Cushion	121405000347	121405000347	121405000347
	7	Cushion	121405000420	121405000420	121405000420
	8	Touch Panel	1234100019900	1234100019900	1234100019900
	9	TFT LCD	1434200010610	1434200010610	1434200010610
	10	Keyboard Unit	840HMS108CKB00S	FGE2010	FGE2011
*	11	Bracket	*****	*****	*****
*	12	IR IC	*****	*****	*****
	13	*****	*****	*****	*****
	14	*****	*****	*****	*****
	15	Bracket	1210000097400MS	1210000097400	1210000097400
	16	Screw S2.6-L5	121104070007	121104070007	121104070007
	28	Screw M2.6-L5	121040000222	121040000222	121040000222
	29	FFC Connector	1238200008300	1238200008300	1238200008300
	30	DIN Holder	Not used	Not used	Not used

9.3 EXTERIOR (2)



EXTERIOR (1) SECTION PARTS LIST

Mark	No.	Description	DMH-340EX/XNUC	DMH-341EX/XNUC	DMH-342EX/XNUC
	17	Screw M2.6-L8	BMZ26P080FTC	BMZ26P080FTC	BMZ26P080FTC
	18	Holder	1210000097000	1210000097000	1210000097000
	19	Mother Unit	FGE1009	FGE1008	FGE1012
*	20	Heat Sink	121410000424	121410000424	121410000424
*	21	Shield Cover	121000025325	121000025325	121000025325
*	22	Shield Case	1210000096800	1210000096800	1210000096800
*	23	Bracket	1210000097100	1210000097100	1210000097100
	24	Frame	1210000096900	1210000096900	1210000096900
	25	Heat Sink	1210100011600	1210100011600	1210100011600
	26	Screw M2.6-L12	BMZ26P120FTC	BMZ26P120FTC	BMZ26P120FTC
	27	Screw M2.6-L8	BMZ26P080FTC	BMZ26P080FTC	BMZ26P080FTC
	31	Power AMP IC	TCB501HQ	TCB501HQ	TCB501HQ
*	32	Connector	*****	*****	*****

Mark	No.	Description	DMH-130BT/XNUC	DMH-A345BT/XECS	DMH-A340DAB/XEEU
	17	Screw P2.6-L8	BMZ26P080FTC	BMZ26P080FTC	BMZ26P080FTC
	18	Holder	1210000097000	1210000097000MS	1210000097000MS
	19	Mother Unit	FGE1007	843HMS108BMB00S	843HMS108AMB00S
*	20	Heat Sink	121410000424	121410000424	121410000424
*	21	Shield Cover	121000025325	121000025325	121000025325
*	22	Shield Case	1210000096800	1210000096800	1210000096800
*	23	Bracket	1210000097100	1210000097100	1210000097100
	24	Frame	1210000096900	1210000096900MS	1210000096900MS
	25	Heat Sink	1210100011600	1210100011600MS	1210100011600MS
	26	Screw P2.6-L12	BMZ26P120FTC	BMZ26P120FTC	BMZ26P120FTC
	27	Screw P2.6-L8	BMZ26P080FTC	BMZ26P080FTC	BMZ26P080FTC
	31	Power AMP IC	TCB501HQ	TCB501HQ	TCB501HQ
*	32	Connector	*****	*****	*****

Mark	No.	Description	DMH-A345BT/XEGS	DMH-A345BT/XNGS	DMH-A345BT/XNID
	17	Screw P2.6-L8	BMZ26P080FTC	BMZ26P080FTC	BMZ26P080FTC
	18	Holder	1210000097000MS	1210000097000	1210000097000
	19	Mother Unit	843HMS108CMB00S	FGE1010	FGE1011
*	20	Heat Sink	121410000424	121410000424	121410000424
*	21	Shield Cover	121000025325	121000025325	121000025325
*	22	Shield Case	1210000096800	1210000096800	1210000096800
*	23	Bracket	1210000097100	1210000097100	1210000097100
	24	Frame	1210000096900MS	1210000096900	1210000096900
	25	Heat Sink	1210100011600MS	1210100011600	1210100011600
	26	Screw P2.6-L12	BMZ26P120FTC	BMZ26P120FTC	BMZ26P120FTC
	27	Screw P2.6-L8	BMZ26P080FTC	BMZ26P080FTC	BMZ26P080FTC
	31	Power AMP IC	TCB501HQ	TCB501HQ	TCB501HQ
*	32	Connector	*****	*****	*****