

SAFETY INFORMATION

WARNING

- A
- This service manual is intended for use by qualified service technicians and is not intended for the do-it-yourselfer. Qualified technicians have the necessary training, experience, and test and safety equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual. Servicing this product is not like changing a battery; **attempting repair or servicing without the required skill, experience, tools and equipment could result in serious personal injury including burns, punctures and electric shock.** Additionally, improper or faulty repair could compromise the safety and reliability of the product and of the vehicle into which it is installed.

Possessing this manual is not the same as being qualified to follow it. IF YOU ARE NOT QUALIFIED TO PERFORM A REPAIR PROPERLY AND SAFELY, DO NOT RISK IT. REFER THE REPAIR TO A QUALIFIED SERVICE TECHNICIAN OF YOUR CHOICE IN ORDER TO PROTECT THE PRODUCT, YOUR VEHICLE, AND ESPECIALLY YOURSELF.

B

SERVICE PRECAUTIONS

-
- Carefully follow all cautions and warnings in this Service Precautions section and elsewhere in the manual.
 - Ensure that repairs follow applicable regulations including those relating to safety and radio interference.
 - Be careful in handling metal parts. There might be internal sharp edges or burrs.
 - Handle, store and dispose of any solution used to clean components with care: wear protective gloves, keep the solution away from flames and work in a well-ventilated area.

C

EXPLODED VIEWS AND PARTS LIST

PACKING (Page 15)

PACKING SECTION PARTS LIST

D

Mark	No.	Description	DMH-160BT/XNUC	DMH-160BT-II/XNUS
*	1	Unit Box	KB010MLXNUC-UNITBOX	KB010WMXNUSUNITBOX_A
	2	Contain Box	KB010MLXNUC-CONTBOX (1/4)	KB010WMXNUSCONTBOX_A (1/4)
	16-1	Quick Start Guide	QSG_DMH1700NEXUC_A	QSG_DMH160BTIIUS_A
	16-2	Installation Manual	INSTM_DMH1700NEXUC_A	INSTM_DMH160BTIIUS_A
	16-3	Warranty Card	QRY3001	Not used
	16-4	Owner's Manual	OWN_DMH160BTUC_A	OWM_DMH160BTIIUS_A

Owner's Manual, Quick Start Guide, Installation Manual

E

Part No.	Language
OWM-DMH160BTIIUS_A	English, French, Spanish(Espanol)
QSG_DMH160BTIIUS_A	English, French, Spanish(Espanol)
INSTM_DMH160BTIIUS_A	English, French, Spanish(Espanol)

F

EXTERIOR (Page 18)

EXTERIOR SECTION PARTS LIST

Mark	No.	Description	DMH-160BT/XNUC	DMH-160BT-II/XNUS
	6	Touch Panel	2401602000219	2401602000288
	18	Bracket	2440301000765	2440301000865
	22	Screw	BMZ26P120FTC (x3)	BMZ26P120FTC (x2)
	31	Screw	Not used	2490304000136

