



EXPLODED VIEW (MECHANISM)



EXPLODED VIEW (UNIT)



PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
KDC-X679					
201	1C	*	A02-2732-03	PLASTIC CABINET ASSY	
205	3C	*	A22-3023-12	SUB PANEL ASSY	
206	2C	*	A46-1798-01	REAR COVER	
207	1D	*	A52-0845-12	TOP PLATE	
PA1	3C	*	A64-3212-12	PANEL ASSY	
PME1	3D	*	A10-5112-12	CHASSIS ASSY	
RM1	1C	*	A70-2059-05	REMOTE CONTROLLER ASSY (RC-505)	
-			B46-0100-50	WARRANTY CARD	
-			B46-0606-04	ID CARD	
-		*	B46-0648-13	USER CARD	
-		*	B64-2764-00	INSTRUCTION MANUAL (ENGLISH)	
-		*	B64-2765-00	INSTRUCTION MANUAL (FRE.SPA.)	
210	1C		B07-3083-02	ESCUTCHEON	
211	2C	*	B07-3095-02	ESCUTCHEON	
212	3C	*	B10-4509-04	FRONT GLASS	
213	3C	*	B10-4502-01	FRONT GLASS	
214	3C	*	B19-2245-04	LIGHTING BOARD	
215	3C		B43-1518-04	BADGE	
216	1C		D10-4589-04	LEVER	
217	3D	*	D10-4799-13	SLIDER ASSY	
219	3C	*	D10-4805-03	LEVER	
220	3C	*	D10-4806-03	LEVER	
222	3C	*	D10-4807-13	LEVER	
223	2D	*	D13-2318-13	RACK (GEAR)	
225	2D	*	D13-2320-04	GEAR	
226	2D	*	D13-2321-04	GEAR	
227	3C	*	D21-2442-04	SHAFT	
228	3C	*	D21-2443-04	SHAFT	
230	3C	*	E29-1970-03	CONDUCTIVE RUBBER	
232	1D	*	E30-6290-05	CORD WITH PINPLUG	
△ DC1	1C	*	E30-6294-05	DC CORD	
FC1	1D	*	E39-0666-05	FLAT CABLE (24P)	
238	1D		F29-0626-04	INSULATING COVER	
△ F1	2D		F52-0006-05	FUSE (MINI BLADE TYPE) 10A	
240	3C	*	G01-3210-04	TORSION COIL SPRING	
241	3C	*	G01-3211-04	TORSION COIL SPRING	
242	3C	*	G01-3212-04	TORSION COIL SPRING	
243	3C	*	G01-3213-04	COMPRESSION SPRING	
244	3D	*	G01-3215-04	EXTENSION SPRING	
248	3D	*	G11-3564-04	CUSHION	
249	3C	*	G11-3573-04	CUSHION	
252	3D	*	G16-1482-14	SHEET	
253	3D	*	G16-1483-04	SHEET	
-		*	H10-4890-02	POLYSTYRENE FOAMED FIXTURE	
-			H25-0329-04	PROTECTION BAG (280X450X0.03)	
-			H25-0337-04	PROTECTION BAG (180X300X0.03)	
-		*	H54-3092-03	ITEM CARTON CASE	
257	3C	*	J19-5273-02	HOLDER	
258	1C		J21-9716-03	MOUNTING HARDWARE ASSY	
260	3C	*	J22-0114-03	MOUNTING HARDWARE ASSY	
261	3D	*	J22-0117-02	MOUNTING HARDWARE	

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
264	3D	*	J31-1062-04	COLLAR	
266	3C	*	K24-4104-03	KNOB (RELEASE)	
267	3C	*	K24-4128-03	KNOB (SRC)	
268	3C	*	K24-4129-03	KNOB (EJECT)	
269	3C	*	K25-1600-02	KNOB (1-4,AUTO)	
270	3C	*	K25-1640-02	KNOB (5-6,DISP)	
271	2C	*	K29-7084-03	KNOB BASE (VOL)	
272	3C	*	K29-7085-03	KNOB BASE (FM/AM)	
273	2C	*	K29-7086-03	KEY TOP (VOL)	
274	3C	*	K29-7087-03	KEY TOP (FM/AM)	
275	1C		N99-1723-05	SCREW SET	
A	3D	*	N09-6139-05	STEPPED SCREW (M2X2)	
B	3D	*	N09-6140-05	STEPPED SCREW (M1.7X2)	
C	3D	*	N09-6141-05	STEPPED SCREW (M2X2)	
D	3D	*	N09-6142-05	MACHINE SCREW (M2X2.5)	
E	3C	*	N09-6190-05	TAPPING SCREW (1.7X4.5)	
F	1C	*	N09-6212-05	TAPPING SCREW (2X5)	
G	2D	*	N19-2184-04	FLAT WASHER (1.6X4.0X0.25)	
H	3C	*	N19-2193-04	FLAT WASHER (1.2X3.0X0.25)	
J	2D		N24-3015-60	E TYPE RETAINING RING	
L	3C	*	N78-2660-45	PAN HEAD TAPTITE SCREW	
M	3C		N80-2006-46	PAN HEAD TAPTITE SCREW	
N	2C		N80-2008-45	PAN HEAD TAPTITE SCREW	
P	1D		N83-3005-46	PAN HEAD TAPTITE SCREW	
Q	2D		N83-3008-46	PAN HEAD TAPTITE SCREW	
R	3C		N86-2004-45	BINDING HEAD TAPTITE SCREW	
PM1	3D	*	T42-1086-14	MOTOR ASSY	
DME1	1D	*	X92-4910-00	CD MECHANISM ASSY	
SUB-CIRCUIT UNIT (X16-2510-10)					
D1-12			B30-1605-05	LED (2COLOR PG/RED)	
D13-18		*	B30-1695-05	LED (1608 BLUE K,L)	
D19			B30-1566-05	LED (1608,RED)	
C1,2			CK73GB0J105K	CHIP C 1.0UF K	
C3			CK73GB1H103K	CHIP C 0.010UF K	
C4,5			CK73GB0J105K	CHIP C 1.0UF K	
C6,7			CK73GB1H103K	CHIP C 0.010UF K	
C8			CK73GB0J105K	CHIP C 1.0UF K	
C9			CK73GB1H472K	CHIP C 4700PF K	
C10			CK73GB1H103K	CHIP C 0.010UF K	
C11			CK73GB0J105K	CHIP C 1.0UF K	
C13-20			CK73GB1H103K	CHIP C 0.010UF K	
C21			CK73GB1H104K	CHIP C 0.10UF K	
J1		*	E59-0839-05	RECTANGULAR PLUG	
281	2C	*	F20-2285-14	INSULATING SHEET	
L1			L40-1005-68	SMALL FIXED INDUCTOR	
L2			L40-4795-68	SMALL FIXED INDUCTOR (4.7UH)	
X1			L78-0858-05	RESONATOR	
CP2			RK74HB1J473J	CHIP-COM 47K J 1/16W	
CP3			RK74HB1J101J	CHIP-COM 100 J 1/16W	
CP4			RK74HB1J473J	CHIP-COM 47K J 1/16W	

K : North America

△ Indicates safety critical components.

PARTS LIST

* New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
CP5			RK74HB1J102J	CHIP-COM 1.0K J 1/16W	
CP6			RK74GA1J473J	CHIP-COM 47K J 1/16W	
CP7			RK74GA1J101J	CHIP-COM 100 J 1/16W	
CP8		*	RK74GA1J471J	CHIP-COM 470 J 1/16W	
CP9			RK74HB1J101J	CHIP-COM 100 J 1/16W	
CP10,11			RK74HB1J102J	CHIP-COM 1.0K J 1/16W	
CP12			RK74HB1J473J	CHIP-COM 47K J 1/16W	
CP14			RK74GA1J102J	CHIP-COM 1.0K J 1/16W	
R1			RK73EB2E101J	CHIP R 100 J 1/4W	
R2			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R3-7			RK73EB2E101J	CHIP R 100 J 1/4W	
R8			RK73GB2A471J	CHIP R 470 J 1/10W	
R9			RK73GB2A473J	CHIP R 47K J 1/10W	
R10			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R11			RK73GB2A103J	CHIP R 10K J 1/10W	
R12			RK73GB2A473J	CHIP R 47K J 1/10W	
R13			RK73GB2A103J	CHIP R 10K J 1/10W	
R14			RK73GB2A473J	CHIP R 47K J 1/10W	
R15			RK73GB2A471J	CHIP R 470 J 1/10W	
R16			RK73GB2A103J	CHIP R 10K J 1/10W	
R17			RK73GB2A471J	CHIP R 470 J 1/10W	
R18			RK73GB2A473J	CHIP R 47K J 1/10W	
R19			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R20			RK73GB2A101J	CHIP R 100 J 1/10W	
R21			RK73GB2A104J	CHIP R 100K J 1/10W	
R23			RK73GB2A104J	CHIP R 100K J 1/10W	
R24-26			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R27,28		*	RK73EB2E160J	CHIP R 16 J 1/4W	
R29			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R34			RK73GB2A104J	CHIP R 100K J 1/10W	
R35,36			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R37			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R38			RK73GB2A220J	CHIP R 22 J 1/10W	
R39			RK73FB2B391J	CHIP R 390 J 1/8W	
R42			RK73FB2B391J	CHIP R 390 J 1/8W	
R43			RK73FB2B241J	CHIP R 240 J 1/8W	
R44			RK73FB2B391J	CHIP R 390 J 1/8W	
R46			RK73FB2B391J	CHIP R 390 J 1/8W	
R50			RK73FB2B271J	CHIP R 270 J 1/8W	
R53,54			RK73FB2B271J	CHIP R 270 J 1/8W	
R60			RK73GB2A473J	CHIP R 47K J 1/10W	
R903			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R904,905			RK73GB2A103J	CHIP R 10K J 1/10W	
R906			RK73GB2A102J	CHIP R 1.0K J 1/10W	
S1,2			S70-0901-05	TACT SWITCH	
S25		*	S70-0920-05	TACT SWITCH	
S24		*	T99-0450-05	ROTARY ENCODER	
D901			DA204U	DIODE	
ED1		*	CN2100M	FLUORESCENT INDICATOR TUBE	
IC1		*	30622MWP111GP	MICROCONTROLLER IC	
IC2		*	TAR5S33-F	ANALOGUE IC	
IC3		*	RS-171	ANALOGUE IC	
IC4			TC74HC4050AFT	MOS-IC	

SUB-CIRCUIT UNIT (X16-2510-10)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
Q1		*	2SC4667-F	TRANSISTOR	
Q2		*	2SC2713-F	TRANSISTOR	
Q3		*	2SA1163-F	TRANSISTOR	
Q4			DTA114EE	DIGITAL TRANSISTOR	
Q4		*	PDTA114EE	TRANSISTOR	
Q6			DTC143ZUA	DIGITAL TRANSISTOR	
Q7,8			DTA144EE	DIGITAL TRANSISTOR	
Q7,8		*	PDTA144EE	TRANSISTOR	
Q9,10			DTC143ZUA	DIGITAL TRANSISTOR	
Q11			DTA144EE	DIGITAL TRANSISTOR	
Q11		*	PDTA144EE	TRANSISTOR	
Q12			DTC143ZUA	DIGITAL TRANSISTOR	
SUB-CIRCUIT UNIT (X16-2570-10)					
J1		*	E58-0982-05	RECTANGULAR RECEPTACLE	
283	3C	*	F20-2284-14	INSULATING SHEET	
FPC1	3C	*	J86-0003-05	FPC (LEAD FREE)	
CD PLAYER UNIT (X32-5560-00)					
C5			CK73GB1C104K	CHIP C 0.10UF K	
C6			CK73GB1H103K	CHIP C 0.010UF K	
C7			CK73FB1A225K	CHIP C 2.2UF K	
C10-15			CK73GB1C104K	CHIP C 0.10UF K	
C16			CK73FB1A225K	CHIP C 2.2UF K	
C17,18			CK73GB1C104K	CHIP C 0.10UF K	
C19			CK73FB1A225K	CHIP C 2.2UF K	
C20			CK73GB1C104K	CHIP C 0.10UF K	
C21			CK73GB1H102K	CHIP C 1000PF K	
C25-27			CK73GB1C104K	CHIP C 0.10UF K	
C28			CK73FB0J106M	CHIP C 10UF M	
C29			CK73GB1C104K	CHIP C 0.10UF K	
C30			CK73GB1H152K	CHIP C 1500PF K	
C31			CC73GCH1H470J	CHIP C 47PF J	
C33			CK73GB1C104K	CHIP C 0.10UF K	
C34			CC73GCH1H560J	CHIP C 56PF J	
C35			CK73GB1C104K	CHIP C 0.10UF K	
C37			CK73GB1H102K	CHIP C 1000PF K	
C38			CK73GB1H682K	CHIP C 6800PF K	
C39			CK73GB1C104K	CHIP C 0.10UF K	
C41			CK73GB1A334K	CHIP C 0.33UF K	
C42-44			CK73GB1C104K	CHIP C 0.10UF K	
C46			CK73GB1H682K	CHIP C 6800PF K	
C47			CK73GB1C104K	CHIP C 0.10UF K	
C48			CC73GCH1H040C	CHIP C 4.0PF C	
C49			CK73GB1H332K	CHIP C 3300PF K	
C50			CK73GB1C104K	CHIP C 0.10UF K	
C51			CC73GCH1H330J	CHIP C 33PF J	
C52,53			CK73FB1A225K	CHIP C 2.2UF K	
C54,55			CK73GB1H103K	CHIP C 0.010UF K	
C56,57			CK73GB1H331K	CHIP C 330PF K	
C58			CK73GB1H472K	CHIP C 4700PF K	
C59-63			CK73GB1H152K	CHIP C 1500PF K	
C64			CK73GB1C104K	CHIP C 0.10UF K	
C66,67			CC73GCH1H100D	CHIP C 10PF D	

K : North America

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

CD PLAYER UNIT (X32-5560-00)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation	Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
C68			CK73GB0J105K	CHIP C 1.0UF K		R36			RK73FB2B4R7J	CHIP R 4.7 J 1/8W	
C69-71			CK73GB1C104K	CHIP C 0.10UF K		R37			RK73GB2A103J	CHIP R 10K J 1/10W	
C72			CK73FB1A225K	CHIP C 2.2UF K		R40			RK73GB2A274J	CHIP R 270K J 1/10W	
C74			CK73FB0J475K	CHIP C 4.7UF K		R42			RK73GB2A101J	CHIP R 100 J 1/10W	
C75			CC73GCH1H221J	CHIP C 220PF J		R43			RK73GB2A393J	CHIP R 39K J 1/10W	
C78-80			CC73GCH1H221J	CHIP C 220PF J		R44,45			RK73GB2A302J	CHIP R 3.0K J 1/10W	
C81-84			CC73GCH1H102J	CHIP C 1000PF J		R46			RK73GB2A105J	CHIP R 1.0M J 1/10W	
C86			CK73GB1A105K	CHIP C 1.0UF K		R47			RK73GB2A104J	CHIP R 100K J 1/10W	
C87			CK73FB0J475K	CHIP C 4.7UF K		R48,49			RK73GB2A331J	CHIP R 330 J 1/10W	
C89			CK73GB1H103K	CHIP C 0.010UF K		R50			RK73GB2A101J	CHIP R 100 J 1/10W	
C90			CK73GB1H102K	CHIP C 1000PF K		R51			RK73GB2A392J	CHIP R 3.9K J 1/10W	
C91			CC73GCH1H102J	CHIP C 1000PF J		R52			RK73GB2A163J	CHIP R 16K J 1/10W	
C92			CK73FB0J475K	CHIP C 4.7UF K		R53			RK73GB2A123J	CHIP R 12K J 1/10W	
C93,94			CK73GB1H103K	CHIP C 0.010UF K		R54			RK73GB2A333J	CHIP R 33K J 1/10W	
C95,96			CK73GB1C104K	CHIP C 0.10UF K		R55			RK73GB2A103J	CHIP R 10K J 1/10W	
C97			CK73GB0J105K	CHIP C 1.0UF K		R56			RK73GB2A123J	CHIP R 12K J 1/10W	
C98			CK73FB1A225K	CHIP C 2.2UF K		R57,58			RK73GB2A133J	CHIP R 13K J 1/10W	
C99			CC73GCH1H121J	CHIP C 120PF J		R59			RK73GB2A472J	CHIP R 4.7K J 1/10W	
C100			CC73GCH1H050C	CHIP C 5.0PF C		R60			RK73GB2A123J	CHIP R 12K J 1/10W	
C101			CK73GB1H102K	CHIP C 1000PF K		R61			RK73GB2A183J	CHIP R 18K J 1/10W	
CN1		*	E41-2083-05	FLAT CABLE CONNECTOR		R62			RK73GB2A432J	CHIP R 4.3K J 1/10W	
CN2			E41-2068-05	FLAT CABLE CONNECTOR		R63			RK73GB2A133J	CHIP R 13K J 1/10W	
CN2			E41-2085-05	FLAT CABLE CONNECTOR		R64			RK73GB2A241J	CHIP R 240 J 1/10W	
X1		*	L77-2863-05	CRYSTAL RESONATOR (16.899M)		R65			RK73GB2A104J	CHIP R 100K J 1/10W	
X2		*	L78-0896-05	RESONATOR (16.00MHZ)		R68			RK73GB2A104J	CHIP R 100K J 1/10W	
CP1			RK74GA1J104J	CHIP-COM 100K J 1/16W		R70			RK73GB2A102J	CHIP R 1.0K J 1/10W	
CP2,3			RK74GA1J101J	CHIP-COM 100 J 1/16W		R71-73			RK73GB2A101J	CHIP R 100 J 1/10W	
CP4			RK74GA1J103J	CHIP-COM 10K J 1/16W		R108-110	*		RK73GH2A392D	CHIP R 3.9K D 1/10W	
CP5			RK74GA1J102J	CHIP-COM 1.0K J 1/16W		R111,112	*		RK73GH2A562D	CHIP R 5.6K D 1/10W	
CP7			RK74GB1J102J	CHIP-COM 1.0K J 1/16W		R113	*		RK73GH2A392D	CHIP R 3.9K D 1/10W	
CP10			RK74GB1J103J	CHIP-COM 10K J 1/16W		R114	*		RK73GH2A562D	CHIP R 5.6K D 1/10W	
CP11			RK74GB1J472J	CHIP-COM 4.7K J 1/16W		R115	*		RK73GH2A392D	CHIP R 3.9K D 1/10W	
CP12			RK74GA1J104J	CHIP-COM 100K J 1/16W		R116	*		RK73GH2A562D	CHIP R 5.6K D 1/10W	
CP13,14			RK74GB1J104J	CHIP-COM 100K J 1/16W		R117	*		RK73GH2A392D	CHIP R 3.9K D 1/10W	
CP15			RK74GA1J104J	CHIP-COM 100K J 1/16W		R118,119	*		RK73GH2A100D	CHIP R 10 D 1/10W	
CP16		*	RK74GB1J222J	CHIP-COM 2.2K J 1/16W		R120,121	*		RK73GH2A392D	CHIP R 3.9K D 1/10W	
CP17			RK74GA1J102J	CHIP-COM 1.0K J 1/16W		R122	*		RK73GH2A202D	CHIP R 2.0K D 1/10W	
CP18			RK74GA1J104J	CHIP-COM 100K J 1/16W		R123	*		RK73GH2A681D	CHIP R 680 D 1/10W	
CP19,20			RK74GB1J104J	CHIP-COM 100K J 1/16W		R124			RK73GB2A680J	CHIP R 68 J 1/10W	
R2			R92-3494-05	CHIP R 5.6 F 1/2W		R128,129			RK73GB2A101J	CHIP R 100 J 1/10W	
R5			RK73GB2A101J	CHIP R 100 J 1/10W		R130			RK73GB2A221J	CHIP R 220 J 1/10W	
R6		*	RK73GH2A223D	CHIP R 22K D 1/10W		R132,133			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R8		*	RK73GH2A393D	CHIP R 39K D 1/10W		R134	*		RK73GH2A202D	CHIP R 2.0K D 1/10W	
R9			RK73GB2A104J	CHIP R 100K J 1/10W		R135	*		RK73GH2A681D	CHIP R 680 D 1/10W	
R10			RK73GB2A101J	CHIP R 100 J 1/10W		R136			RK73EB2E220J	CHIP R 22 J 1/4W	
R11,12			RK73GB2A104J	CHIP R 100K J 1/10W		R137			RK73GB2A680J	CHIP R 68 J 1/10W	
R13			RK73GB2A102J	CHIP R 1.0K J 1/10W		R138			RK73GB2A470J	CHIP R 47 J 1/10W	
R18			RK73GB2A101J	CHIP R 100 J 1/10W		R139-141	*		RK73GH2A151D	CHIP R 150 D 1/10W	
R21,22			RK73GB2A103J	CHIP R 10K J 1/10W		R142			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	
R27			RK73GB2A104J	CHIP R 100K J 1/10W		R143			RK73GB2A104J	CHIP R 100K J 1/10W	
R28			RK73GB2A103J	CHIP R 10K J 1/10W		R144			RK73GB2A103J	CHIP R 10K J 1/10W	
R29			RK73GB2A102J	CHIP R 1.0K J 1/10W		R145	*		RK73GH2A330D	CHIP R 33 D 1/10W	
R34			RK73GB2A472J	CHIP R 4.7K J 1/10W		R146,147			RK73GB2A101J	CHIP R 100 J 1/10W	
R35			RK73GB2A104J	CHIP R 100K J 1/10W		R148			RK73GB2A562J	CHIP R 5.6K J 1/10W	
						R149			RK73GB2A104J	CHIP R 100K J 1/10W	

K : North America

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

CD PLAYER UNIT (X32-5560-00)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
R151 R152 W10			RK73GB2A104J RK73GB2A472J R92-1252-05	CHIP R 100K J 1/10W CHIP R 4.7K J 1/10W CHIP R 0 OHM J 1/16W	
S1,2 S3			S68-0863-05 S68-0862-05	PUSH SWITCH PUSH SWITCH	
D2 D3 D4,5 IC1 IC2		*	DA204UF DAN202UF MAZS0510L 91CW12AFG-4VF6 UPD63712GC	DIODE DIODE ZENER DIODE MICROCONTROLLER IC MOS-IC	
IC3 IC4 IC5 IC5 IC10		*	TC94A20F-010 BA5824FP-F NJM2880U133 NJM2880U33 PCM1793DB	MOS-IC ANALOGUE IC ANALOGUE IC ANALOGUE IC MOS-IC	
IC13 IC14 IC15 Q1 Q3		*	NJM4580V-LF TAR5S50-F NJM2890R3325 2SK3018F UMD9N	ANALOGUE IC ANALOGUE IC ANALOGUE IC FET TRANSISTOR	
Q4 Q5 Q6 Q7 Q8		*	2SK3018F UMD9N UMD12N DTC124EUAF 2SB0970	FET TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR	
Q9,10 Q11,12			DTC114YUAF 2SB0970	DIGITAL TRANSISTOR TRANSISTOR	

ELECTRIC UNIT (X34-3000-10)

D302			B30-1566-05	LED (1608,RED)	
C1 C2 C3 C4 C5		*	C90-5626-05 CK73GB1H103K C90-5692-05 CK73GB1H103K CE32CL1C100M	ELECTRO 3900UF 16WV CHIP C 0.010UF K ELECTRO 220UF 16WV CHIP C 0.010UF K CHIP EL 10UF 16WV	
C6 C7 C8 C9 C10		*	CD04AS0J101M CD04BE1J820M CK73FB1C105K CD04AT1A221M CK73GB1A474K	ELECTRO 100UF 6.3WV ELECTRO 82UF 63WV CHIP C 1.0UF K ELECTRO 220UF 10WV CHIP C 0.47UF K	
C11 C12 C13 C14 C16		*	CD04AT1A101M CK73GB1A474K CD04AT1A101M CD04BF1E101M CD04BF1C101M	ELECTRO 100UF 10WV CHIP C 0.47UF K ELECTRO 100UF 10WV ELECTRO 100UF 25WV ELECTRO 100UF 16WV	
C17 C18 C19 C20 C21		*	C90-5680-05 CK73FB1C334K CK73EB1C225K CK73GB1H103K C94-0151-05	ELECTRO 100UF 16WV CHIP C 0.33UF K CHIP C 2.2UF K CHIP C 0.010UF K ELECTRO 100UF 16WV	
C23 C101 C102 C103-106		*	C90-5680-05 CD04AS1E4R7M CD04BF1C101M CK73EB1C225K	ELECTRO 100UF 16WV ELECTRO 4.7UF 25WV ELECTRO 100UF 16WV CHIP C 2.2UF K	

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
C107 C108 C109 C110,111 C112		*	CD04AS1C220M CK73GB1E223K CK73GB1H103K CK73EB1C225K CD04BA1H3R3M	ELECTRO 22UF 16WV CHIP C 0.022UF K CHIP C 0.010UF K CHIP C 2.2UF K ELECTRO 3.3UF 50WV	
C113 C114 C115 C116 C117		*	CK73GB0J105K CD04BA1H0R1M CK73GB1H103K CK73GB1E223K CK73FB1C105K	CHIP C 1.0UF K ELECTRO 0.1UF 50WV CHIP C 0.010UF K CHIP C 0.022UF K CHIP C 1.0UF K	
C118 C119 C120,121 C201 C202			CK73GB1H103K CK73GB1H102K CK73GB1H103K CC73GCH1H220J CK73GB1H104K	CHIP C 0.010UF K CHIP C 1000PF K CHIP C 0.010UF K CHIP C 22PF J CHIP C 0.10UF K	
C203 C204-206 C207 C208 C209			CC73GCH1H270J CK73GB1H103K CD04AS0J470M CK73GB1H102K CK73GB1H103K	CHIP C 27PF J CHIP C 0.010UF K ELECTRO 47UF 6.3WV CHIP C 1000PF K CHIP C 0.010UF K	
C301,302 C303 C314-316 C317 C318			CK73GB1H103K CK73FB1C105K CK73GB1C104K CC73GCH1H220J CK73FB1C105K	CHIP C 0.010UF K CHIP C 1.0UF K CHIP C 0.10UF K CHIP C 22PF J CHIP C 1.0UF K	
C319 C320,321 C401,402 C403,404 C405,406		*	CD04AS1E4R7M CK73GB1H103K CE32CL1C100M CD04AS1C220M CE32CL1C100M	ELECTRO 4.7UF 25WV CHIP C 0.010UF K CHIP EL 10UF 16WV ELECTRO 22UF 16WV CHIP EL 10UF 16WV	
C407,408 C409,410 C411,412 C435-438 C439		*	CD04AS1C220M CE32CL1C100M CD04AS1C220M CK73GB1C104K CK73FB1C334K	ELECTRO 22UF 16WV CHIP EL 10UF 16WV ELECTRO 22UF 16WV CHIP C 0.10UF K CHIP C 0.33UF K	
C440 C441 C442 C443 C444			CK73GB1A334K CK73FB1C334K CK73GB1A334K CK73FB1C334K CK73GB1A334K	CHIP C 0.33UF K CHIP C 0.33UF K CHIP C 0.33UF K CHIP C 0.33UF K CHIP C 0.33UF K	
C445 C446 C447 C448 C449		*	CK73FB1C334K CK73GB1A334K C92-1883-05 CK73GB1H103K CD04AS1C470M	CHIP C 0.33UF K CHIP C 0.33UF K ELECTRO 1UF 50WV CHIP C 0.010UF K ELECTRO 47UF 16WV	
C453,454 C455 C456 C457,458 C461		*	CD04AS1H3R3M CK73GB1A474K CC73GCH1H221J CK73GB1C104K CK73GB1H103K	ELECTRO 3.3UF 50WV CHIP C 0.47UF K CHIP C 220PF J CHIP C 0.10UF K CHIP C 0.010UF K	
C462-465 C466-469 C470,471 C476,477 C478		*	CK73FB1C105K CK73FB1A225K CK73FB1C105K CK73FB1C105K C92-1884-05	CHIP C 1.0UF K CHIP C 2.2UF K CHIP C 1.0UF K CHIP C 1.0UF K ELECTRO 2.2UF 50WV	

K : North America

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X34-3000-10)

Ref. No.	Add	New	Parts No.	Description	Destination	Ref. No.	Add	New	Parts No.	Description	Destination
C479,480 C481-485 C501-506 C509 C510			CD04AS1HR47M CK73FB1C105K CK73GB1H222K CK73FB1C105K CK73FB1C474K	ELECTRO 0.47UF 50WV CHIP C 1.0UF K CHIP C 2200PF K CHIP C 1.0UF K CHIP C 0.47UF K		R11 R12 R14 R15,16 R101			RK73GB2A102J RK73FB2B751J RK73GB2A473J RK73GB2A104J RK73EB2E102J	CHIP R 1.0K J 1/10W CHIP R 750 J 1/8W CHIP R 47K J 1/10W CHIP R 100K J 1/10W CHIP R 1.0K J 1/4W	
C511 C512 C513 C514 C515			CD04AS0J470M CK73FB1C474K CK73GB1H103K CK73FB1C105K CD04AS1C330M	ELECTRO 47UF 6.3WV CHIP C 0.47UF K CHIP C 0.010UF K CHIP C 1.0UF K ELECTRO 33UF 16WV		R102,103 R104 R105 R106 R107			RK73EB2E103J RK73GB2A102J RK73GB2A750J RK73GB2A272J RK73GB2A470J	CHIP R 10K J 1/4W CHIP R 1.0K J 1/10W CHIP R 75 J 1/10W CHIP R 2.7K J 1/10W CHIP R 47 J 1/10W	
C516-519 C520 C521,522 C523,524			C90-5620-05 CK73FB1C105K CD04BA1H010M CK73FB1C105K	ELECTRO 0.47UF 50WV CHIP C 1.0UF K ELECTRO 1UF 50WV CHIP C 1.0UF K		R108 R109 R110 R111 R112			RK73GB2A752J RK73GB2A274J RK73GB2A563J RK73GB2A470J RK73GB2A103J	CHIP R 7.5K J 1/10W CHIP R 270K J 1/10W CHIP R 56K J 1/10W CHIP R 47 J 1/10W CHIP R 10K J 1/10W	
CN2 CN3 CN5 CN6 CN7		*	E41-2083-05 E41-2101-05 E41-2123-05 E41-0956-05 E41-0944-05	FLAT CABLE CONNECTOR FLAT CABLE CONNECTOR PIN ASSY PIN ASSY PIN ASSY		R113,114 R115 R116,117 R118 R119		*	RK73GB2A913J RK73FB2B472J R92-5024-05 RK73GB2A223J RK73FB2B472J	CHIP R 91K J 1/10W CHIP R 4.7K J 1/8W CHIP R 1.0K J 3/4W CHIP R 22K J 1/10W CHIP R 4.7K J 1/8W	
△ J1 J2 J3 W3		*	E58-0991-05 E56-0855-05 E63-0897-05 E30-6218-05	RECTANGULAR RECEPTACLE CYLINDRICAL RECEPTACLE PIN JACK CORD WITH PLUG		R120 R121 R122 R123 R124		*	R92-5024-05 RK73GB2A223J R92-5024-05 RK73FB2B561J RK73GB2A223J	CHIP R 1.0K J 3/4W CHIP R 22K J 1/10W CHIP R 1.0K J 3/4W CHIP R 560 J 1/8W CHIP R 22K J 1/10W	
L1 L2 L3 L4 L101		*	L33-1988-05 L33-1978-05 L33-1902-15 L33-1029-05 L40-2205-34	CHOKE COIL ASSY CHOKE COIL SMALL FIXED INDUCTOR SMALL FIXED INDUCTOR SMALL FIXED INDUCTOR (22UH)		R125 R126 R127 R128 R129			RK73GB2A473J RK73GB2A104J RK73GB2A103J RK73FB2B203J RK73GB2A104J	CHIP R 47K J 1/10W CHIP R 100K J 1/10W CHIP R 10K J 1/10W CHIP R 20K J 1/8W CHIP R 100K J 1/10W	
L201 L202 L301 L302-305 L401		*	L40-4795-68 L92-0075-05 L33-1977-05 L40-1005-68 L40-4795-68	SMALL FIXED INDUCTOR (4.7UH) CHIP FERRITE CHOKE COIL SMALL FIXED INDUCTOR SMALL FIXED INDUCTOR (4.7UH)		R130 R131 R132 R133,134 R135			RD14DB2H332J RK73EB2E473J RK73EB2E101J RK73GB2A103J RK73GB2A183J	SMALL-RD 3.3K J 1/2W CHIP R 47K J 1/4W CHIP R 100 J 1/4W CHIP R 10K J 1/10W CHIP R 18K J 1/10W	
X1 X2		*	L77-2880-05 L78-0862-05	CRYSTAL RESONATOR RESONATOR (16.00MHZ)		R136 R137 R138 R139 R140		*	RK73GB2A104J RK73GB2A223J RK73FB2B683J RK73GB2A393J RK73GB2A333J	CHIP R 100K J 1/10W CHIP R 22K J 1/10W CHIP R 68K J 1/8W CHIP R 39K J 1/10W CHIP R 33K J 1/10W	
P S T U	2D 2D 2D 2D		N83-3005-46 N80-3010-46 N82-2608-46 N83-3020-46	PAN HEAD TAPTITE SCREW PAN HEAD TAPTITE SCREW BINDING HEAD TAPTITE SCREW PAN HEAD TAPTITE SCREW		R141 R201 R202 R206 R207			RK73GB2A474J RK73GB2A104J RK73GB2A222J RK73GB2A104J RK73GB2A102J	CHIP R 470K J 1/10W CHIP R 100K J 1/10W CHIP R 2.2K J 1/10W CHIP R 100K J 1/10W CHIP R 1.0K J 1/10W	
CP202 CP203 CP204 CP205 CP206		*	RK74GA1J101J RK74GB1J102J RK74GA1J103J RK74GA1J222J RK74GB1J102J	CHIP-COM 100 J 1/16W CHIP-COM 1.0K J 1/16W CHIP-COM 10K J 1/16W CHIP-COM 2.2K J 1/16W CHIP-COM 1.0K J 1/16W		R208 R210,211 R212 R213-215 R216			RK73GB2A103J RK73GB2A473J RK73GB2A104J RK73GB2A102J RK73GB2A223J	CHIP R 10K J 1/10W CHIP R 47K J 1/10W CHIP R 100K J 1/10W CHIP R 1.0K J 1/10W CHIP R 22K J 1/10W	
CP207-209 R1 R2 R3 R4			RK74GB1J101J RK73FB2B223J RK73GB2A101J RK73GB2A223J RK73GB2A222J	CHIP-COM 100 J 1/16W CHIP R 22K J 1/8W CHIP R 100 J 1/10W CHIP R 22K J 1/10W CHIP R 2.2K J 1/10W		R217,218 R219,220 R221,222 R223 R224			RK73GB2A473J RK73GB2A472J RK73GB2A471J RK73GB2A101J RK73GB2A472J	CHIP R 47K J 1/10W CHIP R 4.7K J 1/10W CHIP R 470 J 1/10W CHIP R 100 J 1/10W CHIP R 4.7K J 1/10W	
R5 R6 R7 R8 R9,10		*	RK73FB2B221J RK73GB2A153J RK73GH2A432D RK73GH2A243D RK73FB2B152J	CHIP R 220 J 1/8W CHIP R 15K J 1/10W CHIP R 4.3K D 1/10W CHIP R 24K D 1/10W CHIP R 1.5K J 1/8W							

K : North America

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X34-3000-10)

Ref. No.	Add	New	Parts No.	Description	Destination
R225			RK73GB2A101J	CHIP R 100 J 1/10W	
R226			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R227			RK73GB2A104J	CHIP R 100K J 1/10W	
R228			RK73GB2A473J	CHIP R 47K J 1/10W	
R229			RK73GB2A471J	CHIP R 470 J 1/10W	
R230			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R231			RK73GB2A471J	CHIP R 470 J 1/10W	
R232			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R236			RK73GB2A473J	CHIP R 47K J 1/10W	
R239			RK73GB2A101J	CHIP R 100 J 1/10W	
R240			RK73GB2A473J	CHIP R 47K J 1/10W	
R241			RK73GB2A101J	CHIP R 100 J 1/10W	
R245			RK73GB2A473J	CHIP R 47K J 1/10W	
R247			RK73GB2A473J	CHIP R 47K J 1/10W	
R250,251			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R252			RK73GB2A101J	CHIP R 100 J 1/10W	
R253			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R254			RK73GB2A473J	CHIP R 47K J 1/10W	
R257-259			RK73GB2A473J	CHIP R 47K J 1/10W	
R261,262			RK73GB2A473J	CHIP R 47K J 1/10W	
R265			RK73GB2A473J	CHIP R 47K J 1/10W	
R272-274			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R275			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R276-278			RK73GB2A473J	CHIP R 47K J 1/10W	
R279			RK73GB2A104J	CHIP R 100K J 1/10W	
R280,281			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R282,283			RK73GB2A104J	CHIP R 100K J 1/10W	
R284,285			RK73GB2A101J	CHIP R 100 J 1/10W	
R301			RK73FB2B102J	CHIP R 1.0K J 1/8W	
R302			RK73GB2A223J	CHIP R 22K J 1/10W	
R307,308			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R309			RK73GB2A241J	CHIP R 240 J 1/10W	
R310,311			RK73GB2A103J	CHIP R 10K J 1/10W	
R312			RK73GB2A124J	CHIP R 120K J 1/10W	
R313			RK73GB2A104J	CHIP R 100K J 1/10W	
R314			RK73FB2B472J	CHIP R 4.7K J 1/8W	
R315			RK73FB2B223J	CHIP R 22K J 1/8W	
R316			RK73GB2A223J	CHIP R 22K J 1/10W	
R317			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R318			RK73EB2E101J	CHIP R 100 J 1/4W	
R319,320			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R321-323			RK73EB2E101J	CHIP R 100 J 1/4W	
R324			RK73EB2E472J	CHIP R 4.7K J 1/4W	
R325			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R326,327			RK73GB2A104J	CHIP R 100K J 1/10W	
R328			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R329			RK73GB2A471J	CHIP R 470 J 1/10W	
R330			RK73GB2A104J	CHIP R 100K J 1/10W	
R332			RK73GB2A471J	CHIP R 470 J 1/10W	
R401			RK73GB2A820J	CHIP R 82 J 1/10W	
R402			RK73GB2A103J	CHIP R 10K J 1/10W	
R403,404			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R405			RK73GB2A103J	CHIP R 10K J 1/10W	
R406			RK73GB2A820J	CHIP R 82 J 1/10W	
R408,409			RK73GB2A222J	CHIP R 2.2K J 1/10W	

Ref. No.	Add	New	Parts No.	Description	Destination
R411,412			RK73GB2A361J	CHIP R 360 J 1/10W	
R413			RK73GB2A820J	CHIP R 82 J 1/10W	
R414			RK73GB2A103J	CHIP R 10K J 1/10W	
R415,416			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R417			RK73GB2A103J	CHIP R 10K J 1/10W	
R418			RK73GB2A820J	CHIP R 82 J 1/10W	
R420,421			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R423,424			RK73GB2A361J	CHIP R 360 J 1/10W	
R425			RK73GB2A820J	CHIP R 82 J 1/10W	
R426			RK73GB2A103J	CHIP R 10K J 1/10W	
R427,428			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R429			RK73GB2A103J	CHIP R 10K J 1/10W	
R430			RK73GB2A820J	CHIP R 82 J 1/10W	
R432,433			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R435,436			RK73GB2A361J	CHIP R 360 J 1/10W	
R461			RK73GB2A103J	CHIP R 10K J 1/10W	
R462			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R463,464			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R468			RK73FB2B361J	CHIP R 360 J 1/8W	
R469,470			RK73FB2B473J	CHIP R 47K J 1/8W	
R471,472			RK73FB2B361J	CHIP R 360 J 1/8W	
R473,474			RK73FB2B473J	CHIP R 47K J 1/8W	
R475			RK73FB2B361J	CHIP R 360 J 1/8W	
R480,481			RK73GB2A104J	CHIP R 100K J 1/10W	
R505			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R506-508			RK73EB2E471J	CHIP R 470 J 1/4W	
R509			RK73EB2E472J	CHIP R 4.7K J 1/4W	
R510			RK73EB2E101J	CHIP R 100 J 1/4W	
R511			RK73EB2E472J	CHIP R 4.7K J 1/4W	
R512,513			RK73EB2E101J	CHIP R 100 J 1/4W	
R514			RK73EB2E472J	CHIP R 4.7K J 1/4W	
R515,516			RK73EB2E101J	CHIP R 100 J 1/4W	
R517			RK73EB2E100J	CHIP R 10 J 1/4W	
R518			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	
R519			RK73EB2E100J	CHIP R 10 J 1/4W	
R520			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R521			RK73GB2A473J	CHIP R 47K J 1/10W	
R522			RK73GB2A752J	CHIP R 7.5K J 1/10W	
R523			RK73GB2A100J	CHIP R 10 J 1/10W	
R524			RK73GB2A432J	CHIP R 4.3K J 1/10W	
R525			RK73GB2A223J	CHIP R 22K J 1/10W	
R526,527			RK73GB2A221J	CHIP R 220 J 1/10W	
R528			RK73GB2A683J	CHIP R 68K J 1/10W	
R529			RK73GB2A103J	CHIP R 10K J 1/10W	
W6			R92-1252-05	CHIP R 0 OHM J 1/16W	
S1,2		*	S68-0886-05	PUSH SWITCH	
D1		*	S2V60*A	DIODE	
D2			RB160L-40	DIODE	
D3			UDZS5.6B	ZENER DIODE	
D4			UDZS8.2B	ZENER DIODE	
D5		*	SFPB-54VNF	DIODE	
D6		*	HZU11(B1)-E	ZENER DIODE	
D7		*	HZU9.1(B1)-E	ZENER DIODE	
D101		*	UDZS11B	ZENER DIODE	

K : North America

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X34-3000-10)

Ref. No.	Add	New	Parts No.	Description	Destination
D102			UDZS5.6B	ZENER DIODE	
D103-107			1SR154-400	DIODE	
D108			UDZS5.6B	ZENER DIODE	
D109			UDZS4.7B	ZENER DIODE	
D110,111			UDZS6.8B	ZENER DIODE	
D112			UDZS6.2B	ZENER DIODE	
D113,114			DAP202U	DIODE	
D115			DAN202U	DIODE	
D201			DAP202U	DIODE	
D301		*	IMSA-6801-E	SURGE ABSORBER	
D304			DA204K	DIODE	
D305		*	STZ6.2N	ZENER DIODE	
D306-312			DA204K	DIODE	
D313		*	STZ6.2N	ZENER DIODE	
D314			STZ6.8N	ZENER DIODE	
D315			DA204U	DIODE	
D406			DAP202U	DIODE	
D501-504		*	STZ6.2N	ZENER DIODE	
D505,506			STZ6.8N	ZENER DIODE	
D507-510			1SR154-400	DIODE	
D511,512			DAP222	DIODE	
D513-516			1SR154-400	DIODE	
D517		*	STZ6.2N	ZENER DIODE	
D519-522			DA204U	DIODE	
IC1		*	30624MGPA27GP	MICROCONTROLLER IC	
IC2		*	E-TDA7414	ANALOGUE IC	
IC3			M5237ML	ANALOGUE IC	
IC4		*	E-TDA7560A	ANALOGUE IC	
IC5		*	E-TDA7401	ANALOGUE IC	
IC7		*	SI-8050JDNF	ANALOGUE IC	
IC8			ICL7660SIBA	ANALOGUE IC	
IC10		*	TC7W02FU-F	MOS-IC	
IC11		*	PST3436UL-E	MOS-IC	
IC13		*	LB1930M-E	ANALOGUE IC	
IC14		*	TA75S558F-F	ANALOGUE IC	
IC15-17		*	NJM4565M-ZB	ANALOGUE IC	
IC20		*	SI-3050KD	ANALOGUE IC	
Q1			2SB1565	TRANSISTOR	
Q2			2SC4081	TRANSISTOR	
Q3			2SA1576A	TRANSISTOR	
Q4			DTC124EE	DIGITAL TRANSISTOR	
Q4		*	PDTC124EE	TRANSISTOR	
Q5,6			UMC2N	TRANSISTOR	
Q7			2SB1188(R)	TRANSISTOR	
Q8			2SB1565	TRANSISTOR	
Q9,10			2SC4081	TRANSISTOR	
Q11			2SB1565	TRANSISTOR	
Q12			DTC144EUA	DIGITAL TRANSISTOR	
Q13			UMC2N	TRANSISTOR	
Q15			2SB1565	TRANSISTOR	
Q16			2SC4617	TRANSISTOR	
Q17			2SB1443	TRANSISTOR	
Q18			2SC4081	TRANSISTOR	
Q19		*	2SA1774	TRANSISTOR	
Q20			2SC4617	TRANSISTOR	
Q21		*	2SA1774	TRANSISTOR	
Q22			2SC4081	TRANSISTOR	
Q23			2SA1576A	TRANSISTOR	
Q24			2SC4081	TRANSISTOR	
Q25			2SB1188(Q,R)	TRANSISTOR	
Q26			DTC114YUA	DIGITAL TRANSISTOR	
Q27			2SB1188(Q,R)	TRANSISTOR	
Q28			2SA1576A	TRANSISTOR	
Q29			DTA114EUA	DIGITAL TRANSISTOR	
Q30			DTC114YE	DIGITAL TRANSISTOR	
Q30		*	PDTC114YE	TRANSISTOR	
Q31			DTA123JK	DIGITAL TRANSISTOR	
Q32			DTC144EUA	DIGITAL TRANSISTOR	
Q33			2SC4081	TRANSISTOR	
Q34		*	2SA1774	TRANSISTOR	
Q35			2SC4617	TRANSISTOR	
Q36			2SC4081	TRANSISTOR	
Q37-40			DTA124EUA	DIGITAL TRANSISTOR	
Q41			2SA1576A	TRANSISTOR	
Q42			DTC124EUA	DIGITAL TRANSISTOR	
Q44			DTC124EUA	DIGITAL TRANSISTOR	
Q45			2SB1188(R)	TRANSISTOR	
Q46			DTC124EUA	DIGITAL TRANSISTOR	
Q47-52			DTC143TUA	DIGITAL TRANSISTOR	
Q56-59			DTC143TUA	DIGITAL TRANSISTOR	
Q60			DTC124EE	DIGITAL TRANSISTOR	
Q60		*	PDTC124EE	TRANSISTOR	
TH1		*	PRF21BD471QB2	POSITIVE RESISTOR	
A1		*	W02-3439-05	ELECTRIC CIRCUIT MODULE	
A2	2D	*	X86-3760-11	FRONT-END UNIT	
CD MECHANISM ASSY (X92-4910-00)					
2	1B		A10-4827-32	CHASSIS	
5	1B	*	D10-4576-83	ARM ASSY	
8	2A		D10-4579-13	LEVER ASSY	
10	2A		D10-4581-13	ARM	
11	2A		D10-4582-13	ARM	
12	3A		D10-4583-03	ARM	
13	3A		D10-4584-03	ARM	
14	3B		D10-4585-03	ARM	
15	2A		D10-4586-13	SLIDER	
16	3B	*	D10-4587-42	SLIDER	
17	2B		D10-4588-13	SLIDER	
18	2B		D10-4595-04	ARM	
19	3B	*	D10-4596-24	ARM	
22	2A		D13-2151-04	GEAR	
23	2B		D13-2152-04	GEAR	
24	3B		D13-2153-04	GEAR	
25	3B		D13-2154-04	GEAR	
26	3B		D13-2155-04	WORM	
27	2B		D13-2156-14	GEAR	
28	3B		D13-2157-04	GEAR	
29	3B		D13-2158-04	GEAR	

K : North America

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

CD MECHANISM ASSY (X92-4910-00)

Ref. No.	Add	New	Parts No.	Description	Destination
30	2B	*	D13-2168-04	GEAR	
31	3B		D13-2171-04	GEAR	
32	2B		D13-2172-13	RACK (GEAR)	
33	2A		D14-0759-04	ROLLER	
35	2B		D21-2382-04	SHAFT	
36	1A		D23-0954-04	RETAINER	
37	1B		D39-0246-05	DAMPER	
38	2B		G01-3072-04	EXTENSION SPRING	
39	2A		G01-3073-04	TORSION COIL SPRING	
40	2A		G01-3074-04	EXTENSION SPRING	
41	1B		G01-3075-14	EXTENSION SPRING	
42	2A		G01-3076-04	EXTENSION SPRING	
43	1B		G01-3077-14	EXTENSION SPRING	
44	2B		G02-1399-04	FLAT SPRING	
45	2B		G02-1408-04	FLAT SPRING	
51	1A	*	J21-9676-32	MOUNTING HARDWARE	
52	3B		J21-9677-22	MOUNTING HARDWARE	
53	1B		J21-9678-13	MOUNTING HARDWARE	
55	1A		J90-1001-11	GUIDE	
56	1B		J90-1023-03	GUIDE	
A	2B		N09-4460-05	TAPTITE SCREW (OVAL P TAPTIT)	
B	1B		N09-4472-15	MACHINE SCREW (M1.7X8.0)	
C	2B		N09-6004-05	MACHINE SCREW (M1.7X2.5 IB-L)	
E	2B		N09-6007-05	MACHINE SCREW (PAN M2X2)	
F	1A		N09-6051-05	TAPTITE SCREW (BIND P 2X5)	
G	2A		N19-2163-04	FLAT WASHER	
H	1B		N39-2020-46	PAN HEAD MACHIN SCREW	
J	1B		N09-6108-05	MACHINE SCREW (M2*3.5TYPE3)	
K	3B		N09-6155-05	SEMS (TAPTITE SCREW) (PT2X6)	
DM1	3B		T42-1066-04	DC MOTOR ASSY (SP)	
DM2	2B		T42-1067-04	DC MOTOR ASSY (LO)	
DPU1	2B		X93-2010-00	OPTICAL PICKUP ASSY	

Ref. No.	Add	New	Parts No.	Description	Destination

K : North America

⚠ Indicates safety critical components.