

- This service manual should be used together with the manual(s) listed below.

For the parts numbers, adjustments, etc. which are not shown in this manual, refer to the following manual(s).

Model No.	Order No.	Mech. Module	Remarks
FX-MG8006ZT/UC	CRT2547		
CX-631	CRT1640	2L	Cassette Mech. Module:Mech.Description, Disassembly
CX-890	CRT2376	G1	CD Mech. Module:Circuit Description, Mech.Description, Disassembly

● **SUPPLEMENTARY MODEL**

Description	Part No.		
	FX-MG8006ZT-91/UC	FX-MG8006ZT-92/UC	FX-MG8506ZT-92/UC
Polyethylene Bag	CEG1026	CEG1174	CEG1174

EXPLODED VIEWS AND PARTS LIST

EXTERIOR(Page 4)

● **EXTERIOR SECTION PARTS LIST**

Mark No.	Symbol and Description	Part No.		
		FX-MG8006ZT/UC	FX-MG8006ZT-02/UC	FX-MG8006ZT-92/UC
3	Screw	BMZ50P080FMC	BMZ50P080FMC	Not used
9	Main Unit	CWM6847	CWM7873	CWM7873
37	Grille Unit	CXB7308	CXB7701	CXB7701
39	Door	CAT2102	CAT2266	CAT2266
56	86208-50010	CXB6031	CXB6031	Not used
57	86207-50010	CXB6032	CXB6032	Not used

● **EXTERIOR SECTION PARTS LIST**

Mark No.	Symbol and Description	Part No.		
		FX-MG8506ZT/UC	FX-MG8506ZT-02/UC	FX-MG8506ZT-92/UC
3	Screw	BMZ50P080FMC	BMZ50P080FMC	Not used
9	Main Unit	CWM6847	CWM7873	CWM7873
37	Grille Unit	CXB7310	CXB7700	CXB7700
39	Door	CAT2169	CAT2265	CAT2265
56	86208-50010	CXB6031	CXB6031	Not used
57	86207-50010	CXB6032	CXB6032	Not used

ELECTRICAL PARTS LIST(Page 54)

● **Main Unit**

Circuit Symbol and No.	Part No.	
	FX-MG8006ZT/UC	FX-MG8006ZT-02/UC
	FX-MG8006ZT-91/UC	FX-MG8006ZT-92/UC
	FX-MG8506ZT/UC	FX-MG8506ZT-02/UC
	FX-MG8506ZT-91/UC	FX-MG8506ZT-92/UC
IC601	PD5556E	PD5677A
IC701	PD5715A	PD5716A