

Pioneer

Service Manual

ORDER NO.
CRT4582

CD RECEIVER

DXT-2266UB /XSUS



This service manual should be used together with the following manual(s) listed below. For the parts numbers, adjustments, etc. which are not shown in this manual, refer to the following manual(s).

Model No.	Order No.	Mech. Module	Remarks
DEH-22UB/XSUC	CRT4454		
CX-3269	CRT4488	S11iPod/USB	CD Mech.Module:Circuit Descriptions, Mech. Descriptions, Disassembly

SAFETY INFORMATION

WARNING

This product may contain a chemical known to the State of California to cause cancer, or birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 - Proposition 65

EXPLODED VIEWS AND PARTS LIST

PACKING(Page 32)

PACKING SECTION PARTS LIST

*:Non spare part

Mark	No.	Description	DEH-22UB/XSUC	DXT-2266UB/XSUS
	2	Remote Control Unit	CXE2758	Not used
	11	Unit Box	YHG5557	YHG5578
	12	Contain Box	YHL5557	YHL5578
	15-2	Owner's Manual	YRD5305	YRD5321
		Sub Unit Box	Not used	YHG5579
		Speaker Unit	Not used	TS-G622L/XAUC (x 4)

EXTERIOR(1)(Page 34)

EXTERIOR(1) SECTION PARTS LIST

Mark	No.	Description	DEH-22UB/XSUC	DXT-2266UB/XSUS
	2	Remote Control Unit	CXE2758	Not used
	3	Cover	CNS7068	Not used
	7	Detachable Assy	YXA5680	YXA5772
	19	Spacer	CNN2527	Not used
	24	Grille Unit	YXA5688	YXA5773

ELECTRICAL PARTS LIST(Page 66)

KEYBOARD UNIT

Circuit Symbol and No.	Part Name	DEH-22UB/XSUC	DXT-2266UB/XSUS
IC1802	Remote IC	GP1UXC14RK	Not used
X1801	Ceramic Resonator 5.00 MHz	CSS1731	CSS1547
R1801		Not used	RS1/10SR473J
R1802		RS1/10SR2R2J	Not used
R1803		RS1/10SR103J	Not used
R1804		RS1/10SR101J	Not used
C1801		CKSYF106Z10	Not used

The mounting positions of the additional parts are described in the circuit diagram and PCB diagram of the parent manual.