

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
KAC-PS521/X521					
1	1B	*	A21-4337-02	DRESSING PANEL	K E1
1	1B	*	A21-4338-02	DRESSING PANEL	
3	3A	*	A64-3297-02	PANEL	
4	1A	*	B07-3102-03	ESCUTCHEON	K E1
5	1B	*	B07-3103-02	ESCUTCHEON	
6	1B	*	B07-3104-02	ESCUTCHEON	
7	1A	*	B10-4544-03	FRONT GLASS	
8	1B	*	B19-2257-03	LIGHTING BOARD	
10	1B	*	B43-1521-04	BADGE	K E1
10	1B	*	B43-1522-04	BADGE	
-			B46-0100-50	WARRANTY CARD	K
-			B46-0648-13	USER CARD	
-		*	B64-2795-00	INSTRUCT.MANUAL (ENG.FRE.SPA.)	E1
-		*	B64-2796-00	INST.MANUAL (GER.DUT.ITA.POR.)	
FC1	3B	*	E39-0642-05	FLAT CABLE	K E1
13	1B	*	F01-1751-01	HEAT SINK	
14	1B	*	F07-1138-12	COVER	
14	1B	*	F07-1139-12	COVER	
16	1B		F09-1846-05	FAN (40X40X10) SIDE	
17	1A	*	F09-1885-05	FAN (60X60X11.5) TOP	
F1,2	3A		F52-0015-05	FUSE (BLADE TYPE) 30A	
-		*	H10-4894-13	POLYSTYRENE FOAMED FIXTURE	K
-		*	H13-2055-04	CARTON BOARD	
-		*	H25-1199-04	PROTECTION BAG	
-		*	H25-1200-04	PROTECTION BAG (250X350X0.03)	
-		*	H54-3131-03	ITEM CARTON CASE	
-		*	H54-3132-03	ITEM CARTON CASE	E1
24	2B	*	K24-4146-03	KNOB (VR CAP)	K E1
26	1A		N99-1577-15	SCREW SET	
27	1A	*	N99-1752-05	SCREW SET	
A	2A	*	N09-6216-05	TAPTITE SCREW (3X12)	
B	3A	*	N09-6218-05	TAPTITE SCREW (4X8)	
C	2B	*	N09-6220-05	TAPTITE SCREW (2X5)	
D	3A	*	N15-1040-48	FLAT WASHER (4)	
E	3A	*	N80-2008-43	PAN HEAD TAPTITE SCREW	K E1
F	3A		N80-3010-43	PAN HEAD TAPTITE SCREW	
G	1A		N82-2006-48	BINDING HEAD TAPTITE SCREW	
H	2A	*	N84-2606-48	PAN HEAD TAPTITE SCREW	
J	3A		N89-3006-43	BINDING HEAD TAPTITE SCREW	K E1
K	3A	*	N89-3008-43	BINDING HEAD TAPTITE SCREW	
L	2A		N89-3008-48	BINDING HEAD TAPTITE SCREW	
M	2A	*	N89-3016-48	BINDING HEAD TAPTITE SCREW	
P	2B	*	N80-2008-48	PAN HEAD TAPTITE SCREW	K E1
Q	2B	*	N83-3012-48	PAN HEAD TAPTITE SCREW	
28	1A		W01-1606-05	ACCESSORY	K E1
PREAMPLIFIER UNIT (X08-4150-10)					
40	2B	*	B11-1446-04	REFLECTION SHEET	K E1
41	2A	*	B11-1447-04	OPTICAL DIFFUSER	

Ref. No.	Added	New	Parts No.	Description	Destination
42	2B	*	B19-2258-12	LIGHTING BOARD	K E1
D2		*	B30-1694-05	LED	
ED1		*	B38-1150-05	LCD DISPLAY ASSY	
C3-6			CK73FB1C224K	CHIP C 0.22UF	K
C9,10			CD04AS1H010M	ELECTRO 1UF	50WV
C11-13			CK73GB1H103K	CHIP C 0.010UF	K
C15-20			CD04AS1C100M	ELECTRO 10UF	16WV
C21,22			CK73GB1C104K	CHIP C 0.10UF	K
C23,24			CK73FB1C224K	CHIP C 0.22UF	K
C25,26			CD04AS1C100M	ELECTRO 10UF	16WV
C27,28			CK73GB1H103K	CHIP C 0.010UF	K
C29,30			CK73GB1H102K	CHIP C 1000PF	K
C31,32			CD04AS1C100M	ELECTRO 10UF	16WV
C33			CK73GB1C104K	CHIP C 0.10UF	K
C34			CK73FB1C154K	CHIP C 0.15UF	K
C35			CK73GB1E223K	CHIP C 0.022UF	K
C37,38			CK73GB1H103K	CHIP C 0.010UF	K
C39			CD04AS1C100M	ELECTRO 10UF	16WV
C40-45			CK73GB1H103K	CHIP C 0.010UF	K
C48,49			CK73GB1H103K	CHIP C 0.010UF	K
C61			CD04AS1C100M	ELECTRO 10UF	16WV
C63-66			CK73FB1C224K	CHIP C 0.22UF	K
C67,68			CD04AS1C100M	ELECTRO 10UF	16WV
C73			CK73GB1C104K	CHIP C 0.10UF	K
C74			CK73FB1C154K	CHIP C 0.15UF	K
C75			CK73GB1E333K	CHIP C 0.033UF	K
C101			CK73GB1H821K	CHIP C 820PF	K
C102,103			CK73GB1H473K	CHIP C 0.047UF	K
C104			CK73GB1H103K	CHIP C 0.010UF	K
C105			CD04AS1C100M	ELECTRO 10UF	16WV
C107			CK73GB1H102K	CHIP C 1000PF	K
CN1		*	E41-2178-05	FLAT CABLE CONNECTOR (22P)	K E1
CN2		*	E41-0941-05	PIN ASSY (2P)	
WH2		*	E39-0655-05	WIRING HARNESS	K E1
R1,2			RK73GB2A473J	CHIP R 47K J	1/10W
R3,4			RK73GB2A134J	CHIP R 130K J	1/10W
R5,6			RK73GB2A223J	CHIP R 22K J	1/10W
R7-12			RK73GB2A473J	CHIP R 47K J	1/10W
R13			RD14BB2C391J	RD 390 J	1/6W
R14-16			RK73GB2A101J	CHIP R 100 J	1/10W
R17-20			RK73GB2A102J	CHIP R 1.0K J	1/10W
R21,22			RK73GB2A103J	CHIP R 10K J	1/10W
R23,24			RK73GB2A473J	CHIP R 47K J	1/10W
R25,26			RK73GB2A563J	CHIP R 56K J	1/10W
R27,28			RK73GB2A912J	CHIP R 9.1K J	1/10W
R29,30			RK73GB2A822J	CHIP R 8.2K J	1/10W
R31-33			RK73GB2A473J	CHIP R 47K J	1/10W
R34			RK73GB2A103J	CHIP R 10K J	1/10W
R38			RK73GB2A203J	CHIP R 20K J	1/10W
R39,40			RK73GB2A471J	CHIP R 470 J	1/10W
R41,42			RK73GB2A153J	CHIP R 15K J	1/10W
R43			RK73GB2A332J	CHIP R 3.3K J	1/10W
R44			RK73GB2A222J	CHIP R 2.2K J	1/10W
R45			RK73GB2A153J	CHIP R 15K J	1/10W

E1 : KAC-PS521 K : KAC-X521 (E : Europe K : North America)

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

PREAMPLIFIER UNIT (X08-4150-10)

Ref. No.	Add	New	Parts No.	Description	Destination
R46			RK73GB2A473J	CHIP R 47K J 1/10W	
R52			RK73GB2A473J	CHIP R 47K J 1/10W	
R55,56			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R63,64			RK73GB2A563J	CHIP R 56K J 1/10W	
R65,66			RK73GB2A393J	CHIP R 39K J 1/10W	
R69,70			RK73GB2A103J	CHIP R 10K J 1/10W	
R72			RK73GB2A752J	CHIP R 7.5K J 1/10W	
R73			RK73GB2A103J	CHIP R 10K J 1/10W	
R74			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R76			RK73GB2A224J	CHIP R 220K J 1/10W	
R77			RK73GB2A123J	CHIP R 12K J 1/10W	
R78			RK73GB2A101J	CHIP R 100 J 1/10W	
R79			RK73GB2A103J	CHIP R 10K J 1/10W	
R101-104			RK73GB2A471J	CHIP R 470 J 1/10W	
R105			RK73GB2A683J	CHIP R 68K J 1/10W	
R106			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R107,108			RK73GB2A471J	CHIP R 470 J 1/10W	
R109-111			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R112			RK73GB2A104J	CHIP R 100K J 1/10W	
R114,115			RK73GB2A103J	CHIP R 10K J 1/10W	
R116			RD14BB2C391J	RD 390 J 1/6W	
R117			RD14BB2C6R8J	RD 6.8 J 1/6W	
VR1			R31-0225-05	VARIABLE RESISTOR 50K (C)	
VR2		*	R31-0238-05	VARIABLE RESISTOR	
VR3			R31-0225-05	VARIABLE RESISTOR 50K (C)	
S1-3		*	S62-0873-05	SLIDE SWITCH	
S4		*	S62-0874-05	SLIDE SWITCH	
S7-9		*	S70-0922-05	TACT SWITCH	
D1			MA3082-M	ZENER DIODE	
IC1		*	NJM2058M-ZB	ANALOGUE IC	
IC3		*	E-TDA7409DTR	ANALOGUE IC	
IC4		*	NJM4565MD-ZB	ANALOGUE IC	
IC5		*	NJM2058M-ZB	ANALOGUE IC	
IC6		*	NJM4565MD-ZB	ANALOGUE IC	
IC7		*	LC75853NE-E	MOS-IC	
AUDIO UNIT (X09-5760-10)					
C1,2			CK73GB1H471K	CHIP C 470PF K	
C3,4		*	C90-5592-05	ELECTRO 10UF 35WV	
C5,6			CC73GCH1H150J	CHIP C 15PF J	
C11-14			CC73GCH1H150J	CHIP C 15PF J	
C15,16		*	C90-5586-05	ELECTRO 22UF 25WV	
C17,18		*	C90-5592-05	ELECTRO 10UF 35WV	
C19			CF92FV1H102J	MF-C 1000PF J	
C21			CK73FB1H104K	CHIP C 0.10UF K	
C23,24			CK73FB1H104K	CHIP C 0.10UF K	
C51		*	C90-5557-05	ELECTRO 10UF 25WV	
C52		*	C90-5588-05	ELECTRO 47UF 25WV	
C53			CK73GB1H102K	CHIP C 1000PF K	
C54		*	C90-5588-05	ELECTRO 47UF 25WV	
C55,56		*	CD04BC1C392M	ELECTRO 3900UF 16WV	
C61		*	C90-5592-05	ELECTRO 10UF 35WV	
C62			CK73GB1H103K	CHIP C 0.010UF K	
C63,64		*	C90-5588-05	ELECTRO 47UF 25WV	
C65,66			CK73GB1H103K	CHIP C 0.010UF K	
C67,68		*	C90-5592-05	ELECTRO 10UF 35WV	
C69			C90-5601-05	ELECTRO 1UF 50WV	
C70		*	C90-5588-05	ELECTRO 47UF 25WV	
C71			CK73GB1C104K	CHIP C 0.10UF K	
C72			CF92FV1H152J	MF-C 1500PF J	
C73			CF92FV1H182J	MF-C 1800PF J	
C74		*	C90-5590-05	ELECTRO 220UF 25WV	
C76		*	C90-5592-05	ELECTRO 10UF 35WV	
C89			CF92FV1H152J	MF-C 1500PF J	
C90,91		*	C90-5690-05	ELECTRO 4700UF 56WV	
C97,98			CK73GB1H221K	CHIP C 220PF K	
C99,100			CC73GCH1H220J	CHIP C 22PF J	
C101,102		*	C90-5586-05	ELECTRO 22UF 25WV	
C103,104			CK45FB1H471K	CERAMIC 470PF K	
C105,106			CK73GB1H472K	CHIP C 4700PF K	
C107,108			C90-5601-05	ELECTRO 1UF 50WV	
C109,110		*	C90-5592-05	ELECTRO 10UF 35WV	
C111,112		*	C90-5588-05	ELECTRO 47UF 25WV	
C115,116			CC45FSL1H331J	CERAMIC 330PF J	
C117-120			CC45FSL1H220J	CERAMIC 22PF J	
C121,122			CK45FB1H102K	CERAMIC 1000PF K	
C123,124			CC45FSL1H220J	CERAMIC 22PF J	
C125-128			CK73GB1H471K	CHIP C 470PF K	
C129-136			CK45FB1H471K	CERAMIC 470PF K	
C137		*	C90-5695-05	ELECTRO 100UF 63WV	
C138			C90-5602-05	ELECTRO 2.2UF 50WV	
C139		*	C90-5570-05	ELECTRO 33UF 10WV	
C140		*	C90-5588-05	ELECTRO 47UF 25WV	
C141			C90-5566-05	ELECTRO 100UF 6.3WV	
C142			CK73GB1H103K	CHIP C 0.010UF K	
C143			C90-5566-05	ELECTRO 100UF 6.3WV	
C145,146			CF92FV1H473J	MF-C 0.047UF J	
C251,252			CK73GB1H103K	CHIP C 0.010UF K	
C301		*	C90-5557-05	ELECTRO 10UF 25WV	
C302,303			CK73GB1C104K	CHIP C 0.10UF K	
C306,307			CK73GB1H103K	CHIP C 0.010UF K	
C308		*	C90-5592-05	ELECTRO 10UF 35WV	
C309-311			CK73GB1H103K	CHIP C 0.010UF K	
C313,314			CC73GCH1H101J	CHIP C 100PF J	
C343			CK73GB1H103K	CHIP C 0.010UF K	
C349,350		*	C90-5592-05	ELECTRO 10UF 35WV	
C351		*	C90-5588-05	ELECTRO 47UF 25WV	
C352		*	C90-5592-05	ELECTRO 10UF 35WV	
C353,354			CK73GB1H103K	CHIP C 0.010UF K	
C358		*	C90-5592-05	ELECTRO 10UF 35WV	
C401			C90-5572-05	ELECTRO 100UF 10WV	
C402			CK73GB1H103K	CHIP C 0.010UF K	
C403			C90-5602-05	ELECTRO 2.2UF 50WV	
C404,405			CC73GCH1H270J	CHIP C 27PF J	
C406			CK73GB1H103K	CHIP C 0.010UF K	
C451-453			CC73GCH1H101J	CHIP C 100PF J	
C454			CK73GB1H102K	CHIP C 1000PF K	
C458-461			CK73GB1H103K	CHIP C 0.010UF K	
CN1			E41-0928-05	PIN ASSY (3P)	

E1 : KAC-PS521 K : KAC-X521 (E : Europe K : North America)

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

AUDIO UNIT (X09-5760-10)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
CN2			E41-0927-05	PIN ASSY (2P)	
CN10		*	E41-2202-05	FLAT CABLE CONNECTOR (22P)	
J1		*	E63-0901-05	PIN JACK (4P)	
J2			E70-0838-05	SCREW TERMINAL BOARD (7P)	
J3		*	E56-0856-05	CYLINDRICAL RECEPTACLE (13P)	
J4		*	E56-0853-05	CYLINDRICAL RECEPTACLE (M-D4P)	
△ CN9			J13-0602-05	FUSE HOLDER	
L2		*	L33-1972-05	CHOKE COIL 25UH	
L4		*	L19-0764-05	TRANSFORMER FOR CONVERTER	
L5		*	L19-0758-05	TRANSFORMER FOR CONVERTER	
L9		*	L41-4795-33	SMALL FIXED INDUCTOR 4.7U	
X1		*	L77-2844-05	CRYSTAL RESONATOR 12.288MHZ	
F	3A		N80-3010-43	PAN HEAD TAPTITE SCREW	
K	3A	*	N89-3008-43	BINDING HEAD TAPTITE SCREW	
N	2B	*	N09-6217-05	TAPTITE SCREW	
R1,2			RD14BB2C102J	RD 1.0K J 1/6W	
R3,4			RK73GB2A103J	CHIP R 10K J 1/10W	
R5,6			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R7-10			RK73GB2A103J	CHIP R 10K J 1/10W	
R11-18			RN73GH1J103D	CHIP R 10K D 1/16W	
R21-23			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R51			RK73GB2A104J	CHIP R 100K J 1/10W	
R52			RK73GB2A333J	CHIP R 33K J 1/10W	
R53			RK73GB2A682J	CHIP R 6.8K J 1/10W	
R54			RK73GB2A153J	CHIP R 15K J 1/10W	
R55,56			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R57,58			RK73GB2A560J	CHIP R 56 J 1/10W	
R59,60			RK73GB2A100J	CHIP R 10 J 1/10W	
R61,62			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R65,66			RD14NB2E100J	RD 10 J 1/4W	
R67			RK73GB2A821J	CHIP R 820 J 1/10W	
R69			RK73GB2A103J	CHIP R 10K J 1/10W	
R70			RK73GB2A101J	CHIP R 100 J 1/10W	
R71			RK73GB2A103J	CHIP R 10K J 1/10W	
R72			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R73			RD14DB2H100J	SMALL-RD 10 J 1/2W	
R74			RK73GB2A104J	CHIP R 100K J 1/10W	
R76			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R77			RK73GB2A511J	CHIP R 510 J 1/10W	
R79			RK73GB2A103J	CHIP R 10K J 1/10W	
R80			RK73GB2A473J	CHIP R 47K J 1/10W	
R81			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R82			RK73GB2A392J	CHIP R 3.9K J 1/10W	
R83			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R84			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R85			RK73GB2A392J	CHIP R 3.9K J 1/10W	
R86			RK73GB2A103J	CHIP R 10K J 1/10W	
R88,89			RD14DB2H100J	SMALL-RD 10 J 1/2W	
R90,91			RD14BB2C563J	RD 56K J 1/6W	
R92			RK73GB2A103J	CHIP R 10K J 1/10W	
R93			RK73GB2A113J	CHIP R 11K J 1/10W	
R95,96			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R97,98			RK73GB2A102J	CHIP R 1.0K J 1/10W	

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
R99-104			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R105,106			RD14BB2C333J	RD 33K J 1/6W	
R107-110			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R111,112			RK73GB2A101J	CHIP R 100 J 1/10W	
R113,114			RK73GB2A473J	CHIP R 47K J 1/10W	
R115,116			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R117,118			RK73GB2A242J	CHIP R 2.4K J 1/10W	
R119,120			RD14BB2C102J	RD 1.0K J 1/6W	
R121-124			RD14BB2C221J	RD 220 J 1/6W	
R125-128			RD14BB2C682J	RD 6.8K J 1/6W	
R129,130			RD14BB2C151J	RD 150 J 1/6W	
R131,132			RD14BB2C333J	RD 33K J 1/6W	
R133,134			RD14BB2C182J	RD 1.8K J 1/6W	
R135,136			RD14BB2C561J	RD 560 J 1/6W	
R137,138			RD14BB2C330J	RD 33 J 1/6W	
R139-142			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R143,144			RK73GB2A112J	CHIP R 1.1K J 1/10W	
R145,146			RD14NB2E471J	RD 470 J 1/4W	
R147,148			RK73GB2A112J	CHIP R 1.1K J 1/10W	
R151-154			RD14NB2E101J	RD 100 J 1/4W	
R155,156			RD14NB2E471J	RD 470 J 1/4W	
R157-164			RD14NB2E4R7J	RD 4.7 J 1/4W	
R165-172			R92-0205-05	METAL-PLATE 0.1 K 2W	
R173			RD14DB2H100J	SMALL-RD 10 J 1/2W	
R174			RK73GB2A333J	CHIP R 33K J 1/10W	
R175			RK73GB2A153J	CHIP R 15K J 1/10W	
R176			RK73GB2A331J	CHIP R 330 J 1/10W	
R177			RK73GB2A223J	CHIP R 22K J 1/10W	
R178,179			RK73GB2A470J	CHIP R 47 J 1/10W	
R180,181			RK73GB2A682J	CHIP R 6.8K J 1/10W	
R182,183			RK73GB2A103J	CHIP R 10K J 1/10W	
R184-186			RK73GB2A473J	CHIP R 47K J 1/10W	
R187,188			RK73GB2A103J	CHIP R 10K J 1/10W	
R189			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R190			RK73GB2A103J	CHIP R 10K J 1/10W	
R191			RK73GB2A562J	CHIP R 5.6K J 1/10W	
R192			RK73GB2A123J	CHIP R 12K J 1/10W	
R193			RK73GB2A223J	CHIP R 22K J 1/10W	
R194			RK73GB2A822J	CHIP R 8.2K J 1/10W	
R195			RK73GB2A103J	CHIP R 10K J 1/10W	
R196			RK73GB2A104J	CHIP R 100K J 1/10W	
R197,198			RK73GB2A473J	CHIP R 47K J 1/10W	
R199			RK73GB2A562J	CHIP R 5.6K J 1/10W	
R200			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R201,202			RD14DB2H100J	SMALL-RD 10 J 1/2W	
R203			RK73GB2A273J	CHIP R 27K J 1/10W	
R241			RK73GB2A512J	CHIP R 5.1K J 1/10W	
R301,302			RD14BB2C271J	RD 270 J 1/6W	
R303,304			RK73GB2A432J	CHIP R 4.3K J 1/10W	
R305			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R306,307			RN73GH1J103D	CHIP R 10K D 1/16W	
R308,309			RK73GB2A470J	CHIP R 47 J 1/10W	
R310			RK73GB2A123J	CHIP R 12K J 1/10W	
R311			RK73GB2A203J	CHIP R 20K J 1/10W	
R312,313			RK73GB2A152J	CHIP R 1.5K J 1/10W	

E1 : KAC-PS521 K : KAC-X521 (E : Europe K : North America)

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

AUDIO UNIT (X09-5760-10)

Ref. No.	Add	New	Parts No.	Description	Destination	Ref. No.	Add	New	Parts No.	Description	Destination
R314			RK73GB2A203J	CHIP R 20K J 1/10W		W513-532			R92-2053-05	CHIP R 0 J 1/8W	
R315			RK73GB2A123J	CHIP R 12K J 1/10W		W534-545			R92-2053-05	CHIP R 0 J 1/8W	
R316,317			RK73GB2A152J	CHIP R 1.5K J 1/10W		W547-558			R92-2053-05	CHIP R 0 J 1/8W	
R318			RD14BB2C153J	RD 15K J 1/6W		W560-573			R92-2053-05	CHIP R 0 J 1/8W	
R319			RD14BB2C104J	RD 100K J 1/6W		W601-617			R92-1252-05	CHIP R 0 OHM J 1/16W	
R320			RD14BB2C153J	RD 15K J 1/6W		S1			S68-0806-05	PUSH SWITCH	
R321,322			RD14BB2C102J	RD 1.0K J 1/6W		S2		*	S79-0843-05	DIP SWITCHES	
R323			RK73GB2A392J	CHIP R 3.9K J 1/10W		D1			STZ6.8N	ZENER DIODE	
R324			RK73GB2A272J	CHIP R 2.7K J 1/10W		D2		*	LM1MA142WK-G	DIODE	
R325,326			RK73GB2A105J	CHIP R 1.0M J 1/10W		D3			LM1MA142WA-G	DIODE	
R327			RK73GB2A100J	CHIP R 10 J 1/10W		D13			B30-1601-05	LED	
R328,329			RK73GB2A472J	CHIP R 4.7K J 1/10W		D51,52		*	RM4ZLF-J1NF	DIODE	
R330			RK73GB2A470J	CHIP R 47 J 1/10W		D54		*	S5566B-Q	DIODE	
R331			RK73GB2A220J	CHIP R 22 J 1/10W		D55			UDZS4.7B	ZENER DIODE	
R332			RK73GB2A202J	CHIP R 2.0K J 1/10W		D60			RD16JS(B)	ZENER DIODE	
R333			RK73GB2A103J	CHIP R 10K J 1/10W		D68		*	FCH10A20	DIODE	
R334,335			RD14BB2C470J	RD 47 J 1/6W		D69		*	FRH10A20	DIODE	
R336			RK73GB2A104J	CHIP R 100K J 1/10W		D70			UDZS6.8B	ZENER DIODE	
R337-339			RK73GB2A103J	CHIP R 10K J 1/10W		D71			RD15JS(B)	ZENER DIODE	
R341,342			RK73GB2A472J	CHIP R 4.7K J 1/10W		D81		*	LM1MA142WK-G	DIODE	
R344			RK73GB2A473J	CHIP R 47K J 1/10W		D103			LM1MA142WA-G	DIODE	
R345			RD14BB2C473J	RD 47K J 1/6W		D105,106			RD5.1JS(B2)	ZENER DIODE	
R347			RK73GB2A104J	CHIP R 100K J 1/10W		D107			1SS133	DIODE	
R348,349			RK73GB2A182J	CHIP R 1.8K J 1/10W		D108			RD5.1JS(B2)	ZENER DIODE	
R350,351			RK73GB2A103J	CHIP R 10K J 1/10W		D109-118			1SS133	DIODE	
R352			RK73GB2A302J	CHIP R 3.0K J 1/10W		D127-130			1SS133	DIODE	
R353			RK73GB2A561J	CHIP R 560 J 1/10W		D131-133			1SS355	DIODE	
R354-357			RK73GB2A100J	CHIP R 10 J 1/10W		D251			1SS133	DIODE	
R360			RK73GB2A563J	CHIP R 56K J 1/10W		D301			LM1MA142WA-G	DIODE	
R401			RK73GB2A103J	CHIP R 10K J 1/10W		D302		*	LM1MA142WK-G	DIODE	
R402			RK73GB2A473J	CHIP R 47K J 1/10W		D303			STZ6.8N	ZENER DIODE	
R418,419			RK73GB2A104J	CHIP R 100K J 1/10W		D304,305			1SS355	DIODE	
R420			RK73GB2A103J	CHIP R 10K J 1/10W		D306-308			STZ6.8N	ZENER DIODE	
R421,422			RK73GB2A101J	CHIP R 100 J 1/10W		D309			DA204U	DIODE	
R423,424			RK73GB2A103J	CHIP R 10K J 1/10W		D310			UDZS5.1B	ZENER DIODE	
R425,426			RK73GB2A181J	CHIP R 180 J 1/10W		D311			STZ6.8N	ZENER DIODE	
R427-429			RK73GB2A103J	CHIP R 10K J 1/10W		D312		*	UDZS16B	ZENER DIODE	
R430			RK73GB2A222J	CHIP R 2.2K J 1/10W		D313,314			STZ6.8N	ZENER DIODE	
R431			RK73GB2A473J	CHIP R 47K J 1/10W		D315		*	LM1MA142WK-G	DIODE	
R432,433			RK73GB2A272J	CHIP R 2.7K J 1/10W		D317			DA204U	DIODE	
R434			RK73GB2A103J	CHIP R 10K J 1/10W		D318			1SS355	DIODE	
R438			RK73GB2A153J	CHIP R 15K J 1/10W		D319			STZ6.8N	ZENER DIODE	
R439			RK73GB2A301J	CHIP R 300 J 1/10W		D341-344			1SS355	DIODE	
R440			RK73GB2A103J	CHIP R 10K J 1/10W		D351			UDZS5.1B	ZENER DIODE	
R441			RK73GB2A102J	CHIP R 1.0K J 1/10W		D352			UDZS10B	ZENER DIODE	
R442			RK73GB2A182J	CHIP R 1.8K J 1/10W		D353		*	UDZS3.3B	ZENER DIODE	
R443,444			RK73GB2A272J	CHIP R 2.7K J 1/10W		D354			UDZS5.1B	ZENER DIODE	
R450-453			RK73GB2A102J	CHIP R 1.0K J 1/10W		IC1			BA4560F	IC	
R454,455			RK73GB2A101J	CHIP R 100 J 1/10W		IC2		*	UPC494GS	ANALOGUE IC	
R458-460			RK73GB2A101J	CHIP R 100 J 1/10W		IC3			P82B96PN	ANALOGUE IC	
R475,476			RK73GB2A562J	CHIP R 5.6K J 1/10W		IC5			BA10393F	ANALOGUE IC	
R477,478			RK73GB2A133J	CHIP R 13K J 1/10W		IC6		*	784224YGC117	MICROCONTROLLER IC	
R479,480			RK73GB2A103J	CHIP R 10K J 1/10W		IC7			PST3436UL-E	MOS-IC	
VR1,2			R12-0092-05	SEMI FIXED VARIABLE RESIST 220		IC9,10			BA4560F	IC	
W501-511			R92-2053-05	CHIP R 0 J 1/8W							

E1 : KAC-PS521 K : KAC-X521 (E : Europe K : North America)

△ Indicates safety critical components.

PARTS LIST

* New parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

AUDIO UNIT (X09-5760-10)

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
Q50			2SC4081	TRANSISTOR	
Q51,52			2SC4097	TRANSISTOR	
Q53,54			2SA1577	TRANSISTOR	
Q55-60		*	2SK3662-F	FET	
Q61		*	2SD2012-F	TRANSISTOR	
Q62		*	2SB1375-F	TRANSISTOR	
Q63			2SA1576A	TRANSISTOR	
Q64			2SB1241	TRANSISTOR	
Q65			DTC114EUA	DIGITAL TRANSISTOR	
Q66			2SB1238	TRANSISTOR	
Q68			2SC4081	TRANSISTOR	
Q69			2SA1576A	TRANSISTOR	
Q70,71			2SC4081	TRANSISTOR	
Q81		*	2SK246(BL)-F	FET	
Q91,92			DTA114EUA	DIGITAL TRANSISTOR	
Q97			2SC4081	TRANSISTOR	
Q101,102			2SC4081	TRANSISTOR	
Q103-110			2SA992(F,E)	TRANSISTOR	
Q111,112			2SA1576A	TRANSISTOR	
Q113-116			2SC3478A(L,K)	TRANSISTOR	
Q117,118			2SA1376A(L,K)	TRANSISTOR	
Q119,120			2SC3419(Y)	TRANSISTOR	
Q121,122			2SC1845(F,E)	TRANSISTOR	
Q123,124			2SA992(F,E)	TRANSISTOR	
Q125-128		*	2SC2235-F	TRANSISTOR	
Q129-132		*	2SA965-F	TRANSISTOR	
Q133-136		*	2SC3856NF	TRANSISTOR	
Q137-140		*	2SA1492NF	TRANSISTOR	
Q141			DTA124EUA	DIGITAL TRANSISTOR	
Q142			2SA1576A	TRANSISTOR	
Q143,144			2SC4081	TRANSISTOR	
Q145			2SA1576A	TRANSISTOR	
Q146			2SC1845(F,E)	TRANSISTOR	
Q147			2SA992(F,E)	TRANSISTOR	
Q148,149			2SC4081	TRANSISTOR	
Q301			2SC4081	TRANSISTOR	
Q302,303			2SA1576A	TRANSISTOR	
Q304			2SC4081	TRANSISTOR	
Q305,306			2SA1576A	TRANSISTOR	
Q307			DTC114EUA	DIGITAL TRANSISTOR	
Q313			DTC114EUA	DIGITAL TRANSISTOR	
Q314			DTA114EUA	DIGITAL TRANSISTOR	
Q341-344			2SC4081	TRANSISTOR	
Q346			DTC114EUA	DIGITAL TRANSISTOR	
Q347			DTA114EUA	DIGITAL TRANSISTOR	
Q348			DTC114EUA	DIGITAL TRANSISTOR	
Q349			DTA114EUA	DIGITAL TRANSISTOR	
Q351			DTA114EUA	DIGITAL TRANSISTOR	
Q352,353			DTC114EUA	DIGITAL TRANSISTOR	
Q354			DTA114EUA	DIGITAL TRANSISTOR	
Q355			DTC114EUA	DIGITAL TRANSISTOR	
Q356		*	2SC3902	TRANSISTOR	
Q357			2SC4081	TRANSISTOR	
Q358		*	2SC3902	TRANSISTOR	
Q403,404			2SC945(A)(Q,P)	TRANSISTOR	

Ref. No.	A d d	N e w	Parts No.	Description	Desti- nation
TH1-4		*	NT732ATTD103J	THERMISTOR	

E1 : KAC-PS521 K : KAC-X521 (E : Europe K : North America)

△ Indicates safety critical components.