




EXPLODED VIEW



KDC-5019/519/7021/7021Y/8020/B7021

PARTS LIST

* New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnes dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
KDC-5019/519/7021/7021Y/8020/B7021					
200	1A		A02-1497-13	PLASTIC CABINET ASSY	
202	1B	*	A52-0808-02	TOP PLATE	
203	2A		A10-4807-13	CHASSIS CALKING ASSY	
204	1A		A10-4810-13	CHASSIS CALKING ASSY	
205	2A		A10-4893-04	CHASSIS CALKING ASSY	
206	2A	*	A10-4924-02	CHASSIS	
211	3A	*	A21-4171-03	DRESSING PANEL	
212	2A		A22-2865-03	SUB PANEL ASSY	
213	3B	*	A46-1753-01	REAR COVER	
PA1	3A	*	A64-2578-02	PANEL ASSY	K
PA1	3A	*	A64-2579-02	PANEL ASSY	K1
PA1	3A	*	A64-2581-02	PANEL ASSY	M1
PA1	3A	*	A64-2583-02	PANEL ASSY	E2,Z1
PA1	3A	*	A64-2584-02	PANEL ASSY	Z2
PME1	2A	*	A10-4921-02	CHASSIS ASSY	
RC1	1B	*	A70-2025-05	REMOTE CONTROLLER ASSY (RC-410)	
RC2	2B		A70-0886-15	REMOTE CONTROLLER ASSY	E2,Z1,Z2
219	2A		B03-3073-12	DRESSING PLATE	
220	3B		B07-3007-03	ESCUTCHEON ASSY (BLK)	
221	1B		B07-3010-02	ESCUTCHEON (J CAR)	K,K1,M1
222	3A	*	B10-4157-01	FRONT GLASS	K
222	3A	*	B10-4158-01	FRONT GLASS	K1
222	3A	*	B10-4160-01	FRONT GLASS	M1
222	3A	*	B10-4162-01	FRONT GLASS	E2,Z1
222	3A	*	B10-4163-01	FRONT GLASS	Z2
223	3A	*	B10-4222-03	FRONT GLASS	
-			B46-0100-50	WARRANTY CARD	K,K1,M1
-			B46-0100-50	WARRANTY CARD	Z1,Z2
-			B46-0606-04	ID CARD	K,K1
-			B46-0612-14	ID CARD	M1
-			B46-0632-04	ID CARD	E2,Z1,Z2
-			B46-0645-03	USER CARD	K,K1
-		*	B64-2145-00	INST. MANUAL (ENG,RUS)	E2
-		*	B64-2146-00	INST. MANUAL (POL,CZE,HUN)	E2
-		*	B64-2147-00	INST. MANUAL (CRO,SWE,FIN)	E2
-		*	B64-2148-00	INST. MANUAL (ENG,FRE,SPA)	K,K1
-		*	B64-2149-00	INST. MANUAL (ENG,T-CHI)	M1
-		*	B64-2150-00	INST. MANUAL (ARABIC)	M1
-		*	B64-2151-00	INST. MANUAL (ENGLISH)	Z1,Z2
-		*	B64-2152-00	INST. MANUAL (FRE,GER,DUT)	Z1,Z2
-		*	B64-2153-00	INST. MANUAL (ITA,SPA,POR)	Z1,Z2
227	1A		D10-4562-04	LEVER	
227	1A		D10-4621-04	LEVER	Z1,Z2
228	2A		D10-4563-04	ARM ASSY	
229	2A		D10-4590-04	ARM	
230	1A		D13-2135-04	GEAR ASSY	
231	1A		D13-2138-04	GEAR	
232	1B		D13-2139-04	GEAR	
233	1A		D13-2140-04	GEAR	
234	1A		D13-2141-14	GEAR ASSY	
235	2A		D13-2165-03	GEAR ASSY	
236	2A		D14-0754-04	ROLLER	

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
237	2A		D14-0760-03	ROLLER	
243	3A	*	E29-1879-02	CONDUCTIVE RUBBER	
244	2B		E30-4935-05	CORD WITH PINPLUG	E2
244	2B		E30-4935-05	CORD WITH PINPLUG	K,K1,M1
244	2B		E30-4979-05	CORD WITH PINPLUG	Z1,Z2
245	2B		E30-4946-05	CORD WITH DIN CONNECTOR	E2
245	2B		E30-4946-05	CORD WITH DIN CONNECTOR	K,K1,M1
245	2B		E30-4947-05	CORD WITH DIN CONNECTOR	
DC1	1A		E30-4940-05	DC CORD	K,K1
DC2	1A		E30-4939-05	DC CORD	M1
DC3	1A		E30-4942-05	DC CORD	E2
DC3	1A		E30-4956-05	DC CORD	Z1,Z2
FC1	1B	*	E39-0462-05	FLAT CABLE (22P)	
250	1B		F29-0049-05	INSULATING COVER	
F1	2B		F52-0006-05	FUSE (MINI BLADE TYPE) (10A)	
F1	2B		F52-0011-05	FUSE (MINI BLADE TYPE) (10A)	E2
F1	2B		F52-0011-05	FUSE (MINI BLADE TYPE) (10A)	K,K1,M1
255	1B		G01-2924-04	TORSION COIL SPRING	
256	2A		G01-3065-04	EXTENSION SPRING	
257	2A		G01-3066-14	TORSION COIL SPRING	
258	3B		G01-3069-04	EXTENSION SPRING	
259	2A		G01-3080-04	TORSION COIL SPRING	
260	2A		G09-2038-04	FORMED WIRE	
261	2A		G09-2042-04	FORMED WIRE	
262	2A		G11-1927-04	CUSHION	
263	2A		G16-1177-04	SHEET	
-			H10-4762-12	POLYSTYRENE FOAMED FIXTURE	Z1,Z2
-			H10-4763-12	POLYSTYRENE FOAMED FIXTURE	E2
-			H10-4764-12	POLYSTYRENE FOAMED FIXTURE	K,K1,M1
-			H25-0329-04	PROTECTION BAG (280X450X0.03)	E2
-			H25-0329-04	PROTECTION BAG (280X450X0.03)	K,K1,M1
-			H25-0337-04	PROTECTION BAG (180X300X0.03)	
-			H25-1108-04	PROTECTION BAG (100X300X0.03)	
-			H25-1111-04	PROTECTION BAG (280X450X0.03)	Z1,Z2
-	*		H54-2339-03	ITEM CARTON CASE	K1
-	*		H54-2340-03	ITEM CARTON CASE	M1
-	*		H54-2341-03	ITEM CARTON CASE	Z2
-	*		H54-2345-03	ITEM CARTON CASE	K
-	*		H54-2346-03	ITEM CARTON CASE	Z1
-	*		H54-2347-03	ITEM CARTON CASE	E2
266	1B		J19-5051-03	BRACKET (L)	K,K1,M1
267	1B		J19-5052-03	BRACKET (R)	K,K1,M1
268	3A	*	J19-5136-02	HOLDER	
269	2A		J21-9651-13	MOUNTING HARDWARE ASSY	
271	1B		J21-9716-03	MOUNTING HARDWARE ASSY	
272	3A		J90-0999-04	GUIDE	
FFPC1	1A		J84-0122-04	FLEXIBLE PRINTED WIRING BOARD	
275	3A		K24-3646-04	KNOB (OPEN)	
276	3A	*	K24-3835-04	KNOB (SRC)	
277	3A	*	K25-1404-03	KNOB (VOL)	
278	3A	*	K25-1405-02	KNOB (PRESET)	
279	3A	*	K25-1406-03	KNOB (FM,AM)	

K: KDC-519 K1: KDC-5019 M1: KDC-8020
E2: KDC-7021Y Z1: KDC-7021 Z2: KDC-B7021

 indicates safety critical components.

KDC-5019/519/7021/7021Y/8020/B7021

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

KDC-5019/519/7021/7021Y/8020/B7021

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
280	3A	*	K25-1407-03	KNOB (PROG)	K,K1,M1
281	3A	*	K25-1408-03	KNOB (UP,DOWN)	
282	3A		K29-7017-03	KNOB (LOCK)	
284	1B	*	N99-1722-05	SCREW SET	
285	1B		N99-1704-05	SCREW SET	
A	1A		N09-4400-05	MACHINE SCREW (M2X2)	
B	1A		N09-4401-05	MACHINE SCREW (M2X2.5)	
C	1A		N09-4427-05	TAPTITE SCREW (S2X4)	
D	2A		N09-4448-05	MACHINE SCREW (M2X2.5)	
E	3A		N09-4449-05	MACHINE SCREW (M2X1.8 BLK)	
F	1B		N19-2154-04	FLAT WASHER (1.6X5X0.25 LUMI)	
G	2A		N19-2155-04	FLAT WASHER (1.6X5X0.35 LUMI)	
H	2A		N19-2156-04	FLAT WASHER (1.2X3X0.25 POLY)	
J	1A		N29-0523-05	RETAINING RING (2X5X0.4)	
K	2A		N29-0522-05	RETAINING RING (1.5X4X0.4)	
L	3A		N38-2025-46	PAN HEAD MACHIN SCREW	
M	3A		N80-2005-46	PAN HEAD TAPTITE SCREW	
N	2B		N80-2008-45	PAN HEAD TAPTITE SCREW	
P	1B		N83-3005-46	PAN HEAD TAPTITE SCREW	
Q	2A		N86-2004-45	BINDING HEAD TAPTITE SCREW	
PS1-3	1A		S68-0856-05	PUSH SWITCH	
286	1B		T90-0523-05	ANTENNA ADAPTOR	E2,Z1,Z2
286	1B		T90-0534-05	ANTENNA ADAPTOR	
PM1	1A		T42-1034-04	MOTOR ASSY	
DME1	1B		X92-4030-00	MECHANISM ASSY (DXM-6000W)	
SUB-CIRCUIT UNIT (X16-118X-XX)					
J1	2A		E58-0903-05	RECTANGULAR RECEPTACLE (15P)	
FPC1	2A	*	J84-0121-12	FLEXIBLE PRINTED WIRING BOARD	
SWITCH UNIT (X16-1XXX-XX)					
301	3A		B11-1324-04	OPTICAL DIFFUSER	K,E2,Z1
301	3A	*	B11-1382-04	OPTICAL DIFFUSER	
302	3A		B11-1322-04	REFLECTION SHEET	
303	3A	*	B19-2134-03	LIGHTING BOARD	K,E2,Z1
D1-3			B30-1571-05	LED(WHITE)	
D1,2			B30-1571-05	LED(WHITE)	
D5-18			B30-1605-05	LED(2COLOR PG/RED)	K1,M1,Z1
D20-22			B30-1605-05	LED(2COLOR PG/RED)	
D23,24			B30-1564-05	LED(1608,BLUE)	
ED1	3A	*	B38-1086-05	LIQUID CRYSTAL	K,E2,Z1
ED1	3A	*	B38-1088-05	LIQUID CRYSTAL	K1,M1,Z1
C1			CC73GCH1H681J	CHIP C 680PF J	K,E2,Z1
C2-5			CK73GB1C104K	CHIP C 0.10UF K	
C2-5			CK73GB1H104K	CHIP C 0.10UF K	
C6,7			CK73FB1A225K	CHIP C 2.2UF K	
C9			CK73GB1H103K	CHIP C 0.010UF K	
C11-14			CK73GB1H103K	CHIP C 0.010UF K	
304	3A		E29-1885-04	CONDUCTIVE RUBBER	K,E2,Z1
J1			E59-0835-05	RECTANGULAR PLUG (15P)	
CP1			R90-1016-05	MULTI-COMP 470 X4	

Ref.No.	Add	New	Parts No.	Description			Destination	
CP2,3			R90-0724-05	MULTI-COMP	1K	X4		
R1			RK73GB2A433J	CHIP R	43K	J 1/10W		
R2-5			RK73GB2A222J	CHIP R	2.2K	J 1/10W		
R6			RK73GB2A392J	CHIP R	3.9K	J 1/10W		
R7,8			RK73GB2A223J	CHIP R	22K	J 1/10W		
R9			RK73GB2A101J	CHIP R	100	J 1/10W		
R10			RK73GB2A102J	CHIP R	1.0K	J 1/10W		
R11			RK73GB2A4R7J	CHIP R	4.7	J 1/10W		
R12			RK73GB2A361J	CHIP R	360	J 1/10W		
R13,14			RK73GB2A102J	CHIP R	1.0K	J 1/10W		
R15,16			RK73GB2A103J	CHIP R	10K	J 1/10W		
R17-21			RK73FB2B331J	CHIP R	330	J 1/8W		
R22			RK73FB2B511J	CHIP R	510	J 1/8W		
R23			RK73FB2B271J	CHIP R	270	J 1/8W		
R24			RK73FB2B331J	CHIP R	330	J 1/8W		
R25		*	RK73GB2A122J	CHIP R	1.2K	J 1/10W		K,E2,Z1
R27,28			RK73GB2A103J	CHIP R	10K	J 1/10W		K,E2,Z1
R29		*	RK73GB2A122J	CHIP R	1.2K	J 1/10W		
S28			S70-0864-05	TACT SWITCH				K1,M1,Z2 K,E2,Z1
D26			MA3082-M	ZENER DIODE				
D26			MA3091-M	ZENER DIODE				
IC1			LC75808W	MOS-IC				
IC2			RS-171	ANALOGUE IC				
Q1			DTA114EUA	DIGITAL TRANSISTOR				
Q1			KRA302	DIGITAL TRANSISTOR				
Q3-5			2SC4081	TRANSISTOR				
Q6			DTA114EUA	DIGITAL TRANSISTOR				
Q6			KRA302	DIGITAL TRANSISTOR				
Q7			DTC143ZK	DIGITAL TRANSISTOR				
ELECTRIC UNIT (X25-XXXX-XX)								
C1			C90-5242-05	ELECTRO	3300UF	16WV	E2,Z1,Z2	
C2			CK73GB1H222K	CHIP C	2200PF	K		
C3			C90-2866-05	ELECTRO	220UF	16WV		
C4			CK73GB1H103K	CHIP C	0.010UF	K		
C5			CE04NW1C100M	ELECTRO	10UF	16WV		
C6			CE04NW0J101M	ELECTRO	100UF	6.3WV		
C7			CK73FB1C105K	CHIP C	1.0UF	K		
C8			CE04CW1A221M	ELECTRO	220UF	10WV		
C9			CE04NW1A101M	ELECTRO	100UF	10WV		
C11,12			CK73FB1H104K	CHIP C	0.10UF	K		
C20			CK73GB1H103K	CHIP C	0.010UF	K		
C21			CK73GB1E223K	CHIP C	0.022UF	K		
C21			CK73GB1H223K	CHIP C	0.022UF	K		
C22			CE04NW1H010M	ELECTRO	1.0UF	50WV		
C34			CE04NW1V3R3M	ELECTRO	3.3UF	35WV		
C35			CK73GB1C683K	CHIP C	0.068UF	K		
C36			CE04NW1HOR1M	ELECTRO	0.1UF	50WV		
C37			CK73GB1H102K	CHIP C	1000PF	K		
C38,39			CK73GB1H103K	CHIP C	0.010UF	K		
C40			CE04NW0J470M	ELECTRO	47UF	6.3WV		
C41			CK73GB1H103K	CHIP C	0.010UF	K		
C42			CC73GCH1H220J	CHIP C	22PF	J		
C43			CC73GCH1H270J	CHIP C	27PF	J		
C44			CK73GB0J105K	CHIP C	1.0UF	K		

K: KDC-519 K1: KDC-5019 M1: KDC-8020
E2: KDC-7021Y Z1: KDC-7021 Z2: KDC-B7021

⚠ indicates safety critical components.

PARTS LIST

* New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnes dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
C45			CK73EB0J106K	CHIP C 10UF K	
C46			CK73GB1H102K	CHIP C 1000PF K	
C48			CK73GB1H103K	CHIP C 0.010UF K	
C61			CE04NW1A470M	ELECTRO 47UF 10WV	
C62			CK73GB1H103K	CHIP C 0.010UF K	
C63			CE04NW1H2R2M	ELECTRO 2.2UF 50WV	
C65-68			CE04NW1HR47M	ELECTRO 0.47UF 50WV	
C69			CE04NW0J470M	ELECTRO 47UF 6.3WV	
C70			CK73GB1A474K	CHIP C 0.47UF K	
C71			CC73GCH1H151J	CHIP C 150PF J	
C72			CK73GB1E333K	CHIP C 0.033UF K	
C72			CK73GB1H333K	CHIP C 0.033UF K	
C73			CK73GB1H103K	CHIP C 0.010UF K	
C74,75			CK73GB1C104K	CHIP C 0.10UF K	
C74,75			CK73GB1H104K	CHIP C 0.10UF K	
C93-96			C90-2597-05	ELECTRO 10UF 16WV	
C113			CE04NW1HR47M	ELECTRO 0.47UF 50WV	
C114			CE04NW1C220M	ELECTRO 22UF 16WV	
C115			CE04NW1H010M	ELECTRO 1.0UF 50WV	
C116			CK73GB1C104K	CHIP C 0.10UF K	
C116			CK73GB1H104K	CHIP C 0.10UF K	
C117-120			C90-5296-05	NP-ELECT 0.22UF 50WV	
C131			CK73GB1H103K	CHIP C 0.010UF K	
C133			CK73GB1A224K	CHIP C 0.22UF K	
C134			CE04CW1A470M	ELECTRO 47UF 10WV	
C135			CK73GB1H103K	CHIP C 0.010UF K	
C137			CK73GB1H103K	CHIP C 0.010UF K	
C139			CK73GB1H102K	CHIP C 1000PF K	
C140			CK73GB1A474K	CHIP C 0.47UF K	
C141			CC73GCH1H331J	CHIP C 330PF J	E2,Z1,Z2
C142,143			CE04NW1C100M	ELECTRO 10UF 16WV	E2,Z1,Z2
C144			CK73GB1H103K	CHIP C 0.010UF K	E2,Z1,Z2
C145,146			CC73GCH1H100D	CHIP C 10PF D	E2,Z1,Z2
C147,148			CK73GB1A224K	CHIP C 0.22UF K	
C149			CK73GB1C104K	CHIP C 0.10UF K	K,K1,M1
C149			CK73GB1H104K	CHIP C 0.10UF K	K,K1,M1
C151,152			CK73GB1H222K	CHIP C 2200PF K	
C153			CK73GB1E223K	CHIP C 0.022UF K	
C153			CK73GB1H223K	CHIP C 0.022UF K	
C160,161			CK73GB1E473K	CHIP C 0.047UF K	
C160,161			CK73GB1H473K	CHIP C 0.047UF K	
CN1			E40-3241-05	PIN ASSY (6P)	
CN2			E40-3237-05	PIN ASSY (2P)	
CN3			E40-3252-05	PIN ASSY (8P)	
CN4			E40-3261-05	PIN ASSY (3P)	
CN5			E40-9550-05	FLAT CABLE CONNECTOR (22P)	
CN6			E40-9557-05	FLAT CABLE CONNECTOR (13P)	
CN7			E40-5031-05	FLAT CABLE CONNECTOR (7P)	
J1			E58-0863-15	RECTANGULAR RECEPTACLE (16P)	
WH1	2B		E30-4804-05	CORD WITH PLUG	
WH1	2B		E30-4932-05	CORD WITH PLUG	
L1			L33-1170-05	CHOKE COIL ASSY (140UH)	
L4			L40-4795-91	SMALL FIXED INDUCTOR (4.7UH,J)	
L5			L92-0075-05	CHIP FERRITE	

ELECTRIC UNIT (X25-XXXX-XX)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
L6			L40-4795-91	SMALL FIXED INDUCTOR (4.7UH,J)	
L7			L33-1039-05	LINE FILTER COIL (52mH)	
L9-12			L40-4795-91	SMALL FIXED INDUCTOR (4.7UH,J)	
X1			L78-0821-05	RESONATOR (20.0MHz)	
X2			L77-2738-05	CRYSTAL RESONATOR (32.768kHz)	
X3			L77-2002-05	CRYSTAL RESONATOR (4.332MHz)	E2,Z1,Z2
P	2B		N83-3005-46	PAN HEAD TAPTITE SCREW	
R	2B		N80-3008-46	PAN HEAD TAPTITE SCREW	
S	2B		N83-3012-46	PAN HEAD TAPTITE SCREW	
T	2B		N86-2606-46	BINDING HEAD TAPTITE SCREW	
CP1,2			R90-0725-05	MULTI-COMP 1K X2	
CP3			R90-1019-05	MULTI-COMP 100 X2	
CP4			R90-0737-05	MULTI-COMP 100K X2	
CP5			R90-0725-05	MULTI-COMP 1K X2	
CP6			R90-1013-05	MULTI-COMP 2.2K X2	
R1			RK73GB2A223J	CHIP R 22K J 1/10W	
R2			RK73GB2A101J	CHIP R 100 J 1/10W	
R3			RK73GB2A223J	CHIP R 22K J 1/10W	
R4			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R5			RD14BB2C221J	RD 220 J 1/6W	
R6			RK73GB2A153J	CHIP R 15K J 1/10W	
R7			R92-3032-05	CHIP R 4.3K D 1/10W	
R8			R92-3047-05	CHIP R 24K D 1/10W	
R9			RD14BB2C152J	RD 1.5K J 1/6W	
R10		*	RK73EB2E2R2J	CHIP R 2.2 J 1/4W	
R11			RD14BB2C102J	RD 1.0K J 1/6W	
R13			RK73EB2E102J	CHIP R 1.0K J 1/4W	M1,E2,Z1,Z2
R13			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R14			RD14BB2C561J	RD 560 J 1/6W	M1,E2,Z1,Z2
R14			RD14BB2C561J	RD 560 J 1/6W	
R15			RK73EB2E103J	CHIP R 10K J 1/4W	E2,Z1,Z2
R16			RK73GB2A223J	CHIP R 22K J 1/10W	E2,Z1,Z2
R17			RK73GB2A473J	CHIP R 47K J 1/10W	E2,Z1,Z2
R18			RK73GB2A104J	CHIP R 100K J 1/10W	K,K1,M1
R19			RK73EB2E103J	CHIP R 10K J 1/4W	
R20			RK73GB2A104J	CHIP R 100K J 1/10W	
R33			RD14BB2C472J	RD 4.7K J 1/6W	
R34,35			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	K,K1,M1
R36			RD14BB2C223J	RD 22K J 1/6W	K,K1,M1
R37			RD14BB2C472J	RD 4.7K J 1/6W	
R38			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	
R39			RK73GB2A223J	CHIP R 22K J 1/10W	
R40			RD14DB2H102J	SMALL-RD 1.0K J 1/2W	
R41,42			RK73GB2A123J	CHIP R 12K J 1/10W	
R43			RK73GB2A562J	CHIP R 5.6K J 1/10W	
R44			RK73GB2A223J	CHIP R 22K J 1/10W	
R45			RD14DB2H332J	SMALL-RD 3.3K J 1/2W	
R46			RD14BB2C473J	RD 47K J 1/6W	
R47			RK73GB2A183J	CHIP R 18K J 1/10W	
R48			RK73GB2A104J	CHIP R 100K J 1/10W	
R49			RK73GB2A103J	CHIP R 10K J 1/10W	
R50			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R51			RK73GB2A104J	CHIP R 100K J 1/10W	K,K1,Z2
R52			RK73GB2A104J	CHIP R 100K J 1/10W	M1

K: KDC-519 K1: KDC-5019 M1: KDC-8020
E2: KDC-7021Y Z1: KDC-7021 Z2: KDC-B7021

⚠ indicates safety critical components.

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnés dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-XXXX-XX)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
R52,53			RK73GB2A104J	CHIP R 100K J 1/10W	E2,Z1
R53			RK73GB2A104J	CHIP R 100K J 1/10W	K1
R54			RK73GB2A104J	CHIP R 100K J 1/10W	K
R54,55			RK73GB2A104J	CHIP R 100K J 1/10W	M1,Z2
R56			RK73GB2A104J	CHIP R 100K J 1/10W	K,K1,E2
R56			RK73GB2A104J	CHIP R 100K J 1/10W	Z1
R60			RK73GB2A104J	CHIP R 100K J 1/10W	
R62			RK73GB2A104J	CHIP R 100K J 1/10W	
R66			RK73GB2A104J	CHIP R 100K J 1/10W	
R67			RK73GB2A103J	CHIP R 10K J 1/10W	
R68		*	RK73GB2A221J	CHIP R 220 J 1/10W	
R69			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R72			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R73,74			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R75			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R76			RK73GB2A104J	CHIP R 100K J 1/10W	
R77			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R79			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R80,81			RK73GB2A104J	CHIP R 100K J 1/10W	K,K1,M1
R82			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R84			RK73GB2A471J	CHIP R 470 J 1/10W	
R85			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R86			RK73GB2A104J	CHIP R 100K J 1/10W	K,K1,M1
R88			RK73GB2A104J	CHIP R 100K J 1/10W	
R89			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R90			RK73GB2A104J	CHIP R 100K J 1/10W	
R93			RK73GB2A104J	CHIP R 100K J 1/10W	
R96			RK73GB2A104J	CHIP R 100K J 1/10W	
R97,98			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R100			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R101		*	RK73GB2A105J	CHIP R 1.0M J 1/10W	
R102			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R103			RK73GB2A471J	CHIP R 470 J 1/10W	
R104			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R105			RK73GB2A471J	CHIP R 470 J 1/10W	
R106			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R107			RK73GB2A225J	CHIP R 2.2M J 1/10W	
R108			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R109			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R110			RK73GB2A103J	CHIP R 10K J 1/10W	
R111			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R112			RK73GB2A103J	CHIP R 10K J 1/10W	
R113			RK73GB2A473J	CHIP R 47K J 1/10W	
R114			RK73GB2A103J	CHIP R 10K J 1/10W	
R115			RK73GB2A104J	CHIP R 100K J 1/10W	
R116			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R117-119			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R130,131			RK73EB2E472J	CHIP R 4.7K J 1/4W	
R132-134			RK73EB2E101J	CHIP R 100 J 1/4W	
R135-137			RK73EB2E472J	CHIP R 4.7K J 1/4W	
R150			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R151			RK73GB2A103J	CHIP R 10K J 1/10W	
R152			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R155,156			RK73EB2E100J	CHIP R 10 J 1/4W	
R157			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
R158			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R159			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R161-164			RK73FB2B361J	CHIP R 360 J 1/8W	
R165-168			RK73GB2A223J	CHIP R 22K J 1/10W	
R169-172		*	RK73EB2E181J	CHIP R 180 J 1/4W	
R200			RK73GB2A101J	CHIP R 100 J 1/10W	
R201			RK73GB2A103J	CHIP R 10K J 1/10W	
R202			RK73GB2A822J	CHIP R 8.2K J 1/10W	
R203			RK73GB2A473J	CHIP R 47K J 1/10W	
R204		*	RK73GB2A152J	CHIP R 1.5K J 1/10W	
R205-208			RK73GB2A223J	CHIP R 22K J 1/10W	
R210			RD14BB2C102J	RD 1.0K J 1/6W	
R211			RK73GB2A223J	CHIP R 22K J 1/10W	
R212			RD14BB2C102J	RD 1.0K J 1/6W	
R213			RK73GB2A223J	CHIP R 22K J 1/10W	
R214-216			RK73GB2A222J	CHIP R 2.2K J 1/10W	E2,Z1,Z2
R217			RK73GB2A102J	CHIP R 1.0K J 1/10W	E2,Z1,Z2
R218			RK73GB2A472J	CHIP R 4.7K J 1/10W	E2,Z1,Z2
R220,221			RK73GB2A104J	CHIP R 100K J 1/10W	
R222-224			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R230			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R231			RK73GB2A473J	CHIP R 47K J 1/10W	
R233			RK73EB2E471J	CHIP R 470 J 1/4W	
R234			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R235			RK73EB2E472J	CHIP R 4.7K J 1/4W	
R236			RK73EB2E471J	CHIP R 470 J 1/4W	
R237,238			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R240			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R243			RK73GB2A473J	CHIP R 47K J 1/10W	
D1			S2V20*A	DIODE	
D2			1GWJ43	DIODE	
D3			MA4056(N)-M	ZENER DIODE	
D4			HZS9A2L	ZENER DIODE	
D4			MA4082(N)-L	ZENER DIODE	
D5			MA4110-L	ZENER DIODE	
D7			MA4056-M	ZENER DIODE	M1,E2,Z1
D7			MA4056-M	ZENER DIODE	Z2
D8			HZS5B1	ZENER DIODE	E2,Z1,Z2
D8			MA4047-M	ZENER DIODE	E2,Z1,Z2
D11,12			AM01Z	DIODE	
D11,12			DSM1SD2	DIODE	
D11,12			ERA15-01	DIODE	Z1,Z2
D11,12			ERA15-02	DIODE	
D14			AM01Z	DIODE	
D14			DSM1SD2	DIODE	
D14			ERA15-01	DIODE	Z1,Z2
D14			ERA15-02	DIODE	
D15			1SS133	DIODE	
D16			MA4056(N)-M	ZENER DIODE	
D17			HZS6C2L	ZENER DIODE	
D17			MA4062(N)-M	ZENER DIODE	
D18			1SS133	DIODE	
D22-24			HZS6C1	ZENER DIODE	
D22-24			MA4062-L	ZENER DIODE	

K: KDC-519 K1: KDC-5019 M1: KDC-8020
E2: KDC-7021Y Z1: KDC-7021 Z2: KDC-B7021

⚠ indicates safety critical components.

KDC-5019/519/7021/7021Y/8020/B7021

PARTS LIST

* New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnes dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-XXXX-XX)

Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on	Ref.No.	A d d	N e w	Parts No.	Description	Dest inati on
D25,26 D27,28 D29 D29 D30-32			RD6.8M (B2) MA4068 (N)-M HZS6C1 MA4062-L 1SS133	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE DIODE		Q26 Q27 Q27 Q28 Q28			2SB1277 (Q,R) 2SA1576A 2SB1218A DTA124EUA KRA303	TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	E2,Z1,Z2
D33-36 D33-36 D33-36 D33-36 D38-41			AM01Z DSM1SD2 ERA15-01 ERA15-02 AM01Z	DIODE DIODE DIODE DIODE DIODE	Z1,Z2	Q29 Q29 Q30,31 Q30,31 Q32,33			DTC114YUA UN5214 2SC4081 2SD1819A DTA124EUA	DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR	
D38-41 D38-41 D38-41 D60 D60			DSM1SD2 ERA15-01 ERA15-02 IMSA-6801 SA-C2102-101TB	DIODE DIODE DIODE SURGE ABSORBER SURGE ABSORBER	Z1,Z2 Z1,Z2	Q32,33 Q35 Q35 Q36 Q36			KRA303 DTC124EUA UN5212 2SC4081 2SD1819A	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR	
D61-64 IC1 IC2 IC3 IC4		*	1SS133 UPD703033GC139 TDA7407D M5237ML TA8273H	DIODE MI-COM IC ANALOGUE IC IC (VOLTAGE REGULATOR) ANALOGUE IC		Q37-40 Q37-40 Q43 Q43 Q44			DTC143TUA KRC410 DTC124EUA UN5212 2SB1277(Q,R)	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR	
IC8 IC8 IC8 IC14 IC15		2B	HD74HC02FP TC74HC02AF 74VHC02SJ TDA7479D LB1930M	MOS-IC MOS-IC MOS-IC ANALOGUE IC ANALOGUE IC	Z1,Z2 E2,Z1,Z2	Q45 Q45 Q46 Q50 Q50			DTC124EUA UN5212 2SB1277(Q,R) DTC144EUA UN5213	DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	
IC16 Q1 Q2 Q2 Q3			S-80837ANNP 2SB1548(P) 2SC4081 2SD1819A 2SA1576A	MOS-IC TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR		Q51 Q51 Q52 Q52 Q53			2SA1576A 2SB1218A 2SC4081 2SD1819A DTC144EUA	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR	E2,Z1,Z2 E2,Z1,Z2
Q3 Q4 Q5 Q5 Q6,7			2SB1218A 2SB1548(P) DTC144EUA UN5213 DTA124EUA	TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR		Q53 TH1			UN5213 PTH9C42BD471Q	DIGITAL TRANSISTOR POSITIVE RESISTOR	
Q6,7 Q8 Q8 Q9 Q10			KRA303 DTC144EUA UN5213 2SD2375 2SB1184	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR		A1 A1 A1			X86-3240-11 X86-3242-70 X86-3342-71	TUNER UNIT TUNER UNIT TUNER UNIT	K,K1,M1 E2,Z1,Z2 Z1,Z2
Q11 Q11 Q12 Q12 Q13			2SC4081 2SD1819A DTC144EUA UN5213 DTA124EUA	TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR							
Q13 Q14 Q14 Q14 Q14			KRA303 DTA123JK DTA123JK KRA105S KRA105S	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	M1,E2,Z1 Z2 M1,E2,Z1 Z2						
Q15 Q15 Q24 Q24 Q25,26			DTC144EUA UN5213 DTC114YUA UN5214 2SB1277 (Q,R)	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR	K,K1,M1 K,K1,M1 K,K1,M1						

K: KDC-519 K1: KDC-5019 M1: KDC-8020
E2: KDC-7021Y Z1: KDC-7021 Z2: KDC-B7021

 indicates safety critical components.

X92-4030-0x
X92-4440-0x

PARTS LIST

*New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	A d d	N e w	Parts No.	Description			D e s t i n a t i o n
CD PLAYER UNIT (X32-5170-0x, X32-5190-0x)							
C1,2 C3 C4 C5 C6			CK73GB0J105K CK73FB1A225K C92-0566-05 CC73GCH1H150J CC73GCH1H020C	CHIP C CHIP C CHIP-TAN CHIP C CHIP C	1.0UF 2.2UF 10UF 15PF 2.0PF	K K 6.3WV J C	
C7 C8 C10 C11 C12			CK73GB1C104K CK73GB0J105K CK73GB1H472K CK73GB1H682K CK73GB1H332K	CHIP C CHIP C CHIP C CHIP C CHIP C	0.10UF 1.0UF 4700PF 6800PF 3300PF	K K K K K	
C13 C14 C15 C16 C17			CK73GB1C333K CK73GB1H472K CK73GB1E473K CC73GCH1H151J CK73GB1H472K	CHIP C CHIP C CHIP C CHIP C CHIP C	0.033UF 4700PF 0.047UF 150PF 4700PF	K K K J K	
C18 C19,20 C21 C23 C24			CC73GCH1H221J CK73GB1C104K CK73FB1A225K CK73GB1H102K CK73GB1E223K	CHIP C CHIP C CHIP C CHIP C CHIP C	220PF 0.10UF 2.2UF 1000PF 0.022UF	J K K K K	
C25 C26 C28 C29 C33			CK73GB1H153K CK73GB0J105K CK73GB0J105K CK73GB1C104K CK73GB1C104K	CHIP C CHIP C CHIP C CHIP C CHIP C	0.015UF 1.0UF 1.0UF 0.10UF 0.10UF	K K K K K	
C35 C39 C40 C41 C42			CK73GB1C104K CK73GB1H152K CK73GB1H103K CK73EB1C225K CK73GB1H152K	CHIP C CHIP C CHIP C CHIP C CHIP C	0.10UF 1500PF 0.010UF 2.2UF 1500PF	K K K K K	
C44 C46 C51 C55 C67,68			CK73GB1H103K CK73GB1E473K CK73GB1C104K CK73GB1C104K CK73GB1C104K	CHIP C CHIP C CHIP C CHIP C CHIP C	0.010UF 0.047UF 0.10UF 0.10UF 0.10UF	K K K K K	
C71,72 C77,78 C79,80 C85 C89			CK73GB1H471K CC73GCH1H680J CK73GB1H222K CK73GB1C104K CK73GB1H222K	CHIP C CHIP C CHIP C CHIP C CHIP C	470PF 68PF 2200PF 0.10UF 2200PF	K J K K K	
CN1 CN1 CN2 CN2		*	E40-9536-05 E41-0193-05 E40-9339-05 E41-0129-05	FLAT CABLE CONNECTOR (16p) FLAT CABLE CONNECTOR (16p) FLAT CABLE CONNECTOR (22P) FLAT CABLE CONNECTOR			
X1			L78-0572-05	RESONATOR 16.93MHZ			
CP1 CP2 R3 R5 R6		*	R90-1019-05 R90-1014-05 RK73GB2A272J RK73GB2A361J RK73GB2A272J	MULTI-COMP 100 MULTI-COMP 100 CHIP R CHIP R CHIP R	100 100 2.7K 360 2.7K	X2 X4 J 1/10W J 1/10W J 1/10W	
R9 R10,11			RK73FB2B100J RK73GB2A103J	CHIP R CHIP R	10 10K	J 1/8W J 1/10W	

A0 : X92-4030-00 (DXM-6000W) A3 : X92-4030-03 (DXM-6003W)
A1 : X92-4030-01 (DXM-6001W) A4 : X92-4030-04 (DXM-6004W)
A2 : X92-4030-02 (DXM-6002W) A5 : X92-4030-05 (DXM-6005W)

Ref. No.	A d d	N e w	Parts No.	Description			D e s t i n a t i o n
R12 R15 R16 R17 R18		*	RK73GB2A912J RK73GB2A824J RK73GB2A223J RK73GB2A433J RK73GB2A392J	CHIP R CHIP R CHIP R CHIP R CHIP R	9.1K 820K 22K 43K 3.9K	J 1/10W J 1/10W J 1/10W J 1/10W J 1/10W	
R19 R20 R21 R32 R34		*	RK73GB2A513J RK73GB2A104J RK73GB2A244J RK73GB2A683J RK73GB2A363J	CHIP R CHIP R CHIP R CHIP R CHIP R	51K 100K 240K 68K 36K	J 1/10W J 1/10W J 1/10W J 1/10W J 1/10W	
R36 R37 R38 R40 R46		*	RK73GB2A151J RK73GB2A471J RK73GB2A224J RK73GB2A133J RK73GB2A102J	CHIP R CHIP R CHIP R CHIP R CHIP R	150 470 220K 13K 1.0K	J 1/10W J 1/10W J 1/10W J 1/10W J 1/10W	
R47 R49 R52 R54 R70			RK73GB2A103J RK73GB2A472J RK73GB2A104J RK73GB2A104J RK73GB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	10K 4.7K 100K 100K 10K	J 1/10W J 1/10W J 1/10W J 1/10W J 1/10W	
R71 R73 R74 R75 R76		*	RK73GB2A113J RK73GB2A473J RK73GB2A123J RK73GB2A333J RK73GB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	11K 47K 12K 33K 10K	J 1/10W J 1/10W J 1/10W J 1/10W J 1/10W	
R79,80 R81 R82 R84 R101,102		*	RK73GB2A103J RK73GB2A333J RK73GB2A133J RK73GB2A103J RK73GB2A332J	CHIP R CHIP R CHIP R CHIP R CHIP R	10K 33K 13K 10K 3.3K	J 1/10W J 1/10W J 1/10W J 1/10W J 1/10W	
R103,104 R107,108 R110 R117,118 R121,122		*	RK73GB2A562J RK73FB2B331J RK73FB2B201J RK73FB2B203J RK73FB2B203J	CHIP R CHIP R CHIP R CHIP R CHIP R	5.6K 330 200 20K 20K	J 1/10W J 1/8W J 1/8W J 1/8W J 1/8W	
R125,126 R202 R214 R218 R233		*	RK73FB2B203J RK73GB2A104J RK73GB2A104J RK73GB2A473J RK73GB2A622J	CHIP R CHIP R CHIP R CHIP R CHIP R	20K 100K 100K 47K 6.2K	J 1/8W J 1/10W J 1/10W J 1/10W J 1/10W	
R234			RK73GB2A103J	CHIP R	10K	J 1/10W	
S1,2 S3 S4 S4		*	S68-0863-05 S68-0862-05 S68-0864-05 S68-0864-05	PUSH SWITCH PUSH SWITCH PUSH SWITCH PUSH SWITCH			A2A3 B2B3
D1 D2 D3 D4 IC1			DAN202U MA8051-L DA204U DAN202U AN22000AA	DIODE ZENER DIODE DIODE DIODE ANALOGUE IC			
IC2 IC2 IC2 IC2		*	MN662773KH2 MN662773KH2 MN662774KJ2 MN662774KJ2	MOS-IC MOS-IC MOS-IC MOS-IC			B0B1B2 B3B4B5 A0A1A2 A3A4A5

B0 : X92-4440-00 (DXM-6100W) B3 : X92-4440-03 (DXM-6103W)
B1 : X92-4440-01 (DXM-6101W) B4 : X92-4440-04 (DXM-6104W)
B2 : X92-4440-02 (DXM-6102W) B5 : X92-4440-05 (DXM-6105W)

PARTS LIST

* New Parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	A d d	N e w	Parts No.	Description	D e s t i n a t i o n
IC4		*	BA5824FP	ANALOGUE IC	
IC6		*	NJM4580M1	ANALOGUE IC	
Q1			MCH6101	TRANSISTOR	
Q2			DTC124EUA	DIGITAL TRANSISTOR	
Q3			DTA143XUA	DIGITAL TRANSISTOR	
Q4			2SA1362(Y)	TRANSISTOR	
Q5			DTC124EUA	DIGITAL TRANSISTOR	
CD MECHANISM ASSY (X92-4030-0x, X92-4440-0x)					
2	1B	*	A10-4827-12	CHASSIS OUTER	
5	2B	*	D10-4576-23	ARM ASSY CLAMP	
8	2A	*	D10-4579-03	LEVER ASSY ROLLER	
10	3A	*	D10-4581-13	ARM DISC-L	
11	2A	*	D10-4582-13	ARM DISC-R	
12	3A	*	D10-4583-03	ARM JOINT-L	
13	3A	*	D10-4584-03	ARM JOINT-R	
14	3B	*	D10-4585-03	ARM CARRIER	
15	2A	*	D10-4586-03	SLIDER L	
16	3B	*	D10-4587-02	SLIDER R	
17	3B	*	D10-4588-03	SLIDER TRIG	
18	3B	*	D10-4595-04	ARM LOCK	
19	3B	*	D10-4596-04	ARM ROLLER	
22	2A	*	D13-2151-04	GEAR ROLLER	
23	2B	*	D13-2152-04	GEAR HELICAL-1	
24	3B	*	D13-2153-04	GEAR SUN	
25	3B	*	D13-2154-04	GEAR PLANET	
26	3B	*	D13-2155-04	WORM 2	
27	3B	*	D13-2156-04	GEAR HELICAL-2	
28	3B	*	D13-2157-04	GEAR LOAD-1	
29	3B	*	D13-2158-04	GEAR LOAD-2	
30	3B	*	D13-2168-04	GEAR PICK-1	
31	3B	*	D13-2171-04	GEAR PICK-2	
32	2B	*	D13-2172-03	RACK (GEAR)	
33	2A	*	D14-0759-04	ROLLER N100X3DIES	
35	2B	*	D21-2382-04	SHAFT PICK	
36	1A	*	D23-0954-04	RETAINER	
37	1B	*	D39-0246-05	DAMPER	
38	2B	*	G01-3072-04	EXTENSION SPRING TRIGGER	
39	2A	*	G01-3073-04	TORSION COIL SPRING ROLLER-L	
40	2A	*	G01-3074-04	EXTENSION SPRING ROLLER-R	
41	2B	*	G01-3075-04	EXTENSION SPRING PICKUP	
42	2A	*	G01-3076-04	EXTENSION SPRING JOINT-SP	
43	1B	*	G01-3077-04	EXTENSION SPRING FLOATING	
44	2B	*	G02-1399-04	FLAT SPRING CLAMP	
45	2B	*	G02-1408-04	FLAT SPRING WORM	
51	1A	*	J21-9676-12	MOUNTING HARDWARE GUIDE-BKT	
52	3B	*	J21-9677-02	MOUNTING HARDWARE GEAR-BKT	
53	1B	*	J21-9678-03	MOUNTING HARDWARE DAMPER-BKT	
55	1A	*	J90-1001-11	GUIDE 1	
56	1B	*	J90-1023-03	GUIDE 2	
DFPC1	3A	*	J84-0128-15	FLEXIBLE P.W.B. PICK-FPC	
A	2B	*	N09-4460-05	TAPTITE SCREW PT2X8-SARA	
B	1B	*	N09-4472-05	MACHINE SCREW PICK-RACK	

Ref. No.	A d d	N e w	Parts No.	Description	D e s t i n a t i o n
C	2B	*	N09-6004-05	MACHINE SCREW M1.7X2.5	
D	1B	*	N09-6006-05	TAPTITE SCREW ST-2X3.5	
E	2B	*	N09-6007-05	MACHINE SCREW M2X2	
F	1A	*	N09-6051-05	TAPTITE SCREW PT2X6-BIND	
G	2A	*	N19-2163-04	FLAT WASHER 1.6X0.25	
H	1B	*	N39-2020-46	MACHIN SCREW M2X2	
DM1	3B	*	T42-1066-04	DC MOTOR ASSY SP	
DM2	2B	*	T42-1067-04	DC MOTOR ASSY LO	
DPU1	2B	*	T25-0223-05	OPTICAL PICKUP HEAD	

A0 : X92-4030-00 (DXM-6000W) A3 : X92-4030-03 (DXM-6003W)
A1 : X92-4030-01 (DXM-6001W) A4 : X92-4030-04 (DXM-6004W)
A2 : X92-4030-02 (DXM-6002W) A5 : X92-4030-05 (DXM-6005W)

B0 : X92-4440-00 (DXM-6100W) B3 : X92-4440-03 (DXM-6103W)
B1 : X92-4440-01 (DXM-6101W) B4 : X92-4440-04 (DXM-6104W)
B2 : X92-4440-02 (DXM-6102W) B5 : X92-4440-05 (DXM-6105W)