

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

● The  mark found on some component parts indicates the importance of the safety factor of the part.

Therefore, when replacing, be sure to use parts of identical designation.

● Screws adjacent to  mark on product are used for disassembly.

● For the applying amount of lubricants or glue, follow the instructions in this manual.

(In the case of no amount instructions, apply as you think it appropriate.)

● Nos. indicate the pages and Nos. in the service manual for the base model.

● When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560Ω → 56 x 10¹ → 561 RD1/4PU    J

47kΩ → 47 x 10³ → 473 RD1/4PU    J

0.5Ω → R50 RN2H    K

1Ω → 1R0 RS1P    K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62kΩ → 562 x 10¹ → 5621 RN1/4PC     F

CONTRAST TABLE

DDJ-ERGO-V/XJ5 and DDJ-ERGO-K/XJ25 are constructed the same except for the following:

Mark	No.	Symbol and Description	DDJ-ERGO-V/XJ5	DDJ-ERGO-K/XJ25	Remarks	
NSP	P51-1	PCB ASSEMBLIES				
		1..PLMX ASSY	DWM2450	DWM2486		
NSP	P51-2	2..CDJ1 Assy	DWX3302	DWX3428		
		1..PLJK ASSY	DWM2451	DWM2487		
		2..CDJ2 Assy	DWX3303	DWX3429		
		PACKING SECTION				
NSP	P47-2	VIRTUAL DJ LE software CD-ROM	DXX2685	Not used		
	P47-2	TRAKTOR LE 2 software CD-ROM	Not used	DXX2686		
	P47-3	Driver software/operating instructions CD-ROM	DRU1001	DRU1002		
	P47-4	Sound Setup	DRM1363	DRM1369		
	P47-5	Quick Start Guide	DRH1123	DRH1130		
	P47-6	Hardware Diagram for Virtual DJ (Table of Supported Functions) (En)	DRH1124	Not used		
NSP	P47-7	Hardware Diagram for Virtual DJ (Table of Supported Functions) (Fr)	DRH1136	Not used		
		License Key Label Assy	DXA2251	DXA2253		
		P47-18	Packing Case	DHG3079		DHG3141
		EXTERIOR SECION				
		P49-11	Chassis	DNK6005		DNK6153
		P49-19	Rear Panel	DAH2864		DAH2909
		P49-22	Foot/R	DNK6006		DNK6155
		P49-23	Foot/L	DNK6007		DNK6156
		P49-26	Label/V	DRW2492		Not used
NSP		Label/T	Not used	DRW2515	No. 16	
NSP		Label/TR	Not used	DRW2552		
NSP		Label/W	DRW2537	Not used		
		EQ (HI, MID, LOW) controls	DAA1284	DAA1279		
		Rotary VR Knob(B)				
		CONTROL PANEL SECION				
	P51-28	Control Panel	DNK6000	DNK6154		
	P51-29	Play Button Assy	DXA2252	Not used		
	P51-29	Play Button	Not used	DAC2897		

Mark	No.	Symbol and Description	DDJ-ERGO-V/XJ5	DDJ-ERGO-K/XJ25	Remarks
		JOG SECTION			
	P53-7	Plate/JOG	DAH2862	DAH2906	

Notes : The numbers in the remarks column correspond to the numbers on the “EXPLODED VIEWS”.
For PCB ASSEMBLIES, Refer to "CONTRAST OF PCB ASSEMBLIES".

CONTRAST OF PCB ASSEMBLIES

D_F CDJ1 ASSY

DWX3302 and DWX3428 are constructed the same except for the following:

Mark	Symbol and Description	DWX3302	DWX3428	Remarks
	D1250, D1260, D1272, D1283 D1215, D1220, D1232, D1237 D1240 D1258, D1264, D1274, D1281 D1285 R1233 R1255, R1263	SLR343BC4T(KL) SLI-343U8R(HJK) SLI-343U8R(HJK) SLI-343U8R(HJK) SLI-343U8R(HJK) RS1/10SR221J RS1/10SR221J	SLR343WBC7T(MN) SLI-343Y8Y(KLM) SLI-343M8G(GHJ) SLI-343Y8Y(KLM) SLI-343Y8Y(KLM) RS1/10SR750J RS1/10SR151J	

G_F CDJ2 ASSY

DWX3303 and DWX3429 are constructed the same except for the following:

Mark	Symbol and Description	DWX3303	DWX3429	Remarks
	D2246, D2257, D2265, D2275 D2213, D2231, D2247, D2252 D2233 D2262, D2269, D2271 R2224 R2243, R2250	SLR343BC4T(KL) SLI-343U8R(HJK) SLI-343U8R(HJK) SLI-343U8R(HJK) RS1/10SR221J RS1/10SR221J	SLR343WBC7T(MN) SLI-343Y8Y(KLM) SLI-343M8G(GHJ) SLI-343Y8Y(KLM) RS1/10SR750J RS1/10SR151J	