EXPLODED VIEW (DVD MECHANISM)



Parts with the exploded numbers larger than 700 are not supplied.

EXPLODED VIEW (UNIT)



Parts with the exploded numbers larger than 700 are not supplied.

EXPLODED VIEW (DNX4280BT/5180/6040EX/6180/6480BT/6980)



Parts with the exploded numbers larger than 700 are not supplied.

EXPLODED VIEW (DNX5280BT/5380/5380M/5380BT/5580BT)



※Depends on the models. Refer to the parts list.

Parts with the exploded numbers larger than 700 are not supplied.

PARTS LIST

*New Parts
Parts without Parts No. are not supplied.
Les articles non mentionnes dans le Parts No. ne sont pas fournis.
Teile ohne Parts No. werden nicht geliefert.

DNX4280BT/5180/5280BT/5380/5380M/5380BT/5580BT
DNX6040EX/6180/6480BT/6980

Ref.No.	Add	New	Parts No.	Description	Destination
203	1C	*	A22-3301-21	SUB PANEL ASSY	E1Q1X1
203	1C	*	A22-3301-21	SUB PANEL ASSY	M1M2C1
205	1D	*	A52-1160-02	TOP PLATE	
RC1	1E		A70-2107-05	REMOTE CONTROLLER AS(RC-DV3	KR1Q1
RC1	1E		A70-2107-05	REMOTE CONTROLLER AS(RC-DV3	X1M1M2
RC1	1E		A70-2107-05	REMOTE CONTROLLER AS(RC-DV3	C1
-		*	B59-2045-00	SUB-INSTRUCTION MANUAL(ENG.S	KK1K2
-		*	B59-2045-00	SUB-INSTRUCTION MANUAL(ENG.S	R1K3
-		*	B59-2046-00	SUB-INSTRUCTION MANUAL(FRE)	KK1K2
-		*	B59-2046-00	SUB-INSTRUCTION MANUAL(FRE)	K3
-		*	B59-2047-00	SUB-INSTRUCTION MANUAL(POR)	R1
-		*	B59-2048-00	SUB-INSTRUCTION MANUAL(ENG)	E1E2Q1
-		*	B59-2049-00	SUB-INSTRUCTION MA(FRE.GER.DU	E1E2
-		*	B59-2050-00	SUB-INSTRUCTION MANUAL(RUS)	Q1
-		*	B59-2051-00	SUB-INSTRUCTION MANUAL(ENG)	X1M1M2
-		*	B59-2051-00	SUB-INSTRUCTION MANUAL(ENG)	C1
-		*	B59-2052-00	SUB-INSTRUCTION MANUAL(S-CHI)	M1C1
-		*	B59-2053-00	SUB-INSTRUCTION MANUAL(ARA)	M2
-		*	B59-2068-00	SUB-INSTRUCTION MA(ITA.SPA.POR	E1E2
-		*	B64-4795-00	INSTRUCTION MANUAL(ARA)	M2
-		*	B64-4796-00	INSTRUCTION MANUAL(S-CHI)	C1
-		*	B64-4857-00	INSTRUCTION MANUAL(ARA)	M2
-		*	B64-4859-00	INSTRUCTION MANUAL(S-CHI)	C1
206	1E		B07-3165-02	ESCUTCHEON	KK1K2
206	1E		B07-3165-02	ESCUTCHEON	R1E1E2
206	1E		B07-3165-02	ESCUTCHEON	Q1X1K3
206	1E		B07-3165-02	ESCUTCHEON	M1M2
207	1F		B07-3172-12	ESCUTCHEON	X1M1M2
207	1F		B07-3172-12	ESCUTCHEON	C1
210	1E		D10-7012-04	LEVER	KK1K2
210	1E		D10-7012-04	LEVER	R1E1E2
210	1E		D10-7012-04	LEVER	Q1K3
DC1	1E		E30-6881-25	DC CORD	KK1K2
DC1	1E		E30-6881-25	DC CORD	R1X1K3
DC1	1E		E30-6881-25	DC CORD	M1M2C1
DC2	1E		E30-6796-15	DC CORD (ISO)	E1E2Q1
FC1	1D	*	E39-1193-05	FLAT CABLE	
FC2	2D	*	E39-1194-05	FLAT CABLE	
FC3	2D	*	E39-1197-05	FLAT CABLE	KR1
FC4	3D	*	E39-1198-05	FLAT CABLE	
WH1	3D	*	E39-1218-05	WIRING HARNESS	X1M1M2
WH1	3D	*	E39-1218-05	WIRING HARNESS	C1
217	2C	*	F07-2239-02	COVER	E1Q1X1
217	2C	*	F07-2239-02	COVER	M1M2C1
218	1D		F09-2929-04	CAP (USB)	KK1K2
218	1D		F09-2929-04	CAP (USB)	R1E1E2
218	1D		F09-2929-04	CAP (USB)	Q1K3
219	2C	*	F09-3070-05	FAN	
228	3C	*	F19-1839-03	COVER (DUCT)	
F1	2C		F52-0024-05	FUSE(MINI BLADE TYPE) 15A	\
234	1C	*	G01-4778-04	TORSION COIL SPRING	E1Q1X1
234	1C	*	G01-4778-04	TORSION COIL SPRING	M1M2C1
235	1C	*	G01-4779-04	TORSION COIL SPRING	E1Q1X1
235	1C	*	G01-4779-04	TORSION COIL SPRING	M1M2C1
239	3D		G16-1750-14	SHEET	
-		*	H54-4960-03	ITEM CARTON CASE	K
-		*	H54-4961-03	ITEM CARTON CASE	K1
-		*	H54-4962-03	ITEM CARTON CASE	K2
-		*	H54-4963-03	ITEM CARTON CASE	R1
-		*	H54-4964-03	ITEM CARTON CASE	E1
-		*	H54-4965-03	ITEM CARTON CASE	E2
-		*	H54-4966-03	ITEM CARTON CASE	Q1
-		*	H54-4967-03	ITEM CARTON CASE	X1
-		*	H54-4968-03	ITEM CARTON CASE	K3
-		*	H54-4969-03	ITEM CARTON CASE	M1
-		*	H54-4970-03	ITEM CARTON CASE	M2
-		*	H54-5034-03	ITEM CARTON CASE	C1
241	1E		H30-0595-04	ADHESIVE DOUBLE-COATED TAPE	X1M1M2
241	1E		H30-0595-04	ADHESIVE DOUBLE-COATED TAPE	C1
244	1E		J22-0657-03	MOUNTING HARDWARE ASSY	KK1K2
244	1E		J22-0657-03	MOUNTING HARDWARE ASSY	R1E1E2
244	1E		J22-0657-03	MOUNTING HARDWARE ASSY	Q1K3
245	1F		J22-0964-04	MOUNTING HARDWARE (GPS PLATE)	
252	3C		L92-0638-05	FERRITE CORE	
253	1E		N35-2008-43	BINDING HEAD MACHINE SCREW	E1Q1X1
253	1E		N35-2008-43	BINDING HEAD MACHINE SCREW	M1M2C1
254	1E		N99-1779-15	SCREW SET	KK1K2
254	1E		N99-1779-15	SCREW SET	R1X1K3
254	1E		N99-1779-15	SCREW SET	M1M2C1
A	3C		N09-6425-15	MACHINE SCREW (M3.0X5)	
B	2C		N09-6821-05	MACHINE SCREW	
C	2D	*	N09-6848-15	TAPTITE SCREW	
D	1D	*	N09-6851-05	MACHINE SCREW	
F	2C		N35-2614-48	BINDING HEAD MACHINE SCREW	
G	1C		N82-2007-47	BINDING HEAD TAPTITE SCREW	E1Q1X1
G	1C		N82-2007-47	BINDING HEAD TAPTITE SCREW	M1M2C1
H	2C		N82-2608-43	BINDING HEAD TAPTITE SCREW	
J			N86-2606-48	BINDING HEAD TAPTITE SCREW	
K	2C		N86-2608-43	BINDING HEAD TAPTITE SCREW	E1Q1X1
K	2C		N86-2608-43	BINDING HEAD TAPTITE SCREW	M1M2C1
255	1F		W01-1768-15	MICROPHONE	KK1K2
255	1F		W01-1768-15	MICROPHONE	R1E1E2
255	1F		W01-1768-15	MICROPHONE	Q1X1
256	1E	*	W01-2004-05	ACCESSORIES (REMOCON CABLE)	X1M1M2
256	1E	*	W01-2004-05	ACCESSORIES (REMOCON CABLE)	C1
257	1F	*	W01-2005-05	COMPACT DISC (MANUAL)	
258	1F	*	W01-2010-05	CARRYING CASE	E1Q1X1
258	1F	*	W01-2010-05	CARRYING CASE	M1M2C1
259	1E		W02-5304-05	ANTENNA MODULE (GPS ANT)	
260	1D	*	W02-5475-35	NAVIGATION MODULE	K1K2K3
260	1D	*	W02-5476-35	NAVIGATION MODULE	E2
260	1D	*	W02-5477-35	NAVIGATION MODULE	K
260	1D	*	W02-5478-35	NAVIGATION MODULE	E1
260	1D	*	W02-5479-35	NAVIGATION MODULE	R1Q1X1

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

Ref.No.	Add	New	Parts No.	Description	Destination
260	1D	*	W02-5479-35	NAVIGATION MODULE	M1M2C1
264	2C	*	X34-6950-10	ELECTRIC UNIT	K
264	2C	*	X34-6950-11	ELECTRIC UNIT	K1K2
264	2C	*	X34-6950-12	ELECTRIC UNIT	K3
264	2C	*	X34-6950-21	ELECTRIC UNIT	M1
264	2C	*	X34-6950-22	ELECTRIC UNIT	M2
264	2C	*	X34-6950-71	ELECTRIC UNIT	X1
264	2C	*	X34-6952-71	ELECTRIC UNIT	E1
264	2C	*	X34-6952-72	ELECTRIC UNIT	E2
264	2C	*	X34-6953-01	ELECTRIC UNIT	C1
264	2C	*	X34-6953-21	ELECTRIC UNIT	R1
264	2C	*	X34-6953-81	ELECTRIC UNIT	Q1
265	2D	*	X88-2080-10	DIGITAL I/O UNIT	KK1K2
265	2D	*	X88-2080-10	DIGITAL I/O UNIT	R1E1E2
265	2D	*	X88-2080-10	DIGITAL I/O UNIT	Q1K3
265	2D	*	X88-2080-21	DIGITAL I/O UNIT	X1M1M2
265	2D	*	X88-2080-21	DIGITAL I/O UNIT	C1
VME1	1D	*	X92-6640-00	DVD MECHANISM ASSY (DVS-8710W)	
DISPLAY ASSY					
268	2F	*	A46-1919-11	REAR COVER	E1Q1X1
268	2F	*	A46-1919-11	REAR COVER	M1M2C1
PA1	3E	*	A64-5199-21	PANEL	E1
PA1	3E	*	A64-5200-21	PANEL	Q1
PA1	3E	*	A64-5201-21	PANEL	X1
PA1	3E	*	A64-5202-21	PANEL	M1M2C1
PA1	3E	*	LV11752-047A	F. PANEL ASSY	K3
PA1	3E	*	LV11752-048A	F. PANEL ASSY	E2
PA1	3E	*	LV11752-049A	F. PANEL ASSY	K1
PA1	3E	*	LV11752-050A	F. PANEL ASSY	K2
PA1	3E	*	LV11752-051A	F. PANEL ASSY	R1
PA1	3E	*	LV11752-052A	F. PANEL ASSY	K
271	1E		B09-0548-13	CAP	K
271	1E	*	B09-1005-03	CAP	R1
272	3E		B43-1518-04	BADGE	
273	1E	*	LV22871-003A	CAP(USB)	X1M1M2
273	1E	*	LV22871-003A	CAP(USB)	C1
274	3E	*	LV22872-001A	ESCUTCHEON	
277	3E	*	LV39104-001A	REMO LENS	
LCD1	3F		B38-1223-15	LCD	
FC5	2F	*	E39-1199-05	FLAT CABLE	E1Q1X1
FC5	2F	*	E39-1199-05	FLAT CABLE	M1M2C1
FC6	2E	*	E39-1200-05	FLAT CABLE	
WH2	2E	*	E39-1217-05	WIRING HARNESS	X1M1M2
WH2	2E	*	E39-1217-05	WIRING HARNESS	C1
279	1F	*	F07-2240-03	COVER	E1Q1X1
279	1F	*	F07-2240-03	COVER	M1M2C1
280	3F		F09-2970-04	SHEET	E1Q1X1
280	3F		F09-2970-04	SHEET	M1M2C1
281	1F	*	G01-4780-04	COMPRESSION SPRING	E1Q1X1
281	1F	*	G01-4780-04	COMPRESSION SPRING	M1M2C1
282	2F	*	G02-1919-04	FLAT SPRING	E1Q1X1
282	2F	*	G02-1919-04	FLAT SPRING	M1M2C1
284	3E		G16-1749-04	SHEET	
285	3E		G16-1771-04	SHEET	
288	3F	*	K24-5092-04	PUSH KNOB (RELEASE)	E1Q1X1
288	3F	*	K24-5092-04	PUSH KNOB (RELEASE)	M1M2C1
290	3E	*	LV22869-005A	BUTTON (AUD)	R1E1E2
290	3E	*	LV22869-005A	BUTTON (AUD)	Q1X1M1
290	3E	*	LV22869-005A	BUTTON (AUD)	M2C1
290	3E	*	LV22869-006A	BUTTON (AUD)	KK1K2
290	3E	*	LV22869-006A	BUTTON (AUD)	K3
291	3E	*	LV22870-004A	BUTTON (SCRN)	
292	3E	*	LV39102-003A	BUTTON (MENU)	
293	3E	*	LV39103-004A	BUTTON (NAV)	
294	3E	*	LV39106-002A	KNOB (VOL)	
295	3E	*	LV39226-001A	BUTTON (EJECT)	
296	3E	*	LV39227-001A	BUTTON (RESET)	
C	1E	*	N09-6848-15	TAPTITE SCREW	
G	1F		N82-2007-47	BINDING HEAD TAPTITE SCREW	E1Q1X1
G	1F		N82-2007-47	BINDING HEAD TAPTITE SCREW	M1M2C1
L	1F		N09-6489-05	MACHINE SCREW (M2.0X3.0)	E1Q1X1
L	1F		N09-6489-05	MACHINE SCREW (M2.0X3.0)	M1M2C1
M	1F	*	N09-6849-05	TAPTITE SCREW	KK1K2
M	1F	*	N09-6849-05	TAPTITE SCREW	R1E2K3
N	1F	*	N09-6850-05	TAPTITE SCREW	E1Q1X1
N	1F	*	N09-6850-05	TAPTITE SCREW	M1M2C1
298	3F	*	S79-0879-05	SWITCH ASSY	
301	2F	*	X35-5140-10	VIDEO UNIT	KK1K2
301	2F	*	X35-5140-10	VIDEO UNIT	R1E2K3
301	2E	*	X35-5140-21	VIDEO UNIT	X1M1M2
301	2E	*	X35-5140-21	VIDEO UNIT	C1
301	2E	*	X35-5142-71	VIDEO UNIT	E1Q1
VIDEO CONTROL UNIT (X15-154x-xx)					
C1			CK73GB1H104K	CHIP C 0.10UF K	
C2			C90-5670-05	ELECTRO 2200UF 16WV	
C3 ,4			CK73GB1H104K	CHIP C 0.10UF K	
C5			CE32BM1E101M	CHIP EL 100UF 25WV	
C6			CK73HB1E103K	CHIP C 0.010UF K	
C7 ,8			CK73GB1H104K	CHIP C 0.10UF K	
C9			CK73HB1E103K	CHIP C 0.010UF K	
C10 ,11			CK73EB1E106K	CHIP C 10UF K	
C12			CK73GB1H104K	CHIP C 0.10UF K	
C13			CK73HB1E103K	CHIP C 0.010UF K	
C14			CK73FB1E475K	CHIP C 4.7UF K	
C15			CK73GB1H104K	CHIP C 0.10UF K	
C16			CK73HB1E223K	CHIP C 0.022UF K	
C17			CK73HB1H221K	CHIP C 220PF K	
C18			CK73HB1H472K	CHIP C 4700PF K	
C19			CC73HCH1H151J	CHIP C 150PF J	
C21			CK73EB1E106K	CHIP C 10UF K	
C22			CK73GB1H104K	CHIP C 0.10UF K	
C23			C92-2031-05	ELECTRO 220UF	
C24			CK73HB1A104K	CHIP C 0.10UF K	
C25			CK73HB1E103K	CHIP C 0.010UF K	
C26			CK73FB0J226M	CHIP C 22UF M	
C27			CK73GB1H104K	CHIP C 0.10UF K	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO CONTROL UNIT (X15-154x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
C28			CK73HB1E103K	CHIP C 0.010UF K	
C29 ,30			CK73EB1E106K	CHIP C 10UF K	
C31			CK73GB1H104K	CHIP C 0.10UF K	
C32			CK73HB1E103K	CHIP C 0.010UF K	
C33			CK73GB1H104K	CHIP C 0.10UF K	
C34			CK73GB1A105K	CHIP C 1.0UF K	
C35			CK73HB1H332K	CHIP C 3300PF K	
C36			CC73HCH1H181J	CHIP C 180PF J	
C37			CK73HB1H682K	CHIP C 6800PF K	
C38			CK73HB1C473K	CHIP C 0.047UF K	
C39 ,40			CK73HB1A104K	CHIP C 0.10UF K	
C41			CK73GB1A105K	CHIP C 1.0UF K	
C42			CK73GB1H104K	CHIP C 0.10UF K	
C43			CK73HB1E103K	CHIP C 0.010UF K	
C44			CK73HB1A104K	CHIP C 0.10UF K	
C45			CK73FB0J226M	CHIP C 22UF M	
C46			CE32AV0J221M	CHIP EL 220UF 6.3WV	
C47			CK73FB1E475K	CHIP C 4.7UF K	
C48 ,49			CK73GB1H104K	CHIP C 0.10UF K	
C50			CK73HB1E103K	CHIP C 0.010UF K	
C51 ,52			CK73EB1E106K	CHIP C 10UF K	
C53			CK73GB1H104K	CHIP C 0.10UF K	
C54			CK73HB1E103K	CHIP C 0.010UF K	
C55			CK73GB1H332K	CHIP C 3300PF K	
C56			C92-2031-05	ELECTRO 220UF	
C57			CK73HB1A104K	CHIP C 0.10UF K	
C58			CK73HB1E103K	CHIP C 0.010UF K	
C59			CK73FB0J226M	CHIP C 22UF M	
C60			CK73HB1C473K	CHIP C 0.047UF K	
C61			CK73HB1H332K	CHIP C 3300PF K	
C62			CC73HCH1H181J	CHIP C 180PF J	
C63			CK73HB1H682K	CHIP C 6800PF K	
C64			CK73HB1A104K	CHIP C 0.10UF K	
C65			CK73GB1H104K	CHIP C 0.10UF K	
C66			CK73HB1E103K	CHIP C 0.010UF K	
C67 ,68			CK73EB1E106K	CHIP C 10UF K	
C69			CK73GB1H104K	CHIP C 0.10UF K	
C70			CK73HB1E103K	CHIP C 0.010UF K	
C71			CK73GB1H332K	CHIP C 3300PF K	
C72		*	CE32AV1A271M	CHIP EL 270UF 10WV	
C73			CK73HB1A104K	CHIP C 0.10UF K	
C74			CK73HB1E103K	CHIP C 0.010UF K	
C75			CK73EB1A106K	CHIP C 10UF K	
C76			CC73HCH1H470J	CHIP C 47PF J	
C77			CK73HB1A104K	CHIP C 0.10UF K	
C78			CK73GB1A105K	CHIP C 1.0UF K	
C79			CK73HB1C473K	CHIP C 0.047UF K	
C80			CK73HB1H332K	CHIP C 3300PF K	
C81			CC73HCH1H181J	CHIP C 180PF J	
C82			CK73HB1H682K	CHIP C 6800PF K	
C83 -85			CK73HB1A104K	CHIP C 0.10UF K	
C86			CK73GB0J106M	CHIP C 10UF M	
C87			CK73EB1A106K	CHIP C 10UF K	
C88			CE32AV1A121M	CHIP EL 120UF 10WV	
C89			CK73GB0J106M	CHIP C 10UF M	

Ref.No.	Add	New	Parts No.	Description	Destination
C90			CK73HB0J105K	CHIP C 1.0UF K	
C91			CK73GB1H222K	CHIP C 2200PF K	
C93 ,94			CK73HB0J105K	CHIP C 1.0UF K	
C95 ,96			CK73GB1H332K	CHIP C 3300PF K	
C97			CK73HB0J105K	CHIP C 1.0UF K	
C98			CK73FB0J226M	CHIP C 22UF M	
C99			CK73HB1A104K	CHIP C 0.10UF K	
C100			CK73HB1E103K	CHIP C 0.010UF K	
C101			CK73HB0J105K	CHIP C 1.0UF K	
C102			CE32BM1E470M	CHIP EL 47UF 25WV	
C103			CK73HB1E103K	CHIP C 0.010UF K	
C104			CK73GB1H104K	CHIP C 0.10UF K	
C111			CK73GB1A105K	CHIP C 1.0UF K	
C112			CK73FB0J226M	CHIP C 22UF M	
C113			CK73HB0J105K	CHIP C 1.0UF K	
C120			CK73FB0J226M	CHIP C 22UF M	
C121			CK73HB1A104K	CHIP C 0.10UF K	
C122			CK73GB1H104K	CHIP C 0.10UF K	
C124			CK73HB0J105K	CHIP C 1.0UF K	
C125			CK73HB1A104K	CHIP C 0.10UF K	
C127			CK73HB0J105K	CHIP C 1.0UF K	
C130			CK73HB0J105K	CHIP C 1.0UF K	
C200			CK73HB1E103K	CHIP C 0.010UF K	
C201			CK73EB1E106K	CHIP C 10UF K	
C202			CK73HB1H471K	CHIP C 470PF K	
C203			CK73HB0J105K	CHIP C 1.0UF K	
C204			CK73GB1H104K	CHIP C 0.10UF K	
C205			CK73HB1E103K	CHIP C 0.010UF K	
C206			CK73HB1H222K	CHIP C 2200PF K	
C207			CK73GB0J106M	CHIP C 10UF M	
C208			CK73HB1A104K	CHIP C 0.10UF K	
C209			CK73GB0J106M	CHIP C 10UF M	
C210			CK73HB0J105K	CHIP C 1.0UF K	
C211			CK73GB0J106M	CHIP C 10UF M	
C212			CK73HB1H222K	CHIP C 2200PF K	
C213-219			CK73HB1E103K	CHIP C 0.010UF K	KK1K2
C213-219			CK73HB1E103K	CHIP C 0.010UF K	R1E2K3
C213-220			CK73HB1E103K	CHIP C 0.010UF K	E1Q1X1
C213-220			CK73HB1E103K	CHIP C 0.010UF K	M1M2C1
C221			CK73HB0J105K	CHIP C 1.0UF K	
C222-225			CK73HB1A104K	CHIP C 0.10UF K	
C226,227			CK73HB1E103K	CHIP C 0.010UF K	
C228			CC73HCH1H120J	CHIP C 12PF J	
C229			CK73HB1E103K	CHIP C 0.010UF K	
C230			CK73HB1A104K	CHIP C 0.10UF K	
C231			CK73HB1H471K	CHIP C 470PF K	
C232			CK73EB1E106K	CHIP C 10UF K	
C233			CK73HB1E103K	CHIP C 0.010UF K	
C234			CC73HCH1H100D	CHIP C 10PF D	
C235			CC73HCH1H060D	CHIP C 6.0PF D	
C236			CK73HB1E103K	CHIP C 0.010UF K	
C237			CC73HCH1H180J	CHIP C 18PF J	
C238,239			CK73HB1E103K	CHIP C 0.010UF K	E1Q1X1
C238,239			CK73HB1E103K	CHIP C 0.010UF K	M1M2C1
C240			CK73HB1A104K	CHIP C 0.10UF K	R1E1E2

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO CONTROL UNIT (X15-154x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
C240			CK73HB1A104K	CHIP C 0.10UF K	Q1X1M1
C240			CK73HB1A104K	CHIP C 0.10UF K	M2C1
C240,241			CK73HB1A104K	CHIP C 0.10UF K	KK1K2
C240,241			CK73HB1A104K	CHIP C 0.10UF K	K3
C242			CE32BQ0J221M	CHIP EL 220UF 6.3WV	
C243			CK73HB0J105K	CHIP C 1.0UF K	
C244			CK73GB1A105K	CHIP C 1.0UF K	
C245			CK73HB1A104K	CHIP C 0.10UF K	
C246			CC73HCH1H470J	CHIP C 47PF J	KK1K2
C246			CC73HCH1H470J	CHIP C 47PF J	E1K3M1
C246			CC73HCH1H470J	CHIP C 47PF J	M2C1
C247-249			CK73HB1A104K	CHIP C 0.10UF K	
C250,251			CK73HB0J105K	CHIP C 1.0UF K	
C253			CK73HB0J105K	CHIP C 1.0UF K	
C254			CK73GB1A105K	CHIP C 1.0UF K	
C255,256			CC73HCH1H221J	CHIP C 220PF J	E1Q1X1
C255,256			CC73HCH1H221J	CHIP C 220PF J	M1M2C1
C257			CK73HB1A104K	CHIP C 0.10UF K	
C400			CK73EB1A106K	CHIP C 10UF K	KK1K2
C400			CK73EB1A106K	CHIP C 10UF K	R1E1E2
C400			CK73EB1A106K	CHIP C 10UF K	Q1X1
C401			CK73GB0J106M	CHIP C 10UF M	KK1K2
C401			CK73GB0J106M	CHIP C 10UF M	R1E1E2
C401			CK73GB0J106M	CHIP C 10UF M	Q1X1
C403			CC73HCH1H101J	CHIP C 100PF J	KK1K2
C403			CC73HCH1H101J	CHIP C 100PF J	R1E1E2
C403			CC73HCH1H101J	CHIP C 100PF J	Q1X1
C404			CK73HB1A104K	CHIP C 0.10UF K	KK1K2
C404			CK73HB1A104K	CHIP C 0.10UF K	R1E1E2
C404			CK73HB1A104K	CHIP C 0.10UF K	Q1X1
C407			CK73GB1A105K	CHIP C 1.0UF K	KK1K2
C407			CK73GB1A105K	CHIP C 1.0UF K	R1E1E2
C407			CK73GB1A105K	CHIP C 1.0UF K	Q1X1
C408			CC73HCH1H331J	CHIP C 330PF J	KK1K2
C408			CC73HCH1H331J	CHIP C 330PF J	R1E1E2
C408			CC73HCH1H331J	CHIP C 330PF J	Q1X1
C410			CK73GB1A105K	CHIP C 1.0UF K	KK1K2
C410			CK73GB1A105K	CHIP C 1.0UF K	R1E1E2
C410			CK73GB1A105K	CHIP C 1.0UF K	Q1X1
C412			CC73HCH1H101J	CHIP C 100PF J	KK1K2
C412			CC73HCH1H101J	CHIP C 100PF J	R1E1E2
C412			CC73HCH1H101J	CHIP C 100PF J	Q1X1
C413			CK73GB0J106M	CHIP C 10UF M	KK1K2
C413			CK73GB0J106M	CHIP C 10UF M	R1E1E2
C413			CK73GB0J106M	CHIP C 10UF M	Q1X1
C415			CK73GB0J106M	CHIP C 10UF M	KK1K2
C415			CK73GB0J106M	CHIP C 10UF M	R1E1E2
C415			CK73GB0J106M	CHIP C 10UF M	Q1X1
C416			CE32BQ0J331M	CHIP EL 330UF 6.3WV	KK1K2
C416			CE32BQ0J331M	CHIP EL 330UF 6.3WV	R1E1E2
C416			CE32BQ0J331M	CHIP EL 330UF 6.3WV	Q1X1
C417			CK73GB1A105K	CHIP C 1.0UF K	
C419			CK73HB1A104K	CHIP C 0.10UF K	
C424			CK73HB1A104K	CHIP C 0.10UF K	
C425			CK73GB0J106M	CHIP C 10UF M	
C426			CK73EB1A106K	CHIP C 10UF K	
C427			CK73GB0J106M	CHIP C 10UF M	
C428			CK73HB1A104K	CHIP C 0.10UF K	
C429			CK73HB1H222K	CHIP C 2200PF K	
C430,431			CK73HB1A104K	CHIP C 0.10UF K	
C432			CK73GB0J106M	CHIP C 10UF M	
C433			CK73HB1E103K	CHIP C 0.010UF K	
C434			CE32AV0J221M	CHIP EL 220UF 6.3WV	
C435			CC73HCH1H040C	CHIP C 4.0PF C	
C436			CE32BJ1C101M	CHIP EL 100UF 16WV	
C437,438			CE32BJ1C100M	CHIP EL 10UF 16WV	
C441			CK73FB0J226M	CHIP C 22UF M	
C442			CK73HB1A104K	CHIP C 0.10UF K	
C443-445			CK73HB0J105K	CHIP C 1.0UF K	
C446,447			CK73FB0J226M	CHIP C 22UF M	
C448-450			CK73HB0J105K	CHIP C 1.0UF K	
C451,452			CK73GB0J106M	CHIP C 10UF M	
C453,454			CK73HB1A104K	CHIP C 0.10UF K	
C455,456			CK73GB0J106M	CHIP C 10UF M	
C457			CK73HB1A104K	CHIP C 0.10UF K	
C458,459			CK73HB1H332K	CHIP C 3300PF K	
C460,461			CK73GB1H332K	CHIP C 3300PF K	
C462			CK73FB0J226M	CHIP C 22UF M	
C463			CK73EB0J476M	CHIP C 47UF M	
C464			CK73HB1H332K	CHIP C 3300PF K	
C465			CK73GB1H332K	CHIP C 3300PF K	
C466			CK73HB1H332K	CHIP C 3300PF K	
C467			CK73GB1H332K	CHIP C 3300PF K	
C468			CK73HB1A104K	CHIP C 0.10UF K	
C473			CK73HB1A104K	CHIP C 0.10UF K	
C474			CK73FB0J226M	CHIP C 22UF M	
C475			CK73HB1A104K	CHIP C 0.10UF K	
C478-480			CK73GB1H104K	CHIP C 0.10UF K	E1Q1X1
C478-480			CK73GB1H104K	CHIP C 0.10UF K	M1M2C1
C481			CK73EB0J476M	CHIP C 47UF M	
C482,483			CK73GB1A105K	CHIP C 1.0UF K	E1Q1X1
C482,483			CK73GB1A105K	CHIP C 1.0UF K	M1M2C1
C484			CK73FB0J226M	CHIP C 22UF M	
C485			CK73GB1A105K	CHIP C 1.0UF K	E1Q1X1
C485			CK73GB1A105K	CHIP C 1.0UF K	M1M2C1
C486-488			CK73HB1A104K	CHIP C 0.10UF K	KR1E1
C486-488			CK73HB1A104K	CHIP C 0.10UF K	Q1X1
C486,487			CK73HB1A104K	CHIP C 0.10UF K	K1K2E2
C487			CK73HB1A104K	CHIP C 0.10UF K	K3
C487,488			CK73HB1A104K	CHIP C 0.10UF K	M1M2C1
C489			CK73GB0J475K	CHIP C 4.7UF K	KR1E1
C489			CK73GB0J475K	CHIP C 4.7UF K	Q1X1M1
C489			CK73GB0J475K	CHIP C 4.7UF K	M2C1
C490			CK73HB1E103K	CHIP C 0.010UF K	KR1E1
C490			CK73HB1E103K	CHIP C 0.010UF K	Q1X1M1
C490			CK73HB1E103K	CHIP C 0.010UF K	M2C1
C491			CK73EB1A106K	CHIP C 10UF K	KK1K2
C491			CK73EB1A106K	CHIP C 10UF K	R1E1E2
C491			CK73EB1A106K	CHIP C 10UF K	Q1X1
C494			CK73HB0J105K	CHIP C 1.0UF K	KR1E1

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO CONTROL UNIT (X15-154x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
C494			CK73HB0J105K	CHIP C 1.0UF K	Q1X1M1
C494			CK73HB0J105K	CHIP C 1.0UF K	M2C1
C495			CK73GB0J106M	CHIP C 10UF M	
C496,497			CK73HB1E103K	CHIP C 0.010UF K	E1Q1X1
C496,497			CK73HB1E103K	CHIP C 0.010UF K	M1M2C1
C498			CK73HB1H102K	CHIP C 1000PF K	E1Q1X1
C498			CK73HB1H102K	CHIP C 1000PF K	M1M2C1
C501			CK73GB1H104K	CHIP C 0.10UF K	
C503			CK73GB1H104K	CHIP C 0.10UF K	
C508			CK73GB0J106M	CHIP C 10UF M	
C509			CK73HB1A104K	CHIP C 0.10UF K	
C510			CK73HB1E103K	CHIP C 0.010UF K	
C512			CE32BJ1C100M	CHIP EL 10UF 16WV	
C513,514			CK73HB1H102K	CHIP C 1000PF K	
C516			CE32BJ1C100M	CHIP EL 10UF 16WV	
C517			CK73GB1C224K	CHIP C 0.22UF K	
C519			CE32BQ0J331M	CHIP EL 330UF 6.3WV	
C520,521			CK73HB0J105K	CHIP C 1.0UF K	
C522			CK73HB1A104K	CHIP C 0.10UF K	
C524			CK73GB0J106M	CHIP C 10UF M	
C525			CK73HB1A104K	CHIP C 0.10UF K	
C526			CK73HB1E103K	CHIP C 0.010UF K	
C528			CK73GB0J106M	CHIP C 10UF M	
C529			CK73HB1A104K	CHIP C 0.10UF K	
C530,531			CK73HB1E103K	CHIP C 0.010UF K	
C532			CK73HB1A104K	CHIP C 0.10UF K	
C533			CK73GB0J106M	CHIP C 10UF M	
C536			CK73GB1A105K	CHIP C 1.0UF K	
C537			CK73HB1H222K	CHIP C 2200PF K	
C538			CK73HB1A104K	CHIP C 0.10UF K	KK1K2
C538			CK73HB1A104K	CHIP C 0.10UF K	R1E1E2
C538			CK73HB1A104K	CHIP C 0.10UF K	Q1X1
C539-541			CK73HB1H102K	CHIP C 1000PF K	
CN200		*	E41-3251-05	PIN ASSY	
CN201		*	E41-3252-05	PIN ASSY	
CN202			E41-2985-05	FLAT CABLE CONNECTOR	
CN205			E41-2248-05	PIN ASSY	
CN207			E41-2359-05	PIN ASSY	
CN400			E41-3170-05	PIN ASSY	KK1K2
CN400			E41-3170-05	PIN ASSY	R1E1E2
CN400			E41-3170-05	PIN ASSY	Q1X1
CN402			E41-2979-05	FLAT CABLE CONNECTOR	
CN403		*	E41-3254-05	SOCKET FOR PIN ASSY	
CN404			E41-2979-05	FLAT CABLE CONNECTOR	
CN405			E41-3102-05	FLAT CABLE CONNECTOR	KR1
CN408		*	E41-3288-05	FLAT CABLE CONNECTOR	KR1
CN410			E41-2741-05	PIN ASSY	X1M1M2
CN410			E41-2741-05	PIN ASSY	C1
J400			E11-0625-05	PHONE JACK (LGY6502-0900)	KK1K2
J400			E11-0625-05	PHONE JACK (LGY6502-0900)	R1E1E2
J400			E11-0625-05	PHONE JACK (LGY6502-0900)	Q1
J400,401			E11-0625-05	PHONE JACK (LGY6502-0900)	X1
J401			E11-0625-05	PHONE JACK (LGY6502-0900)	M1M2C1
J402			E58-1034-05	RECTANGULAR RECEPTACLE	E1Q1X1
J402			E58-1034-05	RECTANGULAR RECEPTACLE	M1M2C1
J403		*	E58-1145-05	RECTANGULAR RECEPTACLE	
J405			E63-0980-05	PIN JACK	
J406			E68-0826-05	JACK (SD CARD SLOT)	E1Q1X1
J406			E68-0826-05	JACK (SD CARD SLOT)	M1M2C1
J408		*	E68-0833-05	JACK (MICRO SD)	KR1
F1 ,2			F53-0369-05	FUSE 1.6A	
F200			F53-0369-05	FUSE 1.6A	
L1			L92-0374-05	CHIP FERRITE	
L3			L33-2600-05	CHOKE COIL	
L5			L33-2600-05	CHOKE COIL	
L7			L33-2600-05	CHOKE COIL	
L9			L33-2600-05	CHOKE COIL	
L10 ,11			L92-0373-05	CHIP FERRITE	
L12			L33-2603-05	CHOKE COIL	
L13		*	L33-2440-05	SMALL FIXED INDUCTOR	
L200			L92-0332-05	CHIP FERRITE	
L201		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	
L202			L92-0332-05	CHIP FERRITE	
L203			L33-2457-05	SMALL FIXED INDUCTOR	
L400			L92-0373-05	CHIP FERRITE	KK1K2
L400			L92-0373-05	CHIP FERRITE	R1E1E2
L400			L92-0373-05	CHIP FERRITE	Q1X1
L401			L33-2603-05	CHOKE COIL	
L402			L33-2457-05	SMALL FIXED INDUCTOR	
L404		*	L41-1001-62	SMALL FIXED INDUCTOR(10U)	
L405,406			L92-0373-05	CHIP FERRITE	
X200			L77-2921-15	CRYSTAL RESONATOR(32.768KHZ)	
X201			L77-3846-05	CRYSTAL RESONATOR(12MHZ)	
H	2D		N82-2608-43	BINDING HEAD TAPTITE SCREW	
P	2D		N89-3006-48	BINDING HEAD TAPTITE SCREW	
R1			RK73HB1J823J	CHIP R 82K J 1/16W	
R2			RK73HB1J103J	CHIP R 10K J 1/16W	
R3			RK73HB1J224J	CHIP R 220K J 1/16W	
R4			RK73HB1J333J	CHIP R 33K J 1/16W	
R5			RK73HB1J274J	CHIP R 270K J 1/16W	
R6			RK73HH1J104D	CHIP R 100K D 1/16W	
R7			RK73HH1J513D	CHIP R 51K D 1/16W	
R8			RK73HH1J333D	CHIP R 33K D 1/16W	
R9 ,10			RK73HB1J224J	CHIP R 220K J 1/16W	
R11			RK73HH1J113D	CHIP R 11K D 1/16W	
R12			RK73HH1J104D	CHIP R 100K D 1/16W	
R13			RK73HH1J683D	CHIP R 68K D 1/16W	
R14 ,15			RK73HB1J224J	CHIP R 220K J 1/16W	
R16 ,17			RK73HH1J334D	CHIP R 330K D 1/16W	
R18			RK73HB1J224J	CHIP R 220K J 1/16W	
R19			RK73HB1J473J	CHIP R 47K J 1/16W	
R20			RK73HB1J2R2J	CHIP R 2.2 J 1/16W	
R21			RK73HB1J123J	CHIP R 12K J 1/16W	
R22			RK73HH1J563D	CHIP R 56K D 1/16W	
R23			RK73HH1J753D	CHIP R 75K D 1/16W	
R24 -26			RK73HB1J104J	CHIP R 100K J 1/16W	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO CONTROL UNIT (X15-154x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R27			RK73HB1J473J	CHIP R 47K J 1/16W	
R28 -30			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R31 ,32			R92-5244-05	CHIP R 0.039	
R33			RK73HB1J220J	CHIP R 22 J 1/16W	
R34			RK73HH1J303D	CHIP R 30K D 1/16W	
R35			RK73HH1J682D	CHIP R 6.8K D 1/16W	
R36			RK73HB1J122J	CHIP R 1.2K J 1/16W	
R37		*	RK73HH1J241D	CHIP R 240 D 1/16W	
R38			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R39			RK73HH1J204D	CHIP R 200K D 1/16W	
R40 -42			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R43			RK73HB1J2R2J	CHIP R 2.2 J 1/16W	
R44 ,45			R92-5276-05	METAL GR 0.039 J 1/3W	
R46			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R47 ,48			RK73HH1J303D	CHIP R 30K D 1/16W	
R49			RK73HB1J122J	CHIP R 1.2K J 1/16W	
R50			RK73HH1J243D	CHIP R 24K D 1/16W	
R51			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R52		*	RK73PB2H160J	CHIP R 16 J 1/2W	
R53 ,54			R92-5276-05	METAL GR 0.039 J 1/3W	
R55			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R56			RK73HH1J303D	CHIP R 30K D 1/16W	
R57			RK73HH1J512D	CHIP R 5.1K D 1/16W	
R58			RK73HB1J122J	CHIP R 1.2K J 1/16W	
R59			RK73HH1J331D	CHIP R 330 D 1/16W	
R60			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R61			RK73HH1J204D	CHIP R 200K D 1/16W	
R62		*	RK73PB2H160J	CHIP R 16 J 1/2W	
R64			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R65 ,66			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R67			RK73HB1J224J	CHIP R 220K J 1/16W	
R68			RK73HB1J333J	CHIP R 33K J 1/16W	
R71			RK73GB2A000J	CHIP R 0.0 J 1/10W	K1K2E2
R71			RK73GB2A000J	CHIP R 0.0 J 1/10W	K3
R71 ,72			RK73GB2A000J	CHIP R 0.0 J 1/10W	KR1E1
R71 ,72			RK73GB2A000J	CHIP R 0.0 J 1/10W	Q1X1M1
R71 ,72			RK73GB2A000J	CHIP R 0.0 J 1/10W	M2C1
R73 ,74			RK73GB2A123J	CHIP R 12K J 1/10W	
R75			RK73HB1J223J	CHIP R 22K J 1/16W	
R76			RK73GB2A271J	CHIP R 270 J 1/10W	
R77			R92-5276-05	METAL GR 0.039 J 1/3W	
R78			RK73HB1J223J	CHIP R 22K J 1/16W	
R79			RK73GB2A151J	CHIP R 150 J 1/10W	
R80			RK73HB1J104J	CHIP R 100K J 1/16W	
R81			RK73HB1J223J	CHIP R 22K J 1/16W	
R82 ,83			RK73GB2A151J	CHIP R 150 J 1/10W	
R84			RK73HB1J274J	CHIP R 270K J 1/16W	
R85			RK73HB1J333J	CHIP R 33K J 1/16W	
R86			RK73HB1J224J	CHIP R 220K J 1/16W	
R87			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R88			RK73HB1J103J	CHIP R 10K J 1/16W	
R89			RK73HB1J153J	CHIP R 15K J 1/16W	
R90			RK73HB1J103J	CHIP R 10K J 1/16W	
R91			RK73HB1J153J	CHIP R 15K J 1/16W	
R92		*	RK73PB2H160J	CHIP R 16 J 1/2W	

Ref.No.	Add	New	Parts No.	Description	Destination
R93			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R96			RK73HB1J103J	CHIP R 10K J 1/16W	
R97			RK73HB1J153J	CHIP R 15K J 1/16W	
R98			RK73HH1J223D	CHIP R 22K D 1/16W	
R99			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R100		*	RK73PB2H160J	CHIP R 16 J 1/2W	
R101			RK73HH1J682D	CHIP R 6.8K D 1/16W	
R102,103			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R104			RK73HB1J473J	CHIP R 47K J 1/16W	
R105			RK73HB1J152J	CHIP R 1.5K J 1/16W	
R106			RK73HB1J823J	CHIP R 82K J 1/16W	
R107			RK73HB1J103J	CHIP R 10K J 1/16W	
R120,121			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R122			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R124,125			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R127			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R129,130			RK73HH1J303D	CHIP R 30K D 1/16W	
R131			RK73GB2A151J	CHIP R 150 J 1/10W	
R132			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R133			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	
R134			RK73HH1J563D	CHIP R 56K D 1/16W	
R135		*	RK73HB1J911J	CHIP R 910 J 1/16W	
R136			RK73HB1J473J	CHIP R 47K J 1/16W	
R137			RK73HB1J272J	CHIP R 2.7K J 1/16W	
R138			RK73HB1J223J	CHIP R 22K J 1/16W	
R140			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R141			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R143,144			RK73HB1J223J	CHIP R 22K J 1/16W	
R145,146			RK73HB1J101J	CHIP R 100 J 1/16W	X1M1M2
R145,146			RK73HB1J101J	CHIP R 100 J 1/16W	C1
R200			RK73HB1J103J	CHIP R 10K J 1/16W	KK1K2
R200			RK73HB1J103J	CHIP R 10K J 1/16W	K3
R200			RK73HB1J202J	CHIP R 2.0K J 1/16W	E1E2
R200			RK73HB1J203J	CHIP R 20K J 1/16W	C1
R200			RK73HB1J512J	CHIP R 5.1K J 1/16W	Q1
R200			RK73HB1J513J	CHIP R 51K J 1/16W	X1
R200,201			RK73HB1J103J	CHIP R 10K J 1/16W	M1M2
R201			RK73HB1J103J	CHIP R 10K J 1/16W	R1E1E2
R201			RK73HB1J103J	CHIP R 10K J 1/16W	Q1X1C1
R202			RK73HB1J223J	CHIP R 22K J 1/16W	KK1R1
R202			RK73HB1J223J	CHIP R 22K J 1/16W	E1E2Q1
R202			RK73HB1J223J	CHIP R 22K J 1/16W	X1K3M1
R202			RK73HB1J223J	CHIP R 22K J 1/16W	C1
R203			RK73HB1J473J	CHIP R 47K J 1/16W	K2M2
R204			RK73HB1J101J	CHIP R 100 J 1/16W	
R206,207			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R209			RK73HB1J223J	CHIP R 22K J 1/16W	
R210			RK73HB1J103J	CHIP R 10K J 1/16W	
R211,212			RK73HB1J104J	CHIP R 100K J 1/16W	
R213			RK73HB1J101J	CHIP R 100 J 1/16W	
R214,215			RK73HB1J473J	CHIP R 47K J 1/16W	
R216			RK73HB1J223J	CHIP R 22K J 1/16W	E1Q1X1
R216			RK73HB1J223J	CHIP R 22K J 1/16W	M1M2C1
R219			RK73HB1J101J	CHIP R 100 J 1/16W	
R220,221			RK73HB1J222J	CHIP R 2.2K J 1/16W	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO CONTROL UNIT (X15-154x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R222			RK73HB1J101J	CHIP R 100 J 1/16W	
R224			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1K2
R224			RK73HB1J000J	CHIP R 0.0 J 1/16W	R1E2K3
R226			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R227			RK73HB1J473J	CHIP R 47K J 1/16W	E1Q1X1
R227			RK73HB1J473J	CHIP R 47K J 1/16W	M1M2C1
R228			RK73HB1J223J	CHIP R 22K J 1/16W	
R229			RK73HB1J103J	CHIP R 10K J 1/16W	
R230			RK73HB1J223J	CHIP R 22K J 1/16W	
R231			RK73HB1J103J	CHIP R 10K J 1/16W	
R232,233			RK73HB1J101J	CHIP R 100 J 1/16W	
R234			RK73HB1J104J	CHIP R 100K J 1/16W	
R235,236			RK73HB1J101J	CHIP R 100 J 1/16W	
R237			RK73HB1J223J	CHIP R 22K J 1/16W	
R238			RK73HB1J101J	CHIP R 100 J 1/16W	
R239			RK73HB1J223J	CHIP R 22K J 1/16W	
R240,241			RK73HB1J101J	CHIP R 100 J 1/16W	
R242			RK73HB1J473J	CHIP R 47K J 1/16W	
R243,244			RK73HB1J103J	CHIP R 10K J 1/16W	
R245			RK73HB1J104J	CHIP R 100K J 1/16W	
R246			RK73HB1J473J	CHIP R 47K J 1/16W	
R248			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R249			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R251			RK73HB1J272J	CHIP R 2.7K J 1/16W	
R252			RK73HB1J223J	CHIP R 22K J 1/16W	
R253			RK73HB1J470J	CHIP R 47 J 1/16W	
R255			RK73HB1J101J	CHIP R 100 J 1/16W	
R256			RK73HH1J470D	CHIP R 47 D 1/16W	
R260			RK73HH1J470D	CHIP R 47 D 1/16W	
R261,262			RK73HB1J473J	CHIP R 47K J 1/16W	
R263,264			RK73HB1J101J	CHIP R 100 J 1/16W	
R265			RK73HH1J470D	CHIP R 47 D 1/16W	
R266			RK73HB1J101J	CHIP R 100 J 1/16W	
R267			RK73HH1J470D	CHIP R 47 D 1/16W	
R268			RK73HB1J473J	CHIP R 47K J 1/16W	
R269			RK73HB1J101J	CHIP R 100 J 1/16W	
R270			RK73HB1J104J	CHIP R 100K J 1/16W	
R271			RK73HB1J101J	CHIP R 100 J 1/16W	
R272			RK73HB1J223J	CHIP R 22K J 1/16W	
R273			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R274,275			RK73HB1J101J	CHIP R 100 J 1/16W	
R276			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R277			RK73HB1J101J	CHIP R 100 J 1/16W	
R278			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R279-282			RK73HB1J101J	CHIP R 100 J 1/16W	E1Q1X1
R279-282			RK73HB1J101J	CHIP R 100 J 1/16W	M1M2C1
R279,280			RK73HB1J101J	CHIP R 100 J 1/16W	KK1K2
R279,280			RK73HB1J101J	CHIP R 100 J 1/16W	R1E2K3
R282			RK73HB1J101J	CHIP R 100 J 1/16W	KK1K2
R282			RK73HB1J101J	CHIP R 100 J 1/16W	R1E2K3
R283			RK73HB1J223J	CHIP R 22K J 1/16W	
R284,285			RK73HB1J470J	CHIP R 47 J 1/16W	
R286			RK73HB1J104J	CHIP R 100K J 1/16W	
R287			RK73HB1J101J	CHIP R 100 J 1/16W	
R288			RK73HB1J104J	CHIP R 100K J 1/16W	
R289			RK73HB1J101J	CHIP R 100 J 1/16W	
R290			RK73HB1J104J	CHIP R 100K J 1/16W	
R291			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R292,293			RK73HB1J101J	CHIP R 100 J 1/16W	
R294			RK73HB1J100J	CHIP R 10 J 1/16W	E1Q1X1
R294			RK73HB1J100J	CHIP R 10 J 1/16W	M1M2C1
R295			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R296			RK73HB1J101J	CHIP R 100 J 1/16W	
R298			RK73HB1J101J	CHIP R 100 J 1/16W	
R299			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R300			RK73HB1J101J	CHIP R 100 J 1/16W	
R301			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R302,303			RK73HB1J101J	CHIP R 100 J 1/16W	
R304			RK73HB1J103J	CHIP R 10K J 1/16W	
R305			RK73HB1J104J	CHIP R 100K J 1/16W	
R306,307			RK73HB1J101J	CHIP R 100 J 1/16W	
R308			RK73HB1J223J	CHIP R 22K J 1/16W	
R309			RK73HB1J100J	CHIP R 10 J 1/16W	E1Q1X1
R309			RK73HB1J100J	CHIP R 10 J 1/16W	M1M2C1
R310			RK73HB1J104J	CHIP R 100K J 1/16W	
R311,312			RK73HB1J101J	CHIP R 100 J 1/16W	
R313			RK73HB1J223J	CHIP R 22K J 1/16W	
R314,315			RK73HB1J103J	CHIP R 10K J 1/16W	
R316			RK73HB1J104J	CHIP R 100K J 1/16W	
R317			RK73HB1J473J	CHIP R 47K J 1/16W	
R318			RK73HB1J223J	CHIP R 22K J 1/16W	
R321			RK73HB1J103J	CHIP R 10K J 1/16W	KK1K2
R321			RK73HB1J103J	CHIP R 10K J 1/16W	K3
R323			RK73HB1J223J	CHIP R 22K J 1/16W	
R325			RK73HB1J223J	CHIP R 22K J 1/16W	
R326			RK73HB1J104J	CHIP R 100K J 1/16W	E1Q1X1
R326			RK73HB1J104J	CHIP R 100K J 1/16W	M1M2C1
R327			RK73HB1J223J	CHIP R 22K J 1/16W	KK1K2
R327			RK73HB1J223J	CHIP R 22K J 1/16W	R1E2K3
R328			RK73HB1J104J	CHIP R 100K J 1/16W	KK1K2
R328			RK73HB1J104J	CHIP R 100K J 1/16W	R1E1E2
R328			RK73HB1J104J	CHIP R 100K J 1/16W	Q1X1
R329			RK73HB1J223J	CHIP R 22K J 1/16W	K3M1M2
R329			RK73HB1J223J	CHIP R 22K J 1/16W	C1
R330			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1Q1X1
R330			RK73GB2A000J	CHIP R 0.0 J 1/10W	M1M2C1
R331			RK73HB1J000J	CHIP R 0.0 J 1/16W	X1M1M2
R331			RK73HB1J000J	CHIP R 0.0 J 1/16W	C1
R332,333			RK73HB1J100J	CHIP R 10 J 1/16W	X1M1M2
R332,333			RK73HB1J100J	CHIP R 10 J 1/16W	C1
R334			RK73HB1J100J	CHIP R 10 J 1/16W	E1Q1
R334			RK73HB1J162J	CHIP R 1.6K J 1/16W	X1M1M2
R334			RK73HB1J162J	CHIP R 1.6K J 1/16W	C1
R335			RK73HB1J000J	CHIP R 0.0 J 1/16W	E1Q1X1
R335			RK73HB1J000J	CHIP R 0.0 J 1/16W	M1M2C1
R336			RK73HB1J100J	CHIP R 10 J 1/16W	E1Q1
R336			RK73HB1J162J	CHIP R 1.6K J 1/16W	X1M1M2
R336			RK73HB1J162J	CHIP R 1.6K J 1/16W	C1
R337,338			RK73HB1J101J	CHIP R 100 J 1/16W	
R339-342			RK73HB1J100J	CHIP R 10 J 1/16W	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO CONTROL UNIT (X15-154x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R343			RK73HB1J101J	CHIP R 100 J 1/16W	
R344			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R346			RK73HB1J223J	CHIP R 22K J 1/16W	
R347-355			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R356			RK73HB1J473J	CHIP R 47K J 1/16W	
R357			RK73HB1J752J	CHIP R 7.5K J 1/16W	
R358			RK73HB1J000J	CHIP R 0.0 J 1/16W	X1M1M2
R358			RK73HB1J000J	CHIP R 0.0 J 1/16W	C1
R359,360			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1K2
R359,360			RK73HB1J000J	CHIP R 0.0 J 1/16W	R1E1E2
R359,360			RK73HB1J000J	CHIP R 0.0 J 1/16W	Q1K3
R361,362			RK73HB1J000J	CHIP R 0.0 J 1/16W	X1M1M2
R361,362			RK73HB1J000J	CHIP R 0.0 J 1/16W	C1
R363			RK73HB1J104J	CHIP R 100K J 1/16W	K
R364			RK73HB1J223J	CHIP R 22K J 1/16W	K1K2R1
R364			RK73HB1J223J	CHIP R 22K J 1/16W	E1E2Q1
R364			RK73HB1J223J	CHIP R 22K J 1/16W	X1K3M1
R364			RK73HB1J223J	CHIP R 22K J 1/16W	M2C1
R365,366			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1Q1
R367			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R368			RK73HB1J472J	CHIP R 4.7K J 1/16W	KK1K2
R368			RK73HB1J472J	CHIP R 4.7K J 1/16W	E1K3M1
R368			RK73HB1J472J	CHIP R 4.7K J 1/16W	M2C1
R369,370			RK73HB1J103J	CHIP R 10K J 1/16W	KK1K2
R369,370			RK73HB1J103J	CHIP R 10K J 1/16W	E1K3M1
R369,370			RK73HB1J103J	CHIP R 10K J 1/16W	M2C1
R371			RK73HB1J223J	CHIP R 22K J 1/16W	
R372			RK73HB1J101J	CHIP R 100 J 1/16W	E1Q1X1
R372			RK73HB1J101J	CHIP R 100 J 1/16W	M1M2C1
R373			RK73HB1J104J	CHIP R 100K J 1/16W	KK1K2
R373			RK73HB1J104J	CHIP R 100K J 1/16W	R1E2K3
R374			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1Q1
R375			RK73HB1J000J	CHIP R 0.0 J 1/16W	X1M1M2
R375			RK73HB1J000J	CHIP R 0.0 J 1/16W	C1
R376			RK73HB1J620J	CHIP R 62 J 1/16W	X1M1M2
R376			RK73HB1J620J	CHIP R 62 J 1/16W	C1
R376			RK73HB1J750J	CHIP R 75 J 1/16W	E1Q1
R377			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1Q1X1
R377			RK73GB2A000J	CHIP R 0.0 J 1/10W	M1M2C1
R378,379			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1K2
R378,379			RK73HB1J000J	CHIP R 0.0 J 1/16W	R1E2X1
R378,379			RK73HB1J000J	CHIP R 0.0 J 1/16W	K3M1M2
R378,379			RK73HB1J000J	CHIP R 0.0 J 1/16W	C1
R380,381			RK73HB1J000J	CHIP R 0.0 J 1/16W	E1Q1
R400,401			RK73HB1J222J	CHIP R 2.2K J 1/16W	KK1K2
R400,401			RK73HB1J222J	CHIP R 2.2K J 1/16W	R1E1E2
R400,401			RK73HB1J222J	CHIP R 2.2K J 1/16W	Q1X1
R402			RK73GB2A000J	CHIP R 0.0 J 1/10W	KK1K2
R402			RK73GB2A000J	CHIP R 0.0 J 1/10W	R1E1E2
R402			RK73GB2A000J	CHIP R 0.0 J 1/10W	Q1X1
R403			RK73HB1J2R2J	CHIP R 2.2 J 1/16W	KK1K2
R403			RK73HB1J2R2J	CHIP R 2.2 J 1/16W	R1E1E2
R403			RK73HB1J2R2J	CHIP R 2.2 J 1/16W	Q1X1
R405			RK73HB1J473J	CHIP R 47K J 1/16W	KK1K2
R405			RK73HB1J473J	CHIP R 47K J 1/16W	R1E1E2
R405			RK73HB1J473J	CHIP R 47K J 1/16W	Q1X1
R408			RK73HB1J223J	CHIP R 22K J 1/16W	KK1K2
R408			RK73HB1J223J	CHIP R 22K J 1/16W	R1E1E2
R408			RK73HB1J223J	CHIP R 22K J 1/16W	Q1X1
R409			RK73HB1J103J	CHIP R 10K J 1/16W	KK1K2
R409			RK73HB1J103J	CHIP R 10K J 1/16W	R1E1E2
R409			RK73HB1J103J	CHIP R 10K J 1/16W	Q1X1
R412			RK73HB1J223J	CHIP R 22K J 1/16W	KK1K2
R412			RK73HB1J223J	CHIP R 22K J 1/16W	R1E1E2
R412			RK73HB1J223J	CHIP R 22K J 1/16W	Q1X1
R413			RK73HB1J103J	CHIP R 10K J 1/16W	KK1K2
R413			RK73HB1J103J	CHIP R 10K J 1/16W	R1E1E2
R413			RK73HB1J103J	CHIP R 10K J 1/16W	Q1X1
R415			RK73HB1J473J	CHIP R 47K J 1/16W	KK1K2
R415			RK73HB1J473J	CHIP R 47K J 1/16W	R1E1E2
R415			RK73HB1J473J	CHIP R 47K J 1/16W	Q1X1
R419,420			RK73GB2A101J	CHIP R 100 J 1/10W	KK1K2
R419,420			RK73GB2A101J	CHIP R 100 J 1/10W	R1E1E2
R419,420			RK73GB2A101J	CHIP R 100 J 1/10W	Q1X1
R422,423			RK73FB2B101J	CHIP R 100 J 1/8W	KK1K2
R422,423			RK73FB2B101J	CHIP R 100 J 1/8W	R1E1E2
R422,423			RK73FB2B101J	CHIP R 100 J 1/8W	Q1X1
R427			RK73HB1J223J	CHIP R 22K J 1/16W	KK1K2
R427			RK73HB1J223J	CHIP R 22K J 1/16W	R1E1E2
R427			RK73HB1J223J	CHIP R 22K J 1/16W	Q1X1
R428,429			RK73HB1J101J	CHIP R 100 J 1/16W	KK1K2
R428,429			RK73HB1J101J	CHIP R 100 J 1/16W	R1E1E2
R428,429			RK73HB1J101J	CHIP R 100 J 1/16W	Q1X1
R431,432			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1K2
R431,432			RK73HB1J000J	CHIP R 0.0 J 1/16W	R1E1E2
R431,432			RK73HB1J000J	CHIP R 0.0 J 1/16W	Q1K3
R433-435			RK73HB1J000J	CHIP R 0.0 J 1/16W	X1M1M2
R433-435			RK73HB1J000J	CHIP R 0.0 J 1/16W	C1
R435			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1K2
R435			RK73HB1J000J	CHIP R 0.0 J 1/16W	R1E1E2
R435			RK73HB1J000J	CHIP R 0.0 J 1/16W	Q1K3
R438			RK73HB1J101J	CHIP R 100 J 1/16W	
R439			RK73HB1J100J	CHIP R 10 J 1/16W	
R440			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R441,442			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R443			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R445,446			RK73GB2A471J	CHIP R 470 J 1/10W	
R447,448			RK73HB1J473J	CHIP R 47K J 1/16W	
R449-458			RK73HB1J220J	CHIP R 22 J 1/16W	
R459-464			RK73HB1J223J	CHIP R 22K J 1/16W	
R466			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R468			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R469			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R470			RK73HB1J103J	CHIP R 10K J 1/16W	
R471			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R472			RK73HB1J103J	CHIP R 10K J 1/16W	
R473			RK73HB1J221J	CHIP R 220 J 1/16W	
R474			RK73GB2A221J	CHIP R 220 J 1/10W	
R475			RK73HB1J221J	CHIP R 220 J 1/16W	
R476			RK73GB2A221J	CHIP R 220 J 1/10W	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO CONTROL UNIT (X15-154x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R478			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R479			RK73HB1J471J	CHIP R 470 J 1/16W	
R480			RK73GB2A471J	CHIP R 470 J 1/10W	
R481			RK73HB1J471J	CHIP R 470 J 1/16W	
R482			RK73GB2A471J	CHIP R 470 J 1/10W	
R483			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R488-491			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R494,495			RK73HB1J470J	CHIP R 47 J 1/16W	X1M1M2
R494,495			RK73HB1J470J	CHIP R 47 J 1/16W	C1
R496-499			RK73HB1J223J	CHIP R 22K J 1/16W	KR1E1
R496-499			RK73HB1J223J	CHIP R 22K J 1/16W	Q1X1M1
R496-499			RK73HB1J223J	CHIP R 22K J 1/16W	M2C1
R501			RK73HB1J200J	CHIP R 20 J 1/16W	E1Q1X1
R501			RK73HB1J200J	CHIP R 20 J 1/16W	M1M2C1
R502			RK73HB1J100J	CHIP R 10 J 1/16W	E1Q1X1
R502			RK73HB1J100J	CHIP R 10 J 1/16W	M1M2C1
R503			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1K2
R503			RK73HB1J000J	CHIP R 0.0 J 1/16W	R1E1E2
R503			RK73HB1J000J	CHIP R 0.0 J 1/16W	Q1X1
R504,505			RK73HB1J100J	CHIP R 10 J 1/16W	E1Q1X1
R504,505			RK73HB1J100J	CHIP R 10 J 1/16W	M1M2C1
R506			RK73HB1J200J	CHIP R 20 J 1/16W	E1Q1X1
R506			RK73HB1J200J	CHIP R 20 J 1/16W	M1M2C1
R507			RK73HB1J100J	CHIP R 10 J 1/16W	E1Q1X1
R507			RK73HB1J100J	CHIP R 10 J 1/16W	M1M2C1
R508			RK73HB1J101J	CHIP R 100 J 1/16W	
R510			RK73HB1J102J	CHIP R 1.0K J 1/16W	E1Q1X1
R510			RK73HB1J102J	CHIP R 1.0K J 1/16W	M1M2C1
R512			RK73HB1J101J	CHIP R 100 J 1/16W	E1Q1X1
R512			RK73HB1J101J	CHIP R 100 J 1/16W	M1M2C1
R513			RK73HB1J000J	CHIP R 0.0 J 1/16W	E1Q1X1
R513			RK73HB1J000J	CHIP R 0.0 J 1/16W	M1M2C1
R514			RK73HB1J102J	CHIP R 1.0K J 1/16W	E1Q1X1
R514			RK73HB1J102J	CHIP R 1.0K J 1/16W	M1M2C1
R515			RK73EB2E000J	CHIP R 0.0 J 1/4W	X1M1M2
R515			RK73EB2E000J	CHIP R 0.0 J 1/4W	C1
R516			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1K2
R516			RK73HB1J000J	CHIP R 0.0 J 1/16W	R1E1E2
R516			RK73HB1J000J	CHIP R 0.0 J 1/16W	Q1X1
R517			RK73HB1J101J	CHIP R 100 J 1/16W	E1Q1X1
R517			RK73HB1J101J	CHIP R 100 J 1/16W	M1M2C1
R519			RK73HB1J101J	CHIP R 100 J 1/16W	E1Q1X1
R519			RK73HB1J101J	CHIP R 100 J 1/16W	M1M2C1
R521			RK73HB1J101J	CHIP R 100 J 1/16W	E1Q1X1
R521			RK73HB1J101J	CHIP R 100 J 1/16W	M1M2C1
R522		*	RK73HB1J241J	CHIP R 240 J 1/16W	E1Q1X1
R522		*	RK73HB1J241J	CHIP R 240 J 1/16W	M1M2C1
R524			RK73HB1J102J	CHIP R 1.0K J 1/16W	E1Q1X1
R524			RK73HB1J102J	CHIP R 1.0K J 1/16W	M1M2C1
R525			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R526			RK73HB1J103J	CHIP R 10K J 1/16W	KR1E1
R526			RK73HB1J103J	CHIP R 10K J 1/16W	Q1X1M1
R526			RK73HB1J103J	CHIP R 10K J 1/16W	M2C1
R527,528			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R529			RK73HB1J100J	CHIP R 10 J 1/16W	E1Q1X1
R529			RK73HB1J100J	CHIP R 10 J 1/16W	M1M2C1
R531			RK73HB1J472J	CHIP R 4.7K J 1/16W	KR1E1
R531			RK73HB1J472J	CHIP R 4.7K J 1/16W	Q1X1M1
R531			RK73HB1J472J	CHIP R 4.7K J 1/16W	M2C1
R532			RK73HB1J000J	CHIP R 0.0 J 1/16W	E1Q1X1
R532			RK73HB1J000J	CHIP R 0.0 J 1/16W	M1M2C1
R533			RK73HB1J750J	CHIP R 75 J 1/16W	E1Q1X1
R533			RK73HB1J750J	CHIP R 75 J 1/16W	M1M2C1
R534			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	
R539,540			RK73HB1J101J	CHIP R 100 J 1/16W	
R541			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R550			RK73HB1J100J	CHIP R 10 J 1/16W	
R551			RK73EB2E000J	CHIP R 0.0 J 1/4W	X1M1M2
R551			RK73EB2E000J	CHIP R 0.0 J 1/4W	C1
R552			RK73HB1J100J	CHIP R 10 J 1/16W	
R553			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1K2
R553			RK73HB1J000J	CHIP R 0.0 J 1/16W	R1E1E2
R553			RK73HB1J000J	CHIP R 0.0 J 1/16W	Q1X1
R558			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R560			RK73HB1J100J	CHIP R 10 J 1/16W	
R562		*	RK73HB1J9R1J	CHIP R 9.1 J 1/16W	
R565			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R567			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R573			RK73HB1J000J	CHIP R 0.0 J 1/16W	KR1E1
R573			RK73HB1J000J	CHIP R 0.0 J 1/16W	Q1X1M1
R573			RK73HB1J000J	CHIP R 0.0 J 1/16W	M2C1
R574			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R576			RK73HB1J223J	CHIP R 22K J 1/16W	KR1E1
R576			RK73HB1J223J	CHIP R 22K J 1/16W	Q1X1M1
R576			RK73HB1J223J	CHIP R 22K J 1/16W	M2C1
R579			RK73GB2A102J	CHIP R 1.0K J 1/10W	KR1E1
R579			RK73GB2A102J	CHIP R 1.0K J 1/10W	Q1X1M1
R579			RK73GB2A102J	CHIP R 1.0K J 1/10W	M2C1
R583			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R586			RK73HB1J472J	CHIP R 4.7K J 1/16W	KK1K2
R586			RK73HB1J472J	CHIP R 4.7K J 1/16W	R1E1E2
R586			RK73HB1J472J	CHIP R 4.7K J 1/16W	Q1X1
R587			RK73HB1J202J	CHIP R 2.0K J 1/16W	KK1K2
R587			RK73HB1J202J	CHIP R 2.0K J 1/16W	R1E1E2
R587			RK73HB1J202J	CHIP R 2.0K J 1/16W	Q1X1
R597			RK73HB1J101J	CHIP R 100 J 1/16W	
R598			RK73HB1J471J	CHIP R 470 J 1/16W	
R604			RK73HB1J223J	CHIP R 22K J 1/16W	
R606			RK73HH1J680D	CHIP R 68 D 1/16W	
R609		*	RK73HH1J241D	CHIP R 240 D 1/16W	
R610			RK73HB1J223J	CHIP R 22K J 1/16W	
R612			RK73HB1J750J	CHIP R 75 J 1/16W	
R613			RK73HB1J101J	CHIP R 100 J 1/16W	
R614			RK73HB1J471J	CHIP R 470 J 1/16W	
R616			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R627			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R628,629			RK73HB1J102J	CHIP R 1.0K J 1/16W	X1M1M2
R628,629			RK73HB1J102J	CHIP R 1.0K J 1/16W	C1
R630,631			RK73HB1J104J	CHIP R 100K J 1/16W	X1M1M2
R630,631			RK73HB1J104J	CHIP R 100K J 1/16W	C1

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO CONTROL UNIT (X15-154x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R632,633			RK73HB1J511J	CHIP R 510 J 1/16W	X1M1M2
R632,633			RK73HB1J511J	CHIP R 510 J 1/16W	C1
R634,635			RK73HH1J472D	CHIP R 4.7K D 1/16W	X1M1M2
R634,635			RK73HH1J472D	CHIP R 4.7K D 1/16W	C1
R636			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R640			RK73HH1J303D	CHIP R 30K D 1/16W	
R641			RK73HH1J512D	CHIP R 5.1K D 1/16W	
R642		*	RK73HH1J130D	CHIP R 13 D 1/16W	
R643			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R644-650			RK73HB1J101J	CHIP R 100 J 1/16W	KK1K2
R644-650			RK73HB1J101J	CHIP R 100 J 1/16W	R1E1E2
R644-650			RK73HB1J101J	CHIP R 100 J 1/16W	Q1X1
R652			RK73HB1J100J	CHIP R 10 J 1/16W	
R654			RK73HB1J000J	CHIP R 0.0 J 1/16W	
D1 -4		*	RB080L-30	DIODE	
D5			1SR154-400	DIODE	
D7			1SR154-400	DIODE	
D8		*	RKS801KF	DIODE	
D11			1SR154-400	DIODE	
D23		*	RKS801KF	DIODE	
D201-203			CVL10C270M300	VARISTOR	E1Q1X1
D201-203			CVL10C270M300	VARISTOR	M1M2C1
D204		*	VR1005CCA270	VARISTOR	E1Q1X1
D204		*	VR1005CCA270	VARISTOR	M1M2C1
D205		*	VR1005DDA080	VARISTOR	E1Q1X1
D205		*	VR1005DDA080	VARISTOR	M1M2C1
D206,207		*	VR1005CCA270	VARISTOR	E1Q1X1
D206,207		*	VR1005CCA270	VARISTOR	M1M2C1
D210-213		*	VR1005AAA270	VARISTOR	
D214		*	RKS801KF	DIODE	KK1K2
D214		*	RKS801KF	DIODE	K3
D216,217		*	VR1005CCA270	VARISTOR	E1Q1X1
D216,217		*	VR1005CCA270	VARISTOR	M1M2C1
D400-403		*	VR1005DDA080	VARISTOR	X1
D400,401		*	VR1005DDA080	VARISTOR	KK1K2
D400,401		*	VR1005DDA080	VARISTOR	R1E1E2
D400,401		*	VR1005DDA080	VARISTOR	Q1
D402,403		*	VR1005DDA080	VARISTOR	M1M2C1
D404,405			RKZ6.8KG(B2)	ZENER DIODE	E1Q1X1
D404,405			RKZ6.8KG(B2)	ZENER DIODE	M1M2C1
D406			RKZ6.2KG(B2)	ZENER DIODE	E1Q1X1
D406			RKZ6.2KG(B2)	ZENER DIODE	M1M2C1
D413-420			RKZ6.2KG(B2)	ZENER DIODE	E1Q1X1
D413-420			RKZ6.2KG(B2)	ZENER DIODE	M1M2C1
D421,422		*	VR1005DDA080	VARISTOR	E1Q1X1
D421,422		*	VR1005DDA080	VARISTOR	M1M2C1
D423		*	VR1005CCA270	VARISTOR	E1Q1X1
D423		*	VR1005CCA270	VARISTOR	M1M2C1
D424-426			RKZ6.2KG(B2)	ZENER DIODE	E1Q1X1
D424-426			RKZ6.2KG(B2)	ZENER DIODE	M1M2C1
D425,426			RKZ6.2KG(B2)	ZENER DIODE	KK1K2
D425,426			RKZ6.2KG(B2)	ZENER DIODE	R1E2K3
D429		*	RKS801KF	DIODE	
D430		*	VR1005CCA270	VARISTOR	

Ref.No.	Add	New	Parts No.	Description	Destination
D431,432		*	VR1005AAA180	VARISTOR	
D433,434		*	VR1005DDA080	VARISTOR	
D443,444			RKZ6.2KG(B2)	ZENER DIODE	
D451		*	VR1005CCA270	VARISTOR	
D455-457			MC2846-T111	DIODE	
D461		*	VR1005CCA270	VARISTOR	
D462,463			RKZ6.2KG(B2)	ZENER DIODE	X1M1M2
D462,463			RKZ6.2KG(B2)	ZENER DIODE	C1
IC1		*	AN33012UA-VB	ANALOGUE IC	
IC2			AN33013UA-VB	ANALOGUE IC	
IC3			LM26003MHX	ANALOGUE IC	
IC4		*	XC6220B18BP-G	ANALOGUE IC	
IC5		*	XC6223B18BP-G	ANALOGUE IC	
IC6		*	XC6223B121P-G	ANALOGUE IC	
IC7		*	XC6223B331P-G	ANALOGUE IC	
IC8			R1114N181B-TR	ANALOGUE IC (1.8V LF)	
IC9			BA00DD0WHFP	ANALOGUE IC	
IC200			NJM2505AF-ZB	ANALOGUE IC	
IC201			R1114N331B-TR	ANALOGUE IC (3.3V LF)	
IC202			TC7SET08FU-F	MOS-IC	E1Q1X1
IC202			TC7SET08FU-F	MOS-IC	M1M2C1
IC203			XC6120N302N-G	MOS-IC	
IC204			W05-1548-00	ROM IC	KK1K2
IC204			W05-1548-00	ROM IC	K3
IC204			W05-1549-00	ROM IC	E1E2M2
IC204			W05-1550-00	ROM IC	M1
IC204			W05-1551-00	ROM IC	R1X1
IC204			W05-1552-00	ROM IC	Q1
IC204			W05-1553-00	ROM IC	C1
IC205		*	W05-1669-00	MICROCONTROLLER IC	
IC206			TC7SH08FU-F	MOS-IC	
IC207			NJM2505AF-ZB	ANALOGUE IC	
IC400			NJM4565E-ZB	ANALOGUE IC	KK1K2
IC400			NJM4565E-ZB	ANALOGUE IC	R1E1E2
IC400			NJM4565E-ZB	ANALOGUE IC	Q1X1
IC401		*	XC6223B331P-G	ANALOGUE IC	KK1K2
IC401		*	XC6223B331P-G	ANALOGUE IC	R1E1E2
IC401		*	XC6223B331P-G	ANALOGUE IC	Q1X1
IC402			XC6209B502P1	ANALOGUE IC	
IC403		*	BD00C0AWFP	ANALOGUE IC	
IC404,405			AK4388AETP	MOS-IC	
IC406			AN15886A-VF	MOS-IC	
IC408		*	XC6120N412N-G	MOS-IC	
IC409			TC7WH126FU-F	MOS-IC	KK1K2
IC409			TC7WH126FU-F	MOS-IC	R1E1E2
IC409			TC7WH126FU-F	MOS-IC	Q1X1
IC410			TC7SG86FU-F	MOS-IC	KK1K2
IC410			TC7SG86FU-F	MOS-IC	R1E1E2
IC410			TC7SG86FU-F	MOS-IC	Q1X1
Q1			2SA1774	TRANSISTOR	
Q2			RT1N441U-T111	TRANSISTOR	
Q3			2SA1774	TRANSISTOR	
Q4			TPC8110-F	FET	
Q5			2SC5383-T1(F)	TRANSISTOR	
Q6			2SA1774	TRANSISTOR	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO CONTROL UNIT (X15-154x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
Q7			RT1P140M-T111	TRANSISTOR	
Q8			2SC5383-T1(F)	TRANSISTOR	
Q9			2SA1774	TRANSISTOR	
Q10			2SC5383-T1(F)	TRANSISTOR	
Q11			RT1N144U-T111	TRANSISTOR	
Q12			RT1N441U-T111	TRANSISTOR	
Q13			RT1P141U-T111	TRANSISTOR	
Q14 -16			RT1N441U-T111	TRANSISTOR	
Q17 ,18			TPCF8104-F	FET	
Q19			2SB1689	TRANSISTOR	
Q20			RT1N441U-T111	TRANSISTOR	
Q21			CPH3105-E	TRANSISTOR	
Q22			RT1N144U-T111	TRANSISTOR	
Q23			CPH3105-E	TRANSISTOR	
Q24			RT1N144U-T111	TRANSISTOR	
Q27			RTQ025P02	FET	
Q28			RT1N441U-T111	TRANSISTOR	
Q29			2SB1689	TRANSISTOR	
Q30			RT1N441U-T111	TRANSISTOR	
Q31			TPCF8104-F	FET	
Q32 ,33			RT1N441U-T111	TRANSISTOR	
Q34			2SB1689	TRANSISTOR	
Q35 ,36			2SC5383-T1(F)	TRANSISTOR	
Q37 ,38			2SA1774	TRANSISTOR	
Q39			RT1P144U-T111	TRANSISTOR	
Q40			2SA1774	TRANSISTOR	
Q200			2SB1689	TRANSISTOR	E1Q1X1
Q200			2SB1689	TRANSISTOR	M1M2C1
Q201			RT1P144U-T111	TRANSISTOR	
Q202			RT1N441U-T111	TRANSISTOR	
Q203			2SA1774	TRANSISTOR	
Q205			RT1P144U-T111	TRANSISTOR	KK1K2
Q205			RT1P144U-T111	TRANSISTOR	K3
Q208			2SA1774	TRANSISTOR	
Q209,210			2SC5383-T1(F)	TRANSISTOR	KK1K2
Q209,210			2SC5383-T1(F)	TRANSISTOR	E1K3M1
Q209,210			2SC5383-T1(F)	TRANSISTOR	M2C1
Q211			2SB1689	TRANSISTOR	
Q212			RT1N441U-T111	TRANSISTOR	
Q403			RT1P144U-T111	TRANSISTOR	KK1K2
Q403			RT1P144U-T111	TRANSISTOR	R1E1E2
Q403			RT1P144U-T111	TRANSISTOR	Q1X1
Q423			RT1N430M-T111	TRANSISTOR	
Q424			RT1P441M-T111	TRANSISTOR	
Q426			RT1N430M-T111	TRANSISTOR	
Q427			RT1N441U-T111	TRANSISTOR	KK1K2
Q427			RT1N441U-T111	TRANSISTOR	R1E1E2
Q427			RT1N441U-T111	TRANSISTOR	Q1X1
Q436			RT1N144U-T111	TRANSISTOR	KR1E1
Q436			RT1N144U-T111	TRANSISTOR	Q1X1M1
Q436			RT1N144U-T111	TRANSISTOR	M2C1
Q437			RTQ025P02	FET	KR1E1
Q437			RTQ025P02	FET	Q1X1M1
Q437			RTQ025P02	FET	M2C1
Q438			RT1P144U-T111	TRANSISTOR	
Q439,440			RT1N430M-T111	TRANSISTOR	
Q442,443			RT1N144U-T111	TRANSISTOR	X1M1M2
Q442,443			RT1N144U-T111	TRANSISTOR	C1
Q446		*	RT3J33M-1	DUAL FET	X1M1M2
Q446		*	RT3J33M-1	DUAL FET	C1
A401		*	W02-5441-05	ELECTRIC CIRCUIT MODULE (GPS)	
A402		*	W02-5467-05	ELECTRIC CIRCUIT MODULE (BT)	KK1K2
A402		*	W02-5467-05	ELECTRIC CIRCUIT MODULE (BT)	R1E1E2
A402		*	W02-5467-05	ELECTRIC CIRCUIT MODULE (BT)	Q1X1

SWITCH UNIT (X16-7060-10)

Ref.No.	Add	New	Parts No.	Description	Destination
D934			B30-1779-05	LED(1608_SR)	KK1K2
D934			B30-1779-05	LED(1608_SR)	R1E2K3
D936			B30-1779-05	LED(1608_SR)	KK1K2
D936			B30-1779-05	LED(1608_SR)	R1E2K3
C920			CK73HB0J105K	CHIP C 1.0UF K	KK1K2
C920			CK73HB0J105K	CHIP C 1.0UF K	R1E2K3
C921			CK73FB0J226M	CHIP C 22UF M	KK1K2
C921			CK73FB0J226M	CHIP C 22UF M	R1E2K3
CN920		*	E41-3287-05	FLAT CABLE CONNECTOR	KK1K2
CN920		*	E41-3287-05	FLAT CABLE CONNECTOR	R1E2K3
R920			RK73HB1J101J	CHIP R 100 J 1/16W	KK1K2
R920			RK73HB1J101J	CHIP R 100 J 1/16W	R1E2K3
R921			RK73HB1J822J	CHIP R 8.2K J 1/16W	KK1K2
R921			RK73HB1J822J	CHIP R 8.2K J 1/16W	R1E2K3
R922			RK73HB1J223J	CHIP R 22K J 1/16W	KK1K2
R922			RK73HB1J223J	CHIP R 22K J 1/16W	R1E2K3
R924			RK73HB1J392J	CHIP R 3.9K J 1/16W	KK1K2
R924			RK73HB1J392J	CHIP R 3.9K J 1/16W	R1E2K3
R925			RK73HB1J121J	CHIP R 120 J 1/16W	KK1K2
R925			RK73HB1J121J	CHIP R 120 J 1/16W	R1E2K3
R926			RK73GB2A221J	CHIP R 220 J 1/10W	KK1K2
R926			RK73GB2A221J	CHIP R 220 J 1/10W	R1E2K3
R927,928			RK73HB1J512J	CHIP R 5.1K J 1/16W	KK1K2
R927,928			RK73HB1J512J	CHIP R 5.1K J 1/16W	R1E2K3
R929			RK73HH1J361D	CHIP R 360 D 1/16W	KK1K2
R929			RK73HH1J361D	CHIP R 360 D 1/16W	R1E2K3
R930,931			RK73GB2A000J	CHIP R 0.0 J 1/10W	KK1K2
R930,931			RK73GB2A000J	CHIP R 0.0 J 1/10W	R1E2K3
S920-925			S70-0960-05	TACT SWITCH	KK1K2
S920-925			S70-0960-05	TACT SWITCH	R1E2K3
S926			T99-0484-05	ROTARY ENCODER	KK1K2
S926			T99-0484-05	ROTARY ENCODER	R1E2K3
D920		*	VR1005AAA270	VARISTOR	KK1K2
D920		*	VR1005AAA270	VARISTOR	R1E2K3
D922,923			NSSM065T-X	LIGHT EMITTING DIODE	KK1K2
D922,923			NSSM065T-X	LIGHT EMITTING DIODE	R1E2K3
D928			NSSM065T-X	LIGHT EMITTING DIODE	KK1K2
D928			NSSM065T-X	LIGHT EMITTING DIODE	R1E2K3
D935		*	VR1005DDA080	VARISTOR	KK1K2
D935		*	VR1005DDA080	VARISTOR	R1E2K3
IC920			PIC95603	ANALOGUE IC	KK1K2
IC920			PIC95603	ANALOGUE IC	R1E2K3

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

Ref.No.	Add	New	Parts No.	Description	Destination
SWITCH UNIT (X16-716x-xx)					
D914			B30-1779-05	LED(1608_SR)	E1Q1X1
D914			B30-1779-05	LED(1608_SR)	M1M2C1
D916			B30-1779-05	LED(1608_SR)	E1Q1X1
D916			B30-1779-05	LED(1608_SR)	M1M2C1
C900			CK73HB0J105K	CHIP C 1.0UF K	E1Q1X1
C900			CK73HB0J105K	CHIP C 1.0UF K	M1M2C1
C901-903			CK73HB1H102K	CHIP C 1000PF K	E1Q1X1
C901-903			CK73HB1H102K	CHIP C 1000PF K	M1M2C1
C904			CK73FB0J226M	CHIP C 22UF M	E1Q1X1
C904			CK73FB0J226M	CHIP C 22UF M	M1M2C1
C905			CK73HB1E103K	CHIP C 0.010UF K	E1Q1X1
C905			CK73HB1E103K	CHIP C 0.010UF K	M1M2C1
C906			CK73HB1A104K	CHIP C 0.10UF K	E1Q1X1
C906			CK73HB1A104K	CHIP C 0.10UF K	M1M2C1
C907			CK73GB0J106M	CHIP C 10UF M	E1Q1X1
C907			CK73GB0J106M	CHIP C 10UF M	M1M2C1
C908			CK73GB1H104K	CHIP C 0.10UF K	X1M1M2
C908			CK73GB1H104K	CHIP C 0.10UF K	C1
CN900		*	E41-3287-05	FLAT CABLE CONNECTOR	E1Q1X1
CN900		*	E41-3287-05	FLAT CABLE CONNECTOR	M1M2C1
CN901		*	E41-2715-05	PIN ASSY	X1M1M2
CN901		*	E41-2715-05	PIN ASSY	C1
J900		*	QNS0288-003	DIA 3.5 TYPE JACK	E1Q1X1
J900		*	QNS0288-003	DIA 3.5 TYPE JACK	M1M2C1
J901			E58-1129-05	RECTANGULAR RECEPTACLE	X1M1M2
J901			E58-1129-05	RECTANGULAR RECEPTACLE	C1
L902-905			L92-0172-05	CHIP FERRITE	E1Q1X1
L902-905			L92-0172-05	CHIP FERRITE	M1M2C1
R900			RK73HB1J101J	CHIP R 100 J 1/16W	E1Q1X1
R900			RK73HB1J101J	CHIP R 100 J 1/16W	M1M2C1
R901			RK73HB1J822J	CHIP R 8.2K J 1/16W	E1Q1X1
R901			RK73HB1J822J	CHIP R 8.2K J 1/16W	M1M2C1
R902			RK73HB1J223J	CHIP R 22K J 1/16W	E1Q1X1
R902			RK73HB1J223J	CHIP R 22K J 1/16W	M1M2C1
R905			RK73HH1J361D	CHIP R 360 D 1/16W	E1Q1X1
R905			RK73HH1J361D	CHIP R 360 D 1/16W	M1M2C1
R906			RK73HB1J392J	CHIP R 3.9K J 1/16W	E1Q1X1
R906			RK73HB1J392J	CHIP R 3.9K J 1/16W	M1M2C1
R907			RK73HB1J471J	CHIP R 470 J 1/16W	E1Q1X1
R907			RK73HB1J471J	CHIP R 470 J 1/16W	M1M2C1
R911			RK73GB2A221J	CHIP R 220 J 1/10W	E1Q1X1
R911			RK73GB2A221J	CHIP R 220 J 1/10W	M1M2C1
R912,913			RK73HB1J512J	CHIP R 5.1K J 1/16W	E1Q1X1
R912,913			RK73HB1J512J	CHIP R 5.1K J 1/16W	M1M2C1
R914			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	E1Q1X1
R914			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	M1M2C1
S900-905			S70-0960-05	TACT SWITCH	E1Q1X1
S900-905			S70-0960-05	TACT SWITCH	M1M2C1
S906			T99-0484-05	ROTARY ENCODER	E1Q1X1
S906			T99-0484-05	ROTARY ENCODER	M1M2C1

Ref.No.	Add	New	Parts No.	Description	Destination
D900		*	VR1005AAA270	VARISTOR	E1Q1X1
D900		*	VR1005AAA270	VARISTOR	M1M2C1
D902,903			NSSM065T-X	LIGHT EMITTING DIODE	E1Q1X1
D902,903			NSSM065T-X	LIGHT EMITTING DIODE	M1M2C1
D908			NSSM065T-X	LIGHT EMITTING DIODE	E1Q1X1
D908			NSSM065T-X	LIGHT EMITTING DIODE	M1M2C1
D915		*	VR1005DDA080	VARISTOR	E1Q1X1
D915		*	VR1005DDA080	VARISTOR	M1M2C1
D918,919		*	VR1005AAA270	VARISTOR	E1Q1X1
D918,919		*	VR1005AAA270	VARISTOR	M1M2C1
IC900			PIC95603	ANALOGUE IC	E1Q1X1
IC900			PIC95603	ANALOGUE IC	M1M2C1
PROCESSOR UNIT (X17-213x-xx)					
D216			B30-1779-05	LED(1608_SR)	E1Q1X1
D216			B30-1779-05	LED(1608_SR)	M1M2C1
CN1			E41-2985-05	FLAT CABLE CONNECTOR	E1Q1X1
CN1			E41-2985-05	FLAT CABLE CONNECTOR	M1M2C1
CN2		*	E41-2715-05	PIN ASSY	X1M1M2
CN2		*	E41-2715-05	PIN ASSY	C1
CN200		*	E41-3265-05	FLAT CABLE CONNECTOR	E1Q1X1
CN200		*	E41-3265-05	FLAT CABLE CONNECTOR	M1M2C1
CN201			E41-2741-05	PIN ASSY	X1M1M2
CN201			E41-2741-05	PIN ASSY	C1
J1 ,2		*	E59-0863-05	RECTANGULAR PLUG	E1Q1X1
J1 ,2		*	E59-0863-05	RECTANGULAR PLUG	M1M2C1
J200,201		*	E58-1143-05	RECTANGULAR RECEPTACLE	E1Q1X1
J200,201		*	E58-1143-05	RECTANGULAR RECEPTACLE	M1M2C1
R2			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1Q1X1
R2			RK73GB2A000J	CHIP R 0.0 J 1/10W	M1M2C1
R210			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1Q1X1
R210			RK73GB2A000J	CHIP R 0.0 J 1/10W	M1M2C1
R212			RK73GB2A131J	CHIP R 130 J 1/10W	E1Q1X1
R212			RK73GB2A131J	CHIP R 130 J 1/10W	M1M2C1
S200			S68-0880-05	PUSH SWITCH	E1Q1X1
S200			S68-0880-05	PUSH SWITCH	M1M2C1
D2		*	VR1005DDA080	VARISTOR	E1Q1X1
D2		*	VR1005DDA080	VARISTOR	M1M2C1
D3 ,4		*	VR1005AAA270	VARISTOR	E1Q1X1
D3 ,4		*	VR1005AAA270	VARISTOR	M1M2C1
D5		*	VR1005DDA080	VARISTOR	E1Q1X1
D5		*	VR1005DDA080	VARISTOR	M1M2C1
D11 -14		*	VR1005DDA080	VARISTOR	E1Q1X1
D11 -14		*	VR1005DDA080	VARISTOR	M1M2C1
D16 -18		*	VR105C3R3BAA	VARISTOR	E1Q1X1
D16 -18		*	VR105C3R3BAA	VARISTOR	M1M2C1
D19 ,20		*	VR1005AAA270	VARISTOR	E1Q1X1
D19 ,20		*	VR1005AAA270	VARISTOR	M1M2C1
D21		*	VR1005DDA080	VARISTOR	E1Q1X1
D21		*	VR1005DDA080	VARISTOR	M1M2C1
D25		*	VR1005DDA080	VARISTOR	E1Q1X1
D25		*	VR1005DDA080	VARISTOR	M1M2C1
D201		*	VR1005DDA080	VARISTOR	E1Q1X1

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

PROCESSOR UNIT (X17-213x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
D201		*	VR1005DDA080	VARISTOR	M1M2C1
D202,203		*	VR1005AAA270	VARISTOR	E1Q1X1
D202,203		*	VR1005AAA270	VARISTOR	M1M2C1
D204		*	VR1005DDA080	VARISTOR	E1Q1X1
D204		*	VR1005DDA080	VARISTOR	M1M2C1
D205-209		*	VR105C3R3BAA	VARISTOR	E1Q1X1
D205-209		*	VR105C3R3BAA	VARISTOR	M1M2C1
D210-215		*	VR1005DDA080	VARISTOR	E1Q1X1
D210-215		*	VR1005DDA080	VARISTOR	M1M2C1
D217-219		*	VR105C3R3BAA	VARISTOR	E1Q1X1
D217-219		*	VR105C3R3BAA	VARISTOR	M1M2C1
D220,221		*	VR1005AAA270	VARISTOR	E1Q1X1
D220,221		*	VR1005AAA270	VARISTOR	M1M2C1
D222		*	VR1005DDA080	VARISTOR	E1Q1X1
D222		*	VR1005DDA080	VARISTOR	M1M2C1
D226		*	VR1005DDA080	VARISTOR	E1Q1X1
D226		*	VR1005DDA080	VARISTOR	M1M2C1
D227,228		*	VR105C3R3BAA	VARISTOR	E1Q1X1
D227,228		*	VR105C3R3BAA	VARISTOR	M1M2C1
D229,230		*	VR1005DDA080	VARISTOR	E1Q1X1
D229,230		*	VR1005DDA080	VARISTOR	M1M2C1
ELECTRIC UNIT (X34-695x-xx)					
C1			C90-6866-05	ELECTRO 6800UF 16WV	
C2 ,3			CK73GB1H104K	CHIP C 0.10UF K	
C4 ,5			CK73ER2J333K	CHIP C 33000PF K	E1E2M2
C6 -9			CK73GB1C224K	CHIP C 0.22UF K	
C14 -17			CC73GCH1H150J	CHIP C 15PF J	
C20			CK73HB0J105K	CHIP C 1.0UF K	
C21			CE32CL1C100M	CHIP EL 10UF 16WV	
C22			C90-6780-05	ELECTRO 1UF 16WV	
C23			CK73HB0J105K	CHIP C 1.0UF K	
C31		*	C90-7001-05	ELECTRO 100UF 25WV	
C32			CK73FB1H224K	CHIP C 0.22UF K	
C33			CK73GB1C105K	CHIP C 1.0UF K	
C34			CE32CL1C470M	CHIP EL 47UF 16WV	
C35			CK73GB1C104K	CHIP C 0.10UF K	
C36			CE32CL1C470M	CHIP EL 47UF 16WV	
C37			CK73GB1C224K	CHIP C 0.22UF K	
C38		*	C90-7001-05	ELECTRO 100UF 25WV	
C41			CK73HB1E103K	CHIP C 0.010UF K	
C42			C90-6851-05	ELECTRO 220UF 25WV	
C44			CK73HB1A104K	CHIP C 0.10UF K	
C45 ,46			CE32CL1V100M	CHIP EL 10UF 35WV	
C61			CK73FB1C106K	CHIP C 10UF K	KK1K2
C61			CK73FB1C106K	CHIP C 10UF K	E1E2Q1
C61			CK73FB1C106K	CHIP C 10UF K	M1
C62			CK73GB1H104K	CHIP C 0.10UF K	KK1K2
C62			CK73GB1H104K	CHIP C 0.10UF K	E1E2Q1
C62			CK73GB1H104K	CHIP C 0.10UF K	M1
C63			CK73HB1A104K	CHIP C 0.10UF K	KK1K2
C63			CK73HB1A104K	CHIP C 0.10UF K	E1E2Q1
C63			CK73HB1A104K	CHIP C 0.10UF K	M1
C64			CK73FB0J106K	CHIP C 10UF K	KK1K2
C64			CK73FB0J106K	CHIP C 10UF K	E1E2Q1

Ref.No.	Add	New	Parts No.	Description	Destination
C64			CK73FB0J106K	CHIP C 10UF K	M1
C71			CK73FB1C106K	CHIP C 10UF K	K
C72			CE32BJ1C101M	CHIP EL 100UF 16WV	K
C73			CK73FB1E475K	CHIP C 4.7UF K	K
C74			CK73FB1C106K	CHIP C 10UF K	K
C75			CK73FB1E475K	CHIP C 4.7UF K	K
C76			CK73GB1H223K	CHIP C 0.022UF K	K
C77			CK73GB1H103K	CHIP C 0.010UF K	K
C78 ,79			CK73FB1C106K	CHIP C 10UF K	K
C111			CK73HB0J105K	CHIP C 1.0UF K	
C112			CK73HB1E103K	CHIP C 0.010UF K	
C121			CK73GB1C105K	CHIP C 1.0UF K	
C131			CK73HB0J105K	CHIP C 1.0UF K	
C132			CK73HB1E103K	CHIP C 0.010UF K	
C151			CK73FB1E474K	CHIP C 0.47UF K	
C181			CK73HB1E103K	CHIP C 0.010UF K	
C202			CK73HB1E103K	CHIP C 0.010UF K	
C203			CK73GB1C104K	CHIP C 0.10UF K	
C204			CK73HB1E103K	CHIP C 0.010UF K	
C205			CK73GB1C104K	CHIP C 0.10UF K	
C206			CK73FB1C106K	CHIP C 10UF K	
C207			CK73HB1E103K	CHIP C 0.010UF K	
C208			CK73HB1A104K	CHIP C 0.10UF K	
C209			CK73FB1C106K	CHIP C 10UF K	
C210			CK73HB1E103K	CHIP C 0.010UF K	
C211			CK73GB1C104K	CHIP C 0.10UF K	
C212			CK73FB1C106K	CHIP C 10UF K	
C214			CK73FB1C106K	CHIP C 10UF K	
C231			CK73FB1C106K	CHIP C 10UF K	KK1K2
C231			CK73FB1C106K	CHIP C 10UF K	R1E1E2
C231			CK73FB1C106K	CHIP C 10UF K	Q1K3M1
C231			CK73FB1C106K	CHIP C 10UF K	M2
C232			CC73HCH1H331J	CHIP C 330PF J	KK1K2
C232			CC73HCH1H331J	CHIP C 330PF J	R1E1E2
C232			CC73HCH1H331J	CHIP C 330PF J	Q1K3M1
C232			CC73HCH1H331J	CHIP C 330PF J	M2
C233,234			CC73GCH1H120J	CHIP C 12PF J	KK1K2
C233,234			CC73GCH1H120J	CHIP C 12PF J	R1E1E2
C233,234			CC73GCH1H120J	CHIP C 12PF J	Q1K3M1
C233,234			CC73GCH1H120J	CHIP C 12PF J	M2
C235			CK73FB1C106K	CHIP C 10UF K	KK1K2
C235			CK73FB1C106K	CHIP C 10UF K	R1E1E2
C235			CK73FB1C106K	CHIP C 10UF K	Q1K3M1
C235			CK73FB1C106K	CHIP C 10UF K	M2
C236			CK73HB1E103K	CHIP C 0.010UF K	KK1K2
C236			CK73HB1E103K	CHIP C 0.010UF K	R1E1E2
C236			CK73HB1E103K	CHIP C 0.010UF K	Q1K3M1
C236			CK73HB1E103K	CHIP C 0.010UF K	M2
C241			CK73GB1H102K	CHIP C 1000PF K	KK1K2
C241			CK73GB1H102K	CHIP C 1000PF K	E1E2Q1
C241			CK73GB1H102K	CHIP C 1000PF K	M1
C242			CC73GCH1H070D	CHIP C 7.0PF D	KK1K2
C242			CC73GCH1H070D	CHIP C 7.0PF D	E1E2Q1
C242			CC73GCH1H070D	CHIP C 7.0PF D	M1
C243			CC73GCH1H180J	CHIP C 18PF J	KK1K2

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-695x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
C243			CC73GCH1H180J	CHIP C 18PF J	E1E2Q1
C243			CC73GCH1H180J	CHIP C 18PF J	M1
C244			CC73GCH1H150J	CHIP C 15PF J	KK1K2
C244			CC73GCH1H150J	CHIP C 15PF J	E1E2Q1
C244			CC73GCH1H150J	CHIP C 15PF J	M1
C245			CC73GCH1H180J	CHIP C 18PF J	KK1K2
C245			CC73GCH1H180J	CHIP C 18PF J	E1E2Q1
C245			CC73GCH1H180J	CHIP C 18PF J	M1
C246			CC73GCH1H390J	CHIP C 39PF J	KK1K2
C246			CC73GCH1H390J	CHIP C 39PF J	E1E2Q1
C246			CC73GCH1H390J	CHIP C 39PF J	M1
C247			CC73GCH1H020C	CHIP C 2.0PF C	KK1K2
C247			CC73GCH1H020C	CHIP C 2.0PF C	E1E2Q1
C247			CC73GCH1H020C	CHIP C 2.0PF C	M1
C248			CC73GCH1H120J	CHIP C 12PF J	KK1K2
C248			CC73GCH1H120J	CHIP C 12PF J	E1E2Q1
C248			CC73GCH1H120J	CHIP C 12PF J	M1
C249,250			CC73GCH1H102J	CHIP C 1000PF J	KK1K2
C249,250			CC73GCH1H102J	CHIP C 1000PF J	E1E2Q1
C249,250			CC73GCH1H102J	CHIP C 1000PF J	M1
C251			CK73GB1C105K	CHIP C 1.0UF K	KK1K2
C251			CK73GB1C105K	CHIP C 1.0UF K	E1E2Q1
C251			CK73GB1C105K	CHIP C 1.0UF K	M1
C252			CC73GCH1H221J	CHIP C 220PF J	KK1K2
C252			CC73GCH1H221J	CHIP C 220PF J	E1E2Q1
C252			CC73GCH1H221J	CHIP C 220PF J	M1
C253,254			CC73GCH1H102J	CHIP C 1000PF J	KK1K2
C253,254			CC73GCH1H102J	CHIP C 1000PF J	E1E2Q1
C253,254			CC73GCH1H102J	CHIP C 1000PF J	M1
C255			CC73GCH1H030C	CHIP C 3.0PF C	KK1K2
C255			CC73GCH1H030C	CHIP C 3.0PF C	E1E2Q1
C255			CC73GCH1H030C	CHIP C 3.0PF C	M1
C256,257			CC73GCH1H560J	CHIP C 56PF J	KK1K2
C256,257			CC73GCH1H560J	CHIP C 56PF J	E1E2Q1
C256,257			CC73GCH1H560J	CHIP C 56PF J	M1
C261			CC73GCH1H150J	CHIP C 15PF J	KK1K2
C261			CC73GCH1H470J	CHIP C 47PF J	E1E2Q1
C261			CC73GCH1H470J	CHIP C 47PF J	M1
C264			CK73GB1C104K	CHIP C 0.10UF K	
C265,266			CC73GCH1H220J	CHIP C 22PF J	KK1K2
C265,266			CC73GCH1H220J	CHIP C 22PF J	E1E2Q1
C265,266			CC73GCH1H220J	CHIP C 22PF J	M1
C270			CK73HB1A104K	CHIP C 0.10UF K	KK1K2
C270			CK73HB1A104K	CHIP C 0.10UF K	E1E2Q1
C270			CK73HB1A104K	CHIP C 0.10UF K	M1
C271,272			CK73FB0J106K	CHIP C 10UF K	KK1K2
C271,272			CK73FB0J106K	CHIP C 10UF K	E1E2Q1
C271,272			CK73FB0J106K	CHIP C 10UF K	M1
C301			CK73GB1A105K	CHIP C 1.0UF K	
C302			CK73FB1C106K	CHIP C 10UF K	
C303,304			CK73GB1A105K	CHIP C 1.0UF K	
C305			CK73FB1C106K	CHIP C 10UF K	
C306			CK73GB1A105K	CHIP C 1.0UF K	
C307			CK73HB0J105K	CHIP C 1.0UF K	
C308,309			CK73HB0J474K	CHIP C 0.47UF K	
C310			CK73HB0J105K	CHIP C 1.0UF K	
C311,312			CK73GB1A105K	CHIP C 1.0UF K	
C313			CK73HB0J105K	CHIP C 1.0UF K	
C314			CE32CL1H010M	CHIP EL 1.0UF 50WV	
C315			CE32CL1C470M	CHIP EL 47UF 16WV	
C317,318			CK73GB1A105K	CHIP C 1.0UF K	
C319			CK73HB1E103K	CHIP C 0.010UF K	
C320			CE32BJ1C100M	CHIP EL 10UF 16WV	
C321,322			CE32CL1H2R2M	CHIP EL 2.2UF 50WV	
C323-326			CK73GB1A105K	CHIP C 1.0UF K	
C341,342			CE32BJ1C100M	CHIP EL 10UF 16WV	KK1K2
C341,342			CE32BJ1C100M	CHIP EL 10UF 16WV	R1E1Q1
C341,342			CE32BJ1C100M	CHIP EL 10UF 16WV	X1K3M1
C341,342			CE32BJ1C100M	CHIP EL 10UF 16WV	M2C1
C343,344			CK73HB1H102K	CHIP C 1000PF K	KK1K2
C343,344			CK73HB1H102K	CHIP C 1000PF K	R1E1Q1
C343,344			CK73HB1H102K	CHIP C 1000PF K	X1K3M1
C343,344			CK73HB1H102K	CHIP C 1000PF K	M2C1
C351,352			CE32BJ1C100M	CHIP EL 10UF 16WV	KK1K2
C351,352			CE32BJ1C100M	CHIP EL 10UF 16WV	R1E1Q1
C351,352			CE32BJ1C100M	CHIP EL 10UF 16WV	X1K3M1
C351,352			CE32BJ1C100M	CHIP EL 10UF 16WV	M2C1
C353,354			CK73HB1H102K	CHIP C 1000PF K	KK1K2
C353,354			CK73HB1H102K	CHIP C 1000PF K	R1E1Q1
C353,354			CK73HB1H102K	CHIP C 1000PF K	X1K3M1
C353,354			CK73HB1H102K	CHIP C 1000PF K	M2C1
C361,362			CK73EB1C106K	CHIP C 10UF K	
C363,364			CK73HB1H102K	CHIP C 1000PF K	
C371,372			CE32BJ1C100M	CHIP EL 10UF 16WV	K
C373,374			CK73HB1E103K	CHIP C 0.010UF K	K
C381,382			CE32BJ1C100M	CHIP EL 10UF 16WV	K
C383,384			CK73HB1E103K	CHIP C 0.010UF K	K
C391,392			CK73FB1C106K	CHIP C 10UF K	K
C393,394			CK73HB1E103K	CHIP C 0.010UF K	K
C401			CE32BJ1C220M	CHIP EL 22UF 16WV	
C402			CK73GB1C104K	CHIP C 0.10UF K	
C403			CK73FB1C106K	CHIP C 10UF K	
C404-406			CK73GB1A105K	CHIP C 1.0UF K	KK1K2
C404-406			CK73GB1A105K	CHIP C 1.0UF K	R1E1E2
C404-406			CK73GB1A105K	CHIP C 1.0UF K	Q1X1
C407-409			CK73GB1A105K	CHIP C 1.0UF K	K3M1M2
C407-409			CK73GB1A105K	CHIP C 1.0UF K	C1
C411-413			CK73GB1A105K	CHIP C 1.0UF K	KK1K2
C411-413			CK73GB1A105K	CHIP C 1.0UF K	K3
C411-416			CK73GB1A105K	CHIP C 1.0UF K	R1E2
C414-416			CK73GB1A105K	CHIP C 1.0UF K	Q1X1
C417-419			CK73FB1C106K	CHIP C 10UF K	
C420-422			CK73GB1A105K	CHIP C 1.0UF K	
C423			CK73FB1A225K	CHIP C 2.2UF K	
C424			CK73FB1C106K	CHIP C 10UF K	
C425			CK73FB1A225K	CHIP C 2.2UF K	
C426			CK73HB1E103K	CHIP C 0.010UF K	
C428,429			CK73HB1H102K	CHIP C 1000PF K	
C502-504			CK73HB1H102K	CHIP C 1000PF K	KK1K2
C502-504			CK73HB1H102K	CHIP C 1000PF K	R1E1E2

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-695x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
C502-504			CK73HB1H102K	CHIP C 1000PF K	Q1K3
C573			CK73GB1C104K	CHIP C 0.10UF K	KK1K2
C573			CK73GB1C104K	CHIP C 0.10UF K	E1K3M1
C573			CK73GB1C104K	CHIP C 0.10UF K	M2C1
C574			CK73GB0J475K	CHIP C 4.7UF K	KK1K2
C574			CK73GB0J475K	CHIP C 4.7UF K	E1K3M1
C574			CK73GB0J475K	CHIP C 4.7UF K	M2C1
C575-577			CK73GB1A105K	CHIP C 1.0UF K	KK1K2
C575-577			CK73GB1A105K	CHIP C 1.0UF K	E1K3M1
C575-577			CK73GB1A105K	CHIP C 1.0UF K	M2C1
C578			CK73GB1H104K	CHIP C 0.10UF K	KK1K2
C578			CK73GB1H104K	CHIP C 0.10UF K	E1K3M1
C578			CK73GB1H104K	CHIP C 0.10UF K	M2C1
C579			CK73FB1H224K	CHIP C 0.22UF K	KK1K2
C579			CK73FB1H224K	CHIP C 0.22UF K	E1K3M1
C579			CK73FB1H224K	CHIP C 0.22UF K	M2C1
C596			CK73GB0J225K	CHIP C 2.2UF K	
C597			CE32BJ0J470M	CHIP EL 47UF 6.3WV	
C601-604			CC73HCH1H101J	CHIP C 100PF J	
C605-608			CC73HCH1H221J	CHIP C 220PF J	
C609-616			CK73HB1H222K	CHIP C 2200PF K	
C617-620			CC73HCH1H221J	CHIP C 220PF J	
C621,622			CC73HCH1H050C	CHIP C 5.0PF C	
C623			CC73GCH1H102J	CHIP C 1000PF J	
C624,625			CC73HCH1H040C	CHIP C 4.0PF C	
C626			CC73GCH1H101J	CHIP C 100PF J	
C630			CC73HCH1H101J	CHIP C 100PF J	
C631			CC73HCH1H150J	CHIP C 15PF J	
C632			CC73HCH1H070D	CHIP C 7.0PF D	
C633			CC73HCH1H150J	CHIP C 15PF J	
C634			CC73HCH1H070D	CHIP C 7.0PF D	
C643,644			CC73GCH1H470J	CHIP C 47PF J	
CN101		*	E41-3253-05	SOCKET FOR PIN ASSY	
CN102		*	E41-3254-05	SOCKET FOR PIN ASSY	
CN596			E41-1682-05	PIN ASSY	
J1			E58-1043-05	RECTANGULAR RECEPTACLE	
J301		*	E63-0987-05	PIN JACK	KK1K2
J301		*	E63-0987-05	PIN JACK	R1E1Q1
J301		*	E63-0987-05	PIN JACK	X1K3M1
J301		*	E63-0987-05	PIN JACK	M2C1
J302		*	E63-0986-05	PIN JACK	E2
J501		*	E11-0676-05	3.5D PHONE JACK	KK1K2
J501		*	E11-0676-05	3.5D PHONE JACK	R1E1E2
J501		*	E11-0676-05	3.5D PHONE JACK	Q1K3
J531		*	E11-0676-05	3.5D PHONE JACK	KK1K2
J531		*	E11-0676-05	3.5D PHONE JACK	R1E2X1
J531		*	E11-0676-05	3.5D PHONE JACK	K3M1M2
J531		*	E11-0676-05	3.5D PHONE JACK	C1
J571			E58-1097-05	RECTANGULAR RECEPTACLE	KK1K2
J571			E58-1097-05	RECTANGULAR RECEPTACLE	E1K3M1
J571			E58-1097-05	RECTANGULAR RECEPTACLE	M2C1
W201			E30-6883-05	CORD WITH PLUG (ANT)	
F571			F53-0306-05	FUSE(UL,CSA) 5A	KK1K2
F571			F53-0306-05	FUSE(UL,CSA) 5A	E1K3M1
F571			F53-0306-05	FUSE(UL,CSA) 5A	M2C1
L1			L33-2459-05	CHOKE COIL ASSY	\
L2			L33-2436-05	CHOKE COIL ASSY	\
L61		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	KK1K2
L61		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	E1E2Q1
L61		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	M1
L71		*	L41-2201-62	SMALL FIXED INDUCTOR(22U)	K
L201-204		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	
L231		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	KK1K2
L231		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	R1E1E2
L231		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	Q1K3M1
L231		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	M2
L241			L92-0329-05	CHIP FERRITE	KK1K2
L241			L92-0329-05	CHIP FERRITE	E1E2Q1
L241			L92-0329-05	CHIP FERRITE	M1
L242			L41-2705-33	SMALL FIXED INDUCTOR(27U)	KK1K2
L242			L41-2705-33	SMALL FIXED INDUCTOR(27U)	E1E2Q1
L242			L41-2705-33	SMALL FIXED INDUCTOR(27U)	M1
L243			L41-1805-33	SMALL FIXED INDUCTOR(18U)	KK1K2
L243			L41-1805-33	SMALL FIXED INDUCTOR(18U)	E1E2Q1
L243			L41-1805-33	SMALL FIXED INDUCTOR(18U)	M1
L244-246		*	L41-1588-61	SMALL FIXED INDUCTOR(C2012C-R	KK1K2
L244-246		*	L41-1588-61	SMALL FIXED INDUCTOR(C2012C-R	E1E2Q1
L244-246		*	L41-1588-61	SMALL FIXED INDUCTOR(C2012C-R	M1
L247			L19-0825-05	BALUN TRANSFORMER	KK1K2
L247			L19-0825-05	BALUN TRANSFORMER	E1E2Q1
L247			L19-0825-05	BALUN TRANSFORMER	M1
L248		*	L41-1888-61	SMALL FIXED INDUCTOR(C2012C-R	KK1K2
L248		*	L41-1888-61	SMALL FIXED INDUCTOR(C2012C-R	E1E2Q1
L248		*	L41-1888-61	SMALL FIXED INDUCTOR(C2012C-R	M1
L261		*	L41-1588-61	SMALL FIXED INDUCTOR(C2012C-R	KK1K2
L261		*	L41-1588-61	SMALL FIXED INDUCTOR(C2012C-R	E1E2Q1
L261		*	L41-1588-61	SMALL FIXED INDUCTOR(C2012C-R	M1
L262,263			L92-0329-05	CHIP FERRITE	KK1K2
L262,263			L92-0329-05	CHIP FERRITE	E1E2Q1
L262,263			L92-0329-05	CHIP FERRITE	M1
L264			L41-2278-61	SMALL FIXED INDUCTOR(C2012C-R	KK1K2
L264			L41-2278-61	SMALL FIXED INDUCTOR(C2012C-R	E1E2Q1
L264			L41-2278-61	SMALL FIXED INDUCTOR(C2012C-R	M1
L571		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	KK1K2
L571		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	E1K3M1
L571		*	L41-4792-62	SMALL FIXED INDUCTOR(4.7U)	M2C1
X231			L77-3827-05	CRYSTAL RESONATOR	KK1K2
X231			L77-3827-05	CRYSTAL RESONATOR	R1E1E2
X231			L77-3827-05	CRYSTAL RESONATOR	Q1K3M1
X231			L77-3827-05	CRYSTAL RESONATOR	M2
X261			L77-2921-15	CRYSTAL RESONATOR(32.768KHZ)	KK1K2
X261			L77-2921-15	CRYSTAL RESONATOR(32.768KHZ)	E1E2Q1
X261			L77-2921-15	CRYSTAL RESONATOR(32.768KHZ)	M1
Q	2C		N35-2604-43	BINDING HEAD MACHINE SCREW	KK1K2
Q	2C		N35-2604-43	BINDING HEAD MACHINE SCREW	E1K3M1
Q	2C		N35-2604-43	BINDING HEAD MACHINE SCREW	M2C1
R	2C		N80-3008-48	PAN HEAD TAPTITE SCREW	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-695x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R1 -4			RK73GB2A680J	CHIP R 68 J 1/10W	
R5			RK73HB1J473J	CHIP R 47K J 1/16W	
R6			RK73HB1J330J	CHIP R 33 J 1/16W	
R7			RK73HB1J123J	CHIP R 12K J 1/16W	
R8			RK73HB1J473J	CHIP R 47K J 1/16W	
R9			RK73HB1J331J	CHIP R 330 J 1/16W	
R10			RK73GB2A432J	CHIP R 4.3K J 1/10W	
R31			RK73GH2A392D	CHIP R 3.9K D 1/10W	
R32			RK73GH2A751D	CHIP R 750 D 1/10W	
R33			RK73GH2A273D	CHIP R 27K D 1/10W	
R34			RK73GH2A472D	CHIP R 4.7K D 1/10W	
R35			RK73GH2A221D	CHIP R 220 D 1/10W	
R37 -39			RK73FB2B000J	CHIP R 0.0 J 1/8W	
R40			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	
R41			RK73HB1J101J	CHIP R 100 J 1/16W	
R42			RK73FB2B000J	CHIP R 0.0 J 1/8W	
R61			RK73FB2B000J	CHIP R 0.0 J 1/8W	KK1K2
R61			RK73FB2B000J	CHIP R 0.0 J 1/8W	E1E2Q1
R61			RK73FB2B000J	CHIP R 0.0 J 1/8W	M1
R71			RK73FB2B152J	CHIP R 1.5K J 1/8W	K
R72			RK73GB2A104J	CHIP R 100K J 1/10W	K
R73			RK73GB2A750J	CHIP R 75 J 1/10W	K
R74			RK73GB2A473J	CHIP R 47K J 1/10W	K
R75			RK73GB2A272J	CHIP R 2.7K J 1/10W	K
R76			RK73GB2A470J	CHIP R 47 J 1/10W	K
R77			RK73GB2A752J	CHIP R 7.5K J 1/10W	K
R78			RK73GB2A274J	CHIP R 270K J 1/10W	K
R79			RK73GB2A563J	CHIP R 56K J 1/10W	K
R80			RK73GB2A470J	CHIP R 47 J 1/10W	K
R81			RK73GB2A103J	CHIP R 10K J 1/10W	K
R82 ,83			RK73GB2A913J	CHIP R 91K J 1/10W	K
R112			RK73EB2E272J	CHIP R 2.7K J 1/4W	
R113			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R123			RK73EB2E103J	CHIP R 10K J 1/4W	
R132			RK73EB2E272J	CHIP R 2.7K J 1/4W	
R133			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R141			RK73PB2H101J	CHIP R 100 J 1/2W	
R151			RK73EB2E153J	CHIP R 15K J 1/4W	
R152,153			RK73EB2E622J	CHIP R 6.2K J 1/4W	
R154			RK73HB1J912J	CHIP R 9.1K J 1/16W	
R161			RK73FB2B472J	CHIP R 4.7K J 1/8W	KK1K2
R161			RK73FB2B472J	CHIP R 4.7K J 1/8W	R1X1K3
R161			RK73FB2B472J	CHIP R 4.7K J 1/8W	M1M2C1
R171			RK73FB2B472J	CHIP R 4.7K J 1/8W	
R172			RK73EB2E000J	CHIP R 0.0 J 1/4W	E1E2Q1
R181			RK73HB1J104J	CHIP R 100K J 1/16W	
R182			RK73HB1J473J	CHIP R 47K J 1/16W	
R183			RK73EB2E103J	CHIP R 10K J 1/4W	
R201			RK73FB2B1R0J	CHIP R 1.0 J 1/8W	
R202			RK73GB2A000J	CHIP R 0.0 J 1/10W	R1X1K3
R202			RK73GB2A000J	CHIP R 0.0 J 1/10W	M2C1
R203			RK73GB2A000J	CHIP R 0.0 J 1/10W	KK1K2
R203			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1E2Q1
R203			RK73GB2A000J	CHIP R 0.0 J 1/10W	M1
R204			RK73GB2A223J	CHIP R 22K J 1/10W	
R205			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R206-211			RK73HB1J101J	CHIP R 100 J 1/16W	
R231,232			RK73HB1J222J	CHIP R 2.2K J 1/16W	KK1K2
R231,232			RK73HB1J222J	CHIP R 2.2K J 1/16W	R1E1E2
R231,232			RK73HB1J222J	CHIP R 2.2K J 1/16W	Q1K3M1
R231,232			RK73HB1J222J	CHIP R 2.2K J 1/16W	M2
R233			RK73GB2A101J	CHIP R 100 J 1/10W	KK1K2
R233			RK73GB2A101J	CHIP R 100 J 1/10W	R1E1E2
R233			RK73GB2A101J	CHIP R 100 J 1/10W	Q1K3M1
R233			RK73GB2A101J	CHIP R 100 J 1/10W	M2
R234			RK73HB1J222J	CHIP R 2.2K J 1/16W	KK1K2
R234			RK73HB1J222J	CHIP R 2.2K J 1/16W	R1E1E2
R234			RK73HB1J222J	CHIP R 2.2K J 1/16W	Q1K3M1
R234			RK73HB1J222J	CHIP R 2.2K J 1/16W	M2
R241			RK73GB2A332J	CHIP R 3.3K J 1/10W	KK1K2
R241			RK73GB2A332J	CHIP R 3.3K J 1/10W	E1E2Q1
R241			RK73GB2A332J	CHIP R 3.3K J 1/10W	M1
R242			RK73GB2A562J	CHIP R 5.6K J 1/10W	KK1K2
R242			RK73GB2A562J	CHIP R 5.6K J 1/10W	E1E2Q1
R242			RK73GB2A562J	CHIP R 5.6K J 1/10W	M1
R243			RK73GB2A330J	CHIP R 33 J 1/10W	KK1K2
R243			RK73GB2A330J	CHIP R 33 J 1/10W	E1E2Q1
R243			RK73GB2A330J	CHIP R 33 J 1/10W	M1
R244			RK73GB2A331J	CHIP R 330 J 1/10W	KK1K2
R244			RK73GB2A331J	CHIP R 330 J 1/10W	E1E2Q1
R244			RK73GB2A331J	CHIP R 330 J 1/10W	M1
R245			RK73GB2A330J	CHIP R 33 J 1/10W	KK1K2
R245			RK73GB2A330J	CHIP R 33 J 1/10W	E1E2Q1
R245			RK73GB2A330J	CHIP R 33 J 1/10W	M1
R246			RK73GB2A331J	CHIP R 330 J 1/10W	KK1K2
R246			RK73GB2A331J	CHIP R 330 J 1/10W	E1E2Q1
R246			RK73GB2A331J	CHIP R 330 J 1/10W	M1
R247			RK73GB2A431J	CHIP R 430 J 1/10W	KK1K2
R247			RK73GB2A431J	CHIP R 430 J 1/10W	E1E2Q1
R247			RK73GB2A431J	CHIP R 430 J 1/10W	M1
R248			RK73GB2A270J	CHIP R 27 J 1/10W	KK1K2
R248			RK73GB2A270J	CHIP R 27 J 1/10W	E1E2Q1
R248			RK73GB2A270J	CHIP R 27 J 1/10W	M1
R249			RK73GB2A331J	CHIP R 330 J 1/10W	KK1K2
R249			RK73GB2A331J	CHIP R 330 J 1/10W	E1E2Q1
R249			RK73GB2A331J	CHIP R 330 J 1/10W	M1
R250			RK73GB2A151J	CHIP R 150 J 1/10W	KK1K2
R250			RK73GB2A151J	CHIP R 150 J 1/10W	E1E2Q1
R250			RK73GB2A151J	CHIP R 150 J 1/10W	M1
R251			RK73GB2A431J	CHIP R 430 J 1/10W	KK1K2
R251			RK73GB2A431J	CHIP R 430 J 1/10W	E1E2Q1
R251			RK73GB2A431J	CHIP R 430 J 1/10W	M1
R252			RK73GB2A220J	CHIP R 22 J 1/10W	E1E2Q1
R252			RK73GB2A220J	CHIP R 22 J 1/10W	M1
R252			RK73GB2A470J	CHIP R 47 J 1/10W	KK1K2
R262			RK73GB2A000J	CHIP R 0.0 J 1/10W	KK1K2
R262			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1E2Q1
R262			RK73GB2A000J	CHIP R 0.0 J 1/10W	M1
R263			RK73HB1J101J	CHIP R 100 J 1/16W	
R264			RK73HB1J103J	CHIP R 10K J 1/16W	KK1K2

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-695x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R264			RK73HB1J103J	CHIP R 10K J 1/16W	E1E2Q1
R264			RK73HB1J103J	CHIP R 10K J 1/16W	M1
R265			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R266,267			RK73HB1J101J	CHIP R 100 J 1/16W	KK1K2
R266,267			RK73HB1J101J	CHIP R 100 J 1/16W	E1E2Q1
R266,267			RK73HB1J101J	CHIP R 100 J 1/16W	M1
R269			RK73GB2A000J	CHIP R 0.0 J 1/10W	KK1K2
R269			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1E2Q1
R269			RK73GB2A000J	CHIP R 0.0 J 1/10W	M1
R270,271			RK73HB1J102J	CHIP R 1.0K J 1/16W	KK1K2
R270,271			RK73HB1J102J	CHIP R 1.0K J 1/16W	E1E2Q1
R270,271			RK73HB1J102J	CHIP R 1.0K J 1/16W	M1
R272			RK73HB1J221J	CHIP R 220 J 1/16W	KK1K2
R272			RK73HB1J221J	CHIP R 220 J 1/16W	E1E2Q1
R272			RK73HB1J221J	CHIP R 220 J 1/16W	M1
R273			RK73HB1J103J	CHIP R 10K J 1/16W	KK1K2
R273			RK73HB1J103J	CHIP R 10K J 1/16W	E1E2Q1
R273			RK73HB1J103J	CHIP R 10K J 1/16W	M1
R276			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R301			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R302			RK73HB1J104J	CHIP R 100K J 1/16W	
R303,304			RK73HB1J103J	CHIP R 10K J 1/16W	
R305			RK73GB2A101J	CHIP R 100 J 1/10W	
R306			RK73HB1J101J	CHIP R 100 J 1/16W	
R307			RK73EB2E2R2J	CHIP R 2.2 J 1/4W	
R310			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R311-314			RK73HB1J430J	CHIP R 43 J 1/16W	
R315,316			RK73HB1J680J	CHIP R 68 J 1/16W	
R341,342			RK73HB1J471J	CHIP R 470 J 1/16W	KK1K2
R341,342			RK73HB1J471J	CHIP R 470 J 1/16W	R1E1Q1
R341,342			RK73HB1J471J	CHIP R 470 J 1/16W	X1K3M1
R341,342			RK73HB1J471J	CHIP R 470 J 1/16W	M2C1
R343,344			RK73HB1J223J	CHIP R 22K J 1/16W	KK1K2
R343,344			RK73HB1J223J	CHIP R 22K J 1/16W	R1E1Q1
R343,344			RK73HB1J223J	CHIP R 22K J 1/16W	X1K3M1
R343,344			RK73HB1J223J	CHIP R 22K J 1/16W	M2C1
R345,346			RK73HB1J100J	CHIP R 10 J 1/16W	K1K2R1
R345,346			RK73HB1J100J	CHIP R 10 J 1/16W	E1Q1X1
R345,346			RK73HB1J100J	CHIP R 10 J 1/16W	K3M1M2
R345,346			RK73HB1J100J	CHIP R 10 J 1/16W	C1
R351,352			RK73HB1J471J	CHIP R 470 J 1/16W	KK1K2
R351,352			RK73HB1J471J	CHIP R 470 J 1/16W	R1E1Q1
R351,352			RK73HB1J471J	CHIP R 470 J 1/16W	X1K3M1
R351,352			RK73HB1J471J	CHIP R 470 J 1/16W	M2C1
R353,354			RK73HB1J223J	CHIP R 22K J 1/16W	KK1K2
R353,354			RK73HB1J223J	CHIP R 22K J 1/16W	R1E1Q1
R353,354			RK73HB1J223J	CHIP R 22K J 1/16W	X1K3M1
R353,354			RK73HB1J223J	CHIP R 22K J 1/16W	M2C1
R355,356			RK73HB1J100J	CHIP R 10 J 1/16W	K1K2R1
R355,356			RK73HB1J100J	CHIP R 10 J 1/16W	E1Q1X1
R355,356			RK73HB1J100J	CHIP R 10 J 1/16W	K3M1M2
R355,356			RK73HB1J100J	CHIP R 10 J 1/16W	C1
R361,362			RK73HB1J471J	CHIP R 470 J 1/16W	
R363,364			RK73HB1J223J	CHIP R 22K J 1/16W	
R365,366			RK73HB1J100J	CHIP R 10 J 1/16W	K1K2R1
R365,366			RK73HB1J100J	CHIP R 10 J 1/16W	E1E2Q1
R365,366			RK73HB1J100J	CHIP R 10 J 1/16W	X1K3M1
R365,366			RK73HB1J100J	CHIP R 10 J 1/16W	M2C1
R371-374			RK73HB1J103J	CHIP R 10K J 1/16W	K
R375,376			RK73EB2E820J	CHIP R 82 J 1/4W	KK1K2
R375,376			RK73EB2E820J	CHIP R 82 J 1/4W	R1E1Q1
R375,376			RK73EB2E820J	CHIP R 82 J 1/4W	X1K3M1
R375,376			RK73EB2E820J	CHIP R 82 J 1/4W	M2C1
R381-384			RK73HB1J103J	CHIP R 10K J 1/16W	K
R385,386			RK73EB2E820J	CHIP R 82 J 1/4W	KK1K2
R385,386			RK73EB2E820J	CHIP R 82 J 1/4W	R1E1Q1
R385,386			RK73EB2E820J	CHIP R 82 J 1/4W	X1K3M1
R385,386			RK73EB2E820J	CHIP R 82 J 1/4W	M2C1
R391-394			RK73HB1J103J	CHIP R 10K J 1/16W	K
R395,396			RK73EB2E820J	CHIP R 82 J 1/4W	
R397,398			RK73GB2A000J	CHIP R 0.0 J 1/10W	E2
R401			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	
R402,403			RK73HB1J101J	CHIP R 100 J 1/16W	
R404			RK73HB1J473J	CHIP R 47K J 1/16W	
R405			RK73HB1J223J	CHIP R 22K J 1/16W	
R406			RK73GB2A162J	CHIP R 1.6K J 1/10W	
R407,408			RK73GB2A103J	CHIP R 10K J 1/10W	
R409,410			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R411,412			RK73GB2A223J	CHIP R 22K J 1/10W	
R413			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R414			RK73HB1J4R7J	CHIP R 4.7 J 1/16W	
R502			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	KK1K2
R502			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	R1E1E2
R502			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	Q1K3
R503			RK73EB2E100J	CHIP R 10 J 1/4W	KK1K2
R503			RK73EB2E100J	CHIP R 10 J 1/4W	R1E1E2
R503			RK73EB2E100J	CHIP R 10 J 1/4W	Q1K3
R504			RK73GB2A620J	CHIP R 62 J 1/10W	KK1K2
R504			RK73GB2A620J	CHIP R 62 J 1/10W	R1E1E2
R504			RK73GB2A620J	CHIP R 62 J 1/10W	Q1K3
R505			RK73EB2E100J	CHIP R 10 J 1/4W	KK1K2
R505			RK73EB2E100J	CHIP R 10 J 1/4W	R1E1E2
R505			RK73EB2E100J	CHIP R 10 J 1/4W	Q1K3
R506			RK73EB2E162J	CHIP R 1.6K J 1/4W	KK1K2
R506			RK73EB2E162J	CHIP R 1.6K J 1/4W	R1E1E2
R506			RK73EB2E162J	CHIP R 1.6K J 1/4W	Q1K3
R507			RK73GB2A223J	CHIP R 22K J 1/10W	KK1K2
R507			RK73GB2A223J	CHIP R 22K J 1/10W	R1E1E2
R507			RK73GB2A223J	CHIP R 22K J 1/10W	Q1K3
R508			RK73EB2E000J	CHIP R 0.0 J 1/4W	KK1K2
R508			RK73EB2E000J	CHIP R 0.0 J 1/4W	R1E1E2
R508			RK73EB2E000J	CHIP R 0.0 J 1/4W	Q1K3
R509			RK73GB2A223J	CHIP R 22K J 1/10W	KK1K2
R509			RK73GB2A223J	CHIP R 22K J 1/10W	R1E1E2
R509			RK73GB2A223J	CHIP R 22K J 1/10W	Q1K3
R511			RK73EB2E162J	CHIP R 1.6K J 1/4W	KK1K2
R511			RK73EB2E162J	CHIP R 1.6K J 1/4W	R1E1E2
R511			RK73EB2E162J	CHIP R 1.6K J 1/4W	Q1K3
R512,513			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R533			RK73EB2E100J	CHIP R 10 J 1/4W	KK1K2

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-695x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R533			RK73EB2E100J	CHIP R 10 J 1/4W	R1E2X1
R533			RK73EB2E100J	CHIP R 10 J 1/4W	K3M1M2
R533			RK73EB2E100J	CHIP R 10 J 1/4W	C1
R534			RK73GH2A750D	CHIP R 75 D 1/10W	KK1K2
R534			RK73GH2A750D	CHIP R 75 D 1/10W	R1E2X1
R534			RK73GH2A750D	CHIP R 75 D 1/10W	K3M1M2
R534			RK73GH2A750D	CHIP R 75 D 1/10W	C1
R535			RK73EB2E100J	CHIP R 10 J 1/4W	KK1K2
R535			RK73EB2E100J	CHIP R 10 J 1/4W	R1E2X1
R535			RK73EB2E100J	CHIP R 10 J 1/4W	K3M1M2
R535			RK73EB2E100J	CHIP R 10 J 1/4W	C1
R538			RK73EB2E100J	CHIP R 10 J 1/4W	KK1K2
R538			RK73EB2E100J	CHIP R 10 J 1/4W	R1E2X1
R538			RK73EB2E100J	CHIP R 10 J 1/4W	K3M1M2
R538			RK73EB2E100J	CHIP R 10 J 1/4W	C1
R541			RK73EB2E000J	CHIP R 0.0 J 1/4W	KK1K2
R541			RK73EB2E000J	CHIP R 0.0 J 1/4W	R1E2X1
R541			RK73EB2E000J	CHIP R 0.0 J 1/4W	K3M1M2
R541			RK73EB2E000J	CHIP R 0.0 J 1/4W	C1
R571,572			RK73EB2E102J	CHIP R 1.0K J 1/4W	KK1K2
R571,572			RK73EB2E102J	CHIP R 1.0K J 1/4W	E1K3M1
R571,572			RK73EB2E102J	CHIP R 1.0K J 1/4W	M2C1
R573-575			RK73EB2E101J	CHIP R 100 J 1/4W	KK1K2
R573-575			RK73EB2E101J	CHIP R 100 J 1/4W	E1K3M1
R573-575			RK73EB2E101J	CHIP R 100 J 1/4W	M2C1
R580			RK73GB2A103J	CHIP R 10K J 1/10W	KK1K2
R580			RK73GB2A103J	CHIP R 10K J 1/10W	E1K3M1
R580			RK73GB2A103J	CHIP R 10K J 1/10W	M2C1
R581			RK73HB1J473J	CHIP R 47K J 1/16W	KK1K2
R581			RK73HB1J473J	CHIP R 47K J 1/16W	E1K3M1
R581			RK73HB1J473J	CHIP R 47K J 1/16W	M2C1
R582			RK73HB1J103J	CHIP R 10K J 1/16W	KK1K2
R582			RK73HB1J103J	CHIP R 10K J 1/16W	E1K3M1
R582			RK73HB1J103J	CHIP R 10K J 1/16W	M2C1
R583			RK73HB1J223J	CHIP R 22K J 1/16W	KK1K2
R583			RK73HB1J223J	CHIP R 22K J 1/16W	E1K3M1
R583			RK73HB1J223J	CHIP R 22K J 1/16W	M2C1
R584,585			RK73HB1J103J	CHIP R 10K J 1/16W	KK1K2
R584,585			RK73HB1J103J	CHIP R 10K J 1/16W	E1K3M1
R584,585			RK73HB1J103J	CHIP R 10K J 1/16W	M2C1
R586			RK73EB2E100J	CHIP R 10 J 1/4W	KK1K2
R586			RK73EB2E100J	CHIP R 10 J 1/4W	E1K3M1
R586			RK73EB2E100J	CHIP R 10 J 1/4W	M2C1
R587			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	KK1K2
R587			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	E1K3M1
R587			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	M2C1
R588			RK73EB2E100J	CHIP R 10 J 1/4W	KK1K2
R588			RK73EB2E100J	CHIP R 10 J 1/4W	E1K3M1
R588			RK73EB2E100J	CHIP R 10 J 1/4W	M2C1
R589			RK73GB2A823J	CHIP R 82K J 1/10W	KK1K2
R589			RK73GB2A823J	CHIP R 82K J 1/10W	E1K3M1
R589			RK73GB2A823J	CHIP R 82K J 1/10W	M2C1
R590			RK73GB2A103J	CHIP R 10K J 1/10W	KK1K2
R590			RK73GB2A103J	CHIP R 10K J 1/10W	E1K3M1
R590			RK73GB2A103J	CHIP R 10K J 1/10W	M2C1
R591			RK73GB2A473J	CHIP R 47K J 1/10W	KK1K2
R591			RK73GB2A473J	CHIP R 47K J 1/10W	E1K3M1
R591			RK73GB2A473J	CHIP R 47K J 1/10W	M2C1
R601-604			RK73HB1J100J	CHIP R 10 J 1/16W	
R609			RK73HB1J100J	CHIP R 10 J 1/16W	
R616			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R617			RK73EB2E100J	CHIP R 10 J 1/4W	KK1K2
R617			RK73EB2E100J	CHIP R 10 J 1/4W	R1E2X1
R617			RK73EB2E100J	CHIP R 10 J 1/4W	K3M1M2
R617			RK73EB2E100J	CHIP R 10 J 1/4W	C1
R618			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	KK1K2
R618			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	R1E2X1
R618			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	K3M1M2
R618			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	C1
R619			RK73GB2A000J	CHIP R 0.0 J 1/10W	R1E1E2
R619			RK73GB2A000J	CHIP R 0.0 J 1/10W	Q1X1M1
R619			RK73GB2A000J	CHIP R 0.0 J 1/10W	M2C1
D1			RM4ZLF-J4NF	DIODE	
D2			MC2846-T111	DIODE	
D61			HSU119TRF-E	DIODE	KK1K2
D61			HSU119TRF-E	DIODE	E1E2Q1
D61			HSU119TRF-E	DIODE	M1
D71			RKZ11KG(B2)	ZENER DIODE	K
D72			RKZ5.6KG(B2)	ZENER DIODE	K
D111			HSU119TRF-E	DIODE	
D121			HSU119TRF-E	DIODE	
D131			HSU119TRF-E	DIODE	
D141			RKZ6.2KG(B2)	ZENER DIODE	
D151			RKZ6.2KG(B2)	ZENER DIODE	
D152			HSU119TRF-E	DIODE	
D161			RR264M-400	DIODE	KK1K2
D161			RR264M-400	DIODE	R1X1K3
D161			RR264M-400	DIODE	M1M2C1
D162			1SR154-400	DIODE	KK1K2
D162			1SR154-400	DIODE	R1X1K3
D162			1SR154-400	DIODE	M1M2C1
D171			RR264M-400	DIODE	
D172			1SR154-400	DIODE	
D181			RKZ4.7KG(B2)	ZENER DIODE	
D241			EZAEG3A50A	SURGE ABSORBER	
D301-303			MC2846-T111	DIODE	
D304,305			HSU119TRF-E	DIODE	
D341,342			MC2846-T111	DIODE	KK1K2
D341,342			MC2846-T111	DIODE	R1E1Q1
D341,342			MC2846-T111	DIODE	X1K3M1
D341,342			MC2846-T111	DIODE	M2C1
D345,346		*	VR1005AAA180	VARISTOR	KK1K2
D345,346		*	VR1005AAA180	VARISTOR	R1E1Q1
D345,346		*	VR1005AAA180	VARISTOR	X1K3M1
D345,346		*	VR1005AAA180	VARISTOR	M2C1
D351			MC2846-T111	DIODE	KK1K2
D351			MC2846-T111	DIODE	R1E1Q1
D351			MC2846-T111	DIODE	X1K3M1
D351			MC2846-T111	DIODE	M2C1

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

The IC261 in the ELECTRIC UNIT (X34-695x-xx) are not replaceable components. When these ICs are defective, replace the whole ELECTRIC UNIT (X34-695x-xx) .

ELECTRIC UNIT (X34-695x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
D355,356		*	VR1005AAA180	VARISTOR	KK1K2
D355,356		*	VR1005AAA180	VARISTOR	R1E1Q1
D355,356		*	VR1005AAA180	VARISTOR	X1K3M1
D355,356		*	VR1005AAA180	VARISTOR	M2C1
D361,362			MC2846-T111	DIODE	
D365-367		*	VR1005AAA180	VARISTOR	
D402			RKZ8.2KG(B2)	ZENER DIODE	
D403			RKZ6.2KG(B2)	ZENER DIODE	
D404			RKZ8.2KG(B2)	ZENER DIODE	
D501		*	VR1005AAA270	VARISTOR	KK1K2
D501		*	VR1005AAA270	VARISTOR	R1E1E2
D501		*	VR1005AAA270	VARISTOR	Q1K3
D502-504		*	VR1005AAA180	VARISTOR	KK1K2
D502-504		*	VR1005AAA180	VARISTOR	R1E1E2
D502-504		*	VR1005AAA180	VARISTOR	Q1K3
D531,532		*	VR1005AAA180	VARISTOR	KK1K2
D531,532		*	VR1005AAA180	VARISTOR	R1E2X1
D531,532		*	VR1005AAA180	VARISTOR	K3M1M2
D531,532		*	VR1005AAA180	VARISTOR	C1
D534		*	VR1005AAA270	VARISTOR	KK1K2
D534		*	VR1005AAA270	VARISTOR	R1E2X1
D534		*	VR1005AAA270	VARISTOR	K3M1M2
D534		*	VR1005AAA270	VARISTOR	C1
D536		*	VR1005AAA180	VARISTOR	KK1K2
D536		*	VR1005AAA180	VARISTOR	R1E2X1
D536		*	VR1005AAA180	VARISTOR	K3M1M2
D536		*	VR1005AAA180	VARISTOR	C1
D571-573		*	VR1005AAA270	VARISTOR	KK1K2
D571-573		*	VR1005AAA270	VARISTOR	E1K3M1
D571-573		*	VR1005AAA270	VARISTOR	M2C1
D574			HSU119TRF-E	DIODE	KK1K2
D574			HSU119TRF-E	DIODE	E1K3M1
D574			HSU119TRF-E	DIODE	M2C1
D575-577		*	VR1005AAA180	VARISTOR	KK1K2
D575-577		*	VR1005AAA180	VARISTOR	E1K3M1
D575-577		*	VR1005AAA180	VARISTOR	M2C1
D578,579		*	VR1005AAA270	VARISTOR	KK1K2
D578,579		*	VR1005AAA270	VARISTOR	E1K3M1
D578,579		*	VR1005AAA270	VARISTOR	M2C1
D601-604			CVL10C270M300	VARISTOR	
IC1			TB2926HQ	ANALOGUE IC	
IC2			LV5680P	INTEGRATED CIRCUIT(ANALOGUE)	
IC4			XC6201P332PR	ANALOGUE IC	KK1K2
IC4			XC6201P332PR	ANALOGUE IC	E1E2Q1
IC4			XC6201P332PR	ANALOGUE IC	M1
IC71			ICL7660SIBAZ	ANALOGUE IC	K
IC231			E-TDA7478AD	ANALOGUE IC	KK1K2
IC231			E-TDA7478AD	ANALOGUE IC	R1E1E2
IC231			E-TDA7478AD	ANALOGUE IC	Q1K3M1
IC231			E-TDA7478AD	ANALOGUE IC	M2
IC261		*	-	MOS-IC	KK1K2
IC261		*	-	MOS-IC	E1E2Q1
IC261		*	-	MOS-IC	M1
IC301			E-TDA7415CB	ANALOGUE IC	
IC371			NJM4565E-ZB	ANALOGUE IC	K
IC381			NJM4565E-ZB	ANALOGUE IC	K
IC391			NJM4565E-ZB	ANALOGUE IC	K
IC401			AN15863UA-VB	ANALOGUE IC	
IC571			TC74VHCT08AFT	MOS-IC	KK1K2
IC571			TC74VHCT08AFT	MOS-IC	E1K3M1
IC571			TC74VHCT08AFT	MOS-IC	M2C1
Q71			RT1N241M-T111	TRANSISTOR	K
Q72			RT1P241M-T111	TRANSISTOR	K
Q73			2SA1797	TRANSISTOR	K
Q74			2SC4154T1(E,F	TRANSISTOR	K
Q75			ISA1602AM1(F)	TRANSISTOR	K
Q76			2SC4154T1(E,F	TRANSISTOR	K
Q77			ISA1602AM1(F)	TRANSISTOR	K
Q78			2SC4154T1(E,F	TRANSISTOR	K
Q79			ISA1602AM1(F)	TRANSISTOR	K
Q80			2SC4154T1(E,F	TRANSISTOR	K
Q111			RT1N241M-T111	TRANSISTOR	
Q121			RT1P144M-T111	TRANSISTOR	
Q131			RT1N241M-T111	TRANSISTOR	
Q151			2SC4154T1(E,F	TRANSISTOR	
Q201			2SA1577	TRANSISTOR	
Q202			RT1N144M-T111	TRANSISTOR	
Q241			2SC3357-A	TRANSISTOR	KK1K2
Q241			2SC3357-A	TRANSISTOR	E1E2Q1
Q241			2SC3357-A	TRANSISTOR	M1
Q341,342			RT1N430M-T111	TRANSISTOR	KK1K2
Q341,342			RT1N430M-T111	TRANSISTOR	R1E1Q1
Q341,342			RT1N430M-T111	TRANSISTOR	X1K3M1
Q341,342			RT1N430M-T111	TRANSISTOR	M2C1
Q343		*	RT1P436M-T111	TRANSISTOR	KK1K2
Q343		*	RT1P436M-T111	TRANSISTOR	R1E1Q1
Q343		*	RT1P436M-T111	TRANSISTOR	X1K3M1
Q343		*	RT1P436M-T111	TRANSISTOR	M2C1
Q344			RT1N144M-T111	TRANSISTOR	KK1K2
Q344			RT1N144M-T111	TRANSISTOR	R1E1Q1
Q344			RT1N144M-T111	TRANSISTOR	X1K3M1
Q344			RT1N144M-T111	TRANSISTOR	M2C1
Q351,352			RT1N430M-T111	TRANSISTOR	KK1K2
Q351,352			RT1N430M-T111	TRANSISTOR	R1E1Q1
Q351,352			RT1N430M-T111	TRANSISTOR	X1K3M1
Q351,352			RT1N430M-T111	TRANSISTOR	M2C1
Q361,362			RT1N430M-T111	TRANSISTOR	
Q363			RT1P441M-T111	TRANSISTOR	
Q364			RT1N144M-T111	TRANSISTOR	
Q573,574			RT1N441M-T111	TRANSISTOR	KK1K2
Q573,574			RT1N441M-T111	TRANSISTOR	E1K3M1
Q573,574			RT1N441M-T111	TRANSISTOR	M2C1
Q575			RT1N144M-T111	TRANSISTOR	KK1K2
Q575			RT1N144M-T111	TRANSISTOR	E1K3M1
Q575			RT1N144M-T111	TRANSISTOR	M2C1
Q576		*	MTM981400BF	FET	KK1K2
Q576		*	MTM981400BF	FET	E1K3M1
Q576		*	MTM981400BF	FET	M2C1
TH1		*	B59601A0085B0	THERMISTOR	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

ELECTRIC UNIT (X34-695x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
A201		*	X86-4270-11	FRONT-END UNIT	KK1K2
A201		*	X86-4270-11	FRONT-END UNIT	R1X1K3
A201		*	X86-4270-11	FRONT-END UNIT	C1
A201		*	X86-4272-70	FRONT-END UNIT	E1E2Q1
A201		*	X86-4272-70	FRONT-END UNIT	M1M2
VIDEO UNIT (X35-514x-xx)					
C1			CK73FB1E475K	CHIP C 4.7UF K	
C2			CK73GB1E105K	CHIP C 1.0UF K	
C3 -5			CK73EB1E106K	CHIP C 10UF K	
C6			CK73HB1A104K	CHIP C 0.10UF K	
C7 ,8			CK73EB1E106K	CHIP C 10UF K	
C9			CK73GB1H104K	CHIP C 0.10UF K	
C10			CK73HB1E103K	CHIP C 0.010UF K	
C11			CK73GB1E105K	CHIP C 1.0UF K	
C12			CC73GCH1H471J	CHIP C 470PF J	
C13			CK73HB1A104K	CHIP C 0.10UF K	
C15			CK73HB0J105K	CHIP C 1.0UF K	
C16			C93-1509-05	CHIP C 100PF F	
C17			CC73HCH1H101J	CHIP C 100PF J	
C18			CK73GB1H103K	CHIP C 0.010UF K	
C19			CK73HB0J224K	CHIP C 0.22UF K	
C20			CK73GB1H104K	CHIP C 0.10UF K	
C21 -24			CK73EB1H475K	CHIP C 4.7UF K	
C25			CC73HCH1H560J	CHIP C 56PF J	
C26			CK73GB1H104K	CHIP C 0.10UF K	
C27			CK73HB1E103K	CHIP C 0.010UF K	
C28 ,29			CK73HB1A104K	CHIP C 0.10UF K	
C30			CK73HB0J105K	CHIP C 1.0UF K	
C31			CK73HB1E104K	CHIP C 0.10UF K	
C32			CK73HB1E103K	CHIP C 0.010UF K	
C33			CK73GB1H104K	CHIP C 0.10UF K	
C34			CK73GB1H103K	CHIP C 0.010UF K	
C100-102			CK73GB0J106M	CHIP C 10UF M	
C103			CK73HB1E103K	CHIP C 0.010UF K	
C104,105			CK73GB0J106M	CHIP C 10UF M	
C106			CK73EB1E106K	CHIP C 10UF K	
C107			CK73GB1H104K	CHIP C 0.10UF K	
C108			CK73GB1H103K	CHIP C 0.010UF K	
C109			CK73GB1E154K	CHIP C 0.15UF K	
C111,112			CK73FB1E475K	CHIP C 4.7UF K	
C113			CK73HB1H102K	CHIP C 1000PF K	
C114			CC73HCH1H151J	CHIP C 150PF J	
C115			CK73GB1C224K	CHIP C 0.22UF K	
C116-118			CK73FB1C106K	CHIP C 10UF K	
C119,120			CK73GB1A105K	CHIP C 1.0UF K	
C121			CK73GB1H104K	CHIP C 0.10UF K	
C122-124			CK73FB1C106K	CHIP C 10UF K	
C125			CK73FB1E475K	CHIP C 4.7UF K	
C126			CK73HB1E103K	CHIP C 0.010UF K	
C127			CK73GB1H104K	CHIP C 0.10UF K	
C128			CK73FB1C106K	CHIP C 10UF K	
C129			CK73GB1H104K	CHIP C 0.10UF K	
C130			CK73FB1C106K	CHIP C 10UF K	
C135			CK73GB1H104K	CHIP C 0.10UF K	
C136			CK73GB1A105K	CHIP C 1.0UF K	
C138			CK73HB1A104K	CHIP C 0.10UF K	
C139			CK73FB1E475K	CHIP C 4.7UF K	
C140			CK73HB1E104K	CHIP C 0.10UF K	
C141			CK73HB1E103K	CHIP C 0.010UF K	
C142			CK73GB1C225K	CHIP C 2.2UF K	
C200-205			CK73HB1A104K	CHIP C 0.10UF K	
C206			CC73HCH1H150J	CHIP C 15PF J	
C207			CK73HB1A104K	CHIP C 0.10UF K	
C208			CC73HCH1H070D	CHIP C 7.0PF D	
C209			CK73HB0J105K	CHIP C 1.0UF K	
C210			CK73HB0J474K	CHIP C 0.47UF K	
C211			CK73HB1H222K	CHIP C 2200PF K	
C212			CK73HB1A104K	CHIP C 0.10UF K	
C213,214			CK73GB0J106M	CHIP C 10UF M	
C215,216			CK73HB0J105K	CHIP C 1.0UF K	
C217			CK73HB1A104K	CHIP C 0.10UF K	
C218			CK73GB0J106M	CHIP C 10UF M	
C219,220			CK73HB0J105K	CHIP C 1.0UF K	
C221			CK73HB1H222K	CHIP C 2200PF K	
C222			CK73HB1H472K	CHIP C 4700PF K	
C223			CK73HB1H102K	CHIP C 1000PF K	
C224,225			CC73HCH1H101J	CHIP C 100PF J	
C400			CK73HB0J105K	CHIP C 1.0UF K	
C402			CK73HB0J105K	CHIP C 1.0UF K	
C403			CK73FB1E475K	CHIP C 4.7UF K	
C404			CK73GB1H104K	CHIP C 0.10UF K	
C405			CK73HB1E103K	CHIP C 0.010UF K	
C406,407			CK73HB0J105K	CHIP C 1.0UF K	
C408			CK73HB1A104K	CHIP C 0.10UF K	
C409			CK73GB0J106M	CHIP C 10UF M	
C410			CK73HB1A104K	CHIP C 0.10UF K	
C411			CK73FB1E475K	CHIP C 4.7UF K	
C412			CK73HB1A104K	CHIP C 0.10UF K	
C413			CK73HB1E103K	CHIP C 0.010UF K	
C414			CK73GB0J106M	CHIP C 10UF M	
C415			CK73HB1E103K	CHIP C 0.010UF K	
C416			CK73HB0J105K	CHIP C 1.0UF K	
C417			CK73GB0J106M	CHIP C 10UF M	
C418			CK73HB1A104K	CHIP C 0.10UF K	
C419			CK73FB0J226M	CHIP C 22UF M	
C420-423			CK73GB0J106M	CHIP C 10UF M	
C424			CK73HB1A104K	CHIP C 0.10UF K	
C425			CK73HB1E103K	CHIP C 0.010UF K	
C426,427			CC73HCH1H101J	CHIP C 100PF J	
C428,429			CK73HB0J105K	CHIP C 1.0UF K	
C430,431			CK73HB1E103K	CHIP C 0.010UF K	
C432-434			CK73HB1A104K	CHIP C 0.10UF K	
C435			CK73GB0J106M	CHIP C 10UF M	
C436-439			CK73FB1C106K	CHIP C 10UF K	
C440			CK73GB1H104K	CHIP C 0.10UF K	
C441			CK73HB1E103K	CHIP C 0.010UF K	
C442			CK73FB1C106K	CHIP C 10UF K	
C443			CK73GB0J106M	CHIP C 10UF M	
C444-446			CK73HB1A104K	CHIP C 0.10UF K	
C447			CK73GB0J106M	CHIP C 10UF M	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO UNIT (X35-514x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
C448			CK73HB1A104K	CHIP C 0.10UF K	
C450			CC73HCH1H101J	CHIP C 100PF J	
C452-454			CK73HB1A104K	CHIP C 0.10UF K	
C458			CC73HCH1H220J	CHIP C 22PF J	
C464			CK73GB0J106M	CHIP C 10UF M	
C465,466			CK73HB1A104K	CHIP C 0.10UF K	
C477			CK73HB1A104K	CHIP C 0.10UF K	
C479			CK73HB1E103K	CHIP C 0.010UF K	
C481			CK73HB1E103K	CHIP C 0.010UF K	
C483			CK73HB1A104K	CHIP C 0.10UF K	
C485			CK73HB1E103K	CHIP C 0.010UF K	
C487			CK73HB1A104K	CHIP C 0.10UF K	
C489			CK73HB1E103K	CHIP C 0.010UF K	
C490,491			CK73HB1A104K	CHIP C 0.10UF K	
C493			CK73GB0J475K	CHIP C 4.7UF K	
C495,496			CK73HB1A104K	CHIP C 0.10UF K	
C498-503			CK73HB1A104K	CHIP C 0.10UF K	
C504			CC73HCH1H120J	CHIP C 12PF J	
C505			CC73HCH1H070D	CHIP C 7.0PF D	
C506			CK73GB0J106M	CHIP C 10UF M	
C507			CK73HB1A104K	CHIP C 0.10UF K	
C508-521			CK73HB1H102K	CHIP C 1000PF K	
C522			CK73HB1E103K	CHIP C 0.010UF K	
C600			CK73GB0J106M	CHIP C 10UF M	
C700,701			CK73HB1A104K	CHIP C 0.10UF K	
C704			CK73HB1A104K	CHIP C 0.10UF K	
C705,706			CK73HB1E103K	CHIP C 0.010UF K	
C711			CK73GB0J106M	CHIP C 10UF M	
C717			CK73HB1A104K	CHIP C 0.10UF K	
C718			CK73GB1H102K	CHIP C 1000PF K	
C719,720			CK73GB0J106M	CHIP C 10UF M	
C721			CK73GB0J475K	CHIP C 4.7UF K	
CN1			E41-2615-05	FLAT CABLE CONNECTOR	
CN200			E41-2248-05	PIN ASSY	
CN400			E41-2812-05	FLAT CABLE CONNECTOR	
CN401			E41-2985-05	FLAT CABLE CONNECTOR	
CN600			E41-2276-05	FLAT CABLE CONNECTOR	
CN700		*	E41-3269-05	FLAT CABLE CONNECTOR	
F100			F53-0280-05	FUSE 0.63A	
L1			L33-2583-05	CHOKE COIL	
L2			L33-2607-05	CHOKE COIL	
L3			L92-0364-05	CHIP FERRITE	
L100			L33-2583-05	CHOKE COIL	
L101		*	L33-2619-05	SMALL FIXED INDUCTOR	
L102		*	L41-1001-62	SMALL FIXED INDUCTOR(10U)	
L103			L33-2611-05	CHOKE COIL	
L104,105		*	L41-1001-62	SMALL FIXED INDUCTOR(10U)	
L106			L92-0180-05	CHIP FERRITE	
L200			L92-0332-05	CHIP FERRITE	
L202			L92-0332-05	CHIP FERRITE	
L400,401			L92-0180-05	CHIP FERRITE	
L402		*	L41-1001-62	SMALL FIXED INDUCTOR(10U)	
L403,404			L92-0180-05	CHIP FERRITE	
L405			L92-0373-05	CHIP FERRITE	
L406			L92-0180-05	CHIP FERRITE	
L407,408			L92-0668-05	CHIP FERRITE	
L409-411			L92-0180-05	CHIP FERRITE	
L412			L41-2281-15	SMALL FIXED INDUCTOR(220NH)	
L413			L92-0180-05	CHIP FERRITE	
L414-425			L92-0172-05	CHIP FERRITE	
L427-432			L92-0172-05	CHIP FERRITE	
L433-436			L92-0180-05	CHIP FERRITE	
L600		*	L41-1001-62	SMALL FIXED INDUCTOR(10U)	
X200			L77-3846-05	CRYSTAL RESONATOR(12MHZ)	
X400		*	L77-3850-05	CRYSTAL RESONATOR(12MHZ)	
CP400-404			RK74HB1J121J	CHIP-COM 120 J 1/16W	
R1			RK73FB2B302J	CHIP R 3.0K J 1/8W	
R2 ,3			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R6			RK73FB2B392J	CHIP R 3.9K J 1/8W	
R8			RK73HH1J123D	CHIP R 12K D 1/16W	
R9			RK73HH1J103D	CHIP R 10K D 1/16W	
R10 -13			RK73HB1J473J	CHIP R 47K J 1/16W	
R14			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R15 -17			RK73HB1J473J	CHIP R 47K J 1/16W	
R18			RK73HB1J121J	CHIP R 120 J 1/16W	
R19			RK73EB2E100J	CHIP R 10 J 1/4W	
R20 ,21			RK73HB1J473J	CHIP R 47K J 1/16W	
R22			RK73HH1J393D	CHIP R 39K D 1/16W	
R23			RK73HB1J104J	CHIP R 100K J 1/16W	
R24 ,25			RK73HB1J473J	CHIP R 47K J 1/16W	
R26			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R27			RK73HH1J363D	CHIP R 36K D 1/16W	
R28			RK73HH1J914D	CHIP R 910K D 1/16W	
R29			RK73HH1J823D	CHIP R 82K D 1/16W	
R31 ,32			RK73HB1J473J	CHIP R 47K J 1/16W	
R101			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R102			RK73HB1J752J	CHIP R 7.5K J 1/16W	
R104			RK73HB1J101J	CHIP R 100 J 1/16W	
R105			RK73HB1J103J	CHIP R 10K J 1/16W	
R106			RK73HH1J114D	CHIP R 110K D 1/16W	
R107			RK73HH1J822D	CHIP R 8.2K D 1/16W	
R108			RK73HB1J101J	CHIP R 100 J 1/16W	
R109			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R110			RK73HB1J103J	CHIP R 10K J 1/16W	
R113			RK73HH1J104D	CHIP R 100K D 1/16W	
R114			RK73HH1J103D	CHIP R 10K D 1/16W	
R115			RK73HB1J473J	CHIP R 47K J 1/16W	
R116			RK73HB1J302J	CHIP R 3.0K J 1/16W	
R117			RK73HB1J272J	CHIP R 2.7K J 1/16W	
R118			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R119			RK73HB1J203J	CHIP R 20K J 1/16W	
R120			RK73HH1J203D	CHIP R 20K D 1/16W	
R121			RK73HH1J103D	CHIP R 10K D 1/16W	
R122			RK73HH1J122D	CHIP R 1.2K D 1/16W	
R123			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R130			RK73HH1J153D	CHIP R 15K D 1/16W	
R131			RK73HH1J123D	CHIP R 12K D 1/16W	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO UNIT (X35-514x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R132,133			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R134			RK73GB2A302J	CHIP R 3.0K J 1/10W	
R135			RK73HB1J103J	CHIP R 10K J 1/16W	
R136			RK73HB1J473J	CHIP R 47K J 1/16W	
R137			RK73HB1J104J	CHIP R 100K J 1/16W	
R138			RK73HB1J103J	CHIP R 10K J 1/16W	
R140			RK73HB1J104J	CHIP R 100K J 1/16W	
R141			RK73GB2A822J	CHIP R 8.2K J 1/10W	
R202			RK73HB1J473J	CHIP R 47K J 1/16W	
R203,204			RK73HB1J103J	CHIP R 10K J 1/16W	
R205-207			RK73HB1J473J	CHIP R 47K J 1/16W	
R210,211			RK73HB1J473J	CHIP R 47K J 1/16W	
R212-218			RK73HB1J101J	CHIP R 100 J 1/16W	
R219-221			RK73HB1J100J	CHIP R 10 J 1/16W	
R222			RK73HB1J473J	CHIP R 47K J 1/16W	
R223,224			RK73HB1J101J	CHIP R 100 J 1/16W	
R225			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R226,227			RK73HB1J101J	CHIP R 100 J 1/16W	
R228,229			RK73HB1J473J	CHIP R 47K J 1/16W	E1Q1
R229			RK73HB1J473J	CHIP R 47K J 1/16W	KK1K2
R229			RK73HB1J473J	CHIP R 47K J 1/16W	R1E2X1
R229			RK73HB1J473J	CHIP R 47K J 1/16W	K3M1M2
R229			RK73HB1J473J	CHIP R 47K J 1/16W	C1
R230			RK73HB1J101J	CHIP R 100 J 1/16W	
R231			RK73HB1J473J	CHIP R 47K J 1/16W	KK1K2
R231			RK73HB1J473J	CHIP R 47K J 1/16W	R1E2K3
R231,232			RK73HB1J473J	CHIP R 47K J 1/16W	X1M1M2
R231,232			RK73HB1J473J	CHIP R 47K J 1/16W	C1
R233			RK73HB1J473J	CHIP R 47K J 1/16W	KK1K2
R233			RK73HB1J473J	CHIP R 47K J 1/16W	R1E1E2
R233			RK73HB1J473J	CHIP R 47K J 1/16W	Q1K3
R234			RK73HB1J101J	CHIP R 100 J 1/16W	
R236			RK73HB1J473J	CHIP R 47K J 1/16W	
R237			RK73HB1J103J	CHIP R 10K J 1/16W	
R238,239			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R240			RK73HB1J103J	CHIP R 10K J 1/16W	
R242			RK73HB1J101J	CHIP R 100 J 1/16W	
R243			RK73HB1J473J	CHIP R 47K J 1/16W	
R244			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R245			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R246			RK73HB1J473J	CHIP R 47K J 1/16W	
R247,248			RK73HB1J101J	CHIP R 100 J 1/16W	
R249			RK73HB1J473J	CHIP R 47K J 1/16W	
R250			RK73HB1J101J	CHIP R 100 J 1/16W	
R251			RK73HB1J154J	CHIP R 150K J 1/16W	
R252			RK73HB1J101J	CHIP R 100 J 1/16W	
R253			RK73HB1J153J	CHIP R 15K J 1/16W	
R255,256			RK73HB1J101J	CHIP R 100 J 1/16W	
R257			RK73HB1J473J	CHIP R 47K J 1/16W	
R258-262			RK73HB1J101J	CHIP R 100 J 1/16W	
R263			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R264			RK73HB1J473J	CHIP R 47K J 1/16W	
R265,266			RK73HB1J101J	CHIP R 100 J 1/16W	
R267			RK73HB1J471J	CHIP R 470 J 1/16W	
R268			RK73HB1J204J	CHIP R 200K J 1/16W	
R269			RK73HB1J103J	CHIP R 10K J 1/16W	
R270,271			RK73HB1J101J	CHIP R 100 J 1/16W	
R272-275			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R276-281			RK73HB1J101J	CHIP R 100 J 1/16W	
R283-285			RK73HB1J101J	CHIP R 100 J 1/16W	
R286			RK73HB1J100J	CHIP R 10 J 1/16W	
R287			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R288			RK73HB1J123J	CHIP R 12K J 1/16W	
R289,290			RK73HB1J473J	CHIP R 47K J 1/16W	
R291			RK73HB1J104J	CHIP R 100K J 1/16W	
R292			RK73HB1J473J	CHIP R 47K J 1/16W	
R293			RK73HB1J223J	CHIP R 22K J 1/16W	
R294			RK73HB1J473J	CHIP R 47K J 1/16W	
R297			RK73HH1J103D	CHIP R 10K D 1/16W	
R298			RK73HH1J133D	CHIP R 13K D 1/16W	
R299			RK73HH1J471D	CHIP R 470 D 1/16W	
R300-302			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R303			RK73HH1J153D	CHIP R 15K D 1/16W	
R304			RK73HH1J622D	CHIP R 6.2K D 1/16W	
R305-307			RK73HB1J473J	CHIP R 47K J 1/16W	
R308			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R309			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R312			RK73HB1J153J	CHIP R 15K J 1/16W	
R313			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R314			RK73HB1J473J	CHIP R 47K J 1/16W	
R315			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R316,317			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R318			RK73HB1J103J	CHIP R 10K J 1/16W	
R319			RK73HB1J473J	CHIP R 47K J 1/16W	
R320			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R400			RK73HB1J103J	CHIP R 10K J 1/16W	
R401			RK73HH1J912D	CHIP R 9.1K D 1/16W	
R402,403			RK73HB1J101J	CHIP R 100 J 1/16W	
R405			RK73HH1J472D	CHIP R 4.7K D 1/16W	
R406			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R407,408			RK73HB1J473J	CHIP R 47K J 1/16W	
R409			RK73EB2E392J	CHIP R 3.9K J 1/4W	
R410			RK73HH1J123D	CHIP R 12K D 1/16W	
R411			RK73HB1J473J	CHIP R 47K J 1/16W	
R412			RK73HH1J123D	CHIP R 12K D 1/16W	
R413			RK73HB1J101J	CHIP R 100 J 1/16W	
R414			RK73HB1J103J	CHIP R 10K J 1/16W	
R415			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R417			RK73HB1J471J	CHIP R 470 J 1/16W	
R418			RK73HB1J104J	CHIP R 100K J 1/16W	
R419,420			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R421,422			RK73HB1J330J	CHIP R 33 J 1/16W	
R423			RK73HB1J101J	CHIP R 100 J 1/16W	
R424			RK73HB1J330J	CHIP R 33 J 1/16W	
R425			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R426,427			RK73HB1J101J	CHIP R 100 J 1/16W	
R429,430			RK73HB1J470J	CHIP R 47 J 1/16W	
R431			RK73HB1J473J	CHIP R 47K J 1/16W	
R432			RK73HB1J101J	CHIP R 100 J 1/16W	
R433			RK73HH1J822D	CHIP R 8.2K D 1/16W	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

VIDEO UNIT (X35-514x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R434			RK73HH1J472D	CHIP R 4.7K D 1/16W	
R435			RK73HB1J473J	CHIP R 47K J 1/16W	
R436			RK73HH1J752D	CHIP R 7.5K D 1/16W	
R437			RK73HH1J153D	CHIP R 15K D 1/16W	
R438			RK73HB1J473J	CHIP R 47K J 1/16W	
R439			RK73HH1J103D	CHIP R 10K D 1/16W	
R440,441			RK73HB1J473J	CHIP R 47K J 1/16W	
R442-449			RK73HB1J101J	CHIP R 100 J 1/16W	
R451			RK73HB1J101J	CHIP R 100 J 1/16W	
R453			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R454			RK73HB1J103J	CHIP R 10K J 1/16W	
R455			RK73HB1J473J	CHIP R 47K J 1/16W	
R456			RK73HB1J470J	CHIP R 47 J 1/16W	
R457-459			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R460			RK73HB1J101J	CHIP R 100 J 1/16W	
R461,462			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R463			RK73HB1J101J	CHIP R 100 J 1/16W	
R464			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R465			RK73HH1J220D	CHIP R 22 D 1/16W	
R466,467			RK73HB1J101J	CHIP R 100 J 1/16W	
R468		*	RK73HH1J241D	CHIP R 240 D 1/16W	
R469			RK73HB1J101J	CHIP R 100 J 1/16W	
R470			RK73HB1J270J	CHIP R 27 J 1/16W	
R471			RK73HB1J100J	CHIP R 10 J 1/16W	
R472			RK73HB1J121J	CHIP R 120 J 1/16W	
R473			RK73HH1J620D	CHIP R 62 D 1/16W	
R474			RK73HH1J161D	CHIP R 160 D 1/16W	
R476			RK73HH1J430D	CHIP R 43 D 1/16W	
R477			RK73HH1J390D	CHIP R 39 D 1/16W	
R478			RK73HH1J102D	CHIP R 1.0K D 1/16W	
R479-481			RK73HH1J181D	CHIP R 180 D 1/16W	
R482			RK73HH1J101D	CHIP R 100 D 1/16W	
R483			RK73HH1J161D	CHIP R 160 D 1/16W	
R484			RK73HH1J470D	CHIP R 47 D 1/16W	
R485			RK73HH1J101D	CHIP R 100 D 1/16W	
R486			RK73HH1J102D	CHIP R 1.0K D 1/16W	
R487			RK73HH1J390D	CHIP R 39 D 1/16W	
R488			RK73HH1J430D	CHIP R 43 D 1/16W	
R489			RK73HH1J470D	CHIP R 47 D 1/16W	
R490			RK73HH1J161D	CHIP R 160 D 1/16W	
R491			RK73HH1J820D	CHIP R 82 D 1/16W	
R492			RK73HH1J470D	CHIP R 47 D 1/16W	
R493			RK73HB1J470J	CHIP R 47 J 1/16W	
R494			RK73HB1J121J	CHIP R 120 J 1/16W	
R495			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R496			RK73HB1J470J	CHIP R 47 J 1/16W	
R497			RK73HB1J121J	CHIP R 120 J 1/16W	
R498			RK73HB1J470J	CHIP R 47 J 1/16W	
R499,500			RK73HB1J121J	CHIP R 120 J 1/16W	
R501			RK73HB1J101J	CHIP R 100 J 1/16W	
R502			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R503			RK73HB1J103J	CHIP R 10K J 1/16W	
R504			RK73HB1J101J	CHIP R 100 J 1/16W	
R505			RK73HB1J473J	CHIP R 47K J 1/16W	
R506,507			RK73HB1J100J	CHIP R 10 J 1/16W	
R511			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R512,513			RK73HB1J100J	CHIP R 10 J 1/16W	
R514,515			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R600,601			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R604			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R605			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R606,607			RK73HB1J473J	CHIP R 47K J 1/16W	
R608			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R609			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R610,611			RK73HB1J473J	CHIP R 47K J 1/16W	
R612			RK73GH2A100D	CHIP R 10 D 1/10W	
R613			RK73GH2A220D	CHIP R 22 D 1/10W	
R614			RK73GH2A100D	CHIP R 10 D 1/10W	
R615			RK73GH2A220D	CHIP R 22 D 1/10W	
R616			RK73HB1J224J	CHIP R 220K J 1/16W	
R617-620			RK73GB2A100J	CHIP R 10 J 1/10W	
R621,622			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R624			RK73HH1J223D	CHIP R 22K D 1/16W	
R625			RK73HH1J473D	CHIP R 47K D 1/16W	
R626			RK73HH1J102D	CHIP R 1.0K D 1/16W	
R718			RK73HB1J473J	CHIP R 47K J 1/16W	
R719			RK73GH2A301D	CHIP R 300 D 1/10W	
R721			RK73HB1J473J	CHIP R 47K J 1/16W	
R722			RK73GH2A301D	CHIP R 300 D 1/10W	
R724			RK73HB1J473J	CHIP R 47K J 1/16W	
R725			RK73GH2A301D	CHIP R 300 D 1/10W	
R727			RK73HB1J103J	CHIP R 10K J 1/16W	
R728,729			RK73GB2A103J	CHIP R 10K J 1/10W	
R730			RK73HB1J103J	CHIP R 10K J 1/16W	
R736			RK73HB1J100J	CHIP R 10 J 1/16W	KK1K2
R736			RK73HB1J100J	CHIP R 10 J 1/16W	R1E2K3
R738			RK73GB2A000J	CHIP R 0.0 J 1/10W	E1Q1X1
R738			RK73GB2A000J	CHIP R 0.0 J 1/10W	M1M2C1
R741-744			RK73GB2A100J	CHIP R 10 J 1/10W	X1M1M2
R741-744			RK73GB2A100J	CHIP R 10 J 1/10W	C1
R742,743			RK73GB2A100J	CHIP R 10 J 1/10W	E1Q1
R745			RK73HB1J473J	CHIP R 47K J 1/16W	E1Q1X1
R745			RK73HB1J473J	CHIP R 47K J 1/16W	M1M2C1
R746-748			RK73GB2A100J	CHIP R 10 J 1/10W	
R749,750			RK73GB2A101J	CHIP R 100 J 1/10W	
R751-753			RK73GB2A100J	CHIP R 10 J 1/10W	
R754			RK73GB2A101J	CHIP R 100 J 1/10W	
R755			RK73GB2A100J	CHIP R 10 J 1/10W	
R765			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R767			RK73GB2A100J	CHIP R 10 J 1/10W	
R769-774			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R777			RK73GB2A100J	CHIP R 10 J 1/10W	
R781-783			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R785			RK73HH1J301D	CHIP R 300 D 1/16W	
R787,788			RK73HH1J301D	CHIP R 300 D 1/16W	
R789			RK73GB2A100J	CHIP R 10 J 1/10W	
R790			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
D2 ,3		*	SJPB-L4	DIODE	
D100		*	RB162M-60	DIODE	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

The IC3 and IC100 in the VIDEO UNIT (X35-514x-xx) are not replaceable components. When these ICs are defective, replace the whole VIDEO UNIT (X35-514x-xx) .

VIDEO UNIT (X35-514x-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
D101-103		*	RB162M-40	DIODE	
D200-202			RB521S-30	DIODE	
D401			RB521S-30	DIODE	
D402-406		*	VR105C3R3BAA	VARISTOR	
D602-605		*	VR1005AAA270	VARISTOR	
D700,701		*	VR1005AAA270	VARISTOR	E1Q1X1
D700,701		*	VR1005AAA270	VARISTOR	M1M2C1
D705		*	VR1005AAA270	VARISTOR	
D706		*	VR1005DDA080	VARISTOR	
D707		*	VR1005AAA270	VARISTOR	
D708,709		*	VR1005DDA080	VARISTOR	
D710,711		*	VR1005AAA270	VARISTOR	
D712,713		*	VR1005DDA080	VARISTOR	
D714-716		*	VR1005AAA270	VARISTOR	KK1K2
D714-716		*	VR1005AAA270	VARISTOR	R1E2K3
D714-717		*	VR1005AAA270	VARISTOR	E1Q1X1
D714-717		*	VR1005AAA270	VARISTOR	M1M2C1
D718		*	VR105C3R3BAA	VARISTOR	E1Q1X1
D718		*	VR105C3R3BAA	VARISTOR	M1M2C1
D720-722			MC2850-T111	DIODE	
D724			MC2850-T111	DIODE	
IC1			TC7SH17FU-F	MOS-IC	
IC2			TC7WH08FK-F	MOS-IC	
IC3		*	-	ANALOGUE IC	
IC4			TC7SH08FU-F	MOS-IC	
IC5			TC7SH32FU-F	MOS-IC	
IC6		*	XC6216B332M-G	ANALOGUE IC	
IC100		*	-	ANALOGUE IC	
IC101			XC6213B332N-G	ANALOGUE IC	
IC200		*	TC7WH34FK-F	MOS-IC	
IC201		*	XC6120N422N-G	MOS-IC	
IC202			W05-1701-00	MICROCONTROLLER IC	
IC203			MFI341S2162	MICROPROCESSOR IC	
IC204			XC6219B332MR	ANALOGUE IC	
IC400			NJM2107F-ZB	ANALOGUE IC	
IC401		*	XC6223B181P-G	ANALOGUE IC	
IC402		*	W05-1702-00	ROM IC	
IC403			TC7SH08FU-F	MOS-IC	
IC404		*	RP131S331D-FE	ANALOGUE IC	
IC405		*	XC6223B181P-G	ANALOGUE IC	
IC406		*	MST7912KC-ALF	MOS-IC	
IC407			TC7SH08FU-F	MOS-IC	
IC700			TC7WH04FK-F	MOS-IC	
Q1			CPH3105-E	TRANSISTOR	
Q2			2SC5383-T1(F)	TRANSISTOR	
Q4			2SC4154T1(E,F	TRANSISTOR	
Q5			ISA1602AM1(F)	TRANSISTOR	
Q6			RT1N144U-T111	TRANSISTOR	
Q7			TPCF8104-F	FET	
Q100			RT1N144M-T111	TRANSISTOR	
Q101			RT1P144U-T111	TRANSISTOR	
Q102			ISA1602AM1(F)	TRANSISTOR	
Q103			2SA1577	TRANSISTOR	
Q104			2SB1188(R)	TRANSISTOR	
Q105			2SC4154T1(E,F	TRANSISTOR	
Q106			ISA1602AM1(F)	TRANSISTOR	
Q107			2SC4154T1(E,F	TRANSISTOR	
Q108,109			RT1N144U-T111	TRANSISTOR	
Q110			RT1P144U-T111	TRANSISTOR	
Q113			2SC4154T1(E,F	TRANSISTOR	
Q114			ISA1602AM1(F)	TRANSISTOR	
Q115			2SC4154T1(E,F	TRANSISTOR	
Q116			RT1P144U-T111	TRANSISTOR	
Q117			2SC4154T1(E,F	TRANSISTOR	
Q200			RT1N144U-T111	TRANSISTOR	
Q203			RT1N144U-T111	TRANSISTOR	
Q204			2SC4154T1(E,F	TRANSISTOR	
Q205			RT1P144U-T111	TRANSISTOR	
Q206			ISA1602AM1(F)	TRANSISTOR	
Q207			TPCF8104-F	FET	
Q208			RT1N144U-T111	TRANSISTOR	
Q209			RT1N144M-T111	TRANSISTOR	
Q212-214			2SC4154T1(E,F	TRANSISTOR	
Q215,216			ISA1602AM1(F)	TRANSISTOR	
Q217-219			RT1N144U-T111	TRANSISTOR	
Q220,221			2SC4154T1(E,F	TRANSISTOR	
Q222			RT1N144U-T111	TRANSISTOR	
Q400			2SC4154T1(E,F	TRANSISTOR	
Q401			RT1P144U-T111	TRANSISTOR	
Q402			ISA1602AM1(F)	TRANSISTOR	
Q403			TPCF8104-F	FET	
Q404			2SC4154T1(E,F	TRANSISTOR	
Q405			ISA1602AM1(F)	TRANSISTOR	
Q600			2SA2018	TRANSISTOR	
Q601			2SC5585	TRANSISTOR	
Q602			2SA2018	TRANSISTOR	
Q603			2SC5585	TRANSISTOR	
Q604			RT1P144M-T111	TRANSISTOR	
Q605			2SC4154T1(E,F	TRANSISTOR	
Q700-703			2SC4154T1(E,F	TRANSISTOR	
Q705			RT1N144U-T111	TRANSISTOR	E1Q1X1
Q705			RT1N144U-T111	TRANSISTOR	M1M2C1
Q706			RT1P144U-T111	TRANSISTOR	E1Q1X1
Q706			RT1P144U-T111	TRANSISTOR	M1M2C1
Q708-710			2SC4154T1(E,F	TRANSISTOR	

DVD UNIT (X37-1300-00)

C5 -7			CK73HB1E103K	CHIP C 0.010UF K	
C11			CK73HB1E103K	CHIP C 0.010UF K	
C15			CK73HB1A104K	CHIP C 0.10UF K	
C16			CK73FB0J106K	CHIP C 10UF K	
C17			CK73GB0J475K	CHIP C 4.7UF K	
C72			CK73HB1A104K	CHIP C 0.10UF K	
C100			CK73HB1A104K	CHIP C 0.10UF K	
C102			CK73HB1A104K	CHIP C 0.10UF K	
C106			CK73HB1A104K	CHIP C 0.10UF K	
C109			CK73HB1A104K	CHIP C 0.10UF K	
C111			CK73HB1C333K	CHIP C 0.033UF K	
C113			CK73HB1A104K	CHIP C 0.10UF K	
C114			CK73GB1H562K	CHIP C 5600PF K	
C115			CK73HB1C183K	CHIP C 0.018UF K	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

DVD UNIT (X37-1300-00)

Ref.No.	Add	New	Parts No.	Description	Destination
C117			CK73HB1A104K	CHIP C 0.10UF K	
C118			CK73HB0J105K	CHIP C 1.0UF K	
C120,121			CK73HB1A104K	CHIP C 0.10UF K	
C122			CK73GB0J475K	CHIP C 4.7UF K	
C126-129			CK73HB1A104K	CHIP C 0.10UF K	
C130-133			CC73HCH1H151J	CHIP C 150PF J	
C134			CC73HCH1H102J	CHIP C 1000PF J	
C137,138			CK73HB0J105K	CHIP C 1.0UF K	
C143,144			CC73HCH1H100D	CHIP C 10PF D	
C145			CK73HB1A104K	CHIP C 0.10UF K	
C148			CK73HB1A104K	CHIP C 0.10UF K	
C153			CK73HB1A104K	CHIP C 0.10UF K	
C158			CK73HB1A104K	CHIP C 0.10UF K	
C200-203			CK73FB0J106K	CHIP C 10UF K	
C271			CC73HCH1H102J	CHIP C 1000PF J	
C272			CK73HB0J105K	CHIP C 1.0UF K	
C302			CK73FB0J106K	CHIP C 10UF K	
C434			CK73FB0J106K	CHIP C 10UF K	
C435			CK73HB1E103K	CHIP C 0.010UF K	
C443			CK73FB0J226M	CHIP C 22UF M	
C450			CK73HB1A104K	CHIP C 0.10UF K	
C454,455			CK73HB1A104K	CHIP C 0.10UF K	
C461			CK73HB1H472K	CHIP C 4700PF K	
C462			CK73HB1E103K	CHIP C 0.010UF K	
C467			CC73HCH1H121J	CHIP C 120PF J	
C468,469			CK73HB1A104K	CHIP C 0.10UF K	
C476			CC73HCH1H101J	CHIP C 100PF J	
C498			CK73FB0J226M	CHIP C 22UF M	
C510			CC73HCH1H102J	CHIP C 1000PF J	
C511			CK73GB0J475K	CHIP C 4.7UF K	
C521			CK73HB1A104K	CHIP C 0.10UF K	
C531-539			CK73HB1A104K	CHIP C 0.10UF K	
C541-546			CK73HB1A104K	CHIP C 0.10UF K	
C548,549			CK73HB1A104K	CHIP C 0.10UF K	
C551			CK73HB1A104K	CHIP C 0.10UF K	
C552			CK73FB0J226M	CHIP C 22UF M	
C553			CK73HB0J105K	CHIP C 1.0UF K	
C554			CK73FB0J106K	CHIP C 10UF K	
C557			CC73HCH1H680J	CHIP C 68PF J	
C558			CK73HB1A104K	CHIP C 0.10UF K	
C561			CK73HB0J105K	CHIP C 1.0UF K	
C562			CK73HB1A104K	CHIP C 0.10UF K	
C564,565			CK73HB1A104K	CHIP C 0.10UF K	
C566			CK73FB0J226M	CHIP C 22UF M	
C567			CK73HB0J105K	CHIP C 1.0UF K	
C805			CC73HCH1H102J	CHIP C 1000PF J	
C809,810			CC73HCH1H471J	CHIP C 470PF J	
C811,812			CC73HCH1H102J	CHIP C 1000PF J	
C813,814			CK73HB1H472K	CHIP C 4700PF K	
C815			CK73FB0J106K	CHIP C 10UF K	
C816-819			CC73HCH1H102J	CHIP C 1000PF J	
C820			CK73HB1A104K	CHIP C 0.10UF K	
C821,822			CC73HCH1H102J	CHIP C 1000PF J	
CN1			E41-2594-05	FLAT CABLE CONNECTOR	

Ref.No.	Add	New	Parts No.	Description	Destination
CN3			E41-2596-05	FLAT CABLE CONNECTOR	
CN6			E41-2603-05	FLAT CABLE CONNECTOR	
L15			L33-2280-05	SMALL FIXED INDUCTOR	
X2			L77-3830-05	CRYSTAL RESONATOR(27MHZ)	
CP61			RK74HB1J103J	CHIP-COM 10K J 1/16W	
CP68			RK74HB1J470J	CHIP-COM 47 J 1/16W	
R2 -4			RK73HB1J103J	CHIP R 10K J 1/16W	
R10			RK73HB1J163J	CHIP R 16K J 1/16W	
R16			RK73HB1J103J	CHIP R 10K J 1/16W	
R17			RK73HB1J271J	CHIP R 270 J 1/16W	
R19			RK73HB1J301J	CHIP R 300 J 1/16W	
R21 ,22			RK73HB1J103J	CHIP R 10K J 1/16W	
R80			RK73HB1J220J	CHIP R 22 J 1/16W	
R81			RK73HB1J470J	CHIP R 47 J 1/16W	
R84 ,85			RK73HB1J202J	CHIP R 2.0K J 1/16W	
R86			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R87			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R89			RK73HH1J303D	CHIP R 30K D 1/16W	
R90			RK73HB1J223J	CHIP R 22K J 1/16W	
R92			RK73HH1J123D	CHIP R 12K D 1/16W	
R94			RK73HH1J512D	CHIP R 5.1K D 1/16W	
R112,113			RK73HB1J101J	CHIP R 100 J 1/16W	
R116			RK73HB1J103J	CHIP R 10K J 1/16W	
R119			RK73HB1J103J	CHIP R 10K J 1/16W	
R150,151			RK73HB1J100J	CHIP R 10 J 1/16W	
R152,153			RK73HB1J471J	CHIP R 470 J 1/16W	
R154,155			RK73HB1J751J	CHIP R 750 J 1/16W	
R156,157			RK73HB1J560J	CHIP R 56 J 1/16W	
R158,159			RK73HB1J2R2J	CHIP R 2.2 J 1/16W	
R164,165			RK73HB1J101J	CHIP R 100 J 1/16W	
R200			RK73HH1J201D	CHIP R 200 D 1/16W	
R400,401			RK73HB1J470J	CHIP R 47 J 1/16W	
R409			RK73HB1J470J	CHIP R 47 J 1/16W	
R410,411			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R470			RK73HB1J103J	CHIP R 10K J 1/16W	
R475			RK73GB2A2R2J	CHIP R 2.2 J 1/10W	
R476			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R478			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R481			RK73HH1J203D	CHIP R 20K D 1/16W	
R485,486			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R487			RK73HB1J103J	CHIP R 10K J 1/16W	
R497			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R501			RK73HB1J132J	CHIP R 1.3K J 1/16W	
R502			RK73HB1J333J	CHIP R 33K J 1/16W	
R503			RK73HB1J203J	CHIP R 20K J 1/16W	
R504			RK73HB1J242J	CHIP R 2.4K J 1/16W	
R505			RK73HB1J821J	CHIP R 820 J 1/16W	
R511,512			RK73HB1J103J	CHIP R 10K J 1/16W	
R523,524			RK73HB1J4R7J	CHIP R 4.7 J 1/16W	
R588			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R591			RK73HB1J820J	CHIP R 82 J 1/16W	
R615			RK73HB1J1R0J	CHIP R 1.0 J 1/16W	
R621			RK73HB1J103J	CHIP R 10K J 1/16W	
R622			RK73HB1J333J	CHIP R 33K J 1/16W	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

The IC5 in the DVD unit (X37-1300-00) are not replaceable components. When these ICs are defective, replace the whole DVD mechanism assembly (X92-6640-00).

DVD UNIT (X37-1300-00)

Ref.No.	Add	New	Parts No.	Description	Destination
R630			R92-3416-05	METAL GR 0.27 1/2W	
R631-634			RK73HB1J103J	CHIP R 10K J 1/16W	
R651			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R653			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R654-656			RK73HB1J330J	CHIP R 33 J 1/16W	
R659			RK73HB1J103J	CHIP R 10K J 1/16W	
R663,664			RK73HB1J101J	CHIP R 100 J 1/16W	
R665			RK73HB1J103J	CHIP R 10K J 1/16W	
R672			RK73HB1J101J	CHIP R 100 J 1/16W	
R673			RK73HB1J103J	CHIP R 10K J 1/16W	
R674			RK73HB1J101J	CHIP R 100 J 1/16W	
R676,677			RK73HB1J103J	CHIP R 10K J 1/16W	
R678			RK73HB1J101J	CHIP R 100 J 1/16W	
R688			RK73HH1J124D	CHIP R 120K D 1/16W	
R689			RK73HH1J274D	CHIP R 270K D 1/16W	
R694-696			RK73HB1J103J	CHIP R 10K J 1/16W	
R697			RK73HB1J153J	CHIP R 15K J 1/16W	
R698			RK73HB1J682J	CHIP R 6.8K J 1/16W	
R701			RK73HH1J202D	CHIP R 2.0K D 1/16W	
R703-706			RK73HB1J821J	CHIP R 820 J 1/16W	
R707			RK73HB1J103J	CHIP R 10K J 1/16W	
R712			RK73HB1J103J	CHIP R 10K J 1/16W	
R713			RK73HB1J822J	CHIP R 8.2K J 1/16W	
R715			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R716-718			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R803-805			RK73HH1J121D	CHIP R 120 D 1/16W	
R807,808			RK73HB1J123J	CHIP R 12K J 1/16W	
R809,810			RK73HB1J682J	CHIP R 6.8K J 1/16W	
R811,812			RK73HB1J122J	CHIP R 1.2K J 1/16W	
R813			RK73HB1J103J	CHIP R 10K J 1/16W	
R815,816		*	RK73HB1J221JH	CHIP R 220 J 1/16W	
R817,818		*	RK73HB1J471JH	CHIP R 470 J 1/16W	
R819-821			RK73HB1J101J	CHIP R 100 J 1/16W	
R823,824			RK73HB1J4R7J	CHIP R 4.7 J 1/16W	
S1			S68-0911-15	PUSH SWITCH	
S2			S68-0917-05	PUSH SWITCH	
IC1			MN2DS0016AA	MOS-IC	
IC5		*	-	ROM IC	
IC10			AN41250A-VB	ANALOGUE IC	
IC54		*	M12L1281687L	DRAM IC	
IC59			XC9223B082A1	MOS-IC	
IC61			AK4387ET	MOS-IC	
Q1 ,2			RT1P432U-T111	TRANSISTOR	
Q4			RT1P432U-T111	TRANSISTOR	
Q10 ,11			2SC5383-T1(F)	TRANSISTOR	
Q12 ,13			2SB1709	TRANSISTOR	
Q14 ,15			2SK3019	FET	
Q33 -36			2SA1774	TRANSISTOR	

DIGITAL I/O UNIT (X88-2080-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
C10 -13			CK73HB1H102K	CHIP C 1000PF K	
C14			CK73HB1E103K	CHIP C 0.010UF K	
C15 ,16			CK73HB1H102K	CHIP C 1000PF K	
C17			CK73HB1E103K	CHIP C 0.010UF K	
C18 ,19			CK73HB1H102K	CHIP C 1000PF K	
C20 -26			CK73HB1E103K	CHIP C 0.010UF K	
C30 -33			CK73HB1H102K	CHIP C 1000PF K	
C34			CK73HB1E103K	CHIP C 0.010UF K	
C35 ,36			CK73HB1H102K	CHIP C 1000PF K	
C37			CK73HB1E103K	CHIP C 0.010UF K	
C38 ,39			CK73HB1H102K	CHIP C 1000PF K	
C40 -46			CK73HB1E103K	CHIP C 0.010UF K	
C47			CK73HB0J105K	CHIP C 1.0UF K	
C48			CK73GB0J106M	CHIP C 10UF M	
C50 -53			CK73HB1H102K	CHIP C 1000PF K	
C54			CK73HB1E103K	CHIP C 0.010UF K	
C55 ,56			CK73HB1H102K	CHIP C 1000PF K	
C57			CK73HB1E103K	CHIP C 0.010UF K	
C58 ,59			CK73HB1H102K	CHIP C 1000PF K	
C60 -66			CK73HB1E103K	CHIP C 0.010UF K	
C70 -73			CK73HB1H102K	CHIP C 1000PF K	
C74			CK73HB1E103K	CHIP C 0.010UF K	
C75 ,76			CK73HB1H102K	CHIP C 1000PF K	
C77			CK73HB1E103K	CHIP C 0.010UF K	
C78 ,79			CK73HB1H102K	CHIP C 1000PF K	
C80 -86			CK73HB1E103K	CHIP C 0.010UF K	
C87			CK73HB0J105K	CHIP C 1.0UF K	
C88			CK73GB0J106M	CHIP C 10UF M	
C100			CK73GB0J106M	CHIP C 10UF M	
C102			CK73GB0J106M	CHIP C 10UF M	
C103			CK73HB1A104K	CHIP C 0.10UF K	
C104			CK73GB0J106M	CHIP C 10UF M	
C108-111			CK73HB1A104K	CHIP C 0.10UF K	
C112			CK73HB1H102K	CHIP C 1000PF K	
C113,114			CK73HB1A104K	CHIP C 0.10UF K	
C115,116			CK73HB1H102K	CHIP C 1000PF K	
C117			CK73HB1A104K	CHIP C 0.10UF K	
C118,119			CK73HB1E103K	CHIP C 0.010UF K	
C120			CK73HB1H102K	CHIP C 1000PF K	
C121			CK73HB1A104K	CHIP C 0.10UF K	
C122			CK73HB1H102K	CHIP C 1000PF K	
C123,124			CK73HB1E103K	CHIP C 0.010UF K	
C125			CK73HB1A104K	CHIP C 0.10UF K	
C126,127			CK73HB1H102K	CHIP C 1000PF K	
C128			CK73HB1A104K	CHIP C 0.10UF K	
C129-131			CK73HB1E103K	CHIP C 0.010UF K	
C132			CK73HB1A104K	CHIP C 0.10UF K	
C133			CC73HCH1H471J	CHIP C 470PF J	
C134			CK73HB1H102K	CHIP C 1000PF K	
C135			CK73HB1A104K	CHIP C 0.10UF K	
C136,137			CK73GB0J106M	CHIP C 10UF M	
C138			CK73HB1A104K	CHIP C 0.10UF K	
C139			CK73HB1H102K	CHIP C 1000PF K	
C140			CK73HB0J105K	CHIP C 1.0UF K	
C141			CK73HB1E103K	CHIP C 0.010UF K	
C142			CK73HB1H102K	CHIP C 1000PF K	
C143			CC73HCH1H471J	CHIP C 470PF J	
C144,145			CK73HB1A104K	CHIP C 0.10UF K	
C146			CK73HB1H102K	CHIP C 1000PF K	
C147			CK73HB1A104K	CHIP C 0.10UF K	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

DIGITAL I/O UNIT (X88-2080-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
C148			CK73HB1E103K	CHIP C 0.010UF K	
C149			CK73HB1A104K	CHIP C 0.10UF K	
C150			CK73HB0J105K	CHIP C 1.0UF K	
C151			CC73HCH1H150J	CHIP C 15PF J	
C153			CC73HCH1H050C	CHIP C 5.0PF C	
C155			CK73HB1A104K	CHIP C 0.10UF K	
C156			CK73HB1E103K	CHIP C 0.010UF K	
C157,158			CK73HB1H102K	CHIP C 1000PF K	
C159			CK73HB1A104K	CHIP C 0.10UF K	
C160,161			CK73HB1H102K	CHIP C 1000PF K	
C162-164			CK73HB1A104K	CHIP C 0.10UF K	
C165			CK73HB0J105K	CHIP C 1.0UF K	
C166			CK73HB1A104K	CHIP C 0.10UF K	
C168,169			CK73HB1A104K	CHIP C 0.10UF K	
C170			CK73GB0J106M	CHIP C 10UF M	
C171,172			CK73HB1A104K	CHIP C 0.10UF K	
C173,174			CC73HCH1H470J	CHIP C 47PF J	
C175			CC73HCH1H331J	CHIP C 330PF J	
C176			CC73HCH1H470J	CHIP C 47PF J	
C181			CC73HCH1H820J	CHIP C 82PF J	
C182			CC73HCH1H470J	CHIP C 47PF J	
C183-186			CK73HB1A104K	CHIP C 0.10UF K	
C187			CK73HB1E103K	CHIP C 0.010UF K	
C408-410			CK73HB1A104K	CHIP C 0.10UF K	
C501,502			CK73HB1A104K	CHIP C 0.10UF K	
C505			CK73HB1A104K	CHIP C 0.10UF K	
C510-514			CK73GB0J106M	CHIP C 10UF M	KK1K2
C510-514			CK73GB0J106M	CHIP C 10UF M	R1E1E2
C510-514			CK73GB0J106M	CHIP C 10UF M	Q1K3
C702,703			CK73FB0J226M	CHIP C 22UF M	
C715			CK73HB1H102K	CHIP C 1000PF K	
C718			CK73HB1H102K	CHIP C 1000PF K	
C739			CK73GB0J106M	CHIP C 10UF M	
C740,741			CK73HB1A104K	CHIP C 0.10UF K	
C742			CK73GB0J106M	CHIP C 10UF M	
C744-748			CK73HB1A104K	CHIP C 0.10UF K	
C749			CK73GB0J106M	CHIP C 10UF M	
C750			CK73HB1A104K	CHIP C 0.10UF K	
C752			CK73HB1A104K	CHIP C 0.10UF K	
C753,754			CK73HB0J105K	CHIP C 1.0UF K	
C757-760			CK73HB1A104K	CHIP C 0.10UF K	
C761,762			CK73HB0J105K	CHIP C 1.0UF K	
C764			CK73GB0J106M	CHIP C 10UF M	
C772			CK73HB0J105K	CHIP C 1.0UF K	
C773-778			CK73HB1A104K	CHIP C 0.10UF K	
C785			CC73HCH1H080D	CHIP C 8.0PF D	
C786			CK73HB1A104K	CHIP C 0.10UF K	
C787			CC73HCH1H120J	CHIP C 12PF J	
C788			CK73GB0J106M	CHIP C 10UF M	
C789,790			CK73HB1A104K	CHIP C 0.10UF K	
C792,793			CK73HB1A104K	CHIP C 0.10UF K	
C794-796			CK73HB0J474K	CHIP C 0.47UF K	
C797-799			CK73HB1A104K	CHIP C 0.10UF K	
C804			CK73HB0J105K	CHIP C 1.0UF K	
C805			CK73HB1A104K	CHIP C 0.10UF K	

Ref.No.	Add	New	Parts No.	Description	Destination
C809			CK73GB0J106M	CHIP C 10UF M	
C810			CK73HB0J105K	CHIP C 1.0UF K	
C820			CK73HB0J105K	CHIP C 1.0UF K	
C821			CK73HB1A104K	CHIP C 0.10UF K	
C822-825			CK73EB0J476M	CHIP C 47UF M	
C826			CK73HB1A104K	CHIP C 0.10UF K	
C827			CK73FB0J226M	CHIP C 22UF M	
CN700		*	E41-3252-05	PIN ASSY	
CN702			E41-2603-05	FLAT CABLE CONNECTOR	
CN704			E41-2948-05	PIN ASSY	X1M1M2
CN704			E41-2948-05	PIN ASSY	C1
J400		*	E68-0832-05	JACK(OTHERS)	
W700		*	E30-8202-05	CORD WITH CONNECTOR (USB)	KK1K2
W700		*	E30-8202-05	CORD WITH CONNECTOR (USB)	R1E1E2
W700		*	E30-8202-05	CORD WITH CONNECTOR (USB)	Q1K3
L100-103			L92-0373-05	CHIP FERRITE	
L105-107			L92-0373-05	CHIP FERRITE	
L109,110			L92-0373-05	CHIP FERRITE	
L112-114			L92-0373-05	CHIP FERRITE	
L120			L92-0373-05	CHIP FERRITE	
L500-502			L92-0373-05	CHIP FERRITE	
L510			L92-0373-05	CHIP FERRITE	
L700			L92-0641-05	FERRITE CORE	X1M1M2
L700			L92-0641-05	FERRITE CORE	C1
L700,701			L92-0641-05	FERRITE CORE	KK1K2
L700,701			L92-0641-05	FERRITE CORE	R1E1E2
L700,701			L92-0641-05	FERRITE CORE	Q1K3
L705			L92-0373-05	CHIP FERRITE	
L707			L92-0373-05	CHIP FERRITE	
L710-712			L92-0373-05	CHIP FERRITE	
X100			L77-3846-05	CRYSTAL RESONATOR(12MHZ)	
X700		*	L77-3849-05	CRYSTAL RESONATOR(32MHZ)	
CP100-105			RK74HB1J220J	CHIP-COM 22 J 1/16W	
CP400-407			RK74HB1J220J	CHIP-COM 22 J 1/16W	
CP700			RK74HB1J103J	CHIP-COM 10K J 1/16W	
CP701			RK74HB1J473J	CHIP-COM 47K J 1/16W	
CP702,703			RK74HB1J220J	CHIP-COM 22 J 1/16W	
CP705			RK74HB1J220J	CHIP-COM 22 J 1/16W	
CP706			RK74HB1J473J	CHIP-COM 47K J 1/16W	
R1			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R2			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R3			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R6			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R7			RK73HB1J470J	CHIP R 47 J 1/16W	
R8 ,9			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R30			RK73EB2E000J	CHIP R 0.0 J 1/4W	
R100			RK73HB1J223J	CHIP R 22K J 1/16W	
R101			RK73HB1J220J	CHIP R 22 J 1/16W	
R102			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R104			RK73HB1J152J	CHIP R 1.5K J 1/16W	
R106			RK73HB1J223J	CHIP R 22K J 1/16W	
R107			RK73HH1J44R2D	CHIP R 44.2 D 1/16W	
R108			RK73HB1J472J	CHIP R 4.7K J 1/16W	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

⚠ indicates safety critical components.

PARTS LIST

DIGITAL I/O UNIT (X88-2080-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R116-120			RK73HB1J220J	CHIP R 22 J 1/16W	
R122			RK73HB1J220J	CHIP R 22 J 1/16W	
R123			RK73HB1J103J	CHIP R 10K J 1/16W	
R124			RK73HB1J101J	CHIP R 100 J 1/16W	
R126			RK73HB1J220J	CHIP R 22 J 1/16W	
R128			RK73HB1J220J	CHIP R 22 J 1/16W	
R130			RK73HB1J223J	CHIP R 22K J 1/16W	
R131,132			RK73HB1J220J	CHIP R 22 J 1/16W	
R134			RK73HB1J103J	CHIP R 10K J 1/16W	
R135			RK73HH1J122D	CHIP R 1.2K D 1/16W	
R139			RK73HB1J223J	CHIP R 22K J 1/16W	
R142,143			RK73HB1J220J	CHIP R 22 J 1/16W	
R145,146			RK73HB1J220J	CHIP R 22 J 1/16W	
R147			RK73HB1J223J	CHIP R 22K J 1/16W	
R148,149			RK73HB1J220J	CHIP R 22 J 1/16W	
R151			RK73HB1J470J	CHIP R 47 J 1/16W	
R153			RK73HB1J220J	CHIP R 22 J 1/16W	
R154			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R155			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R156			RK73HB1J220J	CHIP R 22 J 1/16W	
R158			RK73HB1J220J	CHIP R 22 J 1/16W	
R160			RK73HB1J220J	CHIP R 22 J 1/16W	
R162,163			RK73HB1J220J	CHIP R 22 J 1/16W	
R164			RK73HB1J223J	CHIP R 22K J 1/16W	
R166-169			RK73HB1J220J	CHIP R 22 J 1/16W	
R172-176			RK73HB1J220J	CHIP R 22 J 1/16W	
R177			RK73HB1J473J	CHIP R 47K J 1/16W	
R179			RK73HB1J220J	CHIP R 22 J 1/16W	
R181			RK73HB1J101J	CHIP R 100 J 1/16W	
R182			RK73HB1J220J	CHIP R 22 J 1/16W	
R183			RK73HB1J103J	CHIP R 10K J 1/16W	
R184			RK73HB1J220J	CHIP R 22 J 1/16W	
R186			RK73HB1J473J	CHIP R 47K J 1/16W	
R188-190			RK73HB1J220J	CHIP R 22 J 1/16W	
R191			RK73HB1J223J	CHIP R 22K J 1/16W	
R194,195			RK73HB1J220J	CHIP R 22 J 1/16W	
R196			RK73HB1J223J	CHIP R 22K J 1/16W	
R197,198			RK73HB1J220J	CHIP R 22 J 1/16W	
R199			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R201			RK73HB1J223J	CHIP R 22K J 1/16W	
R202			RK73HB1J220J	CHIP R 22 J 1/16W	
R204			RK73HB1J101J	CHIP R 100 J 1/16W	
R206			RK73HB1J223J	CHIP R 22K J 1/16W	
R207			RK73HB1J220J	CHIP R 22 J 1/16W	
R210			RK73HB1J220J	CHIP R 22 J 1/16W	
R212,213			RK73HB1J101J	CHIP R 100 J 1/16W	
R215,216			RK73HB1J101J	CHIP R 100 J 1/16W	
R220			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R221			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R222-224			RK73HB1J223J	CHIP R 22K J 1/16W	
R225			RK73HB1J301J	CHIP R 300 J 1/16W	
R250-256			RK73HB1J220J	CHIP R 22 J 1/16W	
R257			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R258			RK73HB1J220J	CHIP R 22 J 1/16W	
R259			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R260			RK73HB1J223J	CHIP R 22K J 1/16W	
R261-263			RK73HB1J220J	CHIP R 22 J 1/16W	
R264			RK73HB1J101J	CHIP R 100 J 1/16W	
R265-267			RK73HB1J220J	CHIP R 22 J 1/16W	
R275,276			RK73HB1J223J	CHIP R 22K J 1/16W	
R278,279			RK73HB1J220J	CHIP R 22 J 1/16W	
R280			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R281,282			RK73HB1J223J	CHIP R 22K J 1/16W	
R283			RK73HB1J220J	CHIP R 22 J 1/16W	
R300			RK73HB1J220J	CHIP R 22 J 1/16W	
R400-411			RK73HB1J220J	CHIP R 22 J 1/16W	
R412			RK73HB1J223J	CHIP R 22K J 1/16W	
R413-422			RK73HB1J220J	CHIP R 22 J 1/16W	
R423			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R424-430			RK73HB1J220J	CHIP R 22 J 1/16W	
R431			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R432			RK73HB1J220J	CHIP R 22 J 1/16W	
R433,434			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R436-439			RK73HB1J220J	CHIP R 22 J 1/16W	
R445,446			RK73HH1J103D	CHIP R 10K D 1/16W	
R500,501			RK73HH1J103D	CHIP R 10K D 1/16W	
R502,503			RK73HB1J301J	CHIP R 300 J 1/16W	
R704			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R712,713			RK73HB1J223J	CHIP R 22K J 1/16W	
R716			RK73GH2A362D	CHIP R 3.6K D 1/10W	
R718,719			RK73HB1J223J	CHIP R 22K J 1/16W	
R720			RK73GH2A201D	CHIP R 200 D 1/10W	
R723			RK73HH1J750D	CHIP R 75 D 1/16W	
R724,725			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R726			RK73HH1J750D	CHIP R 75 D 1/16W	
R731			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R733			RK73HH1J750D	CHIP R 75 D 1/16W	
R735			RK73HB1J100J	CHIP R 10 J 1/16W	
R736			RK73HH1J430D	CHIP R 43 D 1/16W	
R746			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R752,753			RK73HB1J473J	CHIP R 47K J 1/16W	
R755			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R756			RK73HB1J101J	CHIP R 100 J 1/16W	
R759			RK73HB1J122J	CHIP R 1.2K J 1/16W	
R760			RK73HB1J111J	CHIP R 110 J 1/16W	
R761			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R763			RK73HB1J220J	CHIP R 22 J 1/16W	
R770-773			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R781			RK73HB1J223J	CHIP R 22K J 1/16W	
R784-787			RK73HB1J000J	CHIP R 0.0 J 1/16W	X1M1M2
R784-787			RK73HB1J000J	CHIP R 0.0 J 1/16W	C1
R786,787			RK73HB1J000J	CHIP R 0.0 J 1/16W	KK1K2
R786,787			RK73HB1J000J	CHIP R 0.0 J 1/16W	R1E1E2
R786,787			RK73HB1J000J	CHIP R 0.0 J 1/16W	Q1K3
R788,789			RK73HB1J220J	CHIP R 22 J 1/16W	
R790,791			RK73HB1J103J	CHIP R 10K J 1/16W	
R792			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R793-795			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R798,799			RK73HB1J220J	CHIP R 22 J 1/16W	
R800-802			RK73GB2A000J	CHIP R 0.0 J 1/10W	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

indicates safety critical components.

PARTS LIST

The IC103,402, 403, 500 and IC501 in the DIGITAL I/O UNIT (X88-2080-xx) are not replaceable components. When these ICs are defective, replace the whole DIGITAL I/O UNIT (X88-2080-xx)

DIGITAL I/O UNIT (X88-2080-xx)

Ref.No.	Add	New	Parts No.	Description	Destination
R803			RK73HB1J100J	CHIP R 10 J 1/16W	
R804			RK73HB1J473J	CHIP R 47K J 1/16W	
R806-808			RK73GB2A000J	CHIP R 0.0 J 1/10W	
R811			RK73GB2A152J	CHIP R 1.5K J 1/10W	
R812			RK73FB2B151J	CHIP R 150 J 1/8W	
IC103		*	-	MICROPROCESSOR IC	
IC402,403		*	-	DRAM IC	
IC500,501		*	-	DRAM IC	
IC704			THS8136IPHPR	MOS-IC	
IC705			TC7SG86FU-F	MOS-IC	
IC706		*	W05-1700-00	ROM IC	
IC707			TC7SG04FU-F	MOS-IC	
IC708			XC6215B182NR	ANALOGUE IC	
IC714		*	ML86V8202T03	MOS-IC	

VD MECHANISM ASSY (X92-6640-00) (DVS-8710W)

Ref.No.	Add	New	Parts No.	Description	Destination
1	1A		A10-5523-11+	CHASSIS	
2	2B		A10-5543-01	CHASSIS	
3	1A		A10-5535-01	CHASSIS	
4	3A		A10-5534-12	CHASSIS	
7	1B		D10-7080-02	ARM	
8	1B		D10-7081-02	ARM	
9	1B		D10-7082-02	LEVER	
10	1B		D10-7083-02	LEVER	
12	2B		D10-7084-02+	SLIDER	
13	2A		D10-7100-02	ARM	
14	2B		D10-7086-03+	ARM	
15	2B		D10-7087-02	ARM	
25	2B		D10-7092-04+	SLIDER ASSY	
27	2A		D10-7091-04	LEVER	
28	2B		D12-0640-02+	CAM	
31	2B		D13-3029-04	GEAR	
32	2B		D13-3030-04	GEAR	
33	2B		D13-3031-04	GEAR	
34	2B		D13-3032-04	GEAR	
35	2B		D13-3033-04	GEAR	
36	2B		D13-3034-04	GEAR	
40	2A		D13-3038-04	GEAR	
41	2A		D13-3039-04	GEAR	
42	2A		D13-3040-04	GEAR	
43	1B	*	D14-1034-04	ROLLER	
53	1B		D21-2487-24+	SHAFT	
54	2A		D39-0275-05	DAMPER	
55	2A		D39-0276-05	DAMPER	
60	3A		F09-3037-03	SHEET	
65	2B		G01-4734-04	EXTENSION SPRING	
66	1B		G01-4735-14	EXTENSION SPRING	
67	2A		G01-3300-14+	TORSION COIL SPRING	
68	2B		G01-4737-14	EXTENSION SPRING	
69	1B		G01-4602-14+	EXTENSION SPRING	
70	1B		G01-4740-04	TORSION COIL SPRING	
74	2B		G01-4609-24+	TORSION COIL SPRING	
75	1B		G02-1904-03+	FLAT SPRING	
79	2A		J22-0898-01	MOUNTING HARDWARE	
80	3B		J22-0891-11+	MOUNTING HARDWARE	
A	1A		N09-6815-05	MACHINE SCREW (M1.7X2.0)	
B	3B		N09-6408-15	TAPTITE SCREW (1.7X4.0 PT)	
C	1B		N09-6426-15	MACHINE SCREW (LOAD ARM SCREW	
D	3A		N09-6104-05	MACHINE SCREW (2X10 ST)	
93	2A		T99-0471-05	MAGNET	
96	1B		X94-2080-00	ROLLER ASSY	
98	2A		X94-2120-00	TRAVERSE ASSY (PICKUP,SPINDLE)	
VM1	2A		X94-2070-00	MOTOR ASSY (LOADING)	

K: DNX6980 **K1**: DNX6180 **K2**: DNX6040EX **K3**: DDX5180 (North America)
E1: DNX5280BT **E2**: DNX4280BT (Europe) **Q1**: DNX5580BT (Russian)
R1: DNX6480BT (Latin America) **X1**: DNX5380BT (Australia)
C1: DNX5380 (China) **M1**: DNX5380 M2: DNX5380M (Other Areas)

indicates safety critical components.