9. EXPLODED VIEWS AND PARTS LIST

NOTES : • *Parts marked by " * " are generally unavailable because they are not in our Master Spare Parts List.*
• *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
• *Screw adjacent to▽ mark on the product are used for disassembly.*
• *For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions,apply as you think it appropriate.)*

9.1 PACKINGE



PACKING SECTION PARTS LIST

Mark	No.	Description	SPH-DA01/XZUC	SPH-DA01/XZEW5
	1	Screw	121100020113-FY	Not used
	2	Cable(GPS)	124845000126-FY	124845000126-FY
	3	Polyethylene Bag	127060000023-FY	127060000023-FY
	4	Cable(iPhone cable)	841CE6666NPL000-FY	841CE6666NPL000-FY
	5	Polyethylene Bag	127060000353-FY	127060000353-FY
	6	Panel	Not used	141270300453018-FY
	7	Cable(Microphone)	123835000414-FY	123835000414-FY
	8	Cord(EW5: Power cord)	Not used	123840000062-FY
	9	Cord(UC: Speaker cable)	143830000544-FY	Not used
	10	Cord(UC: Power cord)	123840000061-FY	Not used
	11	Polyethylene Bag	127060000088-FY	127060000088-FY
	12	Screw	121100030117-FY	121100030117-FY
	13	Bush	Not used	121050000008-FY
	14	Screw	Not used	121100040089-FY
	15	Protector	127015000222-FY	127015000222-FY
	16	Packing Cover	121455000095-FY	121455000095-FY
	17	Packing Cover	127045000307-FY	127045000307-FY
	18	Polyethylene Bag	127060000283-FY	127060000283-FY
	19	Pad	121405000228-FY	Not used
	20	Sub Unit Box	127005000086-FY	127005000086-FY
	21	Unit Box	127020012585-FY	127020012584-FY
	22	QS Guide(UC: en, fr)	127075023312-FY	Not used
	23	QS Guide(EW5: it, es)	Not used	127075023370-FY
	24	QS Guide(EW5: de, ul)	Not used	127075023371-FY
	25	QS Guide(EW5: ru)	Not used	127075023372-FY
	26	Owner's Manual (UC: Important Information)	127075003311-FY	Not used
	27	Installation Manual(UC)	127070017847-FY	Not used
*	28	Caution Card(UC)	127070007635-FY	Not used
*	29	Registration Card(UC)	127070007826-FY	Not used
	30	Packing Cover	121490000721-FY	121490000721-FY
	31	Cable(Output cable)	123830001253-FY	123830001253-FY
	32	Cord(Control line 1/3)	143835000637-FY	143835000637-FY
	33	Cord(Control line 2/3)	123835000786-FY	123835000786-FY
	34	Socket(Control line 3/3)	123805000215-FY	123805000215-FY
	35	Cushion(GND sheet)	121405000232-FY	121405000232-FY
	36	Screw	Not used	121100020113-FY
	37	Polyethylene Bag	127060000353-FY	Not used
	38	Polyethylene Bag	Not used	127060000353-FY
	39	QS Guide(EW5: en, fr)	Not used	127075023369-FY
	40	Owner's Manual (EW5: Important Information)	Not used	127075003310-FY
	41	Installation Manual(EW5)	Not used	127070007920-FY
*	42	Caution Card(EW5)	Not used	127070007828-FY

AppRadio Operation manual

Part No.	Language
CRB3762	English
CRB3763	French
CRB3764	Italian
CRB3765	Spanish(Espanol)
CRB3766	German
CRB3767	Dutch
CRB3768	Russian
CRB3769	English(UC)
CRB3770	French(UC)

Above operation manuals are arailable on the WEB.

9.2 EXTERIOR (1)



EXTERIOR (1) SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	Tape	121445000134-FY
	2	LCD	143420000085-FY
	3	Panel	141210301295018-FY
	4	Panel	141270500447014-FY
	5	DS Tape	121445010235-FY
	6	DS Tape	121445000233-FY
	7	DS Tape	121445010234-FY
	8	Touch Panel	CSX1175
	9	Screw	121045000007-FY
	10	Micro SD Unit	842CE6666NSD002-FY
	11	FFC	143820000298-FY
	12	Grille	141210301296018-FY
	13	Button	141230303064018-FY
	14	Button	141230303065018-FY
	15	Door	141290302296018-FY
	16	KEY Unit	842CE6666NKB003-FY
	17	Spacer	121405000217-FY
	18	FFC	143820000280-FY
	19	Holder	121240001100000-FY
	20	Screw	121103050001-FY
	21	TFT Unit(EW5)	843CE6666NTFT004E-FY
		TFT Unit(UC)	843CE6666NTFT004U-FY
	22	Holder	141000002767-FY
	23	Cushion	121405000208-FY
	24	FFC	143820000450-FY
	25	Tape	121445000133-FY
	26	Cable(Output cable)	123830001253-FY
	27	Cord(Control line 1/3)	143835000637-FY
	28	Cord(Control line 2/3)	123835000786-FY
	29	Socket(Control line 3/3)	123805000215-FY
	30	Cushion	121405000082-FY
	31	Cushion	121405000229-FY

9.3 EXTERIOR (2)



(1) EXTERIOR (2) SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	Case	141000032052-FY
	2	Insulator	121490000672-FY
	3	Chassis	141000002442-FY
	4	Insulator	121415000082-FY
	5	Insulator	121460000457-FY
	6	Heat Sink	141010000339-FY
	7	Screw	121104070008-FY
	8	Screw	121100050080-FY
	9	Screw	121100070093-FY
	10	Bracket	See Contrast table (2)
	11	Screw	See Contrast table (2)
	12	Screw	121040000222-FY
	13	Holder	See Contrast table (2)
	14	Case	141000002903-FY
	15	Holder	121000012439-FY
	16	Tape	121445000134-FY
	17	Main Unit	See Contrast table (2)
⚠	18	Fuse(15 A)	144800000051-FY
	19	IC	142400000701-FY
	20	Insulator	121450000185-FY
	21	Screw	See Contrast table (2)

(2) CONTRAST TABLE

SPH-DA01/XZUC and SPH-DA01/XZEW5 are constructed the same except for the following:

Mark	No.	Description	SPH-DA01/XZUC	SPH-DA01/XZEW5
	10	Bracket	Not used	121000011978-FY
	11	Screw	Not used	121100020113-FY
	13	Holder	Not used	121000031220-FY
	17	Main Unit	843CE6666NMB004U-FY	843CE6666NMB004E-FY
	21	Screw	Not used	121040000222-FY