2. EXPLODED VIEWS AND PARTS LIST

NOTES:
- *Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.*
- *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*
- *Screws adjacent to ▼ mark on product are used for disassembly.*
- *For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)*

2.1 EXTERIOR SECTION



• EXTERIOR SECTION PARTS LIST

Mark	No.	Description	Part No.	Remarks
	1	Speaker Unit	02.S7000001	×1
	2	Input Unit	02.G0900032	×1
	3	Amp Unit	02.G1900015	×1
	4	Case	01.P0203300	×1
	5	Case Assy	03.PART0166	×1
	6	Cushion	01.P0500564	×1
	7	Cushion	01.P0500565	×1
	8	Cushion (Tube)	01.P0500566	×1
	9	Absorbent	01.P2600120	×1
	10	Screw	01.E8200367-1	×6
	11	Screw	01.E8200540	×4
	12	Screw	01.E8200805	×12

2.2 ACCESSORIES and PACKING SECTION

• ACCESSORIES SECTION PARTS LIST

Mark	No.	Description	Part No.	Remarks
	1	Bracket	01.E6600012	×2
	2	Bracket	01.E6600013	×2
	3	Screw (ϕ5 mm × 14 mm)	01.E8200744	×2
	4	Screw (M5 mm × 25 mm)	01.E8200878	×2
	5	Wire Assy (2.5 m)	01.45-18251-802	×1
	6	Nut	01.E8300042	×2
	7	Cushion	01.P0500563	×4
		Operating Instructions	01.E91B1323	×1
NSP		Warranty (For XCNEL)	CRY1376	×1
NSP		Warranty (For XCNUC)	QRY3001	×1

• PACKING SECTION PARTS LIST

Mark	No.	Description	Part No.	Remarks
		Box Gift	01.E9171554	×1
		Cushion Snow	01.E9130476	×1
		Cushion Snow	01.E9130477	×1

• ACCESSORIES

Caution : The Enclosed Alphanumerics of the below illust are the same as that written in the "Installation procedure" of Operating Instructions.