EXPLODED VIEW



A	ϕ2x8	: N09-4460-05
B	M1.7x8.5	: N09-4472-05
C	M1.7x2.5	: N09-6004-05
D	ϕ2x3.5	: N09-6006-05
E	M2x2	: N09-6007-05
F	ϕ2x6(BLK)	: N09-6051-05
G	1.6 WASHER	: N19-2163-04
H	M2x2	: N39-2020-46

Parts with the exploded numbers larger than 700 are not supplied.

EXPLODED VIEW



A M3x8 : N30-3008-46
B ϕ2x6 : N80-2006-46
C ϕ2x8 (BLK) : N80-2008-45
D ϕ3x5 : N83-3005-46
E ϕ3x10 : N80-3010-46
F ϕ3x20 : N83-3020-46
G ϕ2.6x6 : N86-2606-46
H ϕ1.5 RING : N29-0205-04

※Depends on the modle. Refer to the parts list.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
KDC-2019/2019V/2020/217/217S/219/29MR/3020/4020					
201	1A		A02-1486-13	PLASTIC CABINET ASSY	
203	1A		A22-2863-03	SUB PANEL ASSY	
205	2A	✻	A46-1750-01	REAR COVER	
206	1B	✻	A52-0804-02	TOP PLATE	
PA1	3A	✻	A64-2544-02	PANEL ASSY	K
PA1	3A	✻	A64-2545-02	PANEL ASSY	K2
PA1	3A	✻	A64-2546-02	PANEL ASSY	K3
PA1	3A	✻	A64-2547-02	PANEL ASSY	M
PA1	3A	✻	A64-2548-02	PANEL ASSY	M1
PA1	3A	✻	A64-2566-02	PANEL ASSY	K4
PA1	3A	✻	A64-2680-02	PANEL ASSY	M3
PA1	3A	✻	A64-2695-02	PANEL ASSY	K5
PA1	3A	✻	A64-2711-02	PANEL ASSY	K1
RM1	1A		A70-2024-05	REMOTE CONTROLLER ASSY (RC-400)	KK1K2
RM1	1A		A70-2024-05	REMOTE CONTROLLER ASSY (RC-400)	M1
210	3B		B07-3054-02	ESCUTCHEON (GRAY)	KK1K2
210	3B		B07-3054-02	ESCUTCHEON (GRAY)	K4K5M
210	3B		B07-3055-02	ESCUTCHEON (SILVER)	K3M1M3
211	3A	✻	B10-4132-01	FRONT GLASS	K
211	3A	✻	B10-4133-01	FRONT GLASS	K2
211	3A	✻	B10-4134-01	FRONT GLASS	K3
211	3A	✻	B10-4135-01	FRONT GLASS	M
211	3A	✻	B10-4136-01	FRONT GLASS	M1
211	3A	✻	B10-4143-01	FRONT GLASS	K1
211	3A	✻	B10-4231-01	FRONT GLASS	K5
211	3A	✻	B10-4234-01	FRONT GLASS	M3
211	3A	✻	B10-4244-01	FRONT GLASS	K4
-			B46-0100-50	WARRANTY CARD	
-			B46-0606-04	ID CARD	
-			B58-1344-04	CAUTION CARD	KK1K2
-			B58-1344-04	CAUTION CARD	K4K5
-			B58-1365-04	CAUTION CARD	
-		✻	B64-2114-00	INST.MANUAL (ENG.FRE.SPA.POR.)	KK1K2
-		✻	B64-2114-00	INST.MANUAL (ENG.FRE.SPA.POR.)	K3K4K5
-		✻	B64-2115-00	INST.MANUAL (ENGLISH,T-CHINESE)	MM1M3
-		✻	B64-2116-00	INSTRUCTION MANUAL (ARABIC)	MM1M3
213	1A		D10-4446-03	LEVER	
214	2A		D10-4447-03	LEVER	
215	1A		D10-4589-04	LEVER	
216	1A		D21-2329-04	SHAFT	
218	2A	✻	E29-1872-02	CONDUCTIVE RUBBER	
220	2B		E30-4801-05	CORD WITH PINPLUG	K1K2M1
⚠ DC1	1A		E30-4783-05	DC CORD	KK1K2
⚠ DC1	1A		E30-4783-05	DC CORD	K3K4K5
⚠ DC1	1A		E30-4784-05	DC CORD	MM1M3
FC1	2A		E39-0343-05	FLAT CABLE	
223	1B		F29-0049-05	INSULATING COVER	K1K2M1
⚠ F1	2B		F52-0006-05	FUSE (MINI BLADE TYPE) 10A	
224	1A		G01-2987-04	TORSION COIL SPRING	
225	1A		G01-3096-04	EXTENSION SPRING	
226	3A	✻	G01-3149-04	COMPRESSION SPRING	

Ref. No.	Add	New	Parts No.	Description	Destination
-		✻	H10-4801-02	POLYSTYRENE FOAMED FIXTURE	
-			H25-0329-04	PROTECTION BAG (280X450X0.03)	
-			H25-0337-04	PROTECTION BAG (180X300X0.03)	
-		✻	H54-2271-03	ITEM CARTON CASE	K
-		✻	H54-2272-03	ITEM CARTON CASE	K1
-		✻	H54-2273-03	ITEM CARTON CASE	K2
-		✻	H54-2274-03	ITEM CARTON CASE	K3
-		✻	H54-2275-03	ITEM CARTON CASE	M
-		✻	H54-2276-03	ITEM CARTON CASE	M1
-		✻	H54-2314-03	ITEM CARTON CASE	K5
-		✻	H54-2381-03	ITEM CARTON CASE	M3
-		✻	H54-2396-03	ITEM CARTON CASE	K4
229	1A		J21-9641-13	MOUNTING HARDWARE ASSY	
230	1A		J54-0606-04	STAY	MM1M3
232	3A	✻	K24-3822-04	KNOB (RELEASE)	
233	3A	✻	K24-3823-04	KNOB (SRC)	
234	3A	✻	K24-3824-04	KNOB (AUD)	
235	3A	✻	K24-3825-03	KNOB (VOL)	
236	3A	✻	K24-3826-04	KNOB (EJECT)	
237	3A	✻	K25-1396-03	KNOB (PRE1-6,ATT,RESET)	
238	3A	✻	K25-1397-03	KNOB (AUTO,CLK,FM,AM)	
240	1A		N99-1610-15	SCREW SET	KK1K2
240	1A		N99-1610-15	SCREW SET	K4K5M
240	1A		N99-1610-15	SCREW SET	M1M3
241	1A		N99-1719-05	SCREW SET	
A	3B		N30-3008-46	PAN HEAD MACHINE SCREW	
B	3A		N80-2006-46	PAN HEAD TAPTITE SCREW	
C	2A		N80-2008-45	PAN HEAD TAPTITE SCREW	
D	1B		N83-3005-46	PAN HEAD TAPTITE SCREW	
H	1A		N29-0205-04	RETAINING RING (1.5œŸ)	
DME1	1B	✻	X92-4030-00	MECHANISM ASSY	
SWITCH UNIT (X16-1460-xx)					
245	2A	✻	B11-1358-04	OPTICAL DIFFUSER	KK2K4
245	2A	✻	B11-1358-04	OPTICAL DIFFUSER	K5MM1
245	2A	✻	B11-1372-04	OPTICAL DIFFUSER	K1K3M3
246	2A	✻	B11-1359-04	REFLECTION SHEET	
247	2A	✻	B11-1360-04	COLOR FILTER	K3
247	2A	✻	B11-1361-04	COLOR FILTER	K1
248	2A	✻	B19-2130-03	LIGHTING BOARD	
D1-13			B30-1533-05	LED (1608,PG)	KK2K3
D1-13			B30-1533-05	LED (1608,PG)	K4K5M
D1-13			B30-1533-05	LED (1608,PG)	M1
D1-13			B30-1567-05	LED (1608,RED)	K1M3
D17,18			B30-1533-05	LED (1608,PG)	K3K4K5
D17,18			B30-1533-05	LED (1608,PG)	M
D17,18			B30-1567-05	LED (1608,RED)	M3
D17,18		✻	B30-1642-05	LED	KK1K2
D17,18		✻	B30-1642-05	LED	M1
D19			B30-1633-05	LED (WHITE)	KK1K2
D19			B30-1633-05	LED (WHITE)	K3K4K5
D19			B30-1633-05	LED (WHITE)	MM1
D19			B30-1641-05	LED	M3

K : KDC-219 **K3** : KDC-29MR **M** : KDC-2020
K1 : KDC-2019V **K4** : KDC-217 **M1** : KDC-4020
K2 : KDC-2019 **K5** : KDC-217S **M3** : KDC-3020

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
D20			B30-1533-05	LED (1608,PG)	KK2K3
D20			B30-1533-05	LED (1608,PG)	K4K5M
D20			B30-1533-05	LED (1608,PG)	M1
D20			B30-1567-05	LED (1608,RED)	K1M3
ED1		✻	B38-1080-05	LIQUID CRYSTAL	KK2K4
ED1		✻	B38-1080-05	LIQUID CRYSTAL	K5MM1
ED1		✻	B38-1081-05	LIQUID CRYSTAL	K1K3M3
C1			CK73GB1H102K	CHIP C 1000PF K	
C2,3			CK73GB1E473K	CHIP C 0.047UF K	
C2,3			CK73GB1H473K	CHIP C 0.047UF K	
C4			CK73GB1H103K	CHIP C 0.010UF K	
C5			CK73FB1A225K	CHIP C 2.2UF K	KK1K2
C5			CK73FB1A225K	CHIP C 2.2UF K	K3MM1
C5			CK73FB1A225K	CHIP C 2.2UF K	M3
C6,7			CK73GB1H103K	CHIP C 0.010UF K	KK1K2
C6,7			CK73GB1H103K	CHIP C 0.010UF K	M1
C9			CK73GB1H103K	CHIP C 0.010UFK	
249	2A		E29-1829-04	CONDUCTIVE RUBBER	
250	2A		E29-1834-04	CONDUCTIVE RUBBER	
J1			E59-0828-05	RECTANGULAR PLUG	
-			J19-5130-04	HOLDER (LED)	
R2-4			RK73GB2A471J	CHIP R 470 J 1/10W	
R5			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R7			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R8			RK73GB2A563J	CHIP R 56K J 1/10W	
R10			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R12			RK73GB2A102J	CHIP R 1.0K J 1/10W	KK1K2
R12			RK73GB2A102J	CHIP R 1.0K J 1/10W	K3MM1
R12			RK73GB2A102J	CHIP R 1.0K J 1/10W	M3
R13		✻	RK73FB2B470J	CHIP R 47 J 1/8W	KK1K2
R13		✻	RK73FB2B470J	CHIP R 47 J 1/8W	K3MM1
R13		✻	RK73FB2B470J	CHIP R 47 J 1/8W	M3
R14,15			RK73FB2B331J	CHIP R 330 J 1/8W	
R16-18			RK73FB2B511J	CHIP R 510 J 1/8W	KK1K2
R16-18			RK73FB2B511J	CHIP R 510 J 1/8W	M1
R16-20			RK73FB2B511J	CHIP R 510 J 1/8W	K3K4K5
R16-20			RK73FB2B511J	CHIP R 510 J 1/8W	MM3
R19,20		✻	RK73FB2B391J	CHIP R 390 J 1/8W	KK1K2
R19,20		✻	RK73FB2B391J	CHIP R 390 J 1/8W	M1
R21,22			RK73FB2B221J	CHIP R 220 J 1/8W	
D22			MA3062WA	ZENER DIODE	
IC1			LC75853NE	MOS-IC	
IC2			RS-171	ANALOGUE IC	KK1K2
IC2			RS-171	ANALOGUE IC	K3MM1
IC2			RS-171	ANALOGUE IC	M3
Q1			DTA114EUA	DIGITAL TRANSISTOR	
Q1			UN5111	DIGITAL TRANSISTOR	

ELECTRIC UNIT (X25-9120-xx)

D102			B30-1567-05	LED (1608,RED)	
C1			C90-5242-05	ELECTRO 3300UF 16WV	
C21			CK73GB1H103K	CHIP C 0.010UF K	
C40			CK73GB1H103K	CHIP C 0.010UF K	

SWITCH UNIT (X16-1460-xx)

Ref. No.	Add	New	Parts No.	Description	Destination
C50			CE04NW1E100M	ELECTRO 10UF 25WV	KK1K2
C50			CE04NW1E100M	ELECTRO 10UF 25WV	K3K4K5
C50,51			CE04NW1E100M	ELECTRO 10UF 25WV	MM1M3
C52-54			CE04NW1C100M	ELECTRO 10UF 16WV	
C55			CE04NW1E100M	ELECTRO 10UF 25WV	
C56			CE04CW1H100M	ELECTRO 10UF 50WV	
C57			C90-2980-05	ELECTRO 220UF 16WV	
C58			C90-2962-05	ELECTRO 100UF 16WV	
C63			CE04NW1C220M	ELECTRO 22UF 16WV	
C101			CE04NW0J101M	ELECTRO 100UF 6.3WV	
C102			CK73GB1H103K	CHIP C 0.010UF K	
C103			CK73GB1C104K	CHIP C 0.10UF K	
C103			CK73GB1H104K	CHIP C 0.10UF K	
C104,105			CC73GCH1H150J	CHIP C 15PF J	
C106			CK73GB1H472K	CHIP C 4700PF K	
C142			CK73GB1C104K	CHIP C 0.10UF K	
C142			CK73GB1H104K	CHIP C 0.10UF K	
C201			CE04NW1A470M	ELECTRO 47UF 10WV	
C202			CK73GB1H103K	CHIP C 0.010UF K	
C203-205			CE04NW1H2R2M	ELECTRO 2.2UF 50WV	
C206			CK73GB1H153K	CHIP C 0.015UF K	
C207			CK73GB1A474K	CHIP C 0.47UF K	
C208,209			CK73GB1C104K	CHIP C 0.10UF K	
C208,209			CK73GB1H104K	CHIP C 0.10UF K	
C210			CK73GB1E333K	CHIP C 0.033UF K	
C210			CK73GB1H333K	CHIP C 0.033UF K	
C211			CC73GCH1H151J	CHIP C 150PF J	
C221-224			C90-2597-05	ELECTRO 10UF 16WV	K1K2M1
C223,224			C90-2597-05	ELECTRO 10UF 16WV	KK3K4
C223,224			C90-2597-05	ELECTRO 10UF 16WV	K5MM3
C225			CK73GB1H103K	CHIP C 0.010UF K	KK3K4
C225			CK73GB1H103K	CHIP C 0.010UF K	K5MM3
C225,226			CK73GB1H103K	CHIP C 0.010UF K	K1K2M1
C251-254			C90-5296-05	NP-ELECT 0.22UF 50WV	
C255			CE04NW1H010M	ELECTRO 1.0UF 50WV	
C256			CE04NW1A101M	ELECTRO 100UF 10WV	K3K4K5
C256			CE04NW1A330M	ELECTRO 33UF 10WV	KK1K2M
C256			CE04NW1A330M	ELECTRO 33UF 10WV	M1M3
C257			CE04NW1H010M	ELECTRO 1.0UF 50WV	
C258			C90-2935-05	ELECTRO 1.0UF 50WV	
C301			CE04NW1A101M	ELECTRO 100UF 10WV	
C302,303			CK73GB1H103K	CHIP C 0.010UF K	
C304			CE04CW1A101M	ELECTRO 100UF 10WV	
C305			CK73GB1H103K	CHIP C 0.010UF K	
C306			C90-2594-05	ELECTRO 10UF 10WV	
C307			CK73GB1H103K	CHIP C 0.010UF K	
C309			CK73GB1H103K	CHIP C 0.010UF K	
C401,402			C90-2608-05	ELECTRO 1.0UF 50WV	KK1K2
C401,402			C90-2608-05	ELECTRO 1.0UF 50WV	K3MM1
C401,402			C90-2608-05	ELECTRO 1.0UF 50WV	M3
C403			CE04CW1A101M	ELECTRO 100UF 10WV	KK1K2
C403			CE04CW1A101M	ELECTRO 100UF 10WV	K3MM1
C403			CE04CW1A101M	ELECTRO 100UF 10WV	M3
C404			CK73GB1H103K	CHIP C 0.010UF K	KK1K2
C404			CK73GB1H103K	CHIP C 0.010UF K	K3MM1

K : KDC-219 **K3** : KDC-29MR **M** : KDC-2020
K1 : KDC-2019V **K4** : KDC-217 **M1** : KDC-4020
K2 : KDC-2019 **K5** : KDC-217S **M3** : KDC-3020

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X25-9120-xx)

Ref. No.	Add	New	Parts No.	Description	Destination
C404			CK73GB1H103K	CHIP C 0.010UF K	M3
CN1			E40-9550-05	FLAT CABLE CONNECTOR	
CN2			E40-3238-05	PIN ASSY	K1K2M1
CN3			E40-3246-05	PIN ASSY	K3
J1			E04-0312-05	RF COAXIAL CABLE RECEPTACLE	
⚠ J2			E58-0863-15	RECTANGULAR RECEPTACLE	
J3			E58-0879-05	RECTANGULAR RECEPTACLE	
J4			E56-0834-05	CYLINDRICAL RECEPTACLE	KK1K2
J4			E56-0834-05	CYLINDRICAL RECEPTACLE	K3MM1
J4			E56-0834-05	CYLINDRICAL RECEPTACLE	M3
J5			E63-0852-05	PIN JACK	
L1			L33-1170-05	CHOKE COIL ASSY	
L2			L33-1807-05	CHOKE COIL	
L4			L33-1123-05	LINE FILTER COIL	
L101			L40-4795-91	SMALL FIXED INDUCTOR (4.7UH,J)	
L201			L40-4795-91	SMALL FIXED INDUCTOR (4.7UH,J)	
L303-306			L40-4795-91	SMALL FIXED INDUCTOR (4.7UH,J)	
X1			L77-1167-05	CRYSTAL RESONATOR (4.19M)	
D	2B		N83-3005-46	PAN HEAD TAPTITE SCREW	
E	2B		N80-3010-46	PAN HEAD TAPTITE SCREW	
F	2B		N83-3020-46	PAN HEAD TAPTITE SCREW	
G	2B		N86-2606-46	BINDING HEAD TAPTITE SCREW	
CP1			R90-1056-05	MULTIPLE RESISTOR	
CP2			R90-1047-05	MULTIPLE RESISTOR	
CP3			R90-1046-05	MULTIPLE RESISTOR	
R10			RK73FB2B303J	CHIP R 30K J 1/8W	
R11			RK73GB2A103J	CHIP R 10K J 1/10W	
R12			RK73GB2A104J	CHIP R 100K J 1/10W	
R20			RD14DB2H332J	SMALL-RD 3.3K J 1/2W	
R22			RK73GB2A103J	CHIP R 10K J 1/10W	
R23			RK73GB2A104J	CHIP R 100K J 1/10W	
R51			RK73GB2A473J	CHIP R 47K J 1/10W	
R57		✻	RK73FB2B152J	CHIP R 1.5K J 1/8W	
R58			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R67			RK73GB2A103J	CHIP R 10K J 1/10W	
R71			RK73GB2A823J	CHIP R 82K J 1/10W	
R72		✻	RK73GB2A363J	CHIP R 36K J 1/10W	
R73			RK73GB2A104J	CHIP R 100K J 1/10W	
R103,104			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R105			RK73GB2A471J	CHIP R 470 J 1/10W	
R106			RK73GB2A104J	CHIP R 100K J 1/10W	
R107,108			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R110			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R113,114			RK73GB2A473J	CHIP R 47K J 1/10W	
R115			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R116			RK73GB2A103J	CHIP R 10K J 1/10W	
R117			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R118			RK73GB2A103J	CHIP R 10K J 1/10W	
R119			RK73GB2A473J	CHIP R 47K J 1/10W	
R121			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R122			RK73GB2A101J	CHIP R 100 J 1/10W	
R123			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R125			RK73GB2A102J	CHIP R 1.0K J 1/10W	

Ref. No.	Add	New	Parts No.	Description	Destination
R126			RK73GB2A104J	CHIP R 100K J 1/10W	
R127			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R128			RK73GB2A225J	CHIP R 2.2M J 1/10W	
R129,130			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R131			RK73GB2A682J	CHIP R 6.8K J 1/10W	
R132			RK73GB2A223J	CHIP R 22K J 1/10W	
R133			RK73GB2A164J	CHIP R 160K J 1/10W	
R135			RK73GB2A473J	CHIP R 47K J 1/10W	K4K5
R136			RK73GB2A473J	CHIP R 47K J 1/10W	KK1K2
R136			RK73GB2A473J	CHIP R 47K J 1/10W	K3
R136,137			RK73GB2A473J	CHIP R 47K J 1/10W	MM1M3
R138,139			RK73GB2A473J	CHIP R 47K J 1/10W	KK1K2
R138,139			RK73GB2A473J	CHIP R 47K J 1/10W	K3K4K5
R139			RK73GB2A473J	CHIP R 47K J 1/10W	MM1M3
R143			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R144			RK73GB2A104J	CHIP R 100K J 1/10W	
R201			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R202,203			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R221-224			RK73FB2B271J	CHIP R 270 J 1/8W	K1K2M1
R223,224			RK73FB2B271J	CHIP R 270 J 1/8W	KK3K4
R223,224			RK73FB2B271J	CHIP R 270 J 1/8W	K5MM3
R251			RK73GB2A472J	CHIP R 4.7K J 1/10W	K3K4K5
R254			RK73GB2A472J	CHIP R 4.7K J 1/10W	K3K4K5
R255			RK73GB2A333J	CHIP R 33K J 1/10W	
R256			RK73FB2B102J	CHIP R 1.0K J 1/8W	
R257			RK73GB2A362J	CHIP R 3.6K J 1/10W	
R258			RK73GB2A101J	CHIP R 100 J 1/10W	K3K4K5
R258		✻	RK73GB2A221J	CHIP R 220 J 1/10W	KK1K2M
R258		✻	RK73GB2A221J	CHIP R 220 J 1/10W	M1M3
R260			RK73GB2A751J	CHIP R 750 J 1/10W	K3K4K5
R261		✻	RK73GB2A100J	CHIP R 10 J 1/10W	KK1K2M
R261		✻	RK73GB2A100J	CHIP R 10 J 1/10W	M1M3
R261			RK73GB2A431J	CHIP R 430 J 1/10W	K3K4K5
R263			RK73GB2A184J	CHIP R 180K J 1/10W	K3K4K5
R263			RK73GB2A432J	CHIP R 4.3K J 1/10W	KK1K2M
R263			RK73GB2A432J	CHIP R 4.3K J 1/10W	M1M3
R264			RK73GB2A473J	CHIP R 47K J 1/10W	
R412-415			RK73GB2A104J	CHIP R 100K J 1/10W	KK1K2
R412-415			RK73GB2A104J	CHIP R 100K J 1/10W	K3MM1
R412-415			RK73GB2A104J	CHIP R 100K J 1/10W	M3
R415			RK73GB2A104J	CHIP R 100K J 1/10W	K4K5
W150			R92-1252-05	CHIP R 0 OHM J 1/16W	K3
W151			R92-2053-05	CHIP R 0 J 1/8W	
W152			R92-1252-05	CHIP R 0 OHM J 1/16W	
W155			R92-1252-05	CHIP R 0 OHM J 1/16W	
W156,157			R92-2053-05	CHIP R 0 J 1/8W	
W158,159			R92-1252-05	CHIP R 0 OHM J 1/16W	
W160-165			R92-2053-05	CHIP R 0 J 1/8W	
W167-169			R92-1252-05	CHIP R 0 OHM J 1/16W	
W171-174			R92-1252-05	CHIP R 0 OHM J 1/16W	
W176-178			R92-1252-05	CHIP R 0 OHM J 1/16W	KK1K2M
W176-178			R92-1252-05	CHIP R 0 OHM J 1/16W	M1M3
W179			R92-2052-05	CHIP R 0 OHM J 1/10W	
D1			S2V20✻A	DIODE	

K : KDC-219 **K1** : KDC-2019V **K2** : KDC-2019
K3 : KDC-29MR **K4** : KDC-217 **K5** : KDC-217S
M : KDC-2020 **M1** : KDC-4020 **M3** : KDC-3020

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X25-9120-xx)

Ref. No.	Add	New	Parts No.	Description	Destination
D1			1N5393G-M6	DIODE	
D10			MA4068(N)-M	ZENER DIODE	
D11			D1F60	DIODE	MM1M3
D12			AM01Z	DIODE	MM1M3
D12			DSM1SD2	DIODE	MM1M3
D12			ERA15-02	DIODE	MM1M3
D13			D1F60	DIODE	
D14			AM01Z	DIODE	
D14			DSM1SD2	DIODE	
D14			ERA15-02	DIODE	
D20			MA4068(N)-M	ZENER DIODE	
D40			1SS133	DIODE	
D50			1SS133	DIODE	
D51			HZS9A1L	ZENER DIODE	
D51			MA4082(N)-L	ZENER DIODE	
D70			MA4068(N)-M	ZENER DIODE	
D101			1SS133	DIODE	
D103,104			1SS133	DIODE	
D106-108			HZS6C1	ZENER DIODE	
D106-108			MA4062-L	ZENER DIODE	
D110		✻	HZS12A2	ZENER DIODE	
D201,202			MA4068(N)-M	ZENER DIODE	
D251-253			1SS133	DIODE	
D261-263			AM01Z	DIODE	KK1K2M
D261-263			AM01Z	DIODE	M1M3
D261-263			DSM1SD2	DIODE	KK1K2M
D261-263			DSM1SD2	DIODE	M1M3
D261-263			ERA15-02	DIODE	KK1K2M
D261-263			ERA15-02	DIODE	M1M3
D264			D1F60	DIODE	KK1K2M
D264			D1F60	DIODE	M1M3
D264		✻	S1J	DIODE	KK1K2M
D264		✻	S1J	DIODE	M1M3
D265,266			AM01Z	DIODE	KK1K2M
D265,266			AM01Z	DIODE	M1M3
D265,266			DSM1SD2	DIODE	KK1K2M
D265,266			DSM1SD2	DIODE	M1M3
D265,266			ERA15-02	DIODE	KK1K2M
D265,266			ERA15-02	DIODE	M1M3
D267,268			D1F60	DIODE	KK1K2M
D267,268			D1F60	DIODE	M1M3
D267,268		✻	S1J	DIODE	KK1K2M
D267,268		✻	S1J	DIODE	M1M3
D401,402			MA4068(N)-M	ZENER DIODE	KK1K2
D401,402			MA4068(N)-M	ZENER DIODE	K3MM1
D401,402			MA4068(N)-M	ZENER DIODE	M3
D403,404			HZS6C1	ZENER DIODE	KK1K2
D403,404			HZS6C1	ZENER DIODE	K3MM1
D403,404			HZS6C1	ZENER DIODE	M3
D403,404			MA4062-L	ZENER DIODE	KK1K2
D403,404			MA4062-L	ZENER DIODE	K3MM1
D403,404			MA4062-L	ZENER DIODE	M3
D407			HZS6C1	ZENER DIODE	KK1K2
D407			HZS6C1	ZENER DIODE	K3MM1
D407			HZS6C1	ZENER DIODE	M3
D407			MA4062-L	ZENER DIODE	KK1K2
D407			MA4062-L	ZENER DIODE	K3MM1
D407			MA4062-L	ZENER DIODE	M3
D409-411			HZS6C1	ZENER DIODE	KK1K2
D409-411			HZS6C1	ZENER DIODE	K3MM1
D409-411			HZS6C1	ZENER DIODE	M3
D409-411			MA4062-L	ZENER DIODE	KK1K2
D409-411			MA4062-L	ZENER DIODE	K3MM1
D409-411			MA4062-L	ZENER DIODE	M3
IC1		✻	UPD780058GC429	MI-COM IC	KK1K2
IC1		✻	UPD780058GC429	MI-COM IC	K4K5M
IC1		✻	UPD780058GC429	MI-COM IC	M1M3
IC1		✻	UPD780058GC430	MI-COM IC	K3
IC2			TDA7407D	ANALOGUE IC	
IC4			TDA7386	ANALOGUE IC	K3K4K5
IC4		✻	TDA7560	ANALOGUE IC	KK1K2M
IC4		✻	TDA7560	ANALOGUE IC	M1M3
IC7			BA4911-V4	ANALOGUE IC	
IC8			HD74HC27FP	MOS-IC	
IC11			S-80835ANNP	MOS-IC	
IC12			BR24C01AF	MEMORY IC	
IC12			BR24C01AF-W	MEMORY IC	
IC12			M24C01-WMN6T	MEMORY IC	
IC12			S-24C01B	MEMORY IC	
Q10			2SC4081	TRANSISTOR	
Q10			2SD1819A	TRANSISTOR	
Q20			2SC4081	TRANSISTOR	
Q20			2SD1819A	TRANSISTOR	
Q40			DTA124EUA	DIGITAL TRANSISTOR	
Q40			UN5112	DIGITAL TRANSISTOR	
Q50			2SA1036K	TRANSISTOR	
Q51			UMC2N	TRANSISTOR	
Q53			UMC2N	TRANSISTOR	MM1M3
Q55			2SD2375	TRANSISTOR	
Q55			2SD2396	TRANSISTOR	
Q70			2SC4081	TRANSISTOR	
Q70			2SD1819A	TRANSISTOR	
Q101			2SC4081	TRANSISTOR	
Q101			2SD1819A	TRANSISTOR	
Q102			DTA114YUA	DIGITAL TRANSISTOR	
Q102			UN5114	DIGITAL TRANSISTOR	
Q221-224			DTC143TUA	DIGITAL TRANSISTOR	K1K2M1
Q221-224			UN5216	DIGITAL TRANSISTOR	K1K2M1
Q223,224			DTC143TUA	DIGITAL TRANSISTOR	KK3K4
Q223,224			DTC143TUA	DIGITAL TRANSISTOR	K5MM3
Q223,224			UN5216	DIGITAL TRANSISTOR	KK3K4
Q223,224			UN5216	DIGITAL TRANSISTOR	K5MM3
Q251			DTC114YUA	DIGITAL TRANSISTOR	
Q251			UN5214	DIGITAL TRANSISTOR	
TH1			PTH9C42BE471Q	POSITIVE RESISTOR	
A1		✻	X86-3510-11	FRONT-END UNIT	

K : KDC-219
K1 : KDC-2019V
K2 : KDC-2019
K3 : KDC-29MR
K4 : KDC-217
K5 : KDC-217S
M : KDC-2020
M1 : KDC-4020
M3 : KDC-3020

⚠ Indicates safety critical components.

PARTS LIST

＊New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
CD PLAYER UNIT (X32-5170-0x, X32-5190-0x)					
C1,2			CK73GB0J105K	CHIP C 1.0UF K	
C3			CK73FB1A225K	CHIP C 2.2UF K	
C4			C92-0566-05	CHIP-TAN 10UF 6.3WV	
C5			CC73GCH1H150J	CHIP C 15PF J	
C6			CC73GCH1H020C	CHIP C 2.0PF C	
C7			CK73GB1C104K	CHIP C 0.10UF K	
C8			CK73GB0J105K	CHIP C 1.0UF K	
C10			CK73GB1H472K	CHIP C 4700PF K	
C11			CK73GB1H682K	CHIP C 6800PF K	
C12			CK73GB1H332K	CHIP C 3300PF K	
C13			CK73GB1C333K	CHIP C 0.033UF K	
C14			CK73GB1H472K	CHIP C 4700PF K	
C15			CK73GB1E473K	CHIP C 0.047UF K	
C16			CC73GCH1H151J	CHIP C 150PF J	
C17			CK73GB1H472K	CHIP C 4700PF K	
C18			CC73GCH1H221J	CHIP C 220PF J	
C19,20			CK73GB1C104K	CHIP C 0.10UF K	
C21			CK73FB1A225K	CHIP C 2.2UF K	
C23			CK73GB1H102K	CHIP C 1000PF K	
C24			CK73GB1E223K	CHIP C 0.022UF K	
C25			CK73GB1H153K	CHIP C 0.015UF K	
C26			CK73GB0J105K	CHIP C 1.0UF K	
C28			CK73GB0J105K	CHIP C 1.0UF K	
C29			CK73GB1C104K	CHIP C 0.10UF K	
C33			CK73GB1C104K	CHIP C 0.10UF K	
C35			CK73GB1C104K	CHIP C 0.10UF K	
C39			CK73GB1H152K	CHIP C 1500PF K	
C40			CK73GB1H103K	CHIP C 0.010UF K	
C41			CK73EB1C225K	CHIP C 2.2UF K	
C42			CK73GB1H152K	CHIP C 1500PF K	
C44			CK73GB1H103K	CHIP C 0.010UF K	
C46			CK73GB1E473K	CHIP C 0.047UF K	
C51			CK73GB1C104K	CHIP C 0.10UF K	
C55			CK73GB1C104K	CHIP C 0.10UF K	
C67,68			CK73GB1C104K	CHIP C 0.10UF K	
C71,72			CK73GB1H471K	CHIP C 470PF K	
C77,78			CC73GCH1H680J	CHIP C 68PF J	
C79,80			CK73GB1H222K	CHIP C 2200PF K	
C85			CK73GB1C104K	CHIP C 0.10UF K	
C89			CK73GB1H222K	CHIP C 2200PF K	
CN1			E40-9536-05	FLAT CABLE CONNECTOR (16p)	
CN1		＊	E41-0193-05	FLAT CABLE CONNECTOR (16p)	
CN2			E40-9339-05	FLAT CABLE CONNECTOR (22P)	
CN2			E41-0129-05	FLAT CABLE CONNECTOR	
X1			L78-0572-05	RESONATOR 16.93MHZ	
CP1			R90-1019-05	MULTI-COMP 100 X2	
CP2			R90-1014-05	MULTI-COMP 100 X4	
R3			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R5		＊	RK73GB2A361J	CHIP R 360 J 1/10W	
R6			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R9			RK73FB2B100J	CHIP R 10 J 1/8W	
R10,11			RK73GB2A103J	CHIP R 10K J 1/10W	

Ref. No.	Add	New	Parts No.	Description	Destination
R12		＊	RK73GB2A912J	CHIP R 9.1K J 1/10W	
R15		＊	RK73GB2A824J	CHIP R 820K J 1/10W	
R16			RK73GB2A223J	CHIP R 22K J 1/10W	
R17			RK73GB2A433J	CHIP R 43K J 1/10W	
R18		＊	RK73GB2A392J	CHIP R 3.9K J 1/10W	
R19		＊	RK73GB2A513J	CHIP R 51K J 1/10W	
R20			RK73GB2A104J	CHIP R 100K J 1/10W	
R21		＊	RK73GB2A244J	CHIP R 240K J 1/10W	
R32		＊	RK73GB2A683J	CHIP R 68K J 1/10W	
R34		＊	RK73GB2A363J	CHIP R 36K J 1/10W	
R36			RK73GB2A151J	CHIP R 150 J 1/10W	
R37			RK73GB2A471J	CHIP R 470 J 1/10W	
R38		＊	RK73GB2A224J	CHIP R 220K J 1/10W	
R40		＊	RK73GB2A133J	CHIP R 13K J 1/10W	
R46			RK73GB2A102J	CHIP R 1.0K J 1/10W	
R47			RK73GB2A103J	CHIP R 10K J 1/10W	
R49			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R52			RK73GB2A104J	CHIP R 100K J 1/10W	
R54			RK73GB2A104J	CHIP R 100K J 1/10W	
R70			RK73GB2A103J	CHIP R 10K J 1/10W	
R71		＊	RK73GB2A113J	CHIP R 11K J 1/10W	
R73			RK73GB2A473J	CHIP R 47K J 1/10W	
R74			RK73GB2A123J	CHIP R 12K J 1/10W	
R75			RK73GB2A333J	CHIP R 33K J 1/10W	
R76			RK73GB2A103J	CHIP R 10K J 1/10W	
R79,80			RK73GB2A103J	CHIP R 10K J 1/10W	
R81			RK73GB2A333J	CHIP R 33K J 1/10W	
R82		＊	RK73GB2A133J	CHIP R 13K J 1/10W	
R84			RK73GB2A103J	CHIP R 10K J 1/10W	
R101,102		＊	RK73GB2A332J	CHIP R 3.3K J 1/10W	
R103,104			RK73GB2A562J	CHIP R 5.6K J 1/10W	
R107,108			RK73FB2B331J	CHIP R 330 J 1/8W	
R110		＊	RK73FB2B201J	CHIP R 200 J 1/8W	
R117,118		＊	RK73FB2B203J	CHIP R 20K J 1/8W	
R121,122		＊	RK73FB2B203J	CHIP R 20K J 1/8W	
R125,126		＊	RK73FB2B203J	CHIP R 20K J 1/8W	
R202			RK73GB2A104J	CHIP R 100K J 1/10W	
R214			RK73GB2A104J	CHIP R 100K J 1/10W	
R218			RK73GB2A473J	CHIP R 47K J 1/10W	
R233		＊	RK73GB2A622J	CHIP R 6.2K J 1/10W	
R234			RK73GB2A103J	CHIP R 10K J 1/10W	
S1,2		＊	S68-0863-05	PUSH SWITCH	
S3		＊	S68-0862-05	PUSH SWITCH	
S4		＊	S68-0864-05	PUSH SWITCH	A2A3
S4		＊	S68-0864-05	PUSH SWITCH	B2B3
D1			DAN202U	DIODE	
D2			MA8051-L	ZENER DIODE	
D3			DA204U	DIODE	
D4			DAN202U	DIODE	
IC1			AN22000AA	ANALOGUE IC	
IC2		＊	MN662773KH2	MOS-IC	B0B1B2
IC2		＊	MN662773KH2	MOS-IC	B3B4B5
IC2		＊	MN662774KJ2	MOS-IC	A0A1A2
IC2		＊	MN662774KJ2	MOS-IC	A3A4A5

A0 : X92-4030-00 (DXM-6000W) A3 : X92-4030-03 (DXM-6003W)
A1 : X92-4030-01 (DXM-6001W) A4 : X92-4030-04 (DXM-6004W)
A2 : X92-4030-02 (DXM-6002W) A5 : X92-4030-05 (DXM-6005W)

B0 : X92-4440-00 (DXM-6100W) B3 : X92-4440-03 (DXM-6103W)
B1 : X92-4440-01 (DXM-6101W) B4 : X92-4440-04 (DXM-6104W)
B2 : X92-4440-02 (DXM-6102W) B5 : X92-4440-05 (DXM-6105W)

PARTS LIST

＊New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
IC4		*	BA5824FP	ANALOGUE IC	
IC6		*	NJM4580M1	ANALOGUE IC	
Q1			MCH6101	TRANSISTOR	
Q2			DTC124EUA	DIGITAL TRANSISTOR	
Q3			DTA143XUA	DIGITAL TRANSISTOR	
Q4			2SA1362(Y)	TRANSISTOR	
Q5			DTC124EUA	DIGITAL TRANSISTOR	
CD MECHANISM ASSY (X92-4030-0x, X92-4440-0x)					
2	1B	*	A10-4827-12	CHASSIS OUTER	
5	2B	*	D10-4576-23	ARM ASSY CLAMP	
8	2A	*	D10-4579-03	LEVER ASSY ROLLER	
10	3A	*	D10-4581-13	ARM DISC-L	
11	2A	*	D10-4582-13	ARM DISC-R	
12	3A	*	D10-4583-03	ARM JOINT-L	
13	3A	*	D10-4584-03	ARM JOINT-R	
14	3B	*	D10-4585-03	ARM CARRIER	
15	2A	*	D10-4586-03	SLIDER L	
16	3B	*	D10-4587-02	SLIDER R	
17	3B	*	D10-4588-03	SLIDER TRIG	
18	3B	*	D10-4595-04	ARM LOCK	
19	3B	*	D10-4596-04	ARM ROLLER	
22	2A	*	D13-2151-04	GEAR ROLLER	
23	2B	*	D13-2152-04	GEAR HELICAL-1	
24	3B	*	D13-2153-04	GEAR SUN	
25	3B	*	D13-2154-04	GEAR PLANET	
26	3B	*	D13-2155-04	WORM 2	
27	3B	*	D13-2156-04	GEAR HELICAL-2	
28	3B	*	D13-2157-04	GEAR LOAD-1	
29	3B	*	D13-2158-04	GEAR LOAD-2	
30	3B	*	D13-2168-04	GEAR PICK-1	
31	3B	*	D13-2171-04	GEAR PICK-2	
32	2B	*	D13-2172-03	RACK (GEAR)	
33	2A	*	D14-0759-04	ROLLER N100X3DIES	
35	2B	*	D21-2382-04	SHAFT PICK	
36	1A	*	D23-0954-04	RETAINER	
37	1B	*	D39-0246-05	DAMPER	
38	2B	*	G01-3072-04	EXTENSION SPRING TRIGGER	
39	2A	*	G01-3073-04	TORSION COIL SPRING ROLLER-L	
40	2A	*	G01-3074-04	EXTENSION SPRING ROLLER-R	
41	2B	*	G01-3075-04	EXTENSION SPRING PICKUP	
42	2A	*	G01-3076-04	EXTENSION SPRING JOINT-SP	
43	1B	*	G01-3077-04	EXTENSION SPRING FLOATTING	
44	2B	*	G02-1399-04	FLAT SPRING CLAMP	
45	2B	*	G02-1408-04	FLAT SPRING WORM	
51	1A	*	J21-9676-12	MOUNTING HARDWARE GUIDE-BKT	
52	3B	*	J21-9677-02	MOUNTING HARDWARE GEAR-BKT	
53	1B	*	J21-9678-03	MOUNTING HARDWARE DAMPER-BKT	
55	1A	*	J90-1001-11	GUIDE 1	
56	1B	*	J90-1023-03	GUIDE 2	
DFPC1	3A	*	J84-0128-15	FLEXIBLE P.W.B. PICK-FPC	
A	2B	*	N09-4460-05	TAPTITE SCREW PT2X8-SARA	
B	1B	*	N09-4472-05	MACHINE SCREW PICK-RACK	

Ref. No.	Add	New	Parts No.	Description	Destination
C	2B	*	N09-6004-05	MACHINE SCREW M1.7X2.5	
D	1B	*	N09-6006-05	TAPTITE SCREW ST-2X3.5	
E	2B	*	N09-6007-05	MACHINE SCREW M2X2	
F	1A	*	N09-6051-05	TAPTITE SCREW PT2X6-BIND	
G	2A	*	N19-2163-04	FLAT WASHER 1.6X0.25	
H	1B	*	N39-2020-46	MACHIN SCREW M2X2	
DM1	3B	*	T42-1066-04	DC MOTOR ASSY SP	
DM2	2B	*	T42-1067-04	DC MOTOR ASSY LO	
DPU1	2B	*	T25-0223-05	OPTICAL PICKUP HEAD	

A0 : X92-4030-00 (DXM-6000W) A3 : X92-4030-03 (DXM-6003W)
A1 : X92-4030-01 (DXM-6001W) A4 : X92-4030-04 (DXM-6004W)
A2 : X92-4030-02 (DXM-6002W) A5 : X92-4030-05 (DXM-6005W)

B0 : X92-4440-00 (DXM-6100W) B3 : X92-4440-03 (DXM-6103W)
B1 : X92-4440-01 (DXM-6101W) B4 : X92-4440-04 (DXM-6104W)
B2 : X92-4440-02 (DXM-6102W) B5 : X92-4440-05 (DXM-6105W)