EXPLODED VIEW (DVD MECHANISM)

A	ADJUSTMENT	: N09-4495-05
B	ϕ2x5	: N09-4496-05
C	M1.7x1.8	: N09-6060-05
D	M1.7x3.5	: N09-6061-05
E	M1.7x3.5	: N09-6103-05
F	ϕ2x10	: N09-6104-05
G	M1.7x2.5	: N09-6106-05
H	CONNECTION	: N09-6122-05
J	WASHER	: N19-2022-04
K	WASHER	: N19-2171-04



Parts with the exploded numbers larger than 700 are not supplied.

EXPLODED VIEW (UNIT)

G	φ2x4	:N09-6125-05
H	M2.6X3.2	:N09-6227-15
J	M2X3	:N09-6232-05
K	FLAT WASHER	:N19-2022-04
N	φ2x5	:N80-2005-48
Q	φ2x8	:N80-2008-43
R	φ2x6	:N82-2006-48
S	φ2x8	:N82-2008-43
T	φ2.6x6	:N89-2606-48
U	φ2.6x10	:N89-2610-43



EXPLODED VIEW (PANEL MECHANISM)

A	STEPPED SCREW	:N09-6062-05
B	M2X2.2(BLK)	:N09-6063-15
C	M2X3.5(BLK)	:N09-6064-15
D	M1.7X2.5	:N09-6065-15
E	STEPPED SCREW	:N09-6066-15
F	M1.7X2.2	:N09-6111-15
L	WASHER	:N19-2127-14
M	RETAINING RING	:N29-0206-04



Parts with the exploded numbers larger than 700 are not supplied.

EXPLODED VIEW (AMP UNIT / ACCESSORY)



Parts with the exploded numbers larger than 700 are not supplied.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
KVT-715DVD,725DVD/-B,735DVD,745DVD,765DVD,815DVD					
201	1G		A02-2723-03	PLASTIC CABINET ASSY	
202	3F	✻	A10-5137-02	CHASSIS CALKING ASSY	
203	2F	✻	A10-5013-13	CHASSIS CALKING ASSY	
204	2F	✻	A10-5015-23	CHASSIS CALKING ASSY	
205	2E	✻	A10-5018-22	CHASSIS	
206	3C	✻	A11-1638-04	SUB CHASSIS CALKING ASSY	
207	1C	✻	A21-4347-02	DRESSING PANEL	KK1R1
207	1C	✻	A21-4347-02	DRESSING PANEL	M1C1X1
207	1C	✻	A21-4347-02	DRESSING PANEL	E1
207	1C	✻	A21-4348-02	DRESSING PANEL	E2
208	1D	✻	A21-4349-03	DRESSING PANEL	KK1R1
208	1D	✻	A21-4349-03	DRESSING PANEL	M1C1X1
208	1D	✻	A21-4349-03	DRESSING PANEL	E1
208	1D	✻	A21-4350-03	DRESSING PANEL	E2
210	3C	✻	A22-3037-02	SUB PANEL ASSY	KR1M1
210	3C	✻	A22-3037-02	SUB PANEL ASSY	C1X1E1
210	3C	✻	A22-3038-02	SUB PANEL ASSY	E2
210	3C	✻	A22-3051-02	SUB PANEL ASSY	K1
211	1D		A46-1776-02	REAR COVER	
212	3C	✻	A46-1804-01	REAR COVER	
PA1	1C	✻	A64-3311-01	PANEL ASSY	K
PA1	1C	✻	A64-3312-01	PANEL ASSY	R1
PA1	1C	✻	A64-3313-01	PANEL ASSY	M1
PA1	1C	✻	A64-3314-01	PANEL ASSY	C1
PA1	1C	✻	A64-3315-01	PANEL ASSY	X1
PA1	1C	✻	A64-3316-01	PANEL ASSY	E1
PA1	1C	✻	A64-3317-01	PANEL ASSY	E2
PA1	1C	✻	A64-3374-01	PANEL ASSY	K1
PA2	3C	✻	A64-3326-12	PANEL ASSY	E1
PA2	3C	✻	A64-3327-12	PANEL ASSY	KR1
PA2	3C	✻	A64-3328-12	PANEL ASSY	M1C1X1
PA2	3C	✻	A64-3329-12	PANEL ASSY	E2
PA2	3C	✻	A64-3376-12	PANEL ASSY	K1
PME1	1D	✻	A10-5136-01	CHASSIS ASSY	
RM1	1G	✻	A70-2064-05	REMOTE CONTROLLER (RC-DV420)	
-			B46-0100-50	WARRANTY CARD	
-			B46-0606-04	ID CARD	KK1R1
-			B46-0612-14	ID CARD	M1C1X1
-			B46-0612-14	ID CARD	E1E2
-			B46-0648-13	USER CARD	K1
-		✻	B54-4433-00	INSTALLATION MANUAL (ENG,FRE,SPA,POR)	KK1R1
-		✻	B54-4434-00	INSTALLATION MANUAL (ENG,T-CHI,KOR,S-CHI)	M1C1X1
-		✻	B54-4435-00	INSTALLATION MANUAL (ENG,FRE,GER,DUT,ITA,SPA,POR)	E1E2
-		✻	B64-2846-00	INST. MANUAL (ENG,FRE,SPA)	KK1R1
-		✻	B64-2847-00	INST. MANUAL (PORTUGUESE)	R1
-		✻	B64-2848-00	INST. MANUAL (ENGLISH)	M1C1X1
-		✻	B64-2849-00	INST. MANUAL (T-CHI,KOR)	M1
-		✻	B64-2850-00	INST. MANUAL (S-CHI)	C1
-		✻	B64-2851-00	INST. MANUAL (ENGLISH)	E1E2
-		✻	B64-2852-00	INST. MANUAL (FRE,GER,DUT)	E1E2

Ref. No.	Add	New	Parts No.	Description	Destination
-		✻	B64-2853-00	INST. MANUAL (ITA,SPA,POR)	E1E2
213	2G		B07-3022-02	ESCUTCHEON	KK1
213	2G		B07-3058-02	ESCUTCHEON	R1M1C1
213	2G		B07-3058-02	ESCUTCHEON	X1E1E2
215	3C	✻	B07-3114-03	ESCUTCHEON	KK1R1
215	3C	✻	B07-3114-03	ESCUTCHEON	M1C1X1
215	3C	✻	B07-3114-03	ESCUTCHEON	E1
215	3C	✻	B07-3115-03	ESCUTCHEON	E2
216	3C	✻	B10-4553-03	FRONT GLASS	KR1E1
216	3C	✻	B10-4553-03	FRONT GLASS	E2
216	3C	✻	B10-4554-03	FRONT GLASS	K1M1C1
216	3C	✻	B10-4554-03	FRONT GLASS	X1
218	3C	✻	B19-2263-04	LIGHTING BOARD	
219	3C	✻	B19-2264-04	LIGHTING BOARD	
220	1C	✻	B43-1523-04	KENWOOD BADGE	
LCD1	2C		B38-1122-15	LIQUID CRYSTAL	
222	1G		D10-4589-04	LEVER	
225	2F		D10-4703-23	ARM ASSY	
226	3C		D10-4727-03	ARM	
227	3C		D10-4728-04	ARM	
228	3C		D10-4729-04	LEVER	
229	2E	✻	D10-4733-23	ARM	
230	2F	✻	D10-4761-14	LEVER ASSY	
231	2F	✻	D13-2251-14	GEAR	
232	2F	✻	D13-2252-14	GEAR	
233	1F	✻	D13-2253-14	GEAR	
234	1F	✻	D13-2256-14	GEAR	
235	1F	✻	D13-2257-14	GEAR	
236	1F		D13-2258-24	GEAR	
237	1E		D13-2259-24	GEAR	
238	1F	✻	D13-2260-14	GEAR	
239	1F		D13-2261-14	GEAR	
240	3F		D13-2262-23	RACK (GEAR)	
241	1F	✻	D13-2263-14	GEAR	
242	1F	✻	D13-2264-14	GEAR	
243	2F	✻	D13-2265-14	GEAR	
244	3C		D13-2280-04	GEAR	
245	2F	✻	D21-2416-23	SHAFT	
246	3C		D39-0239-05	DAMPER	
247	2C		E29-1924-04	LEAD PLATE	
248	2D	✻	E30-6298-05	CORD WITH PINPLUG	
249	1G	✻	E30-6300-05	CORD WITH PLUG	
250	2G	✻	E30-6301-05	CORD WITH PLUG (6m)	
DC1	1G	✻	E30-6337-05	DC CORD (8PIN)	E1E2
DC2	1G	✻	E30-6338-05	DC CORD (8PIN)	KK1R1
DC2	1G	✻	E30-6338-05	DC CORD (8PIN)	M1C1X1
DC3	1G	✻	E30-6339-05	DC CORD (16PIN : 6m)	KK1R1
DC3	1G	✻	E30-6339-05	DC CORD (16PIN : 6m)	M1C1X1
DC4	1G	✻	E30-6340-05	DC CORD (16PIN : 6m)	E1E2
FC1	2F		E39-0537-15	FLAT CABLE (9PIN)	
FC2	3C	✻	E39-0675-05	FLAT CABLE (16PIN)	
FC3	2D	✻	E39-0676-05	FLAT CABLE (50PIN)	
261	1D	✻	F07-1145-04	COVER	KK1R1

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

KVT-715DVD,725DVD/-B,735DVD,745DVD,765DVD,815DVD

Ref. No.	Add	New	Parts No.	Description	Destination
261	1D	✻	F07-1145-04	COVER	M1C1X1
261	1D	✻	F07-1145-04	COVER	E1
261	1D	✻	F07-1146-04	COVER	E2
262	2C		F09-1260-04	SHEET	
263	2C		F09-1801-04	SHEET	
264	1D		F09-1832-24	SHEET	
265	2D	✻	F09-1887-02	SHEET	
266	2C		F12-0775-04	SHIELDING SHEET	
267	3C	✻	F19-1431-03	BLIND PLATE	
268	2C		F20-2235-14	INSULATING SHEET	
269	3F	✻	F20-2240-14	INSULATING SHEET	
270	2D		F29-0049-05	INSULATING COVER	
⚠ F1	1G		F52-0004-05	FUSE (5A : MINI BLADE)	
⚠ F2	2G		F52-0006-05	FUSE (10A : MINI BLADE)	
271	2F	✻	G01-3152-14	EXTENSION SPRING	
272	3E	✻	G01-3153-14	TORSION COIL SPRING	
273	3E	✻	G01-3161-14	TORSION COIL SPRING	
274	3C		G01-3168-04	TORSION COIL SPRING	
275	3C		G01-3169-14	COMPRESSION SPRING	
276	3C		G01-3170-04	TORSION COIL SPRING	
277	2E	✻	G11-3512-14	CUSHION	
278	1F	✻	G16-1452-14	SHEET	
279	2F	✻	G16-1453-14	SHEET	
280	3C		G16-1460-14	SHEET	
281	3D	✻	G16-1526-04	SHEET (IC)	
284	3C	✻	G11-3601-04	CUSHION	
-		✻	H12-2747-03	PACKING FIXTURE	
-			H25-0337-04	PROTECTION BAG (180X300X0.03)	KK1R1
-			H25-0337-04	PROTECTION BAG (180X300X0.03)	M1C1X1
-			H25-1115-04	PROTECTION BAG	E1E2
-			H25-1132-04	PROTECTION BAG (0.3X280X450)	KK1R1
-			H25-1132-04	PROTECTION BAG (0.3X280X450)	M1C1X1
-			H25-1158-04	PROTECTION BAG (220X350X0.03)	E1E2
-		✻	H54-3165-03	ITEM CARTON CASE	K
-		✻	H54-3166-03	ITEM CARTON CASE	K1
-		✻	H54-3167-03	ITEM CARTON CASE	R1
-		✻	H54-3168-03	ITEM CARTON CASE	M1
-		✻	H54-3169-03	ITEM CARTON CASE	C1
-		✻	H54-3170-03	ITEM CARTON CASE	X1
-		✻	H54-3171-03	ITEM CARTON CASE	E1
-		✻	H54-3172-03	ITEM CARTON CASE	E2
282	2E		J19-5207-23	HOLDER	
283	3E	✻	J19-5235-14	HOLDER	
285	1G		J21-9784-04	MOUNTING HARDWARE	M1C1X1
286	3E	✻	J21-9916-22	MOUNTING HARDWARE ASSY	
287	1G		J21-9934-03	MOUNTING HARDWARE ASSY	
288	1F	✻	J21-9947-14	MOUNTING HARDWARE ASSY	
289	1F	✻	J21-9949-14	MOUNTING HARDWARE	
290	1F	✻	J21-9984-14	MOUNTING HARDWARE ASSY	
291	1F	✻	J21-9986-13	MOUNTING HARDWARE ASSY	
292	1F	✻	J21-9987-13	MOUNTING HARDWARE ASSY	
293	3F	✻	J90-1053-13	GUIDE	
294	2E	✻	J90-1064-13	GUIDE	
FPC1	2C		J84-0150-05	FLEXIBLE PRINTED WIRING BOARD	
FPC2	2D		J84-0151-05	FLEXIBLE PRINTED WIRING BOARD	
FPC3	2D	✻	J84-0158-05	FLEXIBLE PRINTED WIRING BOARD	
295	1C		K24-4013-04	KNOB (OPEN/CLOSE)	
296	3C	✻	K24-4168-04	KNOB (ATT)	
297	3C	✻	K24-4169-04	KNOB (SRC)	
298	3C	✻	K24-4170-04	KNOB (RELEASE)	
299	1D		K25-1520-04	KNOB (VOL.)	
300	1C	✻	K25-1647-03	KNOB (SCREEN, FNC)	KK1R1
300	1C	✻	K25-1647-03	KNOB (SCREEN, FNC)	M1C1X1
300	1C	✻	K25-1647-03	KNOB (SCREEN, FNC)	E1
300	1C	✻	K25-1648-03	KNOB (SCREEN, FNC)	E2
301	3C	✻	K25-1649-03	KNOB (TI, EJECT)	KK1R1
301	3C	✻	K25-1649-03	KNOB (TI, EJECT)	M1C1X1
301	3C	✻	K25-1649-03	KNOB (TI, EJECT)	E1
301	3C	✻	K25-1650-03	KNOB (TI, EJECT)	E2
302	3C	✻	K29-7093-04	KEY TOP (4WAY)	
303	3C	✻	K29-7094-04	KEY TOP (SRC CAP)	
304	1G		N99-1558-05	SCREW SET	
305	1G		N99-1723-05	SCREW SET	KK1R1
305	1G		N99-1723-05	SCREW SET	M1C1X1
A	2E	✻	N09-6062-15	STEPPED SCREW	
B	3E	✻	N09-6063-15	MACHINE SCREW (M2X2.2)	
C	3F	✻	N09-6064-15	MACHINE SCREW (M2X3.5)	
D	1F	✻	N09-6065-15	MACHINE SCREW (M1.7X2.5)	
E	3F	✻	N09-6066-15	STEPPED SCREW	
F	3F	✻	N09-6111-15	MACHINE SCREW	
G	3C		N09-6125-05	TAPTITE SCREW (P2X4)	
H	2D	✻	N09-6227-15	MACHINE SCREW (M2.6X 3.2NI)	
J	3C	✻	N09-6232-05	MACHINE SCREW (M2.0X3.0)	
K	3C		N19-2022-04	FLAT WASHER	
L	2F		N19-2127-14	FLAT WASHER	
M	2F		N29-0206-04	RETAINING RING	
N	3C	✻	N80-2005-48	PAN HEAD TAPTITE SCREW	K1M1C1
N	3C	✻	N80-2005-48	PAN HEAD TAPTITE SCREW	X1
Q	3C		N80-2008-43	PAN HEAD TAPTITE SCREW	
R	3C		N82-2006-48	BINDING HEAD TAPTITE SCREW	
S	1D		N82-2008-43	BINDING HEAD TAPTITE SCREW	
T	2C	✻	N89-2606-48	BINDING HEAD TAPTITE SCREW	
U	3D	✻	N89-2610-43	BINDING HEAD TAPTITE SCREW	
306	2C		S79-0845-05	SWITCH ASSY	
309	1G		T90-0512-05	ANTENNA ADAPTOR	E1E2
311	3C	✻	W02-3478-05	ELECTRIC CIRCUIT MODULE	K1M1C1
311	3C	✻	W02-3478-05	ELECTRIC CIRCUIT MODULE	X1
VME1	2D		X92-5020-02	MECHANISM ASSY (DVS-3042)	

VIDEO CONTROL UNIT (X14-939x-xx)

C100			CK73GB1H103K	CHIP C	0.010UF	K	
C101		✻	C90-5670-05	ELECTRO	2200UF	16WV	
C102			CK73GB1H103K	CHIP C	0.010UF	K	
C103-105			CK73GB1H104K	CHIP C	0.10UF	K	
C106,107			CK73GB1C333K	CHIP C	0.033UF	K	
C108			CK73GB1E223K	CHIP C	0.022UF	K	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

VIDEO CONTROL UNIT (X14-939x-xx)

Ref. No.	Add	New	Parts No.	Description			Destination
C109-111			CK73GB1H472K	CHIP C	4700PF	K	
C112			CK73FB1C105K	CHIP C	1.0UF	K	
C113			CK73GB1H104K	CHIP C	0.10UF	K	
C114			CK73EB1E474K	CHIP C	0.47UF	K	
C115,116			CK73GB1H104K	CHIP C	0.10UF	K	
C117			CK73FB1H104K	CHIP C	0.10UF	K	
C118			CE32AZ1C221M	CHIP EL	220UF	16WV	
C119			CK73GB1H104K	CHIP C	0.10UF	K	
C120,121			CK73FB1H104K	CHIP C	0.10UF	K	
C122			CK73FB1C105K	CHIP C	1.0UF	K	
C123,124			CK73GB1H472K	CHIP C	4700PF	K	
C125,126			CK73GB1C104K	CHIP C	0.10UF	K	
C127			CK73DF1C106Z	CHIP C	10UF	Z	
C128			CK73EB0J106K	CHIP C	10UF	K	
C129			CK73GB1C104K	CHIP C	0.10UF	K	
C130-133			C93-1210-05	CHIP C	10UF	K	
C134			CK73GB1H103K	CHIP C	0.010UF	K	
C135			CC73GCH1H391J	CHIP C	390PF	J	
C136			C93-1210-05	CHIP C	10UF	K	
C137			CK73DF1E106Z	CHIP C	10UF	Z	
C138-140			CK73GB1H471K	CHIP C	470PF	K	
C141			C93-1210-05	CHIP C	10UF	K	
C142			CK73GB1H102K	CHIP C	1000PF	K	
C143		✻	CE32AU0J121M	CHIP EL	120UF	6.3WV	
C144			CE32AU1A560M	CHIP EL	56UF	10WV	
C145			CE32AU0G331M	CHIP EL	330UF	4.0WV	
C146			CE32AU1A560M	CHIP EL	56UF	10WV	
C148,149			CK73GB1C104K	CHIP C	0.10UF	K	
C151			CK73DF1C106Z	CHIP C	10UF	Z	
C152			CE32AU1A560M	CHIP EL	56UF	10WV	
C153			CK73EB0J106K	CHIP C	10UF	K	
C154,155			CK73GB1C104K	CHIP C	0.10UF	K	
C156			CK73GB1H562K	CHIP C	5600PF	K	
C157			CK73GB1H104K	CHIP C	0.10UF	K	
C158			CK73GB1C104K	CHIP C	0.10UF	K	
C159,160			C92-1766-05	CHIP EL	22UF	12.5WV	
C161			CE32AZ1C221M	CHIP EL	220UF	16WV	
C200-202			CK73GB1H103K	CHIP C	0.010UF	K	
C203,204			CC73GCH1H220J	CHIP C	22PF	J	
C205			C92-1359-05	CHIP-TAN	10UF	16WV	
C206-208			CK73GB1H103K	CHIP C	0.010UF	K	
C209			CK73GB1C104K	CHIP C	0.10UF	K	
C210,211			CK73GB1H103K	CHIP C	0.010UF	K	
C212			CK73FB1C105K	CHIP C	1.0UF	K	
C213-216			CK73GB1H103K	CHIP C	0.010UF	K	
C217			CK73GB1C104K	CHIP C	0.10UF	K	
C300			CK73GB1C104K	CHIP C	0.10UF	K	
C301			C92-1685-05	CHIP EL	47UF	6.3WV	
C302			CK73GB1C104K	CHIP C	0.10UF	K	KK1R1
C302,303			CK73GB1C104K	CHIP C	0.10UF	K	M1C1X1
C302,303			CK73GB1C104K	CHIP C	0.10UF	K	E1E2
C304			CK73EB0J106K	CHIP C	10UF	K	
C306			CC73GCH1H270J	CHIP C	27PF	J	M1C1X1
C306			CC73GCH1H270J	CHIP C	27PF	J	E1E2
C306			CC73GCH1H470J	CHIP C	47PF	J	KK1R1
C307			CK73GB1C104K	CHIP C	0.10UF	K	
C309			CC73GCH1H180J	CHIP C	18PF	J	M1C1X1
C309			CC73GCH1H180J	CHIP C	18PF	J	E1E2
C310			CC73GCH1H220J	CHIP C	22PF	J	
C311			CK73GB1C104K	CHIP C	0.10UF	K	M1C1X1
C311			CK73GB1C104K	CHIP C	0.10UF	K	E1E2
C312,313			CK73GB0J105K	CHIP C	1.0UF	K	
C314,315			CK73GB1C104K	CHIP C	0.10UF	K	E1E2
C316			CK73GB0J105K	CHIP C	1.0UF	K	
C317			CC73GCH1H180J	CHIP C	18PF	J	
C318			CC73GCH1H270J	CHIP C	27PF	J	M1C1X1
C318			CC73GCH1H270J	CHIP C	27PF	J	E1E2
C319,320			CK73GB0J225K	CHIP C	2.2UF	K	
C321-323			CK73GB0J105K	CHIP C	1.0UF	K	
C324			CK73GB1H223K	CHIP C	0.022UF	K	
C325			CK73GB0J475K	CHIP C	4.7UF	K	
C326			CK73GB1C104K	CHIP C	0.10UF	K	KK1R1
C326			CK73GB1C104K	CHIP C	0.10UF	K	M1C1X1
C326,327			CK73GB1C104K	CHIP C	0.10UF	K	E1E2
C328-330			CK73GB0J105K	CHIP C	1.0UF	K	E1E2
C331			CK73GB1C104K	CHIP C	0.10UF	K	E1E2
C332,333			CK73GB0J105K	CHIP C	1.0UF	K	M1C1X1
C332,333			CK73GB0J105K	CHIP C	1.0UF	K	E1E2
C334			CK73GB1C104K	CHIP C	0.10UF	K	
C335,336			CK73GB0J105K	CHIP C	1.0UF	K	M1C1X1
C335,336			CK73GB0J105K	CHIP C	1.0UF	K	E1E2
C337			CK73GB1A474K	CHIP C	0.47UF	K	
C338			CK73EB0J106K	CHIP C	10UF	K	
C339			CK73GB1H223K	CHIP C	0.022UF	K	
C340			CK73GB0J105K	CHIP C	1.0UF	K	
C341			CK73EB0J106K	CHIP C	10UF	K	
C342,343			CK73GB0J105K	CHIP C	1.0UF	K	
C344			CK73GB1H223K	CHIP C	0.022UF	K	
C345-350			CK73GB0J105K	CHIP C	1.0UF	K	
C351			CK73FB1A225K	CHIP C	2.2UF	K	
C352,353			CK73GB1H103K	CHIP C	0.010UF	K	
C354,355			CK73FB1A225K	CHIP C	2.2UF	K	
C356			CK73GB1C104K	CHIP C	0.10UF	K	
C357			CK73EB0J106K	CHIP C	10UF	K	
C358			CK73GB1C104K	CHIP C	0.10UF	K	
C361			C92-1685-05	CHIP EL	47UF	6.3WV	
C362			CK73GB1C104K	CHIP C	0.10UF	K	
C363			CK73EB0J106K	CHIP C	10UF	K	
C364			CC73GCH1H331J	CHIP C	330PF	J	
C365			CK73GB0J105K	CHIP C	1.0UF	K	
C366,367			CK73GB1C104K	CHIP C	0.10UF	K	
C368			CK73GB0J105K	CHIP C	1.0UF	K	
C370			CK73GB1H103K	CHIP C	0.010UF	K	
C371			CK73GB0J475K	CHIP C	4.7UF	K	
C372			CK73GB1H153K	CHIP C	0.015UF	K	
C373			CC73GCH1H151J	CHIP C	150PF	J	
C374			CC73GCH1E102J	CHIP C	1000PF	J	
C375			CC73GCH1H470J	CHIP C	47PF	J	
C376			CC73GCH1H150J	CHIP C	15PF	J	
C400			CC73GCH1H070D	CHIP C	7.0PF	D	M1C1X1

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

VIDEO CONTROL UNIT (X14-939x-xx)

Ref. No.	Add	New	Parts No.	Description			Destination
C400			CC73GCH1H070D	CHIP C	7.0PF	D	E1E2
C400			CC73GCH1H100D	CHIP C	10PF	D	KK1R1
C401			CC73GCH1H120J	CHIP C	12PF	J	
C402			CK73EB0J106K	CHIP C	10UF	K	
C403			CK73GB1C104K	CHIP C	0.10UF	K	
C404			CK73GB0J105K	CHIP C	1.0UF	K	
C405-409			CK73GB1C104K	CHIP C	0.10UF	K	
C410			CK73EB0J106K	CHIP C	10UF	K	
C411			CK73GB1C104K	CHIP C	0.10UF	K	
C412			CK73GB0J105K	CHIP C	1.0UF	K	
C413-416			CK73GB1C104K	CHIP C	0.10UF	K	
C417			CC73GCH1H050C	CHIP C	5.0PF	C	M1C1X1
C417			CC73GCH1H050C	CHIP C	5.0PF	C	E1E2
C520,521			CK73EB0J106K	CHIP C	10UF	K	
C522			CK73GB1C104K	CHIP C	0.10UF	K	
C540			CK73GB0J105K	CHIP C	1.0UF	K	
C541			CC73GCH1H120J	CHIP C	12PF	J	
C542			CC73GCH1H100D	CHIP C	10PF	D	
C561-567			CK73GB1C104K	CHIP C	0.10UF	K	
C580			CK73GB1C104K	CHIP C	0.10UF	K	
C601-606			CK73GB1C104K	CHIP C	0.10UF	K	
C607			CK73GB0J105K	CHIP C	1.0UF	K	
C608-614			CK73GB1C104K	CHIP C	0.10UF	K	
C615,616			CK73EB0J106K	CHIP C	10UF	K	
C617			CK73GB0J105K	CHIP C	1.0UF	K	
C618-628			CK73GB1C104K	CHIP C	0.10UF	K	
C650			CK73GB1C104K	CHIP C	0.10UF	K	
C651-658			CK73GB0J105K	CHIP C	1.0UF	K	
C659			C92-1452-05	ELECTRO	100UF	10WV	
C660			CK73EB0J106K	CHIP C	10UF	K	
C661			CK73GB0J105K	CHIP C	1.0UF	K	
C662			CK73GB1C104K	CHIP C	0.10UF	K	
C663			CK73EB0J106K	CHIP C	10UF	K	
C664			C92-1452-05	ELECTRO	100UF	10WV	
C665-668			CK73GB1C104K	CHIP C	0.10UF	K	
C669			CK73EB0J106K	CHIP C	10UF	K	
C670			CK73GB1C104K	CHIP C	0.10UF	K	
C671,672			CK73GB0J105K	CHIP C	1.0UF	K	
C673			CK73GB1C104K	CHIP C	0.10UF	K	
C674			CK73GB1H103K	CHIP C	0.010UF	K	
C675			CK73GB0J105K	CHIP C	1.0UF	K	
C701			CK73GB1H332K	CHIP C	3300PF	K	
C702,703			CC73GCH1H681J	CHIP C	680PF	J	
C704			CK73GB1C104K	CHIP C	0.10UF	K	
C705			CK73DF1C106Z	CHIP C	10UF	Z	
C706			CK73EB1A475K	CHIP C	4.7UF	K	
C707			CC73GCH1H101J	CHIP C	100PF	J	
C708			CK73GB1H332K	CHIP C	3300PF	K	
C709,710			CC73GCH1H681J	CHIP C	680PF	J	
C711			CK73EB1A475K	CHIP C	4.7UF	K	
C712			CC73GCH1H101J	CHIP C	100PF	J	
C713			CK73DF1C106Z	CHIP C	10UF	Z	
C714,715			CK73GB1C104K	CHIP C	0.10UF	K	
C717			CK73EB0J106K	CHIP C	10UF	K	
C718			CK73GB1C104K	CHIP C	0.10UF	K	

Ref. No.	Add	New	Parts No.	Description				Destination
C750			CK73GB1C104K	CHIP C	0.10UF	K		
C770,771			CK73GB1C104K	CHIP C	0.10UF	K		
C800,801			CC73GCH1H101J	CHIP C	100PF	J		
C900,901			CC73GCH1H101J	CHIP C	100PF	J		
C902			CK73GB0J105K	CHIP C	1.0UF	K		
C903,904			CC73GCH1H101J	CHIP C	100PF	J		
C906			CC73GCH1H101J	CHIP C	100PF	J		
C918			C92-1485-05	CHIP C	22UF	6.3WV		
C919-922			CK73GB1H104K	CHIP C	0.10UF	K		
C925-927			CK73GB1C104K	CHIP C	0.10UF	K		
TC1		✻	C05-0516-05	CERAMIC TRIMMER CAPACITOR (10PF)				
CN501		✻	E41-2114-05	FLAT CABLE CONNECTOR				
CN770			E40-9409-05	PIN ASSY				
CN801		✻	E41-2077-05	PIN ASSY				
CN850			E41-0341-05	FLAT CABLE CONNECTOR				
CN900		✻	E41-2115-05	FLAT CABLE CONNECTOR				
CN904		✻	E41-2074-05	PIN ASSY				
J100			E58-0899-05	RECTANGULAR RECEPTACLE				
P100-103			E23-0746-05	TERMINAL				
CF100-105			L72-0780-05	CERAMIC FILTER				
L100			L19-0733-05	TRANSFORMER FOR CONVERTER				
L101-105			L33-1906-05	CHOKE COIL				
L106,107			L40-1001-78	SMALL FIXED INDUCTOR (10UH)				
L200			L92-0319-05	CHIP FERRITE				
L300			L40-4705-79	SMALL FIXED INDUCTOR (47UH)				
L350			L40-1001-78	SMALL FIXED INDUCTOR (10UH)				
L400			L40-1001-78	SMALL FIXED INDUCTOR (10UH)				
L401		✻	L41-2205-33	SMALL FIXED INDUCTOR				
L402			L40-1001-78	SMALL FIXED INDUCTOR (10UH)				
L540			L40-1001-78	SMALL FIXED INDUCTOR (10UH)				
L601			L92-0373-05	CHIP FERRITE				
L650			L40-1001-78	SMALL FIXED INDUCTOR (10UH)				
L651			L92-0373-05	CHIP FERRITE				
L701,702			L40-1001-78	SMALL FIXED INDUCTOR (10UH)				
L750,751			L92-0373-05	CHIP FERRITE				
X200		✻	L78-0892-05	RESONATOR (19M)				
X201			L77-2304-05	CRYSTAL RESONATOR (32.768KHZ)				
X300			L77-2806-05	CRYSTAL RESONATOR (3.579545MHZ)				
X301			L77-2807-05	CRYSTAL RESONATOR (4.433619MHZ)				M1C1X1
X301			L77-2807-05	CRYSTAL RESONATOR (4.433619MHZ)				E1E2
X360			L78-0549-05	RESONATOR (50KHZ)				
X540			L77-2866-05	CRYSTAL RESONATOR (27MHZ)				
CP400-407			RK74HB1J330J	CHIP-COM	33	J	1/16W	
CP501-505			RK74HB1J330J	CHIP-COM	33	J	1/16W	
CP506-510			RK74HB1J103J	CHIP-COM	10K	J	1/16W	
CP601-604			RK74HB1J472J	CHIP-COM	4.7K	J	1/16W	
CP605			RK74HB1J470J	CHIP-COM	47	J	1/16W	
CP606-612			RK74HB1J220J	CHIP-COM	22	J	1/16W	
CP613,614			RK74HB1J330J	CHIP-COM	33	J	1/16W	
CP615-618			RK74HB1J472J	CHIP-COM	4.7K	J	1/16W	
CP619-625			RK74HB1J220J	CHIP-COM	22	J	1/16W	
R100-102			RK73GB2A223J	CHIP R	22K	J	1/10W	
R103			RK73GB2A681J	CHIP R	680	J	1/10W	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

VIDEO CONTROL UNIT (X14-939x-xx)

Ref. No.	Add	New	Parts No.	Description				Destination
R104			RK73GB2A223J	CHIP R	22K	J	1/10W	
R105			RN73GH1J433D	CHIP R	43K	D	1/16W	
R106			RK73GB2A223J	CHIP R	22K	J	1/10W	
R107			RK73GB2A103J	CHIP R	10K	J	1/10W	
R108			RK73GB2A432J	CHIP R	4.3K	J	1/10W	
R109			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R110			RK73GB2A363J	CHIP R	36K	J	1/10W	
R111			RK73GB2A473J	CHIP R	47K	J	1/10W	
R112			RK73GB2A513J	CHIP R	51K	J	1/10W	
R113			RK73GB2A363J	CHIP R	36K	J	1/10W	
R114			RK73GB2A104J	CHIP R	100K	J	1/10W	
R115		✻	R92-3323-05	CHIP R	3.3K	J	1/2W	
R116			RK73GB2A912J	CHIP R	9.1K	J	1/10W	
R117			RK73GB2A153J	CHIP R	15K	J	1/10W	
R118			RK73FB2B123J	CHIP R	12K	J	1/8W	
R119			RN73GH1J2552D	CHIP R	25.5K	D	1/16W	
R120			RN73GH1J154D	CHIP R	150K	D	1/16W	
R121			RK73GB2A473J	CHIP R	47K	J	1/10W	
R122,123			RK73GB2A103J	CHIP R	10K	J	1/10W	
R124			RK73GB2A822J	CHIP R	8.2K	J	1/10W	
R125			RN73GH1J104D	CHIP R	100K	D	1/16W	
R126			RN73GH1J2212D	CHIP R	22.1K	D	1/16W	
R127			RN73GH1J154D	CHIP R	150K	D	1/16W	
R128			RK73EB2E102J	CHIP R	1.0K	J	1/4W	
R129			RK73GB2A473J	CHIP R	47K	J	1/10W	
R130			RN73GH1J132D	CHIP R	1.3K	D	1/16W	
R131-136			RK73GB2A104J	CHIP R	100K	J	1/10W	
R137-139			RK73GB2A101J	CHIP R	100	J	1/10W	
R140			RK73GB2A201J	CHIP R	200	J	1/10W	
R143			RK73GB2A100J	CHIP R	10	J	1/10W	
R146			RK73GB2A303J	CHIP R	30K	J	1/10W	
R147			RK73GB2A622J	CHIP R	6.2K	J	1/10W	
R148			RN73GH1J102D	CHIP R	1.0K	D	1/16W	
R149			RN73GH1J622D	CHIP R	6.2K	D	1/16W	
R150			RN73GH1J102D	CHIP R	1.0K	D	1/16W	
R151			RN73GH1J242D	CHIP R	2.4K	D	1/16W	
R152			RN73GH1J102D	CHIP R	1.0K	D	1/16W	
R153			RN73GH1J133D	CHIP R	13K	D	1/16W	
R154			RK73GH2A202D	CHIP R	2.0K	D	1/10W	
R155			RN73GH1J102D	CHIP R	1.0K	D	1/16W	
R156			RN73GH1J4021D	CHIP R	4.02K	D	1/16W	
R157			RN73GH1J752D	CHIP R	7.5K	D	1/16W	
R158			RN73GH1J102D	CHIP R	1.0K	D	1/16W	
R159			RN73GH1J622D	CHIP R	6.2K	D	1/16W	
R160		✻	RK73GH2A203D	CHIP R	20K	D	1/10W	
R161			R92-3416-05	CHIP R	0.27	J	1/2W	
R162			RK73GB2A104J	CHIP R	100K	J	1/10W	
R163			R92-1252-05	CHIP R	0 OHM	J	1/16W	
R201			RK73GB2A103J	CHIP R	10K	J	1/10W	KM1E1
R201			RK73GB2A103J	CHIP R	10K	J	1/10W	E2
R201,202			RK73GB2A103J	CHIP R	10K	J	1/10W	K1R1C1
R201,202			RK73GB2A103J	CHIP R	10K	J	1/10W	X1
R203			RK73GB2A103J	CHIP R	10K	J	1/10W	K
R203,204			RK73GB2A103J	CHIP R	10K	J	1/10W	M1E1C2
R204			RK73GB2A103J	CHIP R	10K	J	1/10W	K1R1
R205			RK73GB2A103J	CHIP R	10K	J	1/10W	C1X1
R205,206			RK73GB2A103J	CHIP R	10K	J	1/10W	K
R206			RK73GB2A103J	CHIP R	10K	J	1/10W	R1M1
R207			RK73GB2A103J	CHIP R	10K	J	1/10W	K1C1X1
R207			RK73GB2A103J	CHIP R	10K	J	1/10W	E1E2
R208-211			RK73GB2A104J	CHIP R	100K	J	1/10W	
R212			RK73GB2A471J	CHIP R	470	J	1/10W	
R213,214			RK73GB2A103J	CHIP R	10K	J	1/10W	
R215			RK73GB2A684J	CHIP R	680K	J	1/10W	
R216			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R217			RK73GB2A104J	CHIP R	100K	J	1/10W	
R218			RK73GB2A225J	CHIP R	2.2M	J	1/10W	
R219			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R222			RK73GB2A104J	CHIP R	100K	J	1/10W	
R223			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R224			RK73GB2A104J	CHIP R	100K	J	1/10W	
R225-227			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R228-233			RK73GB2A104J	CHIP R	100K	J	1/10W	
R234			RK73GB2A123J	CHIP R	12K	J	1/10W	
R235			RK73GB2A473J	CHIP R	47K	J	1/10W	
R236			RK73GB2A123J	CHIP R	12K	J	1/10W	
R237			RK73GB2A104J	CHIP R	100K	J	1/10W	
R238			RK73GB2A123J	CHIP R	12K	J	1/10W	
R239			RK73GB2A104J	CHIP R	100K	J	1/10W	
R240			RK73GB2A123J	CHIP R	12K	J	1/10W	
R241			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R242			RK73GB2A104J	CHIP R	100K	J	1/10W	
R243			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R244			RK73GB2A473J	CHIP R	47K	J	1/10W	
R248-254			RK73GB2A104J	CHIP R	100K	J	1/10W	
R256-258			RK73GB2A101J	CHIP R	100	J	1/10W	
R259			RK73GB2A104J	CHIP R	100K	J	1/10W	
R300			RK73GB2A471J	CHIP R	470	J	1/10W	
R301			RK73GB2A103J	CHIP R	10K	J	1/10W	M1C1X1
R301			RK73GB2A103J	CHIP R	10K	J	1/10W	E1E2
R302			RK73GB2A152J	CHIP R	1.5K	J	1/10W	
R303			RK73GB2A752J	CHIP R	7.5K	J	1/10W	
R304,305			RK73GB2A101J	CHIP R	100	J	1/10W	
R306			RK73GB2A103J	CHIP R	10K	J	1/10W	
R307			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R308			RK73GB2A105J	CHIP R	1.0M	J	1/10W	
R309-312			RK73GB2A101J	CHIP R	100	J	1/10W	
R313			RK73GB2A473J	CHIP R	47K	J	1/10W	
R360,361			RK73GB2A103J	CHIP R	10K	J	1/10W	
R362			RK73GB2A272J	CHIP R	2.7K	J	1/10W	
R363			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R364			RK73GB2A361J	CHIP R	360	J	1/10W	
R365			RK73GB2A914J	CHIP R	910K	J	1/10W	
R366,367			RK73GB2A471J	CHIP R	470	J	1/10W	
R368			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R369			RK73GB2A471J	CHIP R	470	J	1/10W	
R370			RK73GB2A302J	CHIP R	3.0K	J	1/10W	
R371			RN73GH1J182D	CHIP R	1.8K	D	1/16W	
R372			RN73GH1J391D	CHIP R	390	D	1/16W	
R373			RK73GB2A101J	CHIP R	100	J	1/10W	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

VIDEO CONTROL UNIT (X14-939x-xx)

Ref. No.	Add	New	Parts No.	Description				Destination
R374			RK73GB2A471J	CHIP R	470	J	1/10W	
R375			RK73GB2A101J	CHIP R	100	J	1/10W	
R380-383			RK73GB2A101J	CHIP R	100	J	1/10W	
R384,385			RK73GB2A471J	CHIP R	470	J	1/10W	
R386			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R387			RN73GH1J473D	CHIP R	47K	D	1/16W	
R388			RK73GB2A241J	CHIP R	240	J	1/10W	
R389			RK73GB2A272J	CHIP R	2.7K	J	1/10W	
R400			RK73GB2A103J	CHIP R	10K	J	1/10W	
R401			RK73GB2A680J	CHIP R	68	J	1/10W	
R402			RK73GB2A152J	CHIP R	1.5K	J	1/10W	
R403			RK73GB2A101J	CHIP R	100	J	1/10W	
R404			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R405			RK73GB2A272J	CHIP R	2.7K	J	1/10W	
R406			RK73GB2A101J	CHIP R	100	J	1/10W	
R407			RK73GB2A272J	CHIP R	2.7K	J	1/10W	
R408			RK73GB2A101J	CHIP R	100	J	1/10W	
R409			RK73GB2A272J	CHIP R	2.7K	J	1/10W	
R410,411			RK73GB2A104J	CHIP R	100K	J	1/10W	
R412			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R413,414			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R415-417			RK73GB2A151J	CHIP R	150	J	1/10W	
R501			RK73GB2A330J	CHIP R	33	J	1/10W	
R502			RK73GB2A103J	CHIP R	10K	J	1/10W	
R503			RK73GB2A820J	CHIP R	82	J	1/10W	
R504,505			RK73GB2A220J	CHIP R	22	J	1/10W	
R506,507			RK73GB2A820J	CHIP R	82	J	1/10W	
R508			RK73GB2A330J	CHIP R	33	J	1/10W	
R520			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R522-528			RK73GB2A103J	CHIP R	10K	J	1/10W	
R529,530			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R531,532			RK73GB2A104J	CHIP R	100K	J	1/10W	
R540,541			RK73GB2A330J	CHIP R	33	J	1/10W	
R542			RK73GB2A105J	CHIP R	1.0M	J	1/10W	
R544			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R586			RK73GB2A152J	CHIP R	1.5K	J	1/10W	
R587			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R601-603			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R604			RK73GB2A470J	CHIP R	47	J	1/10W	
R605-613			RK73GB2A220J	CHIP R	22	J	1/10W	
R614			RK73GB2A330J	CHIP R	33	J	1/10W	
R615-617			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R618,619			RK73GB2A220J	CHIP R	22	J	1/10W	
R620-627			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R650			RK73GB2A332J	CHIP R	3.3K	J	1/10W	
R651-654			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R655			RK73GB2A750J	CHIP R	75	J	1/10W	
R656			RK73GB2A391J	CHIP R	390	J	1/10W	
R657			RK73GB2A152J	CHIP R	1.5K	J	1/10W	
R658,659			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R660			RK73GB2A103J	CHIP R	10K	J	1/10W	
R661,662			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R663,664			RK73GB2A101J	CHIP R	100	J	1/10W	
R665-668			RN73GH1J750D	CHIP R	75	D	1/16W	
R669			RN73GH1J151D	CHIP R	150	D	1/16W	

Ref. No.	Add	New	Parts No.	Description				Destination
R670			RK73GB2A103J	CHIP R	10K	J	1/10W	
R671,672			RK73GB2A104J	CHIP R	100K	J	1/10W	
R673			RN73GH1J151D	CHIP R	150	D	1/16W	
R675			RK73GB2A223J	CHIP R	22K	J	1/10W	
R676			RK73GB2A333J	CHIP R	33K	J	1/10W	
R677			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R678			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R701,702			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R703			RK73GB2A302J	CHIP R	3.0K	J	1/10W	
R704,705			RK73GB2A201J	CHIP R	200	J	1/10W	
R706			RK73GB2A302J	CHIP R	3.0K	J	1/10W	
R707			RK73GB2A471J	CHIP R	470	J	1/10W	
R708			RK73GB2A182J	CHIP R	1.8K	J	1/10W	
R709			RK73GB2A100J	CHIP R	10	J	1/10W	
R710,711			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R712			RK73GB2A302J	CHIP R	3.0K	J	1/10W	
R713,714			RK73GB2A201J	CHIP R	200	J	1/10W	
R715			RK73GB2A302J	CHIP R	3.0K	J	1/10W	
R716			RK73GB2A471J	CHIP R	470	J	1/10W	
R717			RK73GB2A182J	CHIP R	1.8K	J	1/10W	
R718			RK73GB2A100J	CHIP R	10	J	1/10W	
R719			RK73GB2A682J	CHIP R	6.8K	J	1/10W	
R720			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R721			RK73GB2A392J	CHIP R	3.9K	J	1/10W	
R722			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R751,752			RK73GB2A151J	CHIP R	150	J	1/10W	
R770			RK73GB2A103J	CHIP R	10K	J	1/10W	
R771			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R772-776			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R801-804			RK73EB2E102J	CHIP R	1.0K	J	1/4W	
R805-810			RK73EB2E101J	CHIP R	100	J	1/4W	
R811-814			RK73GB2A750J	CHIP R	75	J	1/10W	
R850-863			RK73GB2A101J	CHIP R	100	J	1/10W	
R865,866			RK73GB2A101J	CHIP R	100	J	1/10W	
R867			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R900-902			RK73EB2E102J	CHIP R	1.0K	J	1/4W	
R903-905			RK73EB2E100J	CHIP R	10	J	1/4W	
R909			RK73EB2E101J	CHIP R	100	J	1/4W	
R911			RK73EB2E101J	CHIP R	100	J	1/4W	
R913			RK73EB2E101J	CHIP R	100	J	1/4W	
R914			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R921			RK73GB2A103J	CHIP R	10K	J	1/10W	
R924			RK73GB2A473J	CHIP R	47K	J	1/10W	
R925			RN73GH1J123D	CHIP R	12K	D	1/16W	
R926			RN73GH1J152D	CHIP R	1.5K	D	1/16W	
R927			RN73GH1J243D	CHIP R	24K	D	1/16W	
R928			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R929			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R930,931			RK73GB2A101J	CHIP R	100	J	1/10W	K1M1
VR1			R32-0244-05	SEMI FIXED VARIABLE RESISTOR (2K)				
W105-117			R92-1252-05	CHIP R	0 OHM	J	1/16W	
W164,165			R92-2053-05	CHIP R	0	J	1/8W	
W202			R92-1252-05	CHIP R	0 OHM	J	1/16W	
W300-302			R92-1252-05	CHIP R	0 OHM	J	1/16W	KK1R1
W300-302			R92-1252-05	CHIP R	0 OHM	J	1/16W	M1C1X1

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

VIDEO CONTROL UNIT (X14-939x-xx)

Ref. No.	Add	New	Parts No.	Description	Destination
W400			R92-1252-05	CHIP R 0 OHM J 1/16W	
W408-414			R92-1252-05	CHIP R 0 OHM J 1/16W	
W501			R92-1252-05	CHIP R 0 OHM J 1/16W	
W520-522			R92-1252-05	CHIP R 0 OHM J 1/16W	
W560			R92-1252-05	CHIP R 0 OHM J 1/16W	
W580,581			R92-1252-05	CHIP R 0 OHM J 1/16W	
W601			R92-1252-05	CHIP R 0 OHM J 1/16W	
W603,604			R92-1252-05	CHIP R 0 OHM J 1/16W	
W606-609			R92-1252-05	CHIP R 0 OHM J 1/16W	
W650-652			R92-1252-05	CHIP R 0 OHM J 1/16W	
W654			R92-1252-05	CHIP R 0 OHM J 1/16W	
W658			R92-1252-05	CHIP R 0 OHM J 1/16W	
W660			R92-1252-05	CHIP R 0 OHM J 1/16W	
W701			R92-1252-05	CHIP R 0 OHM J 1/16W	
W750			R92-1252-05	CHIP R 0 OHM J 1/16W	
W754			R92-1252-05	CHIP R 0 OHM J 1/16W	
W770			R92-1252-05	CHIP R 0 OHM J 1/16W	
W772-776			R92-1252-05	CHIP R 0 OHM J 1/16W	
W850			R92-1252-05	CHIP R 0 OHM J 1/16W	
W853			R92-1252-05	CHIP R 0 OHM J 1/16W	
W855			R92-1252-05	CHIP R 0 OHM J 1/16W	
W856			R92-2052-05	CHIP R 0 OHM J 1/10W	
W859-865			R92-1252-05	CHIP R 0 OHM J 1/16W	
W868-870			R92-1252-05	CHIP R 0 OHM J 1/16W	
W872-876			R92-1252-05	CHIP R 0 OHM J 1/16W	
W881-888			R92-1252-05	CHIP R 0 OHM J 1/16W	
W906-908			R92-2053-05	CHIP R 0 J 1/8W	
W910			R92-2053-05	CHIP R 0 J 1/8W	
W912			R92-2053-05	CHIP R 0 J 1/8W	
D100			1SR154-400	DIODE	
D101			RD16S	ZENER DIODE	
D102			RD6.8M(B2)	ZENER DIODE	
D104			DAN202U	DIODE	
D105			RD6.8M(B2)	ZENER DIODE	
D106			DAN202U	DIODE	
D107			MA3062-M	ZENER DIODE	
D108-111			EC31QS04	DIODE	
D113			EC31QS04	DIODE	
D114-117			SB05-05CP	DIODE	
D118,119			D1F60	DIODE	
D300			DAN202U	DIODE	
D301-303			DA204U	DIODE	
D701			DAP202U	DIODE	
D800-804			MA3062WA	ZENER DIODE	
D850-859			AVRM1608120M6A	VARISTOR	
D862			DA204U	DIODE	
D900,901			DA204U	DIODE	
D902			MA3062WA	ZENER DIODE	
D903			DA204U	DIODE	
D904,905			MA3062WA	ZENER DIODE	
D906			DA204U	DIODE	
D907			MA8062-M	ZENER DIODE	
D908			MA3062WA	ZENER DIODE	
D909			AVRM1608120M6A	VARISTOR	

Ref. No.	Add	New	Parts No.	Description	Destination
D910			DA204U	DIODE	
D911,912			MA3062WA	ZENER DIODE	
D913			DA204U	DIODE	
D914			MA8062-M	ZENER DIODE	
D915			UMZ8.2N	ZENER DIODE	
D919-921			MA3062WA	ZENER DIODE	
D922,923			MA8062-M	ZENER DIODE	K1M1
D924			AVRM1608120M6A	VARISTOR	
IC100-102			FA7703V	ANALOGUE IC	
IC103			TA78DL05F	ANALOGUE IC	
IC104			PQ1X331M2ZP	ANALOGUE IC	
IC105			TC75W56FU	MOS-IC	
IC106			TC7SH04FU	MOS-IC	
IC107			M5237ML	ANALOGUE IC	
IC108			SI-3012KM	ANALOGUE IC	
IC200			-	MEMORY IC	
IC202,203			LB1836M-TE-L	ANALOGUE IC	
IC204		✻	70F3089YGJ-7R5	MICROCONTROLLER IC	
IC205			TC7SH08F	MOS-IC	
IC206			TC7W14FU	MOS-IC	
IC207			PST9137NR	ANALOGUE IC	
IC300			TA78L05F	ANALOGUE IC	
IC301			TDA4665T	ANALOGUE IC	M1C1X1
IC301			TDA4665T	ANALOGUE IC	E1E2
IC302			MM1389XFBE	ANALOGUE IC	E1E2
IC303			AN2546FH-AV	ANALOGUE IC	
IC304			MM1234XFBE	ANALOGUE IC	
IC305			NJU7200U30	ANALOGUE IC	
IC361			TC7W00FU	MOS-IC	
IC362			NJW1303V	ANALOGUE IC	
IC363,364			TC7W34FU	MOS-IC	
IC365			TC7WH123FU	MOS-IC	
IC400		✻	LC74735NW9817E	MOS-IC	
IC401		✻	MB29LV8T9TN6R2	ROM IC	
IC520		✻	29LV160ATI7R2	ROM IC	
IC521			K6F1008V2CYF55	SRAM IC	
IC522			TC7SH00FU	MOS-IC	
IC540,541			TC7SHU04FU	MOS-IC	
IC560			MT48LC4M16T75I	DRAM IC	
IC580			TC74VHCT08AFT	MOS-IC	
IC601			ES6218SF	MOS-IC	
IC650		✻	MM1567AJBE	ANALOGUE IC	
IC651			UPC2905T	ANALOGUE IC	
IC652			ADV7170KSU	MOS-IC	
IC701			NJM4580V	ANALOGUE IC	
IC702			TA78L05F	ANALOGUE IC	
IC703			AK4382AVT	ANALOGUE IC	
IC770			M4A3212VI8TV1	MOS-IC	
Q100-103			UN5212	DIGITAL TRANSISTOR	
Q104,105			2SD1819A	TRANSISTOR	
Q106			HAT1038R	FET	
Q107			2SC4081	TRANSISTOR	
Q108			DTA124EUA	DIGITAL TRANSISTOR	
Q109,110			HAT1016R	DUAL FET	
Q111			HAT3008R	DUAL FET	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1**: KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
Q112			2SB1184	TRANSISTOR	
Q117			DTC323TU	DIGITAL TRANSISTOR	
Q118			2SB1218A	TRANSISTOR	
Q119			UN5212	DIGITAL TRANSISTOR	
Q200			UN5212	DIGITAL TRANSISTOR	
Q201			DTB123YK	DIGITAL TRANSISTOR	
Q202			UN5212	DIGITAL TRANSISTOR	
Q203			DTB123YK	DIGITAL TRANSISTOR	
Q204			UN5212	DIGITAL TRANSISTOR	
Q205			DTB123YK	DIGITAL TRANSISTOR	
Q206			UN5113	DIGITAL TRANSISTOR	
Q207			UN5212	DIGITAL TRANSISTOR	
Q300			2SA1576A	TRANSISTOR	M1C1X1
Q300			2SA1576A	TRANSISTOR	E1E2
Q360			2SC4081	TRANSISTOR	
Q361,362			2SA1576A	TRANSISTOR	
Q400-402			2SA1576A	TRANSISTOR	
Q403			DTC143EUA	DIGITAL TRANSISTOR	M1C1X1
Q403			DTC143EUA	DIGITAL TRANSISTOR	E1E2
Q650			DTA144EUA	DIGITAL TRANSISTOR	
Q651			2SC4081	TRANSISTOR	
Q652			DTC144EUA	DIGITAL TRANSISTOR	
Q701-703			2SC4081	TRANSISTOR	
Q704			DTC114TUA	DIGITAL TRANSISTOR	
Q705-707			DTA114TUA	DIGITAL TRANSISTOR	
Q751			2SC4081	TRANSISTOR	
Q752			2SA1576A	TRANSISTOR	
Q901			2SB1189	TRANSISTOR	
Q902			2SC4081	TRANSISTOR	
Q903			DTC143EUA	DIGITAL TRANSISTOR	
SWITCH UNIT (X16-2250-00)					
CN1			E41-0404-05	FLAT CABLE (19PIN)	
R2			RK73GB2A273J	CHIP R 27K J 1/10W	
R1			RK73GB2A751J	CHIP R 750 J 1/10W	
VR1			R31-0237-05	SEMI FIXED VARIABLE RESISTOR	
S1			S68-0863-05	PUSH SWITCH	
S2,S3			S68-0871-05	PUSH SWITCH	
S4			S68-0863-05	PUSH SWITCH	
PH1			T95-0235-05	PHOTO INTERRPTER	
SUB CIRCUIT UNIT (X16-2630-xx)					
D100			B30-1658-05	LED (RED,S)	
D207			B30-1564-05	LED (1608,BLUE)	
D209			B30-1565-05	LED (1608,PG)	K1M1C1
D209			B30-1565-05	LED (1608,PG)	X1
D209,210			B30-1565-05	LED (1608,PG)	KR1E1
D209,210			B30-1565-05	LED (1608,PG)	E2
D211			B30-1566-05	LED (1608,RED)	KR1E1
D211			B30-1566-05	LED (1608,RED)	E2
D212			B30-1565-05	LED (1608,PG)	
D213,214			B30-1566-05	LED (1608,RED)	
D215			B30-1565-05	LED (1608,PG)	
D216			B30-1566-05	LED (1608,RED)	
D217			B30-1565-05	LED (1608,PG)	

VIDEO CONTROL UNIT (X14-939x-xx)

Ref. No.	Add	New	Parts No.	Description	Destination
D218			B30-1566-05	LED (1608,RED)	
C100,101			CK73GB1C104K	CHIP C 0.10UF K	
C200,201			CC73GCH1H101J	CHIP C 100PF J	
C202			CK73GB1H221K	CHIP C 220PF K	
C203,204			CC73GCH1H101J	CHIP C 100PF J	
C205			CK73FB1A225K	CHIP C 2.2UF K	
C206-209			CC73GCH1H101J	CHIP C 100PF J	
C210			CK73FB1C105K	CHIP C 1.0UF K	K1M1C1
C210			CK73FB1C105K	CHIP C 1.0UF K	X1
C211-214			CC73GCH1H101J	CHIP C 100PF J	
C215			CK73GB1C104K	CHIP C 0.10UF K	K1M1C1
C215			CK73GB1C104K	CHIP C 0.10UF K	X1
C216			CC73GCH1H101J	CHIP C 100PF J	
C218			CK73GB1C104K	CHIP C 0.10UF K	
C219,220			CK73GB1H103K	CHIP C 0.010UF K	
C221			CK73GB1C104K	CHIP C 0.10UF K	K1M1C1
C221			CK73GB1C104K	CHIP C 0.10UF K	X1
CN100		✻	E41-2080-05	FLAT CABLE CONNECTOR	
CN200			E41-0456-05	FLAT CABLE CONNECTOR	K1M1C1
CN200			E41-0456-05	FLAT CABLE CONNECTOR	X1
J100			E58-0865-05	RECTANGULAR RECEPTACLE	
J200			E59-0829-05	RECTANGULAR PLUG	
R100			RK73GB2A221J	CHIP R 220 J 1/10W	
R101			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R103-105			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R108			RK73EB2E101J	CHIP R 100 J 1/4W	
R110			RK73EB2E101J	CHIP R 100 J 1/4W	
R200			RK73EB2E101J	CHIP R 100 J 1/4W	
R201			RK73EB2E431J	CHIP R 430 J 1/4W	
R202			RK73EB2E391J	CHIP R 390 J 1/4W	
R203			RK73GB2A104J	CHIP R 100K J 1/10W	
R204			RK73EB2E241J	CHIP R 240 J 1/4W	
R205			RK73EB2E561J	CHIP R 560 J 1/4W	K1M1C1
R205			RK73EB2E561J	CHIP R 560 J 1/4W	X1
R206			RK73EB2E431J	CHIP R 430 J 1/4W	
R207			RK73EB2E561J	CHIP R 560 J 1/4W	K1M1C1
R207			RK73EB2E561J	CHIP R 560 J 1/4W	X1
R208			RK73EB2E101J	CHIP R 100 J 1/4W	
R209			RK73EB2E561J	CHIP R 560 J 1/4W	K1M1C1
R209			RK73EB2E561J	CHIP R 560 J 1/4W	X1
R210			RK73EB2E431J	CHIP R 430 J 1/4W	KR1E1
R210			RK73EB2E431J	CHIP R 430 J 1/4W	E2
R211			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R212			RK73EB2E241J	CHIP R 240 J 1/4W	
R213			RK73EB2E301J	CHIP R 300 J 1/4W	
R214			RK73EB2E431J	CHIP R 430 J 1/4W	KR1E1
R214			RK73EB2E431J	CHIP R 430 J 1/4W	E2
R215			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R216			RK73EB2E431J	CHIP R 430 J 1/4W	
R217			RK73GB2A562J	CHIP R 5.6K J 1/10W	
R218-220			RK73GB2A101J	CHIP R 100 J 1/10W	K1M1C1
R218-220			RK73GB2A101J	CHIP R 100 J 1/10W	X1
R221			RK73GB2A103J	CHIP R 10K J 1/10W	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description				Destination
R222			RK73GB2A273J	CHIP R	27K	J	1/10W	
R223			RK73EB2E101J	CHIP R	100	J	1/4W	
R224			RK73EB2E181J	CHIP R	180	J	1/4W	
W100			R92-2053-05	CHIP R	0	J	1/8W	
S200			S70-0860-05	TACT SWITCH				
S201			S70-0884-05	TACT SWITCH				
S202,203			S70-0860-05	TACT SWITCH				
S204			S70-0874-05	TACT SWITCH				
S206			S70-0826-05	TACT SWITCH				
D200			AVRM1608120M6A	VARISTOR				
D201-203			DA204U	DIODE				
D204			MA8062-M	ZENER DIODE				
D205			DAN202U	DIODE				
IC200			RS-181	ANALOGUE IC				
Q100			UN5212	DIGITAL TRANSISTOR				
Q200-202			UN5112	DIGITAL TRANSISTOR				K1M1C1
Q200-202			UN5112	DIGITAL TRANSISTOR				X1
Q203,204			UN5214	DIGITAL TRANSISTOR				KR1E1
Q203,204			UN5214	DIGITAL TRANSISTOR				E2
ELECTRIC UNIT (X34-315x-xx)								
C1			CK73GB1E473K	CHIP C	0.047UF	K		
C2			CD04AS1C100M	ELECTRO	10UF	16WV		
C3			C90-5619-05	ELECTRO	220UF	16WV		
C4			C90-5572-05	ELECTRO	100UF	10WV		
C5		✻	C90-5699-05	ELECTRO	0.047UF	5.5V		
C6			CK73FB1C105K	CHIP C	1.0UF	K		
C7			CD04AY1A221M	ELECTRO	220UF	10WV		
C8,9			CK73EB1C225K	CHIP C	2.2UF	K		
C10			CK73FB1A105K	CHIP C	1.0UF	K		
C11			CD04AY1A221M	ELECTRO	220UF	10WV		
C12			CK73EB1C225K	CHIP C	2.2UF	K		
C13			C90-2982-05	ELECTRO	100UF	16WV		
C14			CD04BA1E4R7M	ELECTRO	4.7UF	25WV		
C15			CK73EB1C225K	CHIP C	2.2UF	K		
C16		✻	CD04BA1C220M	ELECTRO	22UF	16WV		
C17			CK73GB1E223K	CHIP C	0.022UF	K		
C18			CK73GB1H103K	CHIP C	0.010UF	K		
C19,20			CD04BA1E4R7M	ELECTRO	4.7UF	25WV		
C21,22			CK73GB1H103K	CHIP C	0.010UF	K		
C23		✻	C90-5612-05	ELECTRO	3900UF	16WV		
C24			CK73FB1C105K	CHIP C	1.0UF	K		
C25			CK73GB1C104K	CHIP C	0.10UF	K		
C26			CK73FB1C105K	CHIP C	1.0UF	K		
C27			CD04AS1H3R3M	ELECTRO	3.3UF	50WV		
C28,29			CK73GB1H103K	CHIP C	0.010UF	K		
C100			CK73GB1H104K	CHIP C	0.10UF	K		
C101			CK73GB1H103K	CHIP C	0.010UF	K		
C102			CK73GB1H104K	CHIP C	0.10UF	K		
C104			CK73GB1H103K	CHIP C	0.010UF	K		
C105			CD04AT0J331M	ELECTRO	330UF	6.3WV		
C106,107			CC73GCH1H100D	CHIP C	10PF	D		
C108-110			CK73GB1H103K	CHIP C	0.010UF	K		
C111			CK73GB1A105K	CHIP C	1.0UF	K		
C200,201			CC73GCH1H100D	CHIP C	10PF	D		KK1R1
C200,201			CC73GCH1H100D	CHIP C	10PF	D		M1E1E2

SUB CIRCUIT UNIT (X16-2630-xx)

Ref. No.	Add	New	Parts No.	Description				Destination
C202-205			C92-1427-05	ELECTRO	100UF	16WV		
C211			CC73GCH1H331J	CHIP C	330PF	J		KK1R1
C211			CC73GCH1H331J	CHIP C	330PF	J		M1E1E2
C212			CD04AS1C100M	ELECTRO	10UF	16WV		KK1R1
C212			CD04AS1C100M	ELECTRO	10UF	16WV		M1E1E2
C213-216			CK73GB1H103K	CHIP C	0.010UF	K		
C217			CD04AS1C100M	ELECTRO	10UF	16WV		KK1R1
C217			CD04AS1C100M	ELECTRO	10UF	16WV		M1E1E2
C218			CK73GB1H103K	CHIP C	0.010UF	K		KK1R1
C218			CK73GB1H103K	CHIP C	0.010UF	K		M1E1E2
C250,251			C94-0026-05	ELECTRO	1UF	50WV		
C252			CK73GB1A105K	CHIP C	1.0UF	K		
C253			CK73GB1A474K	CHIP C	0.47UF	K		
C254-257			C90-5620-05	ELECTRO	0.47UF	50WV		
C258		✻	CD04BA1C220M	ELECTRO	22UF	16WV		
C300			CK73FB1C334K	CHIP C	0.33UF	K		
C301			CK73GB1A334K	CHIP C	0.33UF	K		
C302			CK73FB1C334K	CHIP C	0.33UF	K		
C303			CK73GB1A334K	CHIP C	0.33UF	K		
C304			CK73FB1C334K	CHIP C	0.33UF	K		
C305			CK73GB1A334K	CHIP C	0.33UF	K		
C306			CK73FB1C334K	CHIP C	0.33UF	K		
C307			CK73GB1A334K	CHIP C	0.33UF	K		
C308,309			CK73GB1C104K	CHIP C	0.10UF	K		
C310			CD04AS1C470M	ELECTRO	47UF	16WV		
C311			CK73GB1C104K	CHIP C	0.10UF	K		
C312			CD04AS1H010M	ELECTRO	1UF	50WV		
C313-315			CK73GB1C104K	CHIP C	0.10UF	K		
C316			CK73GB1H103K	CHIP C	0.010UF	K		
C317			CC73GCH1H221J	CHIP C	220PF	J		
C318			CK73GB1A474K	CHIP C	0.47UF	K		
C319			CK73FB1C105K	CHIP C	1.0UF	K		
C320			C92-0025-05	CHIP-ELE	3.3UF	50WV		
C321			CD04AS1C470M	ELECTRO	47UF	16WV		
C322			CK73GB1H103K	CHIP C	0.010UF	K		
C323			C92-0025-05	CHIP-ELE	3.3UF	50WV		
C324-331			CK73FB1C105K	CHIP C	1.0UF	K		
C332,333			CK73FB1A225K	CHIP C	2.2UF	K		
C334			C92-1409-05	CHIP-ELE	2.2UF	50WV		
C335,336			CK73FB1C105K	CHIP C	1.0UF	K		
C339,340			CK73FB1C105K	CHIP C	1.0UF	K		
C350,351		✻	CD04AS1H4R7M	ELECTRO	4.7UF	50WV		
C352			CD04AS0J101M	ELECTRO	100UF	6.3WV		
C353			CK73GB1H103K	CHIP C	0.010UF	K		
C354			CD04AS1C220M	ELECTRO	22UF	16WV		
C355			CD04AS1C100M	ELECTRO	10UF	16WV		
C400			CD04AS0J470M	ELECTRO	47UF	6.3WV		
C401,402			CD04AS1H2R2M	ELECTRO	2.2UF	50WV		
C450,451			C92-0687-05	ELECTRO	2.2UF	50WV		
C452			C92-0674-05	ELECTRO	47UF	16WV		
C453			CD04AS1C100M	ELECTRO	10UF	16WV		
C454			C92-1429-05	ELECTRO	220UF	6.3WV		
C455			CK73GB1C104K	CHIP C	0.10UF	K		
C456			C92-1429-05	ELECTRO	220UF	6.3WV		
C457			CK73GB1C104K	CHIP C	0.10UF	K		

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X34-315x-xx)

Ref. No.	Add	New	Parts No.	Description			Destination
C458			CK73GB1H103K	CHIP C	0.010UF	K	
C459			C92-1429-05	ELECTRO	220UF	6.3WV	
C460			CK73GB1C104K	CHIP C	0.10UF	K	
C461			C92-1428-05	ELECTRO	330UF	6.3WV	
C462			CK73GB1C104K	CHIP C	0.10UF	K	
C463			CK73GB1H103K	CHIP C	0.010UF	K	
C464,465			CK73GB1C104K	CHIP C	0.10UF	K	
C500		✻	CD04AS1H4R7M	ELECTRO	4.7UF	50WV	
C501			CD04AS0J470M	ELECTRO	47UF	6.3WV	
C502		✻	CD04AS1H4R7M	ELECTRO	4.7UF	50WV	
C503			CK73GB1H103K	CHIP C	0.010UF	K	
C504			CD04AS1C220M	ELECTRO	22UF	16WV	
C505			CD04AS1C100M	ELECTRO	10UF	16WV	
C506-508			CK73GB1C104K	CHIP C	0.10UF	K	E1E2
C509			CD04AS0J470M	ELECTRO	47UF	6.3WV	E1E2
C510			CK73GB1H103K	CHIP C	0.010UF	K	E1E2
C511-513			CK73GB1C104K	CHIP C	0.10UF	K	E1E2
C550			CK73GB1H103K	CHIP C	0.010UF	K	
C551			CK73GB1A105K	CHIP C	1.0UF	K	
C552			CK73GB1H103K	CHIP C	0.010UF	K	
C553			CD04AS0J470M	ELECTRO	47UF	6.3WV	
C554			CK73GB0J225K	CHIP C	2.2UF	K	
C555			CD04AS1C100M	ELECTRO	10UF	16WV	
C556			CK73GB0J225K	CHIP C	2.2UF	K	
C558,559			CK73GB1A105K	CHIP C	1.0UF	K	
C560			CK73GB1H104K	CHIP C	0.10UF	K	
C561			CK73GB0J225K	CHIP C	2.2UF	K	
C562			CK73GB1H103K	CHIP C	0.010UF	K	
C566			CK73GB1H103K	CHIP C	0.010UF	K	
C569			CK73GB1H103K	CHIP C	0.010UF	K	
C570			CK73GB1H561K	CHIP C	560PF	K	
C571			CK73GB0J105K	CHIP C	1.0UF	K	
C572			CK73GB1H561K	CHIP C	560PF	K	
C574			CK73GB1H103K	CHIP C	0.010UF	K	
C600-605			CD04AS1C220M	ELECTRO	22UF	16WV	
C606		✻	C90-5569-05	ELECTRO	470UF	6.3WV	
C607			CD04AS1C100M	ELECTRO	10UF	16WV	
C609,610			CK73GB1H222K	CHIP C	2200PF	K	
C611			CD04AS1C100M	ELECTRO	10UF	16WV	
C612		✻	CD04AS1H4R7M	ELECTRO	4.7UF	50WV	
C613			CK73GB1H103K	CHIP C	0.010UF	K	
C614		✻	CD04AS1H4R7M	ELECTRO	4.7UF	50WV	
C615			CD04AS1C220M	ELECTRO	22UF	16WV	
C616			CD04AS1A470M	ELECTRO	47UF	10WV	
C622,623			CD04AS1C100M	ELECTRO	10UF	16WV	
C624			C94-0040-05	ELECTRO	22UF	16WV	
C625			CK73GB1H103K	CHIP C	0.010UF	K	
C626			CD04AS1C100M	ELECTRO	10UF	16WV	
C627-629			CK73GB1H103K	CHIP C	0.010UF	K	
C630			CD04AS1C100M	ELECTRO	10UF	16WV	
C631-635			CK73GB1H103K	CHIP C	0.010UF	K	
C636			CD04AS1C100M	ELECTRO	10UF	16WV	
C637			CK73GB1H103K	CHIP C	0.010UF	K	
C638			CD04AS1C100M	ELECTRO	10UF	16WV	
C639			CK73GB1H103K	CHIP C	0.010UF	K	

Ref. No.	Add	New	Parts No.	Description				Destination
C640			CD04AS1C100M	ELECTRO	10UF		16WV	
C641			CK73GB1H103K	CHIP C	0.010UF	K		
C642			C94-0040-05	ELECTRO	22UF		16WV	
C643,644			CK73GB1H103K	CHIP C	0.010UF	K		
C900			CK73EB1C225K	CHIP C	2.2UF	K		
C902			CK73GB1E223K	CHIP C	0.022UF	K		M1E1E2
C904			CC73GCH1H060D	CHIP C	6.0PF	D		M1E1E2
C905			CK73GB1H222K	CHIP C	2200PF	K		M1E1E2
C906			CK73GB1H102K	CHIP C	1000PF	K		M1E1E2
C907			CC73GCH1H820J	CHIP C	82PF	J		M1E1E2
C908			CK73GB1H152K	CHIP C	1500PF	K		M1E1E2
C909			CK73GB1H682K	CHIP C	6800PF	K		M1E1E2
C910			CC73GCH1H471J	CHIP C	470PF	J		M1E1E2
C911			CC73GCH1H121J	CHIP C	120PF	J		M1E1E2
C912			CC73GCH1H102J	CHIP C	1000PF	J		M1E1E2
C913			CK73GB1H221K	CHIP C	220PF	K		M1E1E2
C914			CC73GCH1H180J	CHIP C	18PF	J		M1E1E2
C915			CC73GCH1H102J	CHIP C	1000PF	J		M1E1E2
C916			CK73GB1H221K	CHIP C	220PF	K		M1E1E2
C954			CK73GB1H103K	CHIP C	0.010UF	K		
C960			CK73GB1H103K	CHIP C	0.010UF	K		
CN4,5			E40-9423-05	SOCKET FOR PIN ASSY				
CN100			E40-9706-05	PIN ASSY				
CN200,201			E40-9421-05	PIN ASSY				
CN600		✻	E41-0935-05	PIN ASSY				
CN601		✻	E41-0934-05	PIN ASSY				
CN603		✻	E41-0934-05	PIN ASSY				
CN900			E40-9449-05	PIN ASSY				
J1			E58-0863-15	RECTANGULAR RECEPTACLE				
J350			E56-0825-05	CYLINDRICAL RECEPTACLE				
J400			E56-0843-05	CYLINDRICAL RECEPTACLE				
J500			E58-0900-05	RECTANGULAR RECEPTACLE				
J501			E58-0963-05	RECTANGULAR RECEPTACLE				
P1			E23-0745-05	TERMINAL				
W200		✻	E30-6302-05	CORD WITH PLUG				
WH1		✻	E39-0645-05	WIRING HARNESS				
L1		✻	L41-2205-33	SMALL FIXED INDUCTOR				
L2			L33-1102-05	CHOKE COIL				
L100			L41-1005-33	SMALL FIXED INDUCTOR				
L101			L92-0330-05	CHIP FERRITE				
L200-203			L41-4795-33	SMALL FIXED INDUCTOR				
L204			L33-1123-05	LINE FILTER COIL				
L205			L41-4795-33	SMALL FIXED INDUCTOR				KK1R1
L205			L41-4795-33	SMALL FIXED INDUCTOR				M1E1E2
L300			L41-4795-33	SMALL FIXED INDUCTOR				
L500		✻	L41-1005-33	SMALL FIXED INDUCTOR				E1E2
L551		✻	L41-1005-33	SMALL FIXED INDUCTOR				
X100		✻	L77-2871-05	CRYSTAL RESONATOR (18.874MHZ)				
X200			L77-2002-05	CRYSTAL RESONATOR				KK1R1
X200			L77-2002-05	CRYSTAL RESONATOR				M1E1E2
			N35-3006-48	BINDING HEAD MACHINE SCREW				
R1			RK73GB2A101J	CHIP R	100	J	1/10W	
R2			RK73GB2A223J	CHIP R	22K	J	1/10W	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X34-315x-xx)

Ref. No.	Add	New	Parts No.	Description				Destination
R3			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R4			RK73GB2A223J	CHIP R	22K	J	1/10W	
R5			RK73FB2B221J	CHIP R	220	J	1/8W	
R6			RK73GB2A153J	CHIP R	15K	J	1/10W	
R7			RN73GH1J243D	CHIP R	24K	D	1/16W	
R8		✻	RN73GH1J432D	CHIP R	4.3K	D	1/16W	
R15			RK73FB2B221J	CHIP R	220	J	1/8W	
R16			RK73GB2A153J	CHIP R	15K	J	1/10W	
R17			RN73GH1J153D	CHIP R	15K	D	1/16W	
R18			RN73GH1J512D	CHIP R	5.1K	D	1/16W	
R19			RK73FB2B102J	CHIP R	1.0K	J	1/8W	
R20			RK73GB2A104J	CHIP R	100K	J	1/10W	
R21			RK73GB2A272J	CHIP R	2.7K	J	1/10W	
R22			RK73GB2A470J	CHIP R	47	J	1/10W	
R23			RK73GB2A752J	CHIP R	7.5K	J	1/10W	
R24			RK73GB2A274J	CHIP R	270K	J	1/10W	
R25			RK73GB2A563J	CHIP R	56K	J	1/10W	
R26			RK73GB2A470J	CHIP R	47	J	1/10W	
R27			RK73GB2A103J	CHIP R	10K	J	1/10W	
R28,29			RK73GB2A913J	CHIP R	91K	J	1/10W	
R30			RK73EB2E102J	CHIP R	1.0K	J	1/4W	
R31			RK73EB2E103J	CHIP R	10K	J	1/4W	
R32			RK73EB2E472J	CHIP R	4.7K	J	1/4W	
R33			RK73GB2A104J	CHIP R	100K	J	1/10W	
R34,35			R92-0365-05	CHIP R	1.0K	J	1/2W	
R36			RK73GB2A223J	CHIP R	22K	J	1/10W	
R37,38			RK73FB2B472J	CHIP R	4.7K	J	1/8W	
R39			R92-0366-05	CHIP R	560	J	1W	KK1R1
R39			R92-0366-05	CHIP R	560	J	1W	M1C1X1
R40			RK73GB2A223J	CHIP R	22K	J	1/10W	KK1R1
R40			RK73GB2A223J	CHIP R	22K	J	1/10W	M1C1X1
R41			RK73GB2A103J	CHIP R	10K	J	1/10W	
R42			RK73GB2A223J	CHIP R	22K	J	1/10W	
R43			RK73GB2A104J	CHIP R	100K	J	1/10W	
R44			RK73GB2A223J	CHIP R	22K	J	1/10W	
R45			RK73FB2B561J	CHIP R	560	J	1/8W	
R46			RK73GB2A473J	CHIP R	47K	J	1/10W	
R47			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R50			RK73GB2A104J	CHIP R	100K	J	1/10W	
R100			RK73GB2A104J	CHIP R	100K	J	1/10W	
R101,102			RK73GB2A103J	CHIP R	10K	J	1/10W	
R103-106			RK73GB2A104J	CHIP R	100K	J	1/10W	
R107-109			RK73GB2A101J	CHIP R	100	J	1/10W	
R110			RK73GB2A104J	CHIP R	100K	J	1/10W	
R112-114			RK73GB2A101J	CHIP R	100	J	1/10W	
R115,116			RK73GB2A104J	CHIP R	100K	J	1/10W	
R117			RK73GB2A101J	CHIP R	100	J	1/10W	
R118			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R119			RK73GB2A101J	CHIP R	100	J	1/10W	
R120			RK73GB2A472J	CHIP R	4.7K	J	1/10W	
R123			RK73GB2A473J	CHIP R	47K	J	1/10W	
R125			RK73GB2A223J	CHIP R	22K	J	1/10W	
R126			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R127			RK73GB2A103J	CHIP R	10K	J	1/10W	
R128			RK73GB2A101J	CHIP R	100	J	1/10W	

Ref. No.	Add	New	Parts No.	Description				Destination
R129			RK73GB2A103J	CHIP R	10K	J	1/10W	
R130			RK73GB2A101J	CHIP R	100	J	1/10W	
R131			RK73GB2A103J	CHIP R	10K	J	1/10W	
R132			RK73GB2A101J	CHIP R	100	J	1/10W	
R133			RK73GB2A222J	CHIP R	2.2K	J	1/10W	M1E1E2
R134,135			RK73GB2A104J	CHIP R	100K	J	1/10W	
R136			RK73GB2A101J	CHIP R	100	J	1/10W	
R137-143			RK73GB2A104J	CHIP R	100K	J	1/10W	
R144			RK73GB2A223J	CHIP R	22K	J	1/10W	
R145,146			RK73GB2A104J	CHIP R	100K	J	1/10W	
R147			RK73GB2A101J	CHIP R	100	J	1/10W	
R149			RK73GB2A103J	CHIP R	10K	J	1/10W	
R150			RK73GB2A104J	CHIP R	100K	J	1/10W	
R155			RK73GB2A103J	CHIP R	10K	J	1/10W	K1R1C1
R155			RK73GB2A103J	CHIP R	10K	J	1/10W	X1
R156,157			RK73GB2A103J	CHIP R	10K	J	1/10W	KM1E1
R156,157			RK73GB2A103J	CHIP R	10K	J	1/10W	E2
R157			RK73GB2A103J	CHIP R	10K	J	1/10W	K1R1C1
R157			RK73GB2A103J	CHIP R	10K	J	1/10W	X1
R159			RK73GB2A103J	CHIP R	10K	J	1/10W	K1R1M1
R159			RK73GB2A103J	CHIP R	10K	J	1/10W	E1E2
R160,161			RK73GB2A103J	CHIP R	10K	J	1/10W	KC1X1
R161			RK73GB2A103J	CHIP R	10K	J	1/10W	K1R1M1
R161			RK73GB2A103J	CHIP R	10K	J	1/10W	E1E2
R163			RK73GB2A103J	CHIP R	10K	J	1/10W	KR1M1
R163			RK73GB2A103J	CHIP R	10K	J	1/10W	X1
R164			RK73GB2A103J	CHIP R	10K	J	1/10W	K1C1E1
R164			RK73GB2A103J	CHIP R	10K	J	1/10W	E2
R200			RK73GB2A223J	CHIP R	22K	J	1/10W	
R201			RK73GB2A222J	CHIP R	2.2K	J	1/10W	KK1R1
R201			RK73GB2A222J	CHIP R	2.2K	J	1/10W	M1E1E2
R202,203			RK73GB2A102J	CHIP R	1.0K	J	1/10W	
R204,205			RK73GB2A222J	CHIP R	2.2K	J	1/10W	KK1R1
R204,205			RK73GB2A222J	CHIP R	2.2K	J	1/10W	M1E1E2
R254			RK73GB2A473J	CHIP R	47K	J	1/10W	
R255			RK73GB2A331J	CHIP R	330	J	1/10W	
R256			RK73GB2A154J	CHIP R	150K	J	1/10W	
R257			RK73GB2A222J	CHIP R	2.2K	J	1/10W	
R258			RK73GB2A100J	CHIP R	10	J	1/10W	
R259			RK73GB2A362J	CHIP R	3.6K	J	1/10W	
R300,301			RK73GB2A472J	CHIP R	4.7K	J	1/10W	M1E1E2
R301			RK73GB2A472J	CHIP R	4.7K	J	1/10W	KK1R1
R301			RK73GB2A472J	CHIP R	4.7K	J	1/10W	C1X1
R302			RK73GB2A473J	CHIP R	47K	J	1/10W	
R303			RK73GB2A272J	CHIP R	2.7K	J	1/10W	
R304			RK73GB2A103J	CHIP R	10K	J	1/10W	
R305			RK73GB2A222J	CHIP R	2.2K	J	1/10W	KK1R1
R305			RK73GB2A222J	CHIP R	2.2K	J	1/10W	C1X1
R305,306			RK73GB2A222J	CHIP R	2.2K	J	1/10W	M1E1E2
R359,360			RK73EB2E100J	CHIP R	10	J	1/4W	
R361			RK73EB2E4R7J	CHIP R	4.7	J	1/4W	
R362			RK73EB2E472J	CHIP R	4.7K	J	1/4W	
R363			RK73EB2E101J	CHIP R	100	J	1/4W	
R364-367			RK73EB2E472J	CHIP R	4.7K	J	1/4W	
R368,369			RK73EB2E101J	CHIP R	100	J	1/4W	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X34-315x-xx)

Ref. No.	Add	New	Parts No.	Description	Destination
R400			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R401-404			RK73GB2A750J	CHIP R 75 J 1/10W	
R405,406			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R407			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	
R408,409			RK73EB2E100J	CHIP R 10 J 1/4W	
R452,453			RK73EB2E150J	CHIP R 15 J 1/4W	
R454			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	
R455			RK73GB2A750J	CHIP R 75 J 1/10W	
R456,457			RK73EB2E750J	CHIP R 75 J 1/4W	
R458			RK73EB2E101J	CHIP R 100 J 1/4W	
R459			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R460			RK73EB2E750J	CHIP R 75 J 1/4W	
R461,462			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R463			RK73EB2E101J	CHIP R 100 J 1/4W	
R464,465			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R466			RK73EB2E750J	CHIP R 75 J 1/4W	
R467,468			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R470			RK73GB2A103J	CHIP R 10K J 1/10W	
R500			RK73EB2E100J	CHIP R 10 J 1/4W	
R501			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	
R502			RK73EB2E100J	CHIP R 10 J 1/4W	
R503,504			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R505-507			RK73EB2E101J	CHIP R 100 J 1/4W	
R508,509			RK73EB2E102J	CHIP R 1.0K J 1/4W	
R510-513			RK73GB2A750J	CHIP R 75 J 1/10W	
R550-553			RK73GB2A103J	CHIP R 10K J 1/10W	
R562			RK73GB2A561J	CHIP R 560 J 1/10W	
R563			RK73GB2A334J	CHIP R 330K J 1/10W	
R564			RK73GB2A103J	CHIP R 10K J 1/10W	
R600			RK73GB2A361J	CHIP R 360 J 1/10W	
R601,602			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R603,604			RK73GB2A361J	CHIP R 360 J 1/10W	
R605,606			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R607,608			RK73GB2A361J	CHIP R 360 J 1/10W	
R609,610			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R611			RK73GB2A361J	CHIP R 360 J 1/10W	
R612			RK73EB2E430J	CHIP R 43 J 1/4W	
R616			RK73GB2A361J	CHIP R 360 J 1/10W	
R617			RK73GB2A101J	CHIP R 100 J 1/10W	
R618,619			RK73GB2A223J	CHIP R 22K J 1/10W	
R620			RK73GB2A101J	CHIP R 100 J 1/10W	
R621			RK73GB2A361J	CHIP R 360 J 1/10W	
R622			RK73GB2A750J	CHIP R 75 J 1/10W	
R623,624			RK73EB2E100J	CHIP R 10 J 1/4W	
R625			RK73EB2E4R7J	CHIP R 4.7 J 1/4W	
R630			RK73FB2B223J	CHIP R 22K J 1/8W	
R631			RK73FB2B103J	CHIP R 10K J 1/8W	
R632			RK73FB2B820J	CHIP R 82 J 1/8W	
R635			RK73FB2B820J	CHIP R 82 J 1/8W	
R636			RK73FB2B223J	CHIP R 22K J 1/8W	
R637			RK73FB2B103J	CHIP R 10K J 1/8W	
R638			RK73FB2B223J	CHIP R 22K J 1/8W	
R639			RK73FB2B103J	CHIP R 10K J 1/8W	
R640			RK73FB2B820J	CHIP R 82 J 1/8W	
R643			RK73FB2B820J	CHIP R 82 J 1/8W	
R644			RK73FB2B223J	CHIP R 22K J 1/8W	
R645			RK73FB2B103J	CHIP R 10K J 1/8W	
R646			RK73FB2B223J	CHIP R 22K J 1/8W	
R647			RK73FB2B103J	CHIP R 10K J 1/8W	
R648			RK73FB2B820J	CHIP R 82 J 1/8W	
R651			RK73FB2B820J	CHIP R 82 J 1/8W	
R652			RK73FB2B223J	CHIP R 22K J 1/8W	
R653			RK73FB2B103J	CHIP R 10K J 1/8W	
R900			RK73GB2A222J	CHIP R 2.2K J 1/10W	
R901			RK73GB2A332J	CHIP R 3.3K J 1/10W	
R902			RK73GB2A272J	CHIP R 2.7K J 1/10W	
R903			RK73GB2A123J	CHIP R 12K J 1/10W	
R904			RK73GB2A823J	CHIP R 82K J 1/10W	M1E1E2
R905,906			RK73GB2A103J	CHIP R 10K J 1/10W	M1E1E2
R907			RK73GB2A104J	CHIP R 100K J 1/10W	M1E1E2
R908			RK73GB2A103J	CHIP R 10K J 1/10W	M1E1E2
R909			RK73GB2A153J	CHIP R 15K J 1/10W	M1E1E2
R910			RK73GB2A103J	CHIP R 10K J 1/10W	M1E1E2
R911			RK73GB2A562J	CHIP R 5.6K J 1/10W	M1E1E2
R912,913			RK73GB2A103J	CHIP R 10K J 1/10W	M1E1E2
R914			RK73GB2A333J	CHIP R 33K J 1/10W	M1E1E2
R915			RK73GB2A103J	CHIP R 10K J 1/10W	M1E1E2
R916			RK73GB2A272J	CHIP R 2.7K J 1/10W	M1E1E2
R917			RK73GB2A222J	CHIP R 2.2K J 1/10W	M1E1E2
R918,919			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R920			RK73GB2A103J	CHIP R 10K J 1/10W	
W1			R92-2053-05	CHIP R 0 J 1/8W	
W33			R92-1252-05	CHIP R 0 OHM J 1/16W	E1E2
W102			R92-1252-05	CHIP R 0 OHM J 1/16W	
W251			R92-2053-05	CHIP R 0 J 1/8W	
W252			R92-1252-05	CHIP R 0 OHM J 1/16W	
W454			R92-1252-05	CHIP R 0 OHM J 1/16W	
W500-505			R92-1252-05	CHIP R 0 OHM J 1/16W	KK1R1
W500-505			R92-1252-05	CHIP R 0 OHM J 1/16W	M1C1X1
W900			R92-1252-05	CHIP R 0 OHM J 1/16W	M1E1E2
D1			MA8056-M	ZENER DIODE	
D4			MA8056-M	ZENER DIODE	
D5			RM10ZLF	DIODE	
D6			1SR154-400	DIODE	E1E2
D6,7			1SR154-400	DIODE	KK1R1
D6,7			1SR154-400	DIODE	M1C1X1
D8			DAP202U	DIODE	
D9,10			1SR154-400	DIODE	
D11			MA8068-M	ZENER DIODE	
D12			MA8056-M	ZENER DIODE	
D13			MA8047-M	ZENER DIODE	
D200			IMSA-6801	SURGE ABSORBER	
D250			DAP202U	DIODE	
D350			RD6.8MW	ZENER DIODE	
D351			MA8062-M	ZENER DIODE	
D352-355			MA3062WA	ZENER DIODE	
D400			MA8062-M	ZENER DIODE	
D401			MA3062WA	ZENER DIODE	
D402			MA8062-M	ZENER DIODE	
D403			RD6.8MW	ZENER DIODE	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

ELECTRIC UNIT (X34-315x-xx)

Ref. No.	Add	New	Parts No.	Description	Destination
D404,405			DA204U	DIODE	
D451			MA8062-M	ZENER DIODE	
D452			RD6.8MW	ZENER DIODE	
D453-456			DA204U	DIODE	
D457-461			MA3062WA	ZENER DIODE	
D462			DAN202U	DIODE	
D500,501			MA8062-M	ZENER DIODE	
D502			RD6.8MW	ZENER DIODE	
D503-505			MA3062WA	ZENER DIODE	
D506-511			DA204U	DIODE	E1E2
D507			DA204U	DIODE	KK1R1
D507			DA204U	DIODE	M1C1X1
D509			DA204U	DIODE	KK1R1
D509			DA204U	DIODE	M1C1X1
D511			DA204U	DIODE	KK1R1
D511			DA204U	DIODE	M1C1X1
D550-556			DA204U	DIODE	
D602			DAP202U	DIODE	
D605			DAP202U	DIODE	
D606			RD6.8MW	ZENER DIODE	
D607			MA8062-M	ZENER DIODE	
D901			DAN202U	DIODE	M1E1E2
D902			MA8110-M	ZENER DIODE	
IC1			M5237ML	ANALOGUE IC	
IC3			M5237ML	ANALOGUE IC	
IC4			ICL7660SIBA	ANALOGUE IC	
IC100		✻	HD74HC02FP-E	MOS-IC	
IC101			S-80842CNNB	MOS-IC	
IC103		✻	70F3089YGJ-7R7	MICROCONTROLLER IC	
IC200			TDA7479D	ANALOGUE IC	KK1R1
IC200			TDA7479D	ANALOGUE IC	M1E1E2
IC250			TB2903H	ANALOGUE IC	
IC300			TDA7401	ANALOGUE IC	
IC301			E-TDA7414	ANALOGUE IC	
IC350			BA3121F	ANALOGUE IC	
IC400			TC7SH08FU	MOS-IC	
IC450,451			NJM2267V	ANALOGUE IC	
IC452			TC7SH14FU	MOS-IC	
IC500			BA3121F	ANALOGUE IC	
IC501			MM1234XFBE	ANALOGUE IC	E1E2
IC550		✻	TC4052BFT	MOS-IC	
IC551		✻	MM1503	ANALOGUE IC	
IC552			MM1108XFFE	ANALOGUE IC	
IC553			BA7652AF	ANALOGUE IC	
IC554		✻	TC4052BFT	MOS-IC	
IC555			BA7612F	ANALOGUE IC	
IC600			BA3121F	ANALOGUE IC	
IC602-604			NJM4565M-TE2	ANALOGUE IC	
IC900			NJM4565M-TE2	ANALOGUE IC	M1E1E2
Q1			2SC4081	TRANSISTOR	
Q2			2SB1443	TRANSISTOR	
Q3			2SA1576A	TRANSISTOR	
Q4,5			UMC2N	TRANSISTOR	
Q6			2SB1565	TRANSISTOR	
Q8			UMC2N	TRANSISTOR	
Q9			DTC114EUA	DIGITAL TRANSISTOR	
Q10			2SB1565	TRANSISTOR	
Q11			2SB1443	TRANSISTOR	
Q12			2SC4081	TRANSISTOR	
Q13			2SA1576A	TRANSISTOR	
Q14			2SC4081	TRANSISTOR	
Q15			2SA1576A	TRANSISTOR	
Q16			2SC4081	TRANSISTOR	
Q17			2SA1576A	TRANSISTOR	
Q18			2SC4081	TRANSISTOR	
Q19			DTC124EUA	DIGITAL TRANSISTOR	
Q20,21			DTC114YUA	DIGITAL TRANSISTOR	KK1R1
Q20,21			DTC114YUA	DIGITAL TRANSISTOR	M1C1X1
Q21			DTC114YUA	DIGITAL TRANSISTOR	E1E2
Q22			DTA114EUA	DIGITAL TRANSISTOR	
Q23,24			2SB1188(Q,R)	TRANSISTOR	KK1R1
Q23,24			2SB1188(Q,R)	TRANSISTOR	M1C1X1
Q24			2SB1188(Q,R)	TRANSISTOR	E1E2
Q25			2SA1576A	TRANSISTOR	
Q26			2SC4081	TRANSISTOR	
Q27			DTA123JK	DIGITAL TRANSISTOR	
Q100			DTA124EUA	DIGITAL TRANSISTOR	
Q200			DTC124EUA	DIGITAL TRANSISTOR	
Q201			2SB1188(Q,R)	TRANSISTOR	
Q300			2SD1819A	TRANSISTOR	M1E1E2
Q301			DTC124EUA	DIGITAL TRANSISTOR	
Q551-554			DTC124EUA	DIGITAL TRANSISTOR	
Q600-602			DTC323TU	DIGITAL TRANSISTOR	
Q603			2SA1576A	TRANSISTOR	
Q604-606			DTC323TU	DIGITAL TRANSISTOR	
Q608			DTC323TU	DIGITAL TRANSISTOR	
Q609			DTA124EUA	DIGITAL TRANSISTOR	
Q610			DTC323TU	DIGITAL TRANSISTOR	
Q900			2SB1189	TRANSISTOR	
Q901			2SC4081	TRANSISTOR	
Q902			2SA1576A	TRANSISTOR	
Q903			2SC4081	TRANSISTOR	KK1R1
Q903			2SC4081	TRANSISTOR	C1X1
Q903,904			2SC4081	TRANSISTOR	M1E1E2
Q905			DTC114EUA	DIGITAL TRANSISTOR	M1E1E2
Q906			DTA124EUA	DIGITAL TRANSISTOR	M1E1E2
TH250		✻	PRF18BE471QB2	POSITIVE RESISTOR	
A1			W02-3416-05	FM/AM FRONT-END	KK1R1
A1			W02-3416-05	FM/AM FRONT-END	C1X1
A1			W02-3417-05	FM/AM FRONT-END	M1E1E2

VIDEO UNIT (X35-4280-01)

C1,2			CK73DF1E106Z	CHIP C	10UF	Z	
C3			C93-1281-05	CHIP C	0.47UF	K	
C5			C93-1273-05	CHIP C	15PF	J	
C6			C93-1278-05	CHIP C	0.018UF	K	
C7			CK73GB1E473K	CHIP C	0.047UF	K	
C8			C93-1269-05	CHIP C	220PF	J	
C9			CK73GB0J225K	CHIP C	2.2UF	K	
C10			CK73GB1H103K	CHIP C	0.010UF	K	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

VIDEO UNIT (X35-4280-01)

Ref. No.	Add	New	Parts No.	Description			Destination
C11			CK73GB0J225K	CHIP C	2.2UF	K	
C13			CK73GB1A474K	CHIP C	0.47UF	K	
C14			CK73HB1C103K	CHIP C	0.010UF	K	
C15			CK73GB1E473K	CHIP C	0.047UF	K	
C16			CK73HB1C183K	CHIP C	0.018UF	K	
C17			CK73HB1C103K	CHIP C	0.010UF	K	
C18			C93-1281-05	CHIP C	0.47UF	K	
C21			CK73GB0J225K	CHIP C	2.2UF	K	
C22			CK73HB1H152K	CHIP C	1500PF	K	
C23			CK73DF1E106Z	CHIP C	10UF	Z	
C24			CK73GB1H103K	CHIP C	0.010UF	K	
C25			C93-1270-05	CHIP C	3300PF	K	
C26			CK73GB1H103K	CHIP C	0.010UF	K	
C101			CK73GB1H104K	CHIP C	0.10UF	K	
C102			CK73DF1C106Z	CHIP C	10UF	Z	
C103			CK73GB1H103K	CHIP C	0.010UF	K	
C104			C93-1210-05	CHIP C	10UF	K	
C105			CE32AU1C390M	CHIP EL	39UF	16WV	
C106			CK73GB1H103K	CHIP C	0.010UF	K	
C107			C93-1210-05	CHIP C	10UF	K	
C108			CE32AU1C390M	CHIP EL	39UF	16WV	
C109			CK73FB1C105K	CHIP C	1.0UF	K	
C110			CK73GB1H103K	CHIP C	0.010UF	K	
C111			C93-1210-05	CHIP C	10UF	K	
C112			CK73FB1E154K	CHIP C	0.15UF	K	
C113			CK73EB1C225K	CHIP C	2.2UF	K	
C114			CK73FB1C224K	CHIP C	0.22UF	K	
C115			CK73GB1H104K	CHIP C	0.10UF	K	
C116			CE32BB0J221M	CHIP EL	220UF	6.3WV	
C118			CK73GB1H103K	CHIP C	0.010UF	K	
C211			CK73EB1A475K	CHIP C	4.7UF	K	
C230			CK73GB1H103K	CHIP C	0.010UF	K	
C231,232			CK73DF1E106Z	CHIP C	10UF	Z	
C233			CK73GB1H103K	CHIP C	0.010UF	K	
C234			CC73HCH1H560J	CHIP C	56PF	J	
C301,302			CK73DF1E106Z	CHIP C	10UF	Z	
C303			CK73GB1H103K	CHIP C	0.010UF	K	
C304			CK73GB1H104K	CHIP C	0.10UF	K	
C305,306			CK73GB1H103K	CHIP C	0.010UF	K	
C307			CE32BB0J221M	CHIP EL	220UF	6.3WV	
C308			CK73GB1H103K	CHIP C	0.010UF	K	
C309			CC73HCH1H100D	CHIP C	10PF	D	
C310			CK73HB1H561K	CHIP C	560PF	K	
C311			CK73HB1C103K	CHIP C	0.010UF	K	
C312			CK73GB1H103K	CHIP C	0.010UF	K	
C313,314			CK73HB1C103K	CHIP C	0.010UF	K	
C315,316			CK73GB1H104K	CHIP C	0.10UF	K	
C317			CK73HB1C103K	CHIP C	0.010UF	K	
C318,319			CK73GB1H104K	CHIP C	0.10UF	K	
C320			CC73HCH1H560J	CHIP C	56PF	J	
C321			CK73GB1H104K	CHIP C	0.10UF	K	
C322			CC73GCH1E102J	CHIP C	1000PF	J	
C323			CC73HCH1H101J	CHIP C	100PF	J	
C324,325			CK73HB1C103K	CHIP C	0.010UF	K	
C326			CC73GCH1H681J	CHIP C	680PF	J	
C327,328			CK73GB1H104K	CHIP C	0.10UF	K	
C329			CC73HCH1H390J	CHIP C	39PF	J	
C330			CE32BB0J221M	CHIP EL	220UF	6.3WV	
C331,332			CC73HCH1H390J	CHIP C	39PF	J	
C333			CK73GB1H104K	CHIP C	0.10UF	K	
C334			CK73GB1H103K	CHIP C	0.010UF	K	
C335,336			CK73GB1H104K	CHIP C	0.10UF	K	
C338			CK73DF1C106Z	CHIP C	10UF	Z	
C339			CK73HB1C103K	CHIP C	0.010UF	K	
C401			CK73HB1H102K	CHIP C	1000PF	K	
C421,422			CK73FB1C105K	CHIP C	1.0UF	K	
C423			CK73EB0J106K	CHIP C	10UF	K	
C424			CK73HB1C103K	CHIP C	0.010UF	K	
C425			CK73FB1C105K	CHIP C	1.0UF	K	
C426			CK73EB1E105K	CHIP C	1.0UF	K	
C427			CK73FB1A225K	CHIP C	2.2UF	K	
C428			CK73EB0J106K	CHIP C	10UF	K	
C501-503			CK73HB1C103K	CHIP C	0.010UF	K	
C504			CK73EB0J106K	CHIP C	10UF	K	
C505			CK73HB1H271K	CHIP C	270PF	K	
CN1			E40-9797-05	PIN ASSY			
CN301			E41-0341-05	FLAT CABLE CONNECTOR			
CN302			E41-0133-05	FLAT CABLE CONNECTOR			
CN303			E41-0404-05	FLAT CABLE CONNECTOR			
CN304			E40-9623-05	FLAT CABLE CONNECTOR			
CN305			E40-9708-05	PIN ASSY			
CN501			E41-2087-05	FLAT CABLE CONNECTOR			
CN502			E41-0133-05	FLAT CABLE CONNECTOR			
CN503			E41-0455-05	FLAT CABLE CONNECTOR			
CN601			E41-0340-05	FLAT CABLE CONNECTOR			
F1			F53-0251-05	FUSE			
CF308			L72-0786-05	CERAMIC FILTER			
L1			L19-0727-05	TRANSFORMER FOR CONVERTER			
L101,102			L41-3392-13	SMALL FIXED INDUCTOR			
L103			L41-4792-13	SMALL FIXED INDUCTOR			
L104-106			L40-1001-78	SMALL FIXED INDUCTOR (10UH)			
L301-303			L79-0982-05	LC FILTER			
L306			L40-5695-34	SMALL FIXED INDUCTOR (5.6UH)			
L309			L79-0982-05	LC FILTER			
L401			L40-1001-78	SMALL FIXED INDUCTOR (10UH)			
L501			L40-1001-78	SMALL FIXED INDUCTOR (10UH)			
CP301,302			R90-1094-05	MULTI-COMP	1K X4		
CP303			R90-1524-05	MULTI-COMP	220 X4		
R1			RK73HB1J512J	CHIP R	5.1K	J 1/16W	
R3			RK73HB1J220J	CHIP R	22	J 1/16W	
R4			RN73GH1J153D	CHIP R	15K	D 1/16W	
R5			RK73HB1J153J	CHIP R	15K	J 1/16W	
R6			RN73GH1J623D	CHIP R	62K	D 1/16W	
R7			RK73HB1J220J	CHIP R	22	J 1/16W	
R8			RK73HB1J512J	CHIP R	5.1K	J 1/16W	
R9		✻	RK73GH2A244D	CHIP R	240K	D 1/10W	
R10			RK73HB1J331J	CHIP R	330	J 1/16W	
R11			RK73HB1J220J	CHIP R	22	J 1/16W	
R12			RK73HB1J105J	CHIP R	1.0M	J 1/16W	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

VIDEO UNIT (X35-4280-01)

Ref. No.	Add	New	Parts No.	Description	Destination
R13			RK73HB1J220J	CHIP R 22 J 1/16W	
R14			RN73GH1J4220D	CHIP R 422.0 D 1/16W	
R15			RN73GH1J513D	CHIP R 51K D 1/16W	
R16,17			RK73HB1J220J	CHIP R 22 J 1/16W	
R18			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R101		✻	RK73GH2A104D	CHIP R 100K D 1/10W	
R102			RK73GH2A113D	CHIP R 11K D 1/10W	
R103		✻	RK73GH2A184D	CHIP R 180K D 1/10W	
R104		✻	RK73GH2A133D	CHIP R 13K D 1/10W	
R105			RK73HB1J473J	CHIP R 47K J 1/16W	
R106			RK73HB1J103J	CHIP R 10K J 1/16W	
R218			RK73HB1J222J	CHIP R 2.2K J 1/16W	
R219			RK73HB1J513J	CHIP R 51K J 1/16W	
R234			RN73GH1J472D	CHIP R 4.7K D 1/16W	
R235			RN73GH1J912D	CHIP R 9.1K D 1/16W	
R236			RN73GH1J222D	CHIP R 2.2K D 1/16W	
R239			RK73HB1J123J	CHIP R 12K J 1/16W	
R240			RK73HB1J220J	CHIP R 22 J 1/16W	
R241			RK73HB1J123J	CHIP R 12K J 1/16W	
R242			RK73HB1J220J	CHIP R 22 J 1/16W	
R253			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R305			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R307			RK73HB1J101J	CHIP R 100 J 1/16W	
R308			RK73HB1J621J	CHIP R 620 J 1/16W	
R311			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R313			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R314,315			RK73HB1J103J	CHIP R 10K J 1/16W	
R316			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R318			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R320			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R321			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R323			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R324,325			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R326			RK73HB1J473J	CHIP R 47K J 1/16W	
R327			RK73HB1J683J	CHIP R 68K J 1/16W	
R328			RK73HB1J153J	CHIP R 15K J 1/16W	
R329			RK73HB1J101J	CHIP R 100 J 1/16W	
R330			RK73HB1J182J	CHIP R 1.8K J 1/16W	
R331			RK73HB1J331J	CHIP R 330 J 1/16W	
R332			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R333-335			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R337,338			RK73HB1J101J	CHIP R 100 J 1/16W	
R339			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R340-344			RK73HB1J101J	CHIP R 100 J 1/16W	
R345			RK73HB1J683J	CHIP R 68K J 1/16W	
R346			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R347			RK73HB1J153J	CHIP R 15K J 1/16W	
R348			RK73HB1J362J	CHIP R 3.6K J 1/16W	
R349			RK73HB1J103J	CHIP R 10K J 1/16W	
R350-352			RK73HB1J101J	CHIP R 100 J 1/16W	
R353			RK73HB1J100J	CHIP R 10 J 1/16W	
R359,360			RK73HB1J100J	CHIP R 10 J 1/16W	
R361			RK73GB2A562J	CHIP R 5.6K J 1/10W	
R362			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R368,369			RK73HB1J000J	CHIP R 0.0 J 1/16W	

Ref. No.	Add	New	Parts No.	Description	Destination
R371			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R373,374			RK73HB1J561J	CHIP R 560 J 1/16W	
R401			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R402			RK73HB1J432J	CHIP R 4.3K J 1/16W	
R403			RK73HB1J912J	CHIP R 9.1K J 1/16W	
R404			RK73HB1J303J	CHIP R 30K J 1/16W	
R421			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R422			RK73HB1J473J	CHIP R 47K J 1/16W	
R423			RK73HB1J104J	CHIP R 100K J 1/16W	
R441			RK73GB2A681J	CHIP R 680 J 1/10W	
R451,452			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R453			RK73GB2A681J	CHIP R 680 J 1/10W	
R454			RK73GB2A331J	CHIP R 330 J 1/10W	
R455			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R456			RK73GB2A331J	CHIP R 330 J 1/10W	
R501,502			RK73HB1J333J	CHIP R 33K J 1/16W	
R503-506			RK73EB2E100J	CHIP R 10 J 1/4W	
R641			RK73GB2A621J	CHIP R 620 J 1/10W	
R642			RK73HB1J391J	CHIP R 390 J 1/16W	
R651			RK73HB1J000J	CHIP R 0.0 J 1/16W	
R652			RK73FB2B471J	CHIP R 470 J 1/8W	
R654			RK73GB2A301J	CHIP R 300 J 1/10W	
VR203			R32-0235-05	SEMI FIXED VARIABLE RESISTOR	
VR301			R32-0245-05	SEMI FIXED VARIABLE RESISTOR	
W107			R92-2052-05	CHIP R 0 OHM J 1/10W	
W216,217			R92-2052-05	CHIP R 0 OHM J 1/10W	
W301-304			R92-1252-05	CHIP R 0 OHM J 1/16W	
W310			R92-1252-05	CHIP R 0 OHM J 1/16W	
W354-358			R92-1252-05	CHIP R 0 OHM J 1/16W	
S401-404			S70-0856-05	TACT SWITCH	
S601-603			S70-0856-05	TACT SWITCH	
D1,2			MA8047-M	ZENER DIODE	
D3			MA115	DIODE	
D4,5			DA204U	DIODE	
D6			MA2S784	DIODE	
D7			MA8056-M	ZENER DIODE	
D8			1608SGXA	ZENER DIODE	
D9			DA204U	DIODE	
D10			AVRM1005270MAA	VARISTOR	
D101			MA2ZD18	DIODE	
D102-104			MA2S784	DIODE	
D301			MA8051-M	ZENER DIODE	
D302,303			DA204U	DIODE	
D304			MA8051-M	ZENER DIODE	
D309			1SV231	VARIABLE CAPACITANCE DIODE	
D310-313			1608SGXA	ZENER DIODE	
D314			DA204U	DIODE	
D401			1608SGXA	ZENER DIODE	
D403-410			AVRM1608180M6A	VARISTOR	
D501-504			MA8068-M	ZENER DIODE	
IC1			OZ960IS-C	ANALOGUE IC	
IC101			LT1947	ANALOGUE IC	
IC203			TA75W558FU	ANALOGUE IC	
IC301			TC200G02AF0104	MOS-IC	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1**: KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
IC302			TC7SH08FU	MOS-IC	
IC303			NJM2107F	ANALOGUE IC	
IC304			TC7WH14FU	MOS-IC	
IC401			TPS850	ANALOGUE IC	
Q1			2SC4081	TRANSISTOR	
Q2,3			SI5513DC	DUAL FET	
Q5			2SC4081	TRANSISTOR	
Q201			IMZ1A	DUAL TRANSISTOR	
Q202			2SD601A	TRANSISTOR	
Q203			2SB709A	TRANSISTOR	
Q301			2SC4097	TRANSISTOR	
Q501			DTC124EE	DIGITAL TRANSISTOR	
Q502,503			PUMD13	DUAL TRANSISTOR	
Q601			DTC124EE	DIGITAL TRANSISTOR	
DVD PLAYER UNIT (X37-1020-04)					
C1			CK73FB0J106M	CHIP C 10UF M	
C2			CK73HB1A104K	CHIP C 0.10UF K	
C3,4			CK73FB0J106M	CHIP C 10UF M	
C5			CK73HB1A104K	CHIP C 0.10UF K	
C6			CC73HCH1E221J	CHIP C 220PF J	
C7			CK73HB1A104K	CHIP C 0.10UF K	
C8			CK73FB0J106M	CHIP C 10UF M	
C9,10			CK73HB1A104K	CHIP C 0.10UF K	
C11			CK73HB1H332K	CHIP C 3300PF K	
C12			CK73HB1A104K	CHIP C 0.10UF K	
C13			CK73FB0J106M	CHIP C 10UF M	
C14			C92-1792-05	CHIP C 22UF M	
C15			CK73HB1C103K	CHIP C 0.010UF K	
C17			CC73GCH1H471J	CHIP C 470PF J	
C18			CK73HB1A104K	CHIP C 0.10UF K	
C19			CC73GCH1H471J	CHIP C 470PF J	
C20			CK73HB1A333K	CHIP C 0.033UF K	
C21			CK73HB1A473K	CHIP C 0.047UF K	
C22-24			CK73HB1A104K	CHIP C 0.10UF K	
C25,26			C93-1215-05	CHIP C 10UF M	
C27			CK73HB1A104K	CHIP C 0.10UF K	
C31			C92-1685-05	CHIP C 47UF M	
C32,33			CC73GCH1E102J	CHIP C 1000PF J	
C34,35			CC73GCH1H681J	CHIP C 680PF J	
C36			CK73HB1H222K	CHIP C 2200PF K	
C37			CC73GCH1H331J	CHIP C 330PF J	
C38,39			CK73HB1C103K	CHIP C 0.010UF K	
C40,41			CK73HB1A104K	CHIP C 0.10UF K	
C42			CK73HB1C223K	CHIP C 0.022UF K	
C43			CC73HCH1H470J	CHIP C 47PF J	
C44			CC73GCH1H681J	CHIP C 680PF J	
C45			CK73HB1E682K	CHIP C 6800PF K	
C46			CK73HB1A104K	CHIP C 0.10UF K	
C47			CC73GCH1E102J	CHIP C 1000PF J	
C48-50			CK73HB1A104K	CHIP C 0.10UF K	
C51			C93-1271-05	CHIP C 0.10UF M	
C52-55			CK73HB1A104K	CHIP C 0.10UF K	
C56,57			C93-1271-05	CHIP C 0.10UF M	
C58-60			CK73HB1A104K	CHIP C 0.10UF K	
C62			CK73HB1A104K	CHIP C 0.10UF K	

VIDEO UNIT (X35-4280-01)

Ref. No.	Add	New	Parts No.	Description	Destination
C63			C93-1271-05	CHIP C 0.10UF M	
C64,65			CK73HB1C103K	CHIP C 0.010UF K	
C67			CC73HCH1H220J	CHIP C 22PF J	
C68			CC73HCH1H150J	CHIP C 15PF J	
C69-73			CK73HB1A104K	CHIP C 0.10UF K	
C74			CK73EB1A106K	CHIP C 10UF K	
C75,76			CK73HB1C103K	CHIP C 0.010UF K	
C77			CK73HB1A104K	CHIP C 0.10UF K	
C78			CC73GCH1H331J	CHIP C 330PF J	
C79-81			CK73HB1C103K	CHIP C 0.010UF K	
C82			CK73HB1A104K	CHIP C 0.10UF K	
C83			CC73HCH1E221J	CHIP C 220PF J	
C84			CC73HCH1H101J	CHIP C 100PF J	
C85			C92-1684-05	CHIP C 82UF M	
C87,88			CK73HB1C103K	CHIP C 0.010UF K	
C89			CK73FB0J106M	CHIP C 10UF M	
C90-95			CK73HB1A104K	CHIP C 0.10UF K	
C96			CK73GB1A224K	CHIP C 0.22UF K	
C97,98			CK73HB1A104K	CHIP C 0.10UF K	
C99			C92-1685-05	CHIP C 47UF M	
C100			CK73GB0J105K	CHIP C 1.0UF K	
C101			CK73HB1C103K	CHIP C 0.010UF K	
C102			CK73FB0J106M	CHIP C 10UF M	
C103			CK73FB1A225K	CHIP C 2.2UF K	
C104			CK73HB1A104K	CHIP C 0.10UF K	
C106			CK73HB1A104K	CHIP C 0.10UF K	
C107			CK73GB0J105K	CHIP C 1.0UF K	
C108			C93-1228-05	CHIP C 1.0UF M	
C110-113			CC73HCH1H470J	CHIP C 47PF J	
C114,115			CK73FB1A225K	CHIP C 2.2UF K	
C116			CK73GB1A224K	CHIP C 0.22UF K	
C117			CK73HB1C223K	CHIP C 0.022UF K	
C119			CK73EB0J226K	CHIP C 22UF K	
C123			CC73HCH1H470J	CHIP C 47PF J	
C125-134			CK73HB1C103K	CHIP C 0.010UF K	
C135,136			CC73HCH1H050C	CHIP C 5.0PF C	
C137			CK73HB1H102K	CHIP C 1000PF K	
C138			CK73EB1A106K	CHIP C 10UF K	
CN1			E41-0273-05	FLAT CABLE CONNECTOR (30PIN)	
CN2			E41-0271-05	FLAT CABLE CONNECTOR (4PIN)	
CN3			E41-0272-05	FLAT CABLE CONNECTOR (11PIN)	
CN4			E41-0312-05	FLAT CABLE CONNECTOR (50PIN)	
CN5			E41-0335-05	FLAT CABLE CONNECTOR (4PIN)	
L1			L92-0365-05	CHIP FERRITE	
L2			L92-0329-05	CHIP FERRITE	
L3-8			L92-0365-05	CHIP FERRITE	
L10-13			L92-0365-05	CHIP FERRITE	
L16-18			L92-0365-05	CHIP FERRITE	
L21-27			L92-0365-05	CHIP FERRITE	
L28			L92-0375-05	CHIP FERRITE	
X1			L77-2808-05	CRYSTAL RESONATOR (16.897849MHZ)	
CP1			RK74HB1J102J	CHIP-COM 1.0K J 1/16W	
CP3			RK74HB1J472J	CHIP-COM 4.7K J 1/16W	
CP4-8			RK74HB1J220J	CHIP-COM 22 J 1/16W	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

DVD PLAYER UNIT (X37-1020-04)

Ref. No.	Add	New	Parts No.	Description	Destination
CP9			RK74HB1J820J	CHIP-COM 82 J 1/16W	
CP11			R90-0726-05	MULTI-COMP 10K X2	
CP12			RK74HB1J472J	CHIP-COM 4.7K J 1/16W	
CP13-16			RK74HB1J103J	CHIP-COM 10K J 1/16W	
R3,4			RK73GH1J103D	CHIP R 10K D 1/16W	
R5			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R6			RK73GB2A100J	CHIP R 10 J 1/10W	
R7,8			RK73HB1J273J	CHIP R 27K J 1/16W	
R9			RK73GH1J223D	CHIP R 22K D 1/16W	
R10			RK73GH1J392D	CHIP R 3.9K D 1/16W	
R11			RK73GH1J183D	CHIP R 18K D 1/16W	
R12			RK73GB2A4R7J	CHIP R 4.7 J 1/10W	
R13,14			RK73HB1J125J	CHIP R 1.2M J 1/16W	
R15			RK73GB2A200J	CHIP R 20 J 1/10W	
R16			R92-3409-05	CHIP R 6.8 F 1/4W	
R17			R92-3350-05	CHIP R 2.2 F 1/10W	
R18			RK73GH1J221D	CHIP R 220 D 1/16W	
R19			RK73HB1J100J	CHIP R 10 J 1/16W	
R27,28			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R29			RK73HB1J103J	CHIP R 10K J 1/16W	
R30			RK73HB1J473J	CHIP R 47K J 1/16W	
R31			RK73HB1J102J	CHIP R 1.0K J 1/16W	
R32			RK73GH1J153D	CHIP R 15K D 1/16W	
R33			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R36			RK73HB1J103J	CHIP R 10K J 1/16W	
R37			RK73HB1J273J	CHIP R 27K J 1/16W	
R38			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R39			RK73HB1J273J	CHIP R 27K J 1/16W	
R40			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R41			RK73HB1J103J	CHIP R 10K J 1/16W	
R42			RK73HB1J105J	CHIP R 1.0M J 1/16W	
R43			RK73HB1J152J	CHIP R 1.5K J 1/16W	
R44			RK73HB1J202J	CHIP R 2.0K J 1/16W	
R45			RK73GH1J183D	CHIP R 18K D 1/16W	
R46			RK73GB2A752J	CHIP R 7.5K J 1/10W	
R47			RK73GH1J103D	CHIP R 10K D 1/16W	
R48			R92-3353-05	CHIP R 1.0K F 1/8W	
R53			R92-3353-05	CHIP R 1.0K F 1/8W	
R54			R92-3348-05	CHIP R 0.47 F 1/2W	
R55,56			RK73GB2A820J	CHIP R 82 J 1/10W	
R57			RK73GB2A391J	CHIP R 390 J 1/10W	
R58,59			RK73GB2A103J	CHIP R 10K J 1/10W	
R60			RK73GB2A472J	CHIP R 4.7K J 1/10W	
R61			RK73GB2A153J	CHIP R 15K J 1/10W	
R62,63			RK73GH1J153D	CHIP R 15K D 1/16W	
R64			RK73GH1J303D	CHIP R 30K D 1/16W	
R65			RK73GH1J183D	CHIP R 18K D 1/16W	
R66,67			RK73GH1J153D	CHIP R 15K D 1/16W	
R68			RK73GH1J513D	CHIP R 51K D 1/16W	
R71			RK73GH1J202D	CHIP R 2.0K D 1/16W	
R72			RK73GH1J123D	CHIP R 12K D 1/16W	
R73			RK73HB1J103J	CHIP R 10K J 1/16W	
R74			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R75-79			RK73HB1J132J	CHIP R 1.3K J 1/16W	
R80-83			RK73HB1J103J	CHIP R 10K J 1/16W	

Ref. No.	Add	New	Parts No.	Description	Destination
R88			RK73HB1J103J	CHIP R 10K J 1/16W	
R89			RK73HB1J820J	CHIP R 82 J 1/16W	
R90			RK73HB1J103J	CHIP R 10K J 1/16W	
R91			RK73HB1J220J	CHIP R 22 J 1/16W	
R92			RK73HB1J820J	CHIP R 82 J 1/16W	
R93			RK73HB1J103J	CHIP R 10K J 1/16W	
R94,95			RK73HB1J820J	CHIP R 82 J 1/16W	
R101			RK73HB1J103J	CHIP R 10K J 1/16W	
R103-106			RK73HB1J220J	CHIP R 22 J 1/16W	
R107,108			RK73HB1J103J	CHIP R 10K J 1/16W	
R109			RK73HB1J332J	CHIP R 3.3K J 1/16W	
R110			RK73HB1J473J	CHIP R 47K J 1/16W	
R111			RK73GB2A150J	CHIP R 15 J 1/10W	
R112,113			RK73HB1J221J	CHIP R 220 J 1/16W	
R114			RK73HB1J220J	CHIP R 22 J 1/16W	
R117			RK73GB2A752J	CHIP R 7.5K J 1/10W	
R119,120			RK73HB1J510J	CHIP R 51 J 1/16W	
R121,122			RK73HB1J103J	CHIP R 10K J 1/16W	
R123			R92-3385-05	CHIP R 8.2 F 1/10W	
R124			RK73HB1J103J	CHIP R 10K J 1/16W	
R126,127			RK73HB1J104J	CHIP R 100K J 1/16W	
R128,129			RK73HB1J472J	CHIP R 4.7K J 1/16W	
R130			RK73HB1J751J	CHIP R 750 J 1/16W	
R131-143			RK73HB1J103J	CHIP R 10K J 1/16W	
W1-3			R92-1252-05	CHIP R 0 OHM J 1/16W	
S4			S68-0874-05	PUSH SWITCH	
S5			S68-0866-05	PUSH SWITCH	
D1,2			MAZS0510M	ZENER DIODE	
D3-5			MA2J729	DIODE	
D6			MAZS0560M	ZENER DIODE	
D7			MA4ZD03	DIODE	
D8			MA142WA	DIODE	
IC1			AN8703FH	ANALOGUE IC	
IC2			NJU7042	ANALOGUE IC	
IC4			MN103S26E	MOS-IC	
IC4			MN103S26E2	MOS-IC	
IC5			S-80829CLBB	ANALOGUE IC	
IC6			LA6505	ANALOGUE IC	
IC7			DF2328VTE250S0	MICROCONTROLLER IC	
IC8			S-80815CLBB	ANALOGUE IC	
IC9			UPC2918T	ANALOGUE IC	
IC10			NJM2880U33	ANALOGUE IC	
IC11			S-24C04BMFN	MEMORY IC	
IC12			HD74LV2G66A	MOS-IC	
Q1			2SB0970	TRANSISTOR	
Q2			MCH6101-E	TRANSISTOR	
Q3			2SJ0536	FET	
Q4			UN5114	DIGITAL TRANSISTOR	
Q5			UN5214	DIGITAL TRANSISTOR	
Q6			2SD1819A	TRANSISTOR	
Q9			UN5114	DIGITAL TRANSISTOR	
Q10			UN5214	DIGITAL TRANSISTOR	
Q13			UN5114	DIGITAL TRANSISTOR	
Q15			UN5114	DIGITAL TRANSISTOR	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1**: KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.

PARTS LIST

✻ New parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No.	Add	New	Parts No.	Description	Destination
TH1			TH11-3H103FT	THERMISTOR	
COMPOUND ASSY UNIT (X90-389x-xx)					
320	1H	✻	A01-2837-02	METALLIC CABINET	
321	3B		E30-4953-05	CORD WITH PLUG (6m)	
322		✻	E30-6296-05	CORD WITH PINPLUG	KR1M1
322		✻	E30-6296-05	CORD WITH PINPLUG	C1X1E1
322		✻	E30-6296-05	CORD WITH PINPLUG	E2
322		✻	E30-6356-05	CORD WITH PINPLUG	K1
325		✻	E30-6297-05	CORD WITH PINPLUG	
332	3G	✻	F09-1877-05	FAN	
334	3H		F29-0049-05	INSULATING COVER	
-		✻	H02-0837-03	INNER CARTON CASE	
-			H25-0329-04	PROTECTION BAG (280X450X0.03)	KK1R1
-			H25-0329-04	PROTECTION BAG (280X450X0.03)	M1C1X1
-			H25-1111-04	PROTECTION BAG (280X450X0.03)	E1E2
A	1H	✻	N09-6228-05	TAPTITE SCREW (2.6X25 S-TITE)	
B	1H	✻	N09-6229-05	TAPTITE SCREW (2.6X40 S-TITE)	
C	3H	✻	N84-2614-48	PAN HEAD TAPTITE SCREW	
D	2H		N86-2605-48	BINDING HEAD TAPTITE SCREW	
E	1H		N89-3006-43	BINDING HEAD TAPTITE SCREW	
DVD MECHANISM ASSY (X92-5020-02)					
1	2B		A10-4909-21	CHASSIS	
2	1A		A10-4910-11	CHASSIS	
3	1A		A10-4911-02	CHASSIS	
4	1B		A10-4913-11	CHASSIS	
5	2B		A10-4952-61	CHASSIS ASSY	
7	1B		A10-5091-53	CHASSIS ASSY	
15	3B		D10-4650-03	SLIDER	
16	3B		D10-4651-02	SLIDER	
17	3B		D10-4652-02	SLIDER	
18	2A		D10-4653-02	SLIDER	
19	3B		D10-4654-04	ARM ASSY	
20	3A		D10-4658-33	ARM ASSY	
21	1B		D10-4659-43	LEVER ASSY	
22	1A		D10-4660-04	ARM ASSY	
23	3B		D10-4686-03	SLIDER	
24	3B		D10-4687-03	ARM	
25	3B		D10-4689-03	ARM	
26	3B		D10-4690-03	ARM	
27	3B		D10-4781-03	ARM	
29	1A		D12-0635-03	CAM	
30	2B		D12-0636-13	CAM	
32	3B		D13-2221-04	GEAR	
33	3B		D13-2222-04	GEAR	
34	3B		D13-2223-04	GEAR	
35	3B		D13-2224-04	GEAR	
36	2B		D13-2225-04	GEAR	
37	2B		D13-2226-04	GEAR	
38	3B		D13-2227-04	GEAR	
43	2A		D14-0785-04	ROLLER	
44	1A		D21-2395-13	SHAFT	
46	2B		D21-2414-04	SHAFT	

DVD PLAYER UNIT (X37-1020-04)

Ref. No.	Add	New	Parts No.	Description	Destination
48	1B		D32-0648-04	STOPPER	
49	2B		D32-0654-04	STOPPER	
50	2A		D39-0254-05	DAMPER	
VFC1	2A		E39-0464-05	FLAT CABLE (4PIN)	
54	2B		F09-1748-04	SHEET	
56	1A		G01-3112-04	COMPRESSION SPRING	
58	3B		G01-3114-14	EXTENSION SPRING	
59	3A		G01-3116-14	EXTENSION SPRING	
60	2B		G01-3117-04	EXTENSION SPRING	
61	1B		G01-3118-04	EXTENSION SPRING	
62	2A		G01-3119-04	EXTENSION SPRING	
63	3A		G01-3121-14	TORSION COIL SPRING	
64	3B		G01-3140-04	EXTENSION SPRING	
65	3B		G01-3142-04	TORSION COIL SPRING	
66	3B		G01-3196-04	TORSION COIL SPRING	
69	2A		G02-1421-03	FLAT SPRING	
77	3A	✻	J12-1238-04	PIN	
78	3B		J21-9792-03	MOUNTING HARDWARE	
79	1A		J21-9793-12	MOUNTING HARDWARE	
80	3B		J22-0061-03	MOUNTING HARDWARE	
82	2A		J90-1031-21	GUIDE	
A	1A		N09-4495-05	ADJUSTABLE SCREW (ADJUSTMENT SC)	
B	1A		N09-4496-05	TAPTITE SCREW (02 2X5P-TITE)	
C	1B		N09-6060-05	MACHINE SCREW (02M1.7X1.8 CR)	
D	2B		N09-6061-05	MACHINE SCREW (02M1.7X3.5CUP)	
E	1A		N09-6103-05	MACHINE SCREW (M1.7X3.5(NK G)	
F	1A		N09-6104-05	MACHINE SCREW (2X10 S-TITE)	
G	1B		N09-6106-05	MACHINE SCREW (M1.7X2.5)	
H	2A		N09-6122-05	MACHINE SCREW (CONNECTION SC)	
J	2A		N19-2022-04	FLAT WASHER	
K	3A		N19-2171-04	FLAT WASHER	
VM1	2B		T42-1058-15	MOTOR ASSY (SPINDLE)	
VM2	3A		T49-0101-05	MOTOR ASSY (FEED)	
VM3	3B		T42-1061-04	MOTOR ASSY (LOADING)	
VPU1	1A		T25-0222-05	OPTICAL PICKUP HEAD	
83	2A		W02-3408-15	ELECTRIC CIRCUIT MODULE	

K : KVT-715DVD **K1** : KVT-815DVD **R1** : KVT-745DVD **M1** : KVT-735DVD
C1 : KVT-765DVD **X1** : KVT-745DVD **E1** : KVT-725DVD **E2** : KVT-725DVD-B

⚠ Indicates safety critical components.