7. EXPLODED VIEWS AND PARTS LIST

7.1. PACKING SECTION [SGY-PM900H79]



7.2. PACKING SECTION [SGY-PM900H90]



7.3. EXTERIOR SECTION




⑧
26
⑪
25
25
SGY-PM900H79 : 14
SGY-PM900H90 : 14-16
⑱
26
26

7.4. PARTS LIST

- SGY-PM900H79

			Deliver	Parts number	Name of parts
	1	Left transmitter cover		X-TAAA-049-1	L COVER (BATTERY) ASSY(SVC)
	5	Left waterproof packing		Z-112-017-01	L PACKING
	6	Strain gauge unit cover (left)		Z-112-014-01	L COVER (SENSOR)
	8	Right transmitter cover		X-TAAA-051-1	R COVER (BATTERY) ASSY(SVC)
	11	Right waterproof packing		Z-112-028-01	R PACKING
	14	Junction cable guide		Z-112-025-01	R HOLDER (CHAIN RING)
	18	Strain gauge unit cover (right)		Z-112-021-01	R COVER (SENSOR)
	22	Magnet ring		A-TAAB-386-A	MAGNET RING ASSY
	23	Magnet ring attachment		A-TAAB-387-A	ATTACHMENT ASSY
	25	Screw M1.7		Z-822-004-01	SCREW TAPPING 1.7*5
	26	Screw M2		Z-812-003-01	TRUSS HEAD SCREW M2X5
	27	Screw for magnet ring M3 BOLT		Z-812-004-01	M3 BOLT
	28	Screw for magnet ring attachment M3 NUT		Z-832-002-01	M3 NUT
	29	Tie band		Z-Y200-004-1	TIE BAND ASSY
	30	User manual	EL5	Z-912-017-13	USER MANUAL(SGY-PM900H79) U
	31	Important information	EL5	Z-919-020-01	IMPORTANT INFORMATION(SGY-PM900H79)
*	32	Warranty card	EL5	Z-912-018-21	WARRANTY CARD(SGY-PM900H79) U
	33	Unit Box	EL5	Z-922-022-21	BOX U
	34	Cushion		Z-922-023-01	CUSHION
	35	Spacer		Z-922-025-01	SPEACER(L)
	37	Left transmitter ASSY	EL5	A-TAAB-402-A	TRANSMITTER ASSY(L)
	38	Right transmitter ASSY	EL5	A-TAAB-403-A	TRANSMITTER ASSY(R)

* NSP

- SGY-PM900H90

			Deliver	Parts number	Name of parts
	1	Left transmitter cover		X-TAAA-067-1	L COVER (BATTERY) ASSY(SVC)
	5	Left waterproof packing		Z-112-017-01	L PACKING
	6	Strain gauge unit cover (left)		Z-112-041-01	L COVER (SENSOR)
	8	Right transmitter cover		X-TAAA-051-1	R COVER (BATTERY) ASSY(SVC)
	11	Right waterproof packing		Z-112-028-01	R PACKING
	14	Junction cable guide 34		Z-112-047-01	R HOLDER (CHAIN RING 34) H90
	15	Junction cable guide 36		Z-112-048-01	R HOLDER (CHAIN RING 36) H90
	16	Junction cable guide 38-39		Z-112-049-01	R HOLDER (CHAIN RING 38-39) H90
	18	Strain gauge unit cover (right)		Z-112-044-01	R COVER (SENSOR)
	22	Magnet ring		A-TAAB-386-A	MAGNET RING ASSY
	23	Magnet ring attachment		A-TAAB-387-A	ATTACHMENT ASSY
	25	Screw M1.7		Z-822-004-01	SCREW TAPPING 1.7*5
	26	Screw M2		Z-812-003-01	TRUSS HEAD SCREW M2X5
	27	Screw for magnet ring M3 BOLT		Z-812-004-01	M3 BOLT
	28	Screw for magnet ring attachment M3 NUT		Z-832-002-01	M3 NUT
	29	Tie band		Z-Y200-004-1	TIE BAND ASSY
	30	User manual	EL5	Z-912-021-11	USER MANUAL(SGY-PM900H90) U
	31	Important information	EL5	Z-919-023-01	IMPORTANT INFORMATION(SGY-PM900H90)
*	32	Warranty card	EL5	Z-912-022-11	WARRANTY CARD(SGY-PM900H90) U
	33	Unit Box	EL5	Z-922-029-11	BOX U
	34	Cushion		Z-922-030-01	CUSHION
	35	Spacer			SPEACER(L)
	37	Left transmitter ASSY	EL5	A-TAAB-466-A	TRANSMITTER ASSY(L)
	38	Right transmitter ASSY	EL5	A-TAAB-468-A	TRANSMITTER ASSY(R)

* NSP